




# JAGUAR

## XJ-S 3·6 XJ-SC 3·6 SERVICE MANUAL





## **BOOK 1**

**Containing  
Sections**

**01 INTRODUCTION  
04 GENERAL SPECIFICATION  
05 ENGINE TUNING DATA  
07 GENERAL FITTING INSTRUCTIONS  
08 JACKING LIFTING & TOWING  
09 LUBRICANTS  
10 MAINTENANCE  
99 SERVICE TOOLS**

**XJ-S 3·6  
XJ-SC 3·6**

**SERVICE MANUAL**



---

## INTRODUCTION

This Service Manual covers the Jaguar XJ-S 3.6 and XJ-SC 3.6. It is primarily designed to assist skilled technicians in the efficient repair and maintenance of this range of Jaguar cars.

Using the appropriate service tools and carrying out the procedures as detailed will enable the operations to be completed within the time stated in the 'Repair Operation Times'.

The Service Manual has been produced in 9 separate books; this allows the information to be distributed throughout the specialist areas of the modern service facility.

A table of contents in Book 1 lists the major components and systems together with the section and book numbers. The cover of each book depicts graphically and numerically the sections contained within that book.

The title page of each book carries the part numbers required to order replacement books, binders or complete Service Manuals. This can be done through the normal channels.

The contents section of each book lists the repair operations in the section or sections contained within that book. Each operation is given an operation number that corresponds with those listed in the Repair Operation Times.

The method described on the page number listed against the operation will be the one we consider will meet the requirements of safety and enable the operation to be carried out in the time specified in the Repair Operation Times.

Where no page number is given against an operation, we feel that the method is so obvious as to warrant no explanation. It is, however, included so that a warranty time can be given in the Repair Operation Times.

Extensive research has gone into the diagnosis of faults and where appropriate this is covered in the various areas of the manual. By following the sequence of the diagnosis charts, speedy isolation of faults may be expected, and consequent correction will reduce the vehicle off-the-road time to the minimum.

### Service Tools

Where performance of an operation requires the use of a service tool the tool number is quoted under the operation heading and is repeated in, or following, the instruction involving its use. A list of all necessary tools is included in Book 1, Section 99.

### References

References to the LH or RH side in the manual are made when viewing from the rear. With the engine and gearbox assembly removed the timing cover end of the engine is referred to as the front. A key to abbreviations and symbols is given in Book 1, Section 01.

## REPAIRS AND REPLACEMENTS

When service parts are required it is essential that only genuine Jaguar or Unipart replacements are used.

Attention is particularly drawn to the following points concerning repairs and the fitting of replacement parts and accessories.

1. Safety features embodied in the vehicle may be impaired if other than genuine parts are fitted. In certain territories, legislation prohibits the fitting of parts not to the vehicle manufacturer's specification.
2. Torque wrench setting figures given in this Service Manual must be strictly adhered to.
3. Locking devices, where specified, must be fitted. If the efficiency of a locking device is impaired during removal it must be replaced.
4. Owners purchasing accessories while travelling abroad should ensure that the accessory and its fitted location on the vehicle conform to mandatory requirements existing in their country of origin.
5. The vehicle warranty may be invalidated by the fitting of other than genuine Jaguar or Unipart parts. All Jaguar and Unipart replacements have the full backing of the factory warranty.
6. Jaguar Distributors and Dealers are obliged to supply only genuine service parts.

## SPECIFICATION

Purchasers are advised that the specification details set out in this Manual apply to a range of vehicles and not to any one. For the specification of a particular vehicle, purchasers should consult their Distributor or Dealer.

The Manufacturers reserve the right to vary their specifications with or without notice, and at such times and in such manner as they think fit. Major as well as minor changes may be involved in accordance with the Manufacturer's policy of constant product improvement.

Whilst every effort is made to ensure the accuracy of the particulars contained in this Manual, neither the Manufacturer nor the Distributor or Dealer, by whom this Manual is supplied, shall in any circumstances be held liable for any inaccuracy or the consequences thereof.

## COPYRIGHT

© Jaguar Cars Ltd. 1983

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, electronic, mechanical, photocopying, recording or other means without prior written permission of Jaguar Cars Ltd., Service Department, Radford, Coventry CV6 3GB.

## TABLE OF CONTENTS

|   | SECTION | BOOK |
|---|---------|------|
| Introduction .....  | 01      |      |
| General specification data .....                                | 04      |      |
| Engine tuning and data .....                                    | 05      |      |
| Torque wrench settings — Refer to each individual section       |         |      |
| General fitting instructions .....                              | 07      |      |
| Lifting, jacking and towing .....                               | 08      |      |
| Recommended lubricants, fluids, capacities and dimensions ..... | 09      |      |
| Maintenance .....   | 10      |      |
| Service tools .....   | 99      |      |
| Engine .....  | 12      | 2    |
| Emission control .....  | 17      |      |
| Fuel system .....   | 19      |      |
| Cooling system .....  | 26      |      |
| Manifold and exhaust system .....                               | 30      |      |
| Clutch .....  | 33      |      |
| Manual gearbox .....  | 37      |      |
| Propeller and drive shafts .....                                | 47      |      |
| Final drive .....   | 51      |      |
| Steering .....  | 57      |      |
| Front suspension .....  | 60      |      |
| Rear suspension .....   | 64      |      |
| Brakes .....  | 70      |      |
| Wheels and Tyres .....  | 74      |      |
| Body .....  | 76      | 7    |
| Air conditioning system .....                                   | 82      | 8    |
| Wipers and washers .....  | 84      |      |
| Electrical system .....   | 86      |      |
| Instruments .....   | 88      |      |

## STANDARDIZED ABBREVIATIONS AND SYMBOLS IN THIS MANUAL

| Abbreviation or Symbol | Term                                      | Abbreviation or Symbol | Term   |
|------------------------|---|------------------------|--|
| A                      | Ampere                                    | L.H.Thd.               | Left-hand thread                             |
| A.B.D.C.               | After bottom dead centre                  | L.t.                   | Low tension (electrical)                     |
| a.c.                   | Alternating current                       | M                      | Metric (screw thread)                        |
| A.F.                   | Across flats (bolt/nut size)              | m                      | Metres                                       |
| Ah                     | Ampere hour                               | max.                   | Maximum                                      |
| A.T.D.C.               | After top dead centre                     | MES                    | Miniature Edison Screw                       |
| Atm                    | Atmospheres                               | min.                   | Minimum                                      |
| Auto.                  | Automatic transmission                    | mm                     | Millimetres                                  |
| B.A.                   | British Association (screw thread)        | mmHg                   | Millimetres of mercury                       |
| B.B.D.C.               | Before bottom dead centre                 | m.p.g.                 | Miles per gallon                             |
| B.D.C.                 | Bottom dead centre                        | m.p.h.                 | Miles per hour                               |
| b.h.p.                 | Brake horse-power                         | N                      | Newton                                       |
| b.m.e.p.               | Brake mean effective pressure             | Nm                     | Newton metres                                |
| B.S.                   | British Standards                         | No.                    | Numbers                                      |
| B.S.F.                 | British Standard Fine (screw thread)      | Nox                    | Oxides of nitrogen                           |
| B.S.P.                 | British Standard Pipe (thread)            | N.P.T.F.               | American Standard Taper Pipe (thread)        |
| B.S.W.                 | British Standard Whitworth (screw thread) | O <sub>2</sub>         | Oxygen                                       |
| B.T.D.C.               | Before top dead centre                    | O/D                    | Overdrive                                    |
| C                      | Centigrade (Celsius)                      | o.dia.                 | Outside diameter                             |
| cm                     | Centimetres                               | oz                     | Ounces (mass)                                |
| cm <sup>2</sup>        | Square centimetres                        | ozf                    | Ounces (force)                               |
| cm <sup>3</sup>        | Cubic centimetres                         | ozf in                 | Ounces inch (torque)                         |
| c/min                  | Cycles per minute                         | para.                  | Paragraph                                    |
| CO                     | Carbon monoxide                           | Part no.               | Part number                                  |
| cwt                    | Hundredweight                             | PAS                    | Power assisted steering                      |
| d.c.                   | Direct current                            | pt                     | Imperial pints                               |
| deg.                   | Degree (angle or temperature)             | r                      | Radius                                       |
| dia.                   | Diameter                                  | ref.                   | Reference                                    |
| DIN                    | Deutsche Industrie Norm (Standard)        | rev/min                | Revolutions per minute                       |
| E.C.U.                 | Electronic Control Unit                   | R.H.                   | Right-hand                                   |
| E.G.R.                 | Exhaust Gas Recirculation                 | R.H.Stg.               | Right-hand steering                          |
| F                      | Fahrenheit                                | S.A.E.                 | Society of Automotive Engineers              |
| F.I.                   | Fuel Injection                            | S.C.                   | Single carburettors                          |
| Fig.                   | Figure (illustration)                     | sp. gr.                | Specific gravity                             |
| ft                     | Feet                                      | Std.                   | Standard                                     |
| ft/min                 | Feet per minute                           | s.w.g.                 | Standard wire gauge                          |
| g                      | Grammes (mass)                            | Synchro                | { Synchronizer<br>Synchromesh                |
| gal                    | Imperial gallons                          | T.C.                   | Twin carburettors                            |
| gf                     | Grammes (force)                           | T.D.C.                 | Top dead centre                              |
| h.c.                   | High compression                          | t.p.i.                 | Threads per inch                             |
| hp                     | Horse-power                               | U.N.C.                 | Unified Coarse (screw thread)                |
| h.t.                   | High tension (electrical)                 | U.N.F.                 | Unified Fine (screw thread)                  |
| i.dia.                 | Internal diameter                         | U.K.                   | United Kingdom                               |
| i.f.s.                 | Independent front suspension              | U.S. gal               | Gallons (US)                                 |
| in                     | Inches                                    | U.S. pt                | Pints (US)                                   |
| in <sup>2</sup>        | Square inches                             | V                      | Volts  |
| in <sup>3</sup>        | Cubic inches                              | W                      | Watts  |
| inHg                   | Inches of mercury                         | 1st                    | First  |
| kg                     | Kilogrammes (mass)                        | 2nd                    | Second                                       |
| kgf/cm <sup>2</sup>    | Kilogrammes per square centimetre         | 3rd                    | Third  |
| kgf m                  | Kilogramme metres                         | 4th                    | Fourth                                       |
| km                     | Kilometres                                | 5th                    | Fifth  |
| km/h                   | Kilometres per hour                       | °                      | Degree (angle or temperature)                |
| kPa                    | Kilopascals                               | ∞                      | Infinity                                     |
| k.p.i.                 | King pin inclination                      | /                      | Minute (angle)                               |
| kV                     | Kilovolts                                 | —                      | { Minus (tolerance)<br>Negative (electrical) |
| kW                     | Kilowatts                                 | %                      | Percentage                                   |
| lb                     | Pounds (mass)                             | +                      | Plus (tolerance)                             |
| lbf                    | Pounds (force)                            | +ve                    | Positive (electrical)                        |
| lbf ft                 | Pounds feet (torque)                      | —ve                    | Negative (electrical)                        |
| lbf/ft <sup>2</sup>    | Pounds per square foot                    | ±                      | Plus or minus (tolerance)                    |
| lbf in                 | Pounds inches (torque)                    | //                     | Second (angle)                               |
| lbf/in <sup>2</sup>    | Pounds per square inch                    | Ω                      | Ohms   |
| l.c.                   | Low compression                           |                        |  |
| L.H.                   | Left-hand                                 |                        |  |
| L.H.Stg.               | Left-hand steering                        |                        |  |

|                          |                                  |   |
|--------------------------|----------------------------------|---|
| Engine                   | See engine tuning and data       | Section 05  |
| Final Drive Unit         | Type                             | Hypoid with Powr-Lok differential   |
|                          | Ratio: Standard                  | 3.54:1  |
|                          | North American market            | 3.77:1  |
| Manual Gearbox           | Type                             | Five speed with baulk-ring synchromesh on all forward gears                             |
|                          | Ratios: First gear               | 3.573:1   |
|                          | Second gear                      | 2.056:1   |
|                          | Third gear                       | 1.391:1   |
|                          | Fourth gear                      | 1.0:1   |
|                          | Fifth gear                       | 0.76:1  |
|                          | Reverse                          | 3.463:1   |
| Cooling System           | Water pump: type                 | Centrifugal   |
|                          | drive                            | Belt  |
|                          | Number of cooling fans           | One 11-bladed fan, driven through viscous coupling                                      |
|                          | Cooling system and control       | Thermostat  |
|                          | Auxiliary cooling                | One fan blowing air through radiator; controlled by a sensor in the radiator            |
|                          | Thermostat opening temperature   | 88°C (190°F)  |
|                          | Filter cap: pressure rating      | 1.05 kgf/cm <sup>2</sup> (15 lbf/in <sup>2</sup> )                                      |
|                          | Make                             | AC Delco  |
| Fuel Injection Equipment | Make and type                    | Digital, P type Lucas Bosch   |
| Fuel System Pump         | Make and type                    | Electrial, Lucas 73175 roller cell pump with integral relief valve and non-return valve |
|                          | Fuel pressure                    | 2.5 bar (36 lbf/in <sup>2</sup> )   |
| Braking System           | Front brakes, make and type      | Girling, ventilated discs, bridge type calipers   |
|                          | Rear brakes, make and type       | Girling, damped discs, bridge type calipers incorporating handbrake friction pads       |
|                          | Handbrake: type                  | Mechanical, operating on rear discs   |
|                          | Disc diameter: Front             | 284 mm (11.18 in)   |
|                          | Rear                             | 263,5 mm (10.375 in)  |
|                          | Disc thickness: Front            | 24,13 mm (0.95 in), 22,86 mm (0.90 in) min  |
|                          | Rear                             | 12,7 mm (0.50 in), 11,43 mm (0.45 in) min   |
|                          | Master cylinder bore diameter    | 23,800 to 23,825 mm (0.937 to 0.939 in)   |
|                          | Brake operation                  | Hydraulic   |
|                          | Hydraulic fluid                  | Castrol/Girling Universal Brake and Clutch Fluid — exceeding specification SAE J1703/D  |
|                          | Main brake friction pad material | Ferodo 3401 slotted   |
|                          | Handbrake friction pad material  | Mintex M 68/1   |
|                          | Servo units refs: RHD cars       | Girling 64049669  |
|                          | LHD cars                         | Girling 64049668  |
| Front Suspension         | Type                             | Independent coil spring   |
|                          | Castor angle                     | $3\frac{1}{2}^{\circ} \pm \frac{1}{4}^{\circ}$ positive                                 |
|                          | Camber angle                     | $\frac{1}{2}^{\circ} \pm \frac{1}{4}^{\circ}$ negative                                  |
|                          | Front wheel alignment            | 0 to 3,18 mm toe in (0 to $\frac{1}{8}$ in toe in)                                      |
|                          | Dampers                          | Telescopic, gas filled  |
| Rear Suspension          | Type                             | Independent coil springs, co-axial with dampers   |
|                          | Camber angle                     | $\frac{3}{4}^{\circ} \pm \frac{1}{4}^{\circ}$ negative                                  |
|                          | Rear wheel alignment             | Parallel $\pm 0,08$ mm (Parallel $\pm \frac{1}{32}$ in)                                 |
|                          | Dampers                          | Telescopic, gas filled  |
| Power Assisted Steeri    | Type                             | Rack and Pinion   |
|                          | Number of turns lock to lock     | 2.75  |
|                          | Turning circle — between walls   | 12,0\m (41.3 ft)  |

## GENERAL SPECIFICATION DATA

### Electrical Equipment

#### Battery

|                           |                          |
|---------------------------|--------------------------|
| Make and type             | RH Stg cars — Lucas CP11 |
| Voltage                   | 12V                      |
| Number of plates per cell | 11                       |
| Capacity at 20 hour rate  | 66 Ah                    |

#### Alternator

|   |                       |
|---|-----------------------|
| Make and type: all air conditioned cars | Lucas A133            |
| Normal voltage                          | 12V                   |
| Cut-in voltage                          | 13.5V at 1500 rev/min |
| Earth polarity                          | Negative              |
| Maximum output                          | 75 A                  |
| Maximum operating speed                 | 15,000 rpm            |
| Rotor winding resistance                | 2.43 at 20°C          |
| Brush spring pressure                   | 4.7 to 9.8            |

#### Starter Motor

|                                    |                              |
|------------------------------------|------------------------------|
| Make and type                      | Lucas M45 pre-engaged        |
| Lock torque at 940 amps            | 4.01 kgf m (29 lbf ft)       |
| Torque at 1000 rev/min at 535 amps | 1.80 kgf m (13 lbf ft)       |
| Light running current              | 100A at 5000 to 6000 rev/min |

#### Distributor

|               |             |
|---------------|-------------|
| Make and type | Lucas 45DM6 |
|---------------|-------------|

#### Windscreen Wiper Motor

|   |  |
|---|--|
| Make and type   | Lucas 16W                                |
| Light running speed, rack disconnected (after 60 seconds from cold) | Normal: 46 to 52 rpm; high: 60 to 70 rpm |
| Light running current (after 60 seconds from cold)                  | Normal: 1.5A; high: 2.0A                 |

## TYRE DATA

Fitted as complete sets only

### Tyres

|      |  |                                  |
|------|--|----------------------------------|
| Type | Dunlop 215/70 VR 15 SP or Sport Super D7 | Pirelli P5 215/70 VR15 Cinturato |
|------|--|----------------------------------|

### Inflation Pressure

For speeds above 160 km/hr (100 mph)  
under all  
load conditions

| Front  | Rear   |
|--|--|
| 2.25 kg/cm <sup>2</sup><br>32 lb/in <sup>2</sup> | 2.25 kg/cm <sup>2</sup><br>32 lb/in <sup>2</sup> |
| 2.20 Bars  | 2.20 Bars  |

For maximum comfort in countries where speeds are not in excess of 160 km/hr (100 mph) the above inflation pressures may be reduced by 0.42 kg/cm<sup>2</sup> (6 lb/in<sup>2</sup>, 0.41 Bars) on front and rear tyres.

### Tyre Replacement and Wheel Interchanging

When replacement of tyres is necessary, it is preferable to fit a complete car set. Should either front or rear tyres only show a necessity for replacement, new tyres must be fitted to replace the worn ones. No attempt must be made to interchange tyres from front to rear or vice-versa as tyre wear produces characteristic patterns depending upon their position and if such position is changed after wear has occurred, the performance of the tyre will be adversely affected. It should be remembered that new tyres require to be balanced.

The radial-ply tyres specified above are designed to meet the high-speed performance of which this car is capable.

Only tyres of identical specification as shown under 'TYRE DATA' must be fitted as replacements and, if to different tread pattern, should not be fitted in mixed form.

UNDER NO CIRCUMSTANCES SHOULD CROSS-PLY TYRES BE FITTED.

## RECOMMENDED SNOW TYRE

The following information relates to the only snow tyre recommended for Jaguar Cars. The use of snow tyres fitted with studs is not permitted in certain countries.

| TYRE DESIGNATION   | RECOMMENDED FITMENT      | ROAD SPEED AND TYRE PRESSURES  | REMARKS  |                          |                        |                          |                          |                        |                        |          |          |
|--|--------------------------|--|--|--------------------------|------------------------|--------------------------|--------------------------|------------------------|------------------------|----------|----------|
| Dunlop Weathermaster<br>185SR 15 SP M & S<br>(Mud and Slush)   | Complete sets only       | Up to 137 km/h (85 mph)  | 1. Snow chains may be fitted to rear wheels only.<br><br>2. Tyres may be fitted with studs provided maximum speed does not exceed 121 km/h (75 mph)<br><br>3. Inner tubes with the wording 'Weathermaster only' are available and MUST be fitted when using 185SR 15 SP M & S Dunlop Weathermaster tyres |                          |                        |                          |                          |                        |                        |          |          |
|  |                          | <table><tr><td><b>FRONT</b></td><td><b>REAR</b></td></tr><tr><td>1,90 kgf/cm<sup>2</sup></td><td>1,83 kgf/cm<sup>2</sup></td></tr><tr><td>27 lbf/in<sup>2</sup></td><td>26 lbf/in<sup>2</sup></td></tr><tr><td>1.86 bar</td><td>1.79 bar</td></tr></table> |  | <b>FRONT</b>             | <b>REAR</b>            | 1,90 kgf/cm <sup>2</sup> | 1,83 kgf/cm <sup>2</sup> | 27 lbf/in <sup>2</sup> | 26 lbf/in <sup>2</sup> | 1.86 bar | 1.79 bar |
|  |                          | <b>FRONT</b>   |  | <b>REAR</b>              |                        |                          |                          |                        |                        |          |          |
| 1,90 kgf/cm <sup>2</sup>   | 1,83 kgf/cm <sup>2</sup> |  |  |                          |                        |                          |                          |                        |                        |          |          |
| 27 lbf/in <sup>2</sup>   | 26 lbf/in <sup>2</sup>   |  |  |                          |                        |                          |                          |                        |                        |          |          |
| 1.86 bar   | 1.79 bar                 |  |  |                          |                        |                          |                          |                        |                        |          |          |
| <table><tr><td><b>FRONT</b></td><td><b>REAR</b></td></tr><tr><td>2,46 kgf/cm<sup>2</sup></td><td>2,39 kgf/cm<sup>2</sup></td></tr><tr><td>35 lbf/in<sup>2</sup></td><td>34 lbf/in<sup>2</sup></td></tr><tr><td>2.41 bar</td><td>2.35 bar</td></tr></table> | <b>FRONT</b>             | <b>REAR</b>  | 2,46 kgf/cm <sup>2</sup>   | 2,39 kgf/cm <sup>2</sup> | 35 lbf/in <sup>2</sup> | 34 lbf/in <sup>2</sup>   | 2.41 bar                 | 2.35 bar               |                        |          |          |
| <b>FRONT</b>   | <b>REAR</b>              |  |  |                          |                        |                          |                          |                        |                        |          |          |
| 2,46 kgf/cm <sup>2</sup>   | 2,39 kgf/cm <sup>2</sup> |  |  |                          |                        |                          |                          |                        |                        |          |          |
| 35 lbf/in <sup>2</sup>   | 34 lbf/in <sup>2</sup>   |  |  |                          |                        |                          |                          |                        |                        |          |          |
| 2.41 bar   | 2.35 bar                 |  |  |                          |                        |                          |                          |                        |                        |          |          |

## Stopping distance

|                                    |        |
|------------------------------------|--------|
| (a) fully operational maximum load | 182 ft |
| (b) fully operational light load   | 163 ft |
| (c) emergency — rears only         | 387 ft |
| (d) boost failure                  | 258 ft |

## BULB CHART

|  | Watts   | Lucas Part No. | Unipart No. | Notes                           |
|--|---------|----------------|-------------|---------------------------------|
| Headlamps — not France or USA — main/dip | 60/55   | 472            | GLB 472     | Halogen H4 base bulb            |
| — France only — main/dip                 | 60/55   | 476            | GLB 476     | Yellow Halogen H4 base bulb     |
| — USA only — outer                       | 37.5/60 |                |             | Tungsten sealed beam light unit |
| — USA only — inner                       | 50      |                |             | Tungsten sealed beam light unit |
| Headlamp pilot bulb — not USA            | 4       | 233            | GLB 233     |                                 |
| Front flasher lamp                       | 21      | 382            | GLB 382     | Not USA                         |
| Front flasher and side lamp              | 21/5    | 380            | GLB 380     | USA only                        |
| Stop lamp                                | 21      | 382            | GLB 382     |                                 |
| Tail lamp                                | 5       | 207            | GLB 207     |                                 |
| Rear flasher                             | 21      | 382            | GLB 382     |                                 |
| Reversing lamp                           | 21      | 273            | GLB 273     | Festoon bulb                    |
| Number plate lamp                        | 6       | 254            | GLB 254     | Festoon bulb                    |
| Sidemarkers                              | 4       | 233            | GLB 233     | USA only                        |
| Flasher side repeaters — when fitted     | 4       | 233            | GLB 233     |                                 |
| Rear fog guard lamps                     | 21      | 382            | GLB 382     | Not USA                         |
| Interior/map lamps                       | 6       | 254            | GLB 254     | Festoon bulb                    |
| Roof lamp                                | 10      | 272            | GLB 272     | Festoon bulb                    |
| Boot lamp                                | 5       | 239            | GLB 239     | Festoon bulb                    |
| Fibre optic light source                 | 6       | 254            | GLB 254     |                                 |
| Instrument illumination                  | 2.2     | 987            | GLB 987     |                                 |
| Warning lights                           | 1.2     | 286            | GLB 286     |                                 |
| Automatic selector illumination          | 2.2     | 987            | GLB 987     |                                 |
| Cigar lighter illumination               | 2.2     | 987            | GLB 987     |                                 |
| Door puddle lamp                         | 5       | 501            | GLB 501     |                                 |

## GENERAL SPECIFICATION DATA

### MAIN FUSE BOX — RH Steering

| Fuse No. | Protected Circuit  | Fuse Capacity | Unipart Number |
|----------|--|---------------|----------------|
| 1.       | Cigar lighter .....  | 20A           | GFS420         |
| 2.       | Hazard warning, seat belt logic .....                                | 15A           | GFS415         |
| 3.       | Clock, aerial, caravan, boot lamp .....                              | 35A           | GFS435         |
| 4.       | Panel instruments, reverse light .....                               | 10A           | GFS410         |
| 5.       | Direction indicators, stop lamps, auto kick down switch .....        | 15A           | GFS415         |
| 6.       | Fog rear guard .....   | 10A           | GFS410         |
| 7.       | Panel/cigar lighter/selector illumination .....                      | 10A           | GFS410         |
| 8.       | Door locks, electric mirrors .....                                   | 3A            | GFS43          |
| 9.       | Wipers .....   | 35A           | GFS435         |
| 10.      | Air conditioning motors .....  | 10A           | GFS410         |
| 11.      | Air conditioning controls, horn, washers, radiator cooling fan ..... | 35A           | GFS435         |
| 12.      | Heated rear screen, heated mirrors .....                             | 35A           | GFS435         |

### MAIN FUSE BOX — LH Steering

| Fuse No. | Protected Circuit  | Fuse Capacity | Unipart Number |
|----------|--|---------------|----------------|
| 1.       | Front fog lights .....   | 20A           | GFS240         |
| 2.       | Hazard warning, seat belt logic .....                                | 15A           | GFS415         |
| 3.       | Clock, aerial, caravan, boot lamp .....                              | 35A           | GFS435         |
| 4.       | Panel instruments, reverse light .....                               | 10A           | GFS410         |
| 5.       | Direction indicators, stop lamps, auto kick down switch .....        | 15A           | GFS415         |
| 6.       | Fog rear guard .....   | 10A           | GFS410         |
| 7.       | Panel/cigar lighter/selector illumination .....                      | 10A           | GFS410         |
| 8.       | Door locks, electric mirrors .....                                   | 3A            | GFS43          |
| 9.       | Wipers .....   | 35A           | GFS435         |
| 10.      | Air conditioning motors .....  | 50A           | GFS450         |
| 11.      | Air conditioning controls, horn, washers, radiator cooling fan ..... | 35A           | GFS435         |
| 12.      | Heated rear screen, heated mirrors .....                             | 35A           | GFS435         |

### HEADLAMP FUSE BOX

| Fuse No. | Protected Circuit                                | Fuse Capacity | Unipart Number |
|----------|--|---------------|----------------|
| 1.       | Radiator auxiliary cooling fan motor relay ..... | 25A           | GFS425         |
| 2.       | LH main beam .....                               | 25A           | GFS425         |
| 3.       | LH dip beam .....                                | 10A           | GFS410         |
| 4.       | RH main beam .....                               | 25A           | GFS425         |
| 5.       | RH dip beam .....                                | 10A           | GFS410         |

**AUXILIARY FUSE BOX — RH Steering**

| Fuse No. | Protected Circuit             | Fuse Capacity | Unipart Number |
|----------|-------------------------------|---------------|----------------|
| 13.      | Interior and map lights ..... | 10A           | GFS410         |
| 14.      | LH side lights .....          | 3A            | GFS43          |
| 15.      | RH side lights .....          | 3A            | GFS43          |
| 16.      | Front fog lights .....        | 20A           | GFS420         |
| 17.      | Speed control .....           | 3A            | GFS43          |

**AUXILIARY FUSE BOX — LH Steering**

| Fuse No. | Protected Circuit             | Fuse Capacity | Unipart Number |
|----------|-------------------------------|---------------|----------------|
| 13.      | Interior and map lights ..... | 10A           | GFS410         |
| 14.      | LH side lights .....          | 3A            | GFS43          |
| 15.      | RH side lights .....          | 3A            | GFS43          |
| 16.      | Cigar lighter .....           | 20A           | GFS420         |
| 17.      | Speed control .....           | 3A            | GFS43          |



## ENGINE TUNING AND DATA

|                 |          |  |
|-----------------|----------|--|
| Ignition Timing | Federal  | 18° BTDC @ 2000 RPM vacuum pipe disconnected at normal running temperature |
|                 | European | 21° BTDC @ 2000 RPM vacuum pipe disconnected at normal running temperature |

|                  |                   |                                     |
|------------------|-------------------|-------------------------------------|
| Valve Clearances | Inlet and exhaust | 0,30 to 0,36 mm (0.012 to 0.014 in) |
|------------------|-------------------|-------------------------------------|

|             |           |                    |
|-------------|-----------|--------------------|
| Spark Plugs | Make/type | Champion RC12 YC   |
|             | Gap       | 0,64 mm (0.025 in) |

|               |                                   |                 |
|---------------|-----------------------------------|-----------------|
| Ignition Coil | Make/type                         | Lucas 35 C6     |
|               | Primary resistance at 20°C (68°F) | 0.9 to 1.1 ohms |
|               | Secondary resistance              | 3.95 to 9.52K   |
|               | Consumption: stationary           | 5.0 to 6.5 amps |
|               | running                           | 2.5 to 3.0 amps |

|             |   |  |
|-------------|---|--|
| Distributor | Make/type                                 | Lucas constant energy 45 DM6               |
|             | Rotation of rotor (looking down at rotor) | Clockwise                                  |
|             | Pick-up module to timing rotor gap        | 0,20 to 0,36 mm (0.008 to 0.014 in)        |
|             | Firing order                              | 1, 5, 3, 6, 2, 4 (No. 1 cylinder at front) |

|                             |       |                 |
|-----------------------------|-------|-----------------|
| Spark plug lead resistences | No. 1 | 5.13K to 12.3K  |
|                             | 2     | 5.47K to 13.2K  |
|                             | 3     | 6.11K to 14.69K |
|                             | 4     | 7.24K to 17.34K |
|                             | 5     | 9.0K to 21.48K  |
|                             | 6     | 8.61K to 20.56K |

DISTRIBUTOR ADVANCE CURVE (CENTRIFUGAL)  
EUROPEAN VEHICLESAdvance Characteristics  
(Dynamic)

| Engine rpm | Advance (degrees) |
|------------|-------------------|
| 6400       | 7½° to 9½°        |
| 5000       | 7° to 9°          |
| 3200       | 6° to 8°          |
| 1800       | 5¼° to 7¼°        |
| 1250       | 3° to 6°          |
| 1050       | ½° to 3½°         |
| 850        | -1.2° to 0.8°     |
| 700        | -1.1° to 0.9°     |
| 500        | -¼° to ¼°         |
| 300        | -0.9° to 1.1°     |

## Vacuum Advance Curve

| inHg | Advance (degrees) |
|------|-------------------|
| 24   | 5° to 7°          |
| 12   | 4° to 6°          |
| 8½   | 2° to 4°          |
| 6    | ½° to 2½°         |
| 4    | 0° to 1°          |
| 2    | 0°                |

ENGINE TUNING

DISTRIBUTOR ADVANCE CURVE (CENTRIFUGAL)  
USA FEDERAL VEHICLES

| Advance Characteristics<br>(Dynamic) | Engine rpm | Advance (degrees) |
|--------------------------------------|------------|-------------------|
|                                      | 6400       | 7½° to 10°        |
|                                      | 5200       | 7° to 9°          |
|                                      | 3500       | 5½° to 7½°        |
|                                      | 2000       | 4° to 6°          |
|                                      | 1300       | 2° to 4°          |
|                                      | 1100       | ½° to 2½°         |
|                                      | 900        | –1° to 1°         |
|                                      | 700        | –1.1° to 0.9°     |
|                                      | 500        | –¼° to ¼°         |
|                                      | 300        | –0.9° to 1.1°     |

| Vacuum Advance Curve | inHg | Advance (degrees) |
|----------------------|------|-------------------|
|                      | 20   | 5° to 7°          |
|                      | 9    | 4° to 6°          |
|                      | 7    | 2° to 4°          |
|                      | 5½   | ½° to 2½°         |
|                      | 4    | 0° to 1°          |
|                      | 2    | 0°                |

|                          |                         |                      |
|--------------------------|-------------------------|----------------------|
| Fuel Injection Equipment | Digital . . . . .       | Lucas digital P type |
|                          | Fuel pressure . . . . . | 2.5 bar (36 lbf/in²) |

|                  |   |  |
|------------------|---|--|
| Exhaust Emission | Exhaust gas analyser reading at engine idle speed . | 1 to 2% max. CO at 800 rev/min without air injection |
|------------------|---|--|

|            |                 |
|------------|-----------------|
| Idle Speed | 800±50 rev/min. |
|------------|-----------------|

|                      |                   |                   |
|----------------------|-------------------|-------------------|
| Compression Pressure | European          | Federal           |
|                      | 200 to 220 lb/in² | 160 to 175 lb/in² |

|                                   |                 |                 |
|-----------------------------------|-----------------|-----------------|
| Differential between<br>Cylinders | 10 lb/in² (max) | 10 lb/in² (max) |
|-----------------------------------|-----------------|-----------------|

**Note:** Compressions to be checked with all sparking plugs removed, the throttle wide open, the engine at operating temperature and a cranking speed of 300 rpm (minimum).

## ENGINE DATA

|                 |   |  |
|-----------------|---|--|
| General Data    | Number of cylinders                           | 6  |
|                 | Bore  | 91 mm  |
|                 | Stroke  | 92 mm  |
|                 | Cubic capacity                                | 3590 cc  |
|                 | Compression ratio                             | 9.6:1  |
|                 | Firing order                                  | 1, 5, 3, 6, 2, 4 (No. 1 cylinder at front)   |
| Cylinder Block  | Material (cylinder block)                     | Cast Aluminium alloy   |
|                 | Bore diameters after honing:                  |  |
|                 | Piston grade                                  |  |
|                 | A   | 91,002 to 90,990 mm  |
|                 | B   | 91,018 to 91,005 mm  |
|                 | + 0.010 in                                    | 91,272 to 91,259 mm  |
| Cylinder head   | Material                                      | Aluminium alloy  |
|                 | Valve seat angle (inclusive)                  | 89° 30' to 89° 00'   |
| Crankshaft      | Material                                      | SE Cast Iron   |
|                 | Number of main bearings                       | 7  |
|                 | Main bearing type                             | Vandervell VP2C  |
|                 | Journal diameter                              | 76,230 to 76,218 mm  |
|                 | Journal length (over $\frac{3}{32}$ in radii) |  |
|                 | Front   | 30,48 mm   |
|                 | Centre  | 36,233 to 36,208 mm  |
|                 | Remainder                                     | 30,53 to 30,43 mm  |
|                 | Thrust washer material                        | VP10 or VP2  |
|                 | Thrust washer diameter                        | 3,888 to 3,898 mm  |
|                 | Thrust washer thickness Std                   | 2,57 to 2,62 mm (0.101 to 0.103 in)  |
|                 | Oversize                                      | 2,67 to 2,72 mm (0.105 to 0.107 in)  |
|                 | Permissible end-float                         | 0,10 to 0,25 mm (0.004 to 0.010 in)  |
|                 | Width of main bearing:                        |  |
|                 | Front intermediate and rear                   | 24,71 to 24,33 mm  |
|                 | Centre  | 30,48 to 30,10 mm  |
|                 | Balancing                                     | Crankshaft to be balanced to 45 gm/cm ( $\frac{5}{8}$ oz/in)<br>Unbalance to be corrected by drilling up to 4 holes<br>in each balance weight 9,5 x 29 mm max depth. |
|                 | Diametrical clearance                         | 0,041 to 0,084 mm  |
|                 | Crankpin: Diameter                            | 52,987 to 52,974 mm  |
|                 | Length  | 30,193 to 30,142 mm  |
| Connecting Rods | Length between centres                        | 166,42 to 166,32 mm  |
|                 | Big end bearing material                      | Vandervell VP2C  |
|                 | Bore for big end bearing                      | 56,731 mm  |
|                 | Width of big end bearing                      | 24,77 to 24,38 mm (0.975 to 0.960 in)  |
|                 | Big end diametrical clearance                 | 0,001 to 0,0027 mm   |
|                 | Big end side clearance                        | 0,132 to 0,233 mm  |
|                 | Small end bush material                       | VP10   |
|                 | Bore for small end bush                       | 27,000 to 26,975 mm  |
|                 | Width of small end bush                       | 30,00 to 29,50 mm  |
|                 | Fitted I/D of small end bush                  | 23,818 to 23,814 mm  |
|                 | Bore diameter of small end bush               | 23,48 to 23,38 mm  |
|                 | Small end balance weight:                     |  |
|                 | Minimum dimension after balancing             | 17 mm  |
|                 | Big end balance weight:                       |  |
|                 | Minimum dimension after balancing             | 42 mm  |

## ENGINE DATA

|              |   |   |
|--------------|---|---|
| Pistons      | Type .....  | HG413 (BS 1490 — 1970 — LM13TF)<br>(phosphorous modified) |
|              | Grade .....   |   |
|              | Diameter: A .....                                       | 90,972 to 90,960 mm                                       |
|              | B .....   | 90,987 to 90,975 mm                                       |
|              | + 0.010 in .....  | 91,241 to 91,229 mm                                       |
| Piston Rings | + 0.020 in .....  | 91,495 to 91,483 mm                                       |
|              | No. of compression rings .....                          | 2   |
|              | No. of oil control rings .....                          | 1   |
|              | Top compression ring:                                   |   |
|              | Gap .....   | 0,4 to 0,65 mm  |
|              | Width .....   | 1,490 to 1,495 mm   |
|              | Diameter .....  | 91,00 mm  |
|              | Depth of chrome .....                                   | 0,06 mm   |
|              | Tangential load of 6.62N to 9.93N to close gap to ..... | 0,40 to 0,65 mm   |
|              | Material .....  | Cast iron HG22C   |
|              | Second compression ring:                                |   |
|              | Gap .....   | 0,4 to 0,65 mm  |
|              | Width .....   | 1,990 to 1,975 mm   |
|              | Diameter .....  | 91,00 mm  |
|              | Tangential load of 5.8N to 8.75N to close gap to .....  | 0,40 to 0,65 mm   |
|              | Material .....  | Cast iron HG10  |
|              | Oil control ring:                                       |   |
|              | Gap .....   | 0,3 to 0,55 mm  |
| Gudgeon Pins | Type .....  | Chamfer locking type                                      |
|              | Length .....  | 77,25 to 77,12 mm   |
|              | Outside diameter: .....                                 | 23,812 to 23,807 mm                                       |
|              | Inside diameter .....                                   | 14,81 to 14,30 mm   |
|              | Permissible offset of centre web .....                  | 1,0 mm  |
|              | Material .....  | EN 32   |
| Camshafts    | Number of journals .....                                | 7   |
|              | Journal diameter .....                                  | 26,950 to 29,937 mm                                       |
|              | Diametrical clearance .....                             | 0,063 to 0,037 mm   |
|              | Material .....  | Cast iron to BS 1452 Grade 17                             |
| Valves       | Inlet valve material .....                              | EN 52   |
|              | Exhaust valve material .....                            | Steel 21—4—N  |
|              | Inlet valve head diameter .....                         | 35,43 to 35,17 mm   |
|              | Exhaust valve head diameter .....                       | 29,90 mm  |
|              | Valve Stem diameter:                                    |   |
|              | Inlet and exhaust .....                                 | 7,897 to 7,866 mm   |
|              | Valve lift .....  | 9,525 mm  |
|              | Inlet valve clearance .....                             | 0,031 to 0,036 mm (0.012 to 0.014 in)                     |
|              | Exhaust valve clearance .....                           | 0,031 to 0,036 mm (0.012 to 0.014 in)                     |
|              | Valve stem seal:  |   |
|              | Material .....  | BLS.RU28/E3 (VITRON)                                      |
|              | Internal diameter .....                                 | 7,90 to 7,85 mm   |

|                        |   |   |
|------------------------|---|---|
| Valve Guides and Seats | Valve guide material  | Brico alloy 2 or BS 1452/12 (Brinell hardness 190 to 260) |
|                        | Guide length  | 48,51 mm (1.910 in)                                       |
|                        | Circlip material  | 18 SWG (0.048 in) zinc coated                             |
| Identification         | No groove — Standard  | 12,75 to 12,74 mm (0.5020 to 0.5015 in)                   |
|                        | 1 groove — First oversize (Production)  | 12,80 to 12,79 mm (0.5040 to 0.5035 in)                   |
|                        | 2 grooves — Second oversize (Service)   | 12,88 to 12,87 mm (0.5070 to 0.5065 in)                   |
|                        | 3 grooves — Third oversize (Service)  | 13,00 to 12,99 mm (0.5120 to 0.5115 in)                   |
| Valve guide (service)  | Bore to be concentric with the outside diameter of the guide within 0.001 in. i.e. total indicator reading of 0.002 in. |   |
| Valve seat             | Inlet valve seat outside diameter:  |   |
|                        | Standard  | 36,404 to 36,388 mm                                       |
|                        | Service   | 36,785 to 36,769 mm                                       |
|                        | Interference fit in cylinder head   | 0,077 mm (0.003 in)                                       |
|                        | Exhaust valve seat outside diameter:  |   |
|                        | Standard  | 32,884 to 32,868 mm                                       |
|                        | Service   | 33,265 to 33,249 mm                                       |
|                        | Interference fit in cylinder head   | 0,077 mm (0.003 in)                                       |
| Tappets                | Valve seat angle (inclusive)  | 89° 30' to 89° 00'  |
|                        | Tappet material   | Chilled cast iron   |
|                        | Outside diameter of tappet  | 33,34 to 33,35 mm (1.3125 to 1.3130 in)                   |
|                        | Diametrical clearance of tappet   | 0,051 to 0,020 mm (0.002 to 0.0008 in)                    |
| Valve spring           | Wire diameter   | 3,76 mm (0.148 in)  |
|                        | Inside diameter   | 20,62 ± 0,25 mm (0.812 ± 0.010 in)                        |
|                        | Total No. of coils  | 6   |
|                        | No. of working coils  | 3.75  |
|                        | Helix   | RH  |
|                        | Rate  | 35,51 N/mm (202.5 lb/in)                                  |
|                        | Natural frequency   | 603,4 Hz (36,203 C/min)                                   |
|                        | Free length   | 40,13 mm (1.580 in)                                       |
|                        | Material  | OTEVA 60  |
| Camshaft Sprocket      | No. of teeth  | 30  |
|                        | Pitch of teeth  | 9,525 mm (0.375 in)                                       |
|                        | Pitch circle diameter   | 91,135 mm (3.588 in)                                      |
|                        | Internal surrations   | 131   |
|                        | Pitch circle diameter   | 66,675 mm (2.625 in)                                      |
|                        | Pitch of teeth  | 1,600 mm (0.063 in)                                       |
|                        | o. dia of sprocket  | 95,25 mm ± 0,050 mm (3.75 in ± 0.002 in)                  |
|                        | Total width   | 18,6531 mm ( $\frac{47}{8}$ in)                           |
|                        | Total width across both teeth   | 15,341 to 15,570 mm (0.604 to 0.613 in)                   |
|                        | Concentricity of teeth and sprocket not to exceed   | 0,076 mm (0.003 in)                                       |

## ENGINE DATA

|                                   |   |   |
|-----------------------------------|---|---|
| Crankshaft Sprocket               | No. of teeth                                    | 21  |
|                                   | Pitch   | 9,525 mm (0.375 in)                       |
|                                   | Pitch circle diameter                           | 63,906 mm (2.516 in)                      |
|                                   | Root diameter                                   | 57,556 mm (2.266 in)                      |
|                                   | Roller diameter                                 | 6,35 mm (0.25 in)                         |
|                                   | Measured over 6,35 mm (0.25 in) dia. pins       | 70,008 to 69,95 mm (2.759 to 2.754 in)    |
|                                   | Tooth profile cut to                            | BS 228                                    |
|                                   | Internal diameter                               | 42,875 to 42,857 mm                       |
|                                   | Overall diameter                                | 67,87 to 67,77 mm                         |
|                                   | Width across 1 tooth                            | 5,33 to 5,10 mm                           |
|                                   | Width across all the teeth                      | 38,43 to 38,00 mm                         |
|                                   | Width across 2 teeth (timing chain)             | 15,57 to 15,34 mm                         |
| Crankshaft damper oil seal spacer | Inside diameter                                 | 42,875 to 42,860 mm (1.6880 to 1.6874 in) |
|                                   | Outside diameter                                | 52,00 to 51,81 mm (2.047 to 2.040 in)     |
|                                   | Width   | 17,10 to 16,90 mm                         |
|                                   | Outside diameter to be plunge ground            |   |
|                                   | All chamfers to be polished and free from burrs |   |
| Intermediate shaft bush           | Inside diameter (when fitted)                   | 22,010 to 21,964 mm (0.8665 to 0.8647 in) |
|                                   | Outside diameter                                | 25,083 to 25,057 mm (0.9875 to 0.9865 in) |
|                                   | Width   | 17,25 to 16,25 mm (0.679 to 0.659 in)     |
|                                   | Press fit                                       | 0.036 to 0,083 mm (0.0015 to 0.0033 in)   |
|                                   | Shaft size                                      | 22 mm (0.8645 to 0.8637 in)               |
|                                   | Running clearance                               | 0,071 to 0,005 mm (0.0028 to 0.0002 in)   |
|                                   | Material  | Vandervell No. L10083/3                   |
| Intermediate sprocket inner teeth | Number of teeth                                 | 28  |
|                                   | Pitch   | 9,525 mm (0.375 in)                       |
|                                   | Pitch circle diameter                           | 85,063 mm (3.349 in)                      |
|                                   | Root diameter                                   | 78,70 mm (3.009 in)                       |
|                                   | Roller diameter                                 | 6,35 mm (0.25 in)                         |
|                                   | Measured over 6,35 mm (0.25 in) dia. pins       | 91,41 to 91,29 mm (3.599 to 3.594 in)     |
|                                   | Tooth profile cut to                            | BS 228                                    |
|                                   | Width across the depth                          | 15,57 to 15,34 mm (0.613 to 0.604 in)     |
|                                   | Overall diameter                                | 89,20 to 89,10 mm (3.512 to 3.508 in)     |
|                                   |   |   |
| Intermediate sprocket outer teeth | Number of teeth                                 | 20  |
|                                   | Pitch   | 9,525 mm (0.375 in)                       |
|                                   | Pitch circle diameter                           | 60,884 mm (2.397 in)                      |
|                                   | Root diameter                                   | 54,53 mm (2.147 in)                       |
|                                   | Roller diameter                                 | 6,35 mm (0.25 in)                         |
|                                   | Measured over 6,35 mm (0.25 in) dia. pins       | 67,23 to 67,11 mm (2.647 to 2.642 in)     |
|                                   | Tooth profile cut to                            | BS 228                                    |
|                                   | Overall diameter                                | 65,07 to 64,97 mm (2.562 to 2.558 in)     |
|                                   | Width across both teeth                         | 15,57 to 15,34 mm (0.613 to 0.604 in)     |
|                                   | Total width of sprocket                         | 48,80 to 48,70 mm (1.921 to 1.917 in)     |
|                                   |   |   |
| Primary timing chain              | Pitches   | 80  |
|                                   | Roller diameter                                 | 6,35 mm (0.25 in)                         |
|                                   | Pitch   | 9,525 mm (0.375 in)                       |
|                                   | Type  | Endless duplex chain                      |
| Secondary timing chain            | Pitches   | 86  |
|                                   | Roller diameter                                 | 6,35 mm (0.25 in)                         |
|                                   | Pitch   | 9,525 mm (0.375 in)                       |
|                                   | Type  | Endless duplex chain                      |
| Oil pump chain                    | Pitches   | 52  |
|                                   | Roller diameter                                 | 6,35 mm (0.25 in)                         |
|                                   | Pitch   | 9,525 mm (0.375 in)                       |
|                                   | Type  | Endless simplex chain                     |

|                                 |   |   |
|---------------------------------|---|---|
| Dampers and tensioners          | Backing material<br>Damper material   | Steel BS1449 CR4<br>Rubber  |
| Hydraulic chain tension housing | Bore diameter   | 21,38 to 21,36 mm (0.842 to 0.841 in)   |
| Hydraulic chain tensioner       | Overall length<br>Overall length to bottom of groove in piston<br>Diameter<br>Width of groove in piston<br>Non return valve primary ball diameter<br>Ball free movement   | 45 mm (1.771 in)<br>41 mm (1.614 in)<br>21,349 to 31,336 mm (0.8405 to 0.8400 in)<br>15 mm (0.59 in)<br>4,762 mm (0.1875 in)<br>0,74 to 0,45 mm (0.290 to 0.018 in)   |
| Non return valve secondary      | Ball diameter<br>Ball free movement   | 4,762 mm (0.1875 in)<br>0,74 to 0,45 mm (0.29 to 0.018 in)  |
| Oil pressure relief valve       | Relief valve:<br>O/D .....<br>I/D .....<br>Overall length .....<br>Working length .....<br>Bore depth .....<br>Material .....<br>Cyanide Harden .....<br>Mandrel: Length .....<br>Diameter .....<br>Material .....<br>Spring: Wall thickness .....<br>Free length .....<br>Outside diameter ..... | 17,98 to 17,95 mm (0.7079 to 0.7067 in)<br>15,00 to 14,50 mm (0.591 to 0.571 in)<br>35 mm (1.378 in)<br>30 mm (1.181 in)<br>27 mm (1.063 in)<br>ENIA<br>0,020 to 0,013 mm (0.008 to 0.005 in) deep<br>57 mm (2.244 in)<br>11,11 mm (0.437 in)<br>Steel tube to BS970 (CDS2 or ERW1)<br>1,63 (0.064 in, 16 SWG)<br>or 1,22 (0.048, 18 SWG)<br>106 mm (4.173 in)<br>16,34 mm (0.643 in) |
| Spring Specification            | Wire diameter .....<br>Mean diameter coils .....<br>Total number of coils .....<br>Number of active coils .....<br>Helix of coil .....<br>Spring rate .....   | 2,34 mm (0.092 in, 13 SWG)<br>14,0 mm (0.551 in)<br>26<br>24<br>Left<br>4,49 N/mm (25.65 lb/IN)   |

|               | Length |        | Load  |       | Stress            |                    |
|---------------|--------|--------|-------|-------|-------------------|--------------------|
|               | mm     | inches | kg    | lbs   | N/mm <sup>2</sup> | lb/in <sup>2</sup> |
| Fitted        | 76,00  | 2.992  | 13,74 | 30.29 | 472               | 68,395             |
| Valve opening | 72,00  | 2.835  | 15,58 | 34.35 | 535               | 77.543             |
| Max opening   | 62,00  | 2.441  | 20,15 | 44.43 | 692               | 100.304            |
| Solid (ref)   | 60,80  | 2.392  | 20,71 | 45.66 | 711               | 103.083            |

**Material**

BS. 970/735/A50 (EN.47) Spring steel wire. Ends to be close coiled and ground square to axis, feather edges to be removed to a minimum thickness of 0,5 mm (0.020 in).

## ENGINE DATA

---

|                        |                                  |  |
|------------------------|----------------------------------|--|
| Oil Filter             | Oil filter: type                 | Full flow disposable canister                                  |
| Canister Specification | Maximum working pressure         | 100 lb/in <sup>2</sup>   |
|                        | Relief valve setting             | 13 to 16 lb/in <sup>2</sup> (0.90 to 1.1 kgf/cm <sup>2</sup> ) |
|                        | Canister to withstand            | 17,60 kgf/cm <sup>2</sup> (250 lb/in <sup>2</sup> ) pressure   |
|                        | Element filtration area          | 3555 cm <sup>2</sup> (551 lb/in <sup>2</sup> )                 |
|                        | Canister diameter                | 95,70 mm (3.78 in)   |
|                        | Canister length                  | 148,00 to 145,50 mm (5.827 to 5.728 in)                        |
|                        | Canister case material thickness | 24 SWG   |
|                        | Adaptor thread                   | 1 in 12 UNF — 2B   |
| Oil Pump               | Oil pump                         | Rotor type   |
|                        | Outer rotor outside diameter     | 69,825 to 69,774 mm (2.749 to 2.747 in)                        |
|                        | Outer rotor width                | 27,975 to 27,962 mm (1.1014 to 1.1009 in)                      |
|                        | Inner rotor width                | 27,975 to 27,962 mm (1.1014 to 1.1009 in)                      |
|                        | Clearance outer rotor to body    | 0,1 mm (0.010 in)  |
|                        | Material                         | Cast iron grade 12   |
|                        | Oil pump body rotor bore         | 69,951 to 69,926 mm (2.7539 to 2.7529 in)                      |
|                        | End float                        | 0,1 mm (0.005 in)  |
|                        | 2 horn clearance                 | 0,2 mm (0.010 in)  |
|                        | 3 horn clearance                 | 0,2 mm (0.010 in)  |

## TORQUE WRENCH SETTINGS

For the Torque wrench settings, refer to the front of the relevant section.



## GENERAL FITTING INSTRUCTIONS

### Precautions against damage

Always fit covers to protect the wings before commencing work in the engine compartment. Cover the seats and carpets, wear clean overalls and wash your hands or wear gloves before working inside the car. Avoid spilling hydraulic fluid or battery acid on paintwork. Wash off with water immediately if this occurs. Use polythene sheets in the boot to protect carpets. Always use a recommended service tool, or a satisfactory equivalent, where specified. Protect temporarily exposed screw threads by replacing nuts or fitting plastic caps.

### Safety precautions

Whenever possible use a ramp or pit when working beneath a car, in preference to jacking. Chock the wheels as well as applying the handbrake. Never rely on a jack alone to support a car. Use axle stands or blocks carefully placed at the jacking points to provide a rigid location. Ensure that a suitable form of fire extinguisher is conveniently located. Check that any lifting equipment used has adequate capacity and is fully serviceable. Inspect power leads of any mains electrical equipment for damage, and check that it is properly earthed. Disconnect the earth (grounded) terminal of a car battery. Do not disconnect any pipes in the air conditioning refrigeration system, if fitted, unless trained and instructed to do so. A refrigerant is used which can cause blindness if allowed to contact the eyes. Ensure that adequate ventilation is provided when volatile de-greasing agents are being used.

**CAUTION: Fume extraction equipment must be in operation when trichlorethylene, carbon tetrachloride, methylene chloride, chloroform, or perchlorethylene are used for cleaning purposes.**

Do not apply heat in an attempt to free stiff nuts or fittings; as well as causing damage to protective coatings, there is a risk of damage to electronic equipment and brake lines from stray heat. Do not leave tools, equipment, spilt oil, etc., around or on work area. Wear protective overalls and use barrier creams when necessary.

### Preparation

Before removing a component, clean it and its surrounding area as thoroughly as possible. Blank off any openings exposed by component removal, using greaseproof paper and masking tape.

Immediately seal fuel, oil or hydraulic lines when separated, using plastic caps or plugs, to prevent loss of fluid and entry of dirt. Close the open ends of oilways, exposed by component removal, with tapered hardwood plugs or readily visible plastic plugs. Immediately a component is removed, place it in a suitable container; use a separate container for each component and its associated parts. Before dismantling a component clean it thoroughly with a recommended cleaning agent; check that the agent is suitable for all materials of component. Clean the bench and provide marking materials, labels, containers and locking wire before dismantling a component.

### Dismantling

Observe scrupulous cleanliness when dismantling components, particularly when brake, fuel or hydraulic system parts are being worked on. A particle of dirt or a cloth fragment could cause a dangerous malfunction if trapped in these systems. Blow out all tapped holes, crevices, oilways and fluid passages with an air line. Ensure that any 'O' rings used for sealing are correctly replaced or renewed if disturbed. Mark mating parts to ensure that they are replaced as dismantled. Whenever possible use marking ink, which avoids possibilities of distortion or initiation of cracks, liable if centrepunch or scriber are used. Wire together mating parts where necessary to prevent accidental interchange (e.g. roller bearing components). Wire labels onto all parts which are to be renewed, and to parts requiring further inspection before being passed for reassembly; place these parts in separate containers from those containing parts for rebuild. Do not discard a part due for renewal until after comparing it with a new part, to ensure that its correct replacement has been obtained.

### Inspection — General

Never inspect a component for wear or dimensional check unless it is absolutely clean; a slight smear of grease can conceal an incipient failure. When a component is to be checked dimensionally against figures quoted for it, use correct equipment (surface plates, micrometers, dial gauges, etc.) in serviceable condition. Makeshift checking equipment can be dangerous. Reject a component if its dimensions are outside the limits quoted, or if damage is apparent. A part may, however, be refitted if its critical dimension is exactly limit size, and is otherwise satisfactory. Use Plastigauge 12 Type PG-1 for checking bearing surface clearances. Directions for its use, and a scale giving bearing clearances in 0.00025 mm (0.0001 in) steps are provided with it.

### Ball and roller bearings

NEVER REPLACE A BALL OR ROLLER BEARING WITHOUT FIRST ENSURING THAT IT IS IN AS-NEW CONDITION.

Remove all traces of lubricant from a bearing under inspection by washing it in petrol or a suitable de-greaser; maintain absolute cleanliness throughout the operations.

Inspect visually for markings of any form on rolling elements, raceways, outer surface of outer rings or inner surface of inner rings. Reject any bearings found to be marked, since any markings in these areas indicates onset of wear.

Holding the inner race between fingers and thumb of one hand, spin the outer race and check that it revolves absolutely smoothly. Repeat, holding the outer race and spinning the inner race.

Rotate the outer ring with a reciprocating motion, while holding the inner ring; feel for any check or obstruction to rotation, and reject the bearing if action is not perfectly smooth.

Lubricate the bearing generously with lubricant appropriate to installation. Inspect shaft and bearing housing for discolouration or other marking suggesting that movement has taken place between bearing and seatings.

If markings are found use Loctite in installation of replacement bearing.

Ensure that the shaft and housing are clean and free from burrs before fitting the bearing.

If one bearing of a pair shows an imperfection it is generally advisable to renew both bearings; an exception could be made only if the faulty bearing had covered a low mileage, and it could be established that damage was confined to it. When fitting bearing to shaft, apply force only to inner ring of bearing, and only to outer ring when fitting into housing (Fig. 1).




Fig. 1

In the case of grease-lubricated bearings (e.g. hub bearings) fill the space between the bearing and outer seal with a recommended grade of grease before fitting the seal.

Always mark components of separable bearings (e.g. taper-roller bearings) in dismantling, to ensure correct reassembly. Never fit new rollers in a used cup.

### Oil seals

Always fit new oil seals when rebuilding an assembly. It is not physically possible to replace a seal exactly as it had bedded down.

Carefully examine the seal before fitting to ensure that it is clean and undamaged.

## GENERAL FITTING INSTRUCTIONS

Smear sealing lips with clean grease, pack dust excluder seals with grease, and heavily grease duplex seals in cavity between sealing lips.

Ensure that seal spring, if provided, is correctly fitted.

Place lip of seal towards fluid to be sealed and slide into position on shaft, using fitting sleeve (Fig. 2) when possible to protect sealing lip from damage by sharp corners, threads or splines. If fitting sleeve is not available, use plastic tube or adhesive tape to prevent damage to sealing lip.




Fig. 2

J07 002

Grease the outside diameter of the seal, place it square to the housing recess and press it into position, using great care and if possible a 'bell piece' (Fig. 3) to ensure that seal is not tilted. (In some cases it may be preferable to fit the seal to the housing before fitting to the shaft.) Never let the weight of an unsupported shaft rest in a seal.




Fig. 3

J07 003

If correct service tool is not available, use a suitable drift approximately 0.4 mm (0.015 in) smaller than the outside diameter of the seal. Use a hammer VERY GENTLY on the drift if a press is not suitable.

Press or drift a seal in to the depth of housing if the housing is shouldered, or flush with the face of the housing where no shoulder is provided.

**NOTE:** Most cases of failure of leakage or oil seals are due to careless fitting, and resulting damage to both seals and sealing surfaces. Care in fitting is essential if good results are to be obtained.

### Joints and joint faces

Always use the correct gaskets where they are specified.

Use jointing compound only when recommended. Otherwise fit joints dry.

When jointing compound is used, apply in a thin uniform film to metal surfaces; take great care to prevent it from entering oilways, pipes or blind tapped holes.

Remove all traces of old jointing materials prior to reassembly. Do not use a tool which could damage joint faces.

Inspect joint faces for scratches or burrs and remove with a fine file or oil-stone; do not allow swarf or dirt to enter tapped holes or enclosed parts. Blow out any pipes, channels or crevices with compressed air, renewing any 'O' rings or seals displaced by air blast.

### Flexible hydraulic pipes, hoses

Before removing any brake or power steering hose, clean end fittings and area surrounding them as thoroughly as possible. Obtain appropriate blanking caps before detaching hose end fittings, so that ports can be immediately covered to exclude dirt. Clean hose externally and blow through with airline. Examine carefully for cracks, separation of plies, security of end fittings and external damage. Reject any hose found faulty.

When refitting hose, ensure that no unnecessary bends are introduced, and that hose is not twisted before or during tightening of union nuts.

Containers for hydraulic fluid must be kept absolutely clean.

Do not store hydraulic fluid in an unsealed container. It will absorb water, and fluid in this condition would be dangerous to use due to a lowering of its boiling point.

Do not allow hydraulic fluid to be contaminated with mineral oil, or use a container which has previously contained mineral oil.

Do not re-use fluid bled from system. Always use clean brake fluid, or a recommended alternative, to clean hydraulic components.

Fit a blanking cap to a hydraulic union and a plug to its socket after removal to prevent ingress of dirt.

Absolute cleanliness must be observed with hydraulic components at all times.

After any work on hydraulic systems, inspect carefully for leaks underneath the car while a second operator applies maximum pressure to the brakes (engine running) and operates the steering.

### Metric bolt identification

An ISO metric bolt or screw, made of steel and larger than 6 mm in diameter can be identified by either of the symbols ISO M or M embossed or indented on top of the head (Fig. 4).




Fig. 4

J07 004

In addition to marks to identify the manufacture, the head is also marked with symbols to indicate the strength grade e.g. 8.8, 10.9, 12.9, or 14.9, where the first

figure gives the minimum tensile strength of the bolt material in tens of kgf/mm<sup>2</sup>.

Zinc plated ISO metric bolts and nuts are chromate passivated, a greenish-khaki to gold-bronze colour.

### Metric nut identification

A nut with an ISO metric thread is marked on one face (1, Fig. 5) or on one of the flats (2, Fig. 5) of the hexagon with the strength grade symbol 8, 12 or 14. Some nuts with a strength 4, 5 or 6 are also marked and some have the metric symbol M on the flat opposite the strength grade marking.




Fig. 5

J07 005

A clock face system (3, Fig. 5) is used as an alternative method of indicating the strength grade. The external chamfers or a face of the nut is marked in a position relative to the appropriate hour mark on a clock face to indicate the strength grade.

A dot is used to locate the 12 o'clock position and a dash to indicate the strength grade. If the grade is above 12, two dots identify the 12 o'clock position.

### Hydraulic fittings — Metrification

**WARNING: METRIC AND UNIFIED THREADED HYDRAULIC PARTS. ALTHOUGH PIPE CONNECTIONS TO BRAKE SYSTEM UNITS INCORPORATE THREADS OF METRIC FORM, THOSE FOR POWER ASSISTED STEERING ARE OF UNF TYPE. IT IS VITALLY IMPORTANT THAT THESE TWO THREAD FORMS ARE NOT CONFUSED, AND CAREFUL STUDY SHOULD BE MADE OF THE FOLLOWING NOTES.**

Metric threads and metric sizes are being introduced into motor vehicle manufacture and some duplication of parts must be expected. Although standardization must in the long run be good, it would be wrong not to give warning of the dangers that exist while UNF and metric threaded hydraulic parts continue together in service.

Fitting UNF pipe nuts into metric ports and vice-versa should not happen, but experience of the change from BSF to UNF indicated that there is no certainty in relying upon the difference in thread size when safety is involved.

To provide permanent identification of metric parts is not easy but recognition has been assisted by the following means:

All metric pipe nuts, hose ends, unions and bleed screws are coloured black.

The hexagon area of pipe nuts is indented with the letter 'M'.

Metric and UNF pipe nuts are slightly different in shape.

**NOTE:** In Figs. 6 to 9, A indicates the metric type and 'B' the UNF type.

The metric female nut is **always** used with a trumpet flared pipe and the metric male nut is **always** used with a convex flared pipe (Fig. 6).




Fig. 6

All metric ports in cylinders and calipers have no counterbores, but unfortunately a few cylinders with UNF threads also have no counterbore. The situation is, all ports with counterbores are UNF, but ports not counterbored are most likely to be metric (Fig. 7).



Fig. 7

The colour of the protective plugs in hydraulic ports indicates the size and the type of the threads, but the function of the plugs is protective and not designed as positive identification. In production it is difficult to use the wrong plug but human error must be taken into account.

The plug colours and thread sizes are:

| UNF    |                            |
|--------|----------------------------|
| RED    | $\frac{3}{8}$ in x 24 UNF  |
| GREEN  | $\frac{7}{16}$ in x 20 UNF |
| YELLOW | $\frac{1}{2}$ in x 20 UNF  |
| PINK   | $\frac{5}{8}$ in x 18 UNF  |

| METRIC |             |
|--------|-------------|
| BLACK  | 10 x 1 mm   |
| GREY   | 12 x 1 mm   |
| BROWN  | 14 x 1,5 mm |

Hose ends differ slightly between metric and UNF (Fig. 8).




Fig. 8

Gaskets are not used with metric hoses. The UNF hose is sealed on the cylinder or caliper face by a copper gasket but the metric hose seals against the bottom of the port and there is a gap between faces of the hose end and cylinder (Fig. 9).



Fig. 9

Pipe sizes for UNF are  $\frac{3}{16}$  in,  $\frac{1}{4}$  in, and  $\frac{5}{16}$  in outside diameter.

Metric pipe sizes are 4,75 mm, 6 mm and 8 mm.

4,75 mm pipe is exactly the same as  $\frac{3}{16}$  in pipe.

6 mm pipe is 0.014 in smaller than  $\frac{1}{4}$  in pipe.

8 mm pipe is 0.002 in larger than  $\frac{5}{16}$  in pipe.

Convex pipe flares are shaped differently for metric sizes and when making pipes for metric equipment, metric pipe flaring tools must be used.

The greatest danger lies with the confusion of 10 mm and  $\frac{3}{8}$  in UNF pipe nuts used for  $\frac{3}{16}$  in (or 4,75 mm) pipe. The  $\frac{3}{8}$  in UNF pipe nut or hose can be screwed into a 10 mm port but is very slack and easily stripped. The thread engagement is very weak and cannot provide an adequate seal. The opposite condition, a 10 mm nut in a  $\frac{3}{8}$  in port, is difficult and unlikely to cause trouble. The 10 mm nut will screw in 1½ or two turns and seize. It has a crossed thread 'feel' and it is impossible to force the nut far enough to seal the pipe. With female pipe nuts the position is of course reversed.

The other combinations are so different that there is no danger of confusion.

### Keys and keyways

Remove burrs from edges of keyways with a fine file and clean thoroughly before attempting to refit key.

Clean and inspect key closely; keys are suitable for refitting only if indistinguishable from new, as any indentation may indicate the onset of wear.

### Split pins

Fit new split pins throughout when replacing any unit.

Always fit split pins where split pins were originally used. Do not substitute spring washers; there is always a good reason for the use of a split pin.

All split pins should be fitted as shown in Fig. 10 unless otherwise stated.




Fig. 10

### Tab washers

Fit new tab washers in all places where they are used. Never replace a used tab washer.

Ensure that the new tab washer is of the same design as that replaced.

### Nuts

When tightening up a slotted or castellated nut **never slacken it back** to insert split pin or locking wire except in those recommended cases where this forms part of an adjustment. If difficulty is experienced, alternative washers or nuts should be selected, or washer thickness reduced.

Where self-locking nuts have been removed it is advisable to replace them with new ones of the same type.

**NOTE:** Where bearing pre-load is involved nuts should be tightened in accordance with special instructions.

### Locking wire

Fit new locking wire of the correct type for all assemblies incorporating it.

Arrange wire so that its tension tends to tighten the bolt heads, or nuts, to which it is fitted.

### Screw threads

Both UNF and Metric threads to ISO standards are used. See below for thread identification.

Damaged threads must always be discarded. Cleaning up threads with a die or tap impairs the strength and closeness of fit of the threads and is not recommended.

Always ensure that replacement bolts are at least equal in strength to those replaced.

Do not allow oil, grease or jointing compound to enter blind threaded holes. The hydraulic action on screwing in the bolt or stud could split the housing.

Always tighten a nut or bolt to the recommended torque figure. Damaged or corroded threads can affect the torque reading.

To check or re-tighten a bolt or screw to a specified torque figure, first slacken a quarter of a turn, then re-tighten to the correct figure. Always oil thread lightly before tightening to ensure a free running thread, except in the case of self-locking nuts.

### Unified thread identification bolts

A circular recess is stamped in the upper surface of the bolt head (1, Fig. 11).




Fig. 11

### Nuts

A continuous line of circles is indented on one of the flats of the hexagon, parallel to the axis of the nut (2, Fig. 11)

### Studs, brake rods, etc.

The component is reduced to the core diameter for a short length at its extremity (3, Fig. 11).

TOWED RECOVERY

The car may be towed by another vehicle provided the following precautions are taken:





- 1. The gear box oil is at the correct level.
- 2. The gear lever is in neutral, and the ignition key is in position '1'.
- 3. The towing speed should not exceed 48 km/h (30 mph) and the towing distance should be limited to 48 km (30 miles).
- 4. The registration number of the towing vehicle and an 'ON TOW' sign or warning triangle must be displayed in a prominent position on the rear of the vehicle being towed.

**WARNING: WHEN THE ENGINE IS NOT RUNNING THE STEERING WILL NO LONGER BE POWER ASSISTED, AND THE BRAKE SERVO WILL BECOME INEFFECTIVE AFTER A FEW APPLICATIONS OF THE BRAKES. THEREFORE BE PREPARED FOR RELATIVELY HEAVY STEERING, AND THE NEED FOR INCREASED BRAKE PEDAL PRESSURE.**





If the distance to be towed will exceed 48 km (30 miles) then the car should be towed with the rear wheels clear of the ground or the propellor shaft disconnected from the final drive input flange.





If the propellor shaft is disconnected then it must be firmly secured away from the final drive flange.

TAPER ROLLER BEARING — FAULT DIAGNOSIS





| CONDITION OF BEARING  | CAUSE   | REMEDY  |
|---|---|---|
| <div><p>J51-049</p><p>Fig. 12<br/>Good Bearing</p></div> | —   | —   |
| <div><p>J51-050</p><p>Fig. 13<br/>Bent cage</p></div>   | Improper handling or tool usage   | Replace the bearing   |
| <div><p>J51-051</p><p>Fig. 14<br/>Bent cage</p></div>  | Improper handling or tool usage   | Replace the bearing   |
| <div><p>J51-052</p><p>Fig. 15<br/>Galling</p></div>    | Marks on roller ends due to overheating.<br>Lubricant failure or overloading. | Replace the bearing. Check the seals and ensure that the bearing is properly lubricated |

GENERAL FITTING INSTRUCTIONS



| CONDITION OF BEARING  | CAUSE  | REMEDY  |
|---|--|---|
| <div></div> <div>J51-053</div> <div>Fig. 16<br/>Step wear</div>      | <p>Wear on the roller ends caused by fine abrasives</p>  | <p>Clean all components and housing. Check the seals and bearings and replace if leaking, rough or noisy.</p> |
| <div></div> <div>J51-054</div> <div>Fig. 17<br/>Etching</div>        | <p>The bearing surfaces are grey or greyish black in colour. With the rollers and track material being etched away usually related to roller spacing</p> | <p>Replace the bearings, check the seals and also ensure there is adequate lubrication.</p>                   |
| <div></div> <div>J51-055</div> <div>Fig. 18<br/>Misalignment</div> | <p>Outer track misalignment usually due to a foreign body under the track.</p>   | <p>Clean all components and replace the bearing and ensure that the new track is correctly seated.</p>        |
| <div></div> <div>J51-056</div> <div>Fig. 19<br/>Indentations</div> | <p>Surfaces are depressed on the race and the track caused by hard particles of foreign material.</p>  | <p>Clean all parts and housings, check the seals and replace if rough or noisy.</p>                           |

| CONDITION OF BEARING   | CAUSE   | REMEDY   |
|--|---|--|
| <div><p>J51-057</p><p>Fig. 20<br/>Flaking</p></div>       | Flaking of the surface material due to fatigue.   | Replace the bearing and clean all related components.  |
| <div><p>J51-058</p><p>Fig. 21<br/>Indentations</p></div>  | Surface indentations in track caused by rollers either vibrating or impact loading while the bearing is not rotating. | Replace the bearing if rough or noisy.   |
| <div><p>J51-059</p><p>Fig. 22<br/>Cage wear</p></div>   | Wear around the outside diameter of the cage and roller pockets caused by poor lubrication and abrasive material.     | Replace the bearings and check the conditions of the seals.  |
| <div><p>J51-060</p><p>Fig. 23<br/>Roller wear</p></div> | Marks on track and rollers caused by fine abrasives.  | Clean all components and housings. Check the seal and bearing condition and replace if leaking or noisy. |

GENERAL FITTING INSTRUCTIONS

| CONDITION OF BEARING   | CAUSE   | REMEDY  |
|--|---|---|
| <div><p>J51-061</p><p>Fig. 24<br/>Discolouration</p></div>                      | <p>Discolouration ranges from black to light brown caused by moisture or incorrect use of lubricants.</p>   | <p>Re-use bearings if stains can be removed by light polishing or if no evidence of overheating is apparent. Check the seal and other component part condition.</p>   |
| <div><p>J51-062</p><p>Fig. 25<br/>Heat discolouration</p></div>                 | <p>Heat discolouration ranges from blue to faint yellow resulting from overload or incorrect lubricant. As excessive heat can cause softening of tracks and rollers, check by drawing a fine file over a softened area. If faultily the file will grab and cut metal, if it remains hard the file will skid over the surface without removing any material.</p> | <p>Replace the bearings and seals if any heat damage is evident.</p>  |
| <div><p>J51-065</p><p>Fig. 26<br/>Cracked race</p></div>                      | <p>Race cracked due to incorrect fitment to shaft, tipping or poor seating.</p>   | <p>Replace the bearing and check the condition of the seals.</p>  |
| <div><p>J51-064</p><p>Fig. 27<br/>Rotating track and<br/>inner race</p></div> | <p>Removal of material due to slippage. This can be caused by poor fits, incorrect lubrication, overheating, overloading and poor assembly.</p>   | <p>Replace bearings and clean all related parts, check the fit and ensure the replacement bearings are the correct type. Replace the shaft or housing if damaged.</p> |



| CONDITION OF BEARING  | CAUSE   | REMEDY  |
|---|---|---|
| <div><p>J51-063</p><p>Fig. 28<br/>Fretting</p></div> | <p>Corrosion caused by small movement of components with no lubrication.</p>            | <p>Replace the bearing, check the seals for leakage and ensure there is adequate lubrication.</p> |
| <div><p>J51-066</p><p>Fig. 29<br/>Seizure</p></div>  | <p>Caused by lack of lubrication, excessive loads on the ingress of foreign matter.</p> | <p>Change the bearings. Check the seals for wear and ensure there is adequate lubrication.</p>    |

## LIFTING AND JACKING

### Stands

When carrying out any work on the car which requires a wheel to be raised (apart from a simple wheel change) it is essential that the jack is replaced by a stand, located by the jacking spigot, to provide a secure support for the car.

### Jacking Points (Fig. 1)

The jack provided in the car's tool kit engages with spigots situated below the body side members, in front of the rear wheels and behind the front wheels. Always chock wheels as well as applying handbrake when using the jack.





Fig. 1

### Workshop Jack

#### Front — one wheel (Fig. 2)

Jack under the lower spring support pan, using a suitable wooden block on the jack head. Place a stand in position at the adjacent spigot when the wheel is raised.




J08 005

Fig. 2

#### Rear — one wheel (Fig. 3)

Locate the jack with a wooden block on its head, under the outer fork of the wishbone at the wheel to be raised. Take care to avoid damage to the aluminium alloy hub carrier or to the grease nipple fitted to it. Place a stand under the adjacent jacking spigot when the wheel is raised.




J08 002

Fig. 3

#### Front — both wheels (Fig. 4)

Place the jack, with a wooden block on its head, centrally under the front suspension. Place stands under both front jacking spigots when the car is raised.




J08 003

Fig. 4

#### Rear — both wheels (Fig. 5)

Place a suitable shaped wooden block between the jack head and the plate in the centre of the rear crossmember, ensuring that the jacking load is not applied to the flanges of the plate. Place stands under both rear jacking spigots when the car is raised.



J08 004

Fig. 5

### Lifting

Locate lifting pads at the four jacking spigots.

## TOWED RECOVERY

The car may be towed by another vehicle provided the following precautions are taken:

1. The gearbox oil is at the correct level.
2. The gear lever is in Neutral, and the ignition key is in position '1'.
3. The towing speed should not exceed 48 km/h (30 m.p.h.) and the towing distance should be limited to 48 km (30 miles).
4. The registration number of the towing vehicle and an 'ON TOW' sign or warning triangle, must be displayed in a prominent position on the rear of the vehicle being towed.

**WARNING: WHEN THE ENGINE IS NOT RUNNING THE STEERING WILL NO LONGER BE POWER ASSISTED, AND THE BRAKE SERVO WILL BECOME INEFFECTIVE AFTER A FEW APPLICATIONS OF THE BRAKES. THEREFORE BE PREPARED FOR RELATIVELY HEAVY STEERING, AND THE NEED FOR INCREASED BRAKE PEDAL PRESSURE.**

If the distance to be towed will exceed 48 km (30 miles) then the car should be towed with the rear wheels clear of the ground or the propellor shaft disconnected from the final drive input flange.

If the propellor shaft is disconnected then it must be firmly secured away from the final drive flange.

Engine Oil — Recommended S.A.E. Viscosity Range/Ambient Temperature Scale




Fig. 1

| Component — Model                                   | Temperature Range  | Specification   | SAE Viscosity Rating   | Approved Brands Available in UK for Temperatures Above -10°C (14°F)   |
|---|--|---|--|---|
| Engine Distributor<br>Oil Can                       | Above -10°C (14°F)<br>-20°C to 10°C (-4°F to 50°F)<br>Below -10°C (14°F) | BLSO OL02<br>or<br>MIL-L-2104 B<br>or<br>A.P.I. SE                  | 10W/50, 15W/50,<br>20W/40, 20W/50<br>10W/30, 10W/40,<br>10W/50<br>5W/20, 5W/30 | Unipart Super Multigrade, BP Super Viscostatic, Castrol GTX, Duckhams Q Motor Oil, Esso Uniflow, Fina Super Grade, Mobiloil Super, Shell Super Oil, Texaco Havoline   |
| Manual Gearbox                                      | All<br>All   | —<br>MIL-L-2105A,<br>APIGL4   | SAE 80   | BP gear oil SAE 80EP, Shell spirax 80EP, Castrol Hypoy, Duckhams Hypoid 80, Esso gear oil GX 85W/140, Mobilube HD 80  |
| Powr-Lok Differential<br>— Initial Fill<br>— Refill | All<br>All   | Use only approved brands of fluid specially formulated for Powr-Lok | 90<br>90   | Shell Spirax Super 90, Shell Spirax Super 90, BP Gear Oil 1453, BP Limslip Gear Oil 90/1, Castrol G722, Castrol Hypoy LS, Duckhams Hypoid 90 DL, Texaco 3450 Gear Oil, Veedol Multigear Limited Slip SAE 90 |
| Power Assisted Steering                             | All  | Type G  | —  | BP Autran G, Castrol TQF, Duckhams Q-Matic, Esso Glide Type G, Fina Purfomatic 33F, Mobil AT210, Shell Donax TF, Texaco Texamatic Type G  |
| Grease Points — All                                 | All  | Multipurpose Lithium Grease, N.L.C.I. Consistency No. 2             | —  | BP Energrease L8, Castrol LM, Duckhams LB10, Esso Multipurpose H, Fina Marson HTL2, Mobilgrease MP, Shell Retinax A, Texaco Marfak  |

COOLING SYSTEM

|             |  |
|-------------|--|
| Additive    | Barr's Leak Inhibitor, 1 sachet per car  |
| Anti-freeze | BP Type HS25 Bluecol, 'U', Union Carbide UT 184 or Unipart Universal<br>If these are not available, phosphate free anti-freeze conforming to specification BS3150 or 3152 may be used.<br>Concentration — UK and RHD export markets only 40% sp.gr 1.065<br>In North America use Jaguar Part No. ZVW 244101<br>All other markets 55% sp.gr 1.074 |

In territories where anti-freeze is unnecessary the cooling system must be filled with a solution of Marston Corrosion Inhibitor Concentrate SQ36.

Always top-up the cooling system with recommended strength of anti-freeze or Corrosion Inhibitor, NEVER with water only.

## RECOMMENDED LUBRICANTS

| CAPACITIES   | Litres | Imperial Pints | US Quarts |
|--|--------|----------------|-----------|
| Engine refill (including filter)   | 8,50   | 15             | 9         |
| (excluding filter)   | 7,95   | 14             | 5.8       |
| Automatic transmission unit from dry   | 10,60  | 18.60          | 11.2      |
| Drain and refill   | 3,30   | 7              | 4.20      |
| Manual gearbox   | 1,40   | 2.50           | 1.50      |
| Final drive unit   | 1,50   | 2.75           | 1.65      |
| Cooling system including reservoir and air conditioning: Initial fill from dry | 11,60  | 20.50          | 12.3      |
| Drain and refill   | 9,90   | 17.50          | 10.5      |
| Washer bottle  | 2,60   | 4.58           | 2.75      |
| Washer bottle (headlamp wash/wipe)   | 5,40   | 9.50           | 5.70      |
| Fuel tank  | 91     | 20 gal         | 24 gal    |

| DIMENSIONS                       | mm     | Inches   |
|----------------------------------|--------|----------|
| Wheelbase                        | 2591   | 102      |
| Track: Front                     | 1482   | 58.4     |
| Rear                             | 1504   | 59.2     |
| Overall length: European cars    | 4764   | 187.6    |
| USA and Canada                   | 4859   | 191.3    |
| Overall width                    | 1793   | 70.6     |
| Overall height                   | 1261   | 49.6     |
| Turning circle between walls     | 12,6 m | 41ft 4in |
| kerbs                            | 12,0 m | 39ft 4in |
| Ground clearance: kerb condition | 140    | 5.5      |

## WEIGHTS AND FUEL REQUIREMENTS

| UK AND EUROPEAN MODELS            | kg   | lb   |
|-----------------------------------|------|------|
| Kerb weight                       | 1660 | 3652 |
| Front axle weight                 | 873  | 1921 |
| Rear axle weight                  | 787  | 1731 |
| Gross vehicle weight              | 2010 | 4422 |
| *Gross car weight                 | 3510 | 7722 |
| Maximum permitted front axle load | 980  | 2156 |
| Maximum permitted rear axle load  | 1070 | 2354 |

\* Gross car weight is the gross vehicle weight plus maximum trailer weight.

| <b>FEDERAL MODELS</b>            | <b>kg</b> | <b>lb</b> |
|----------------------------------|-----------|-----------|
| Gross vehicle weight rating      | 2040      | 4487      |
| Gross axle weight rating — Front | 982       | 2161      |
| Gross axle weight rating — Rear  | 1057      | 2326      |
| Front axle weight                | 906       | 1993      |
| Rear axle weight                 | 806       | 1774      |
| Kerb weight                      | 1721      | 3787      |
| <b>CANADIAN MODELS</b>           | <b>kg</b> | <b>lb</b> |
| Gross vehicle weight             | 2035      | 4477      |
| Front axle weight                | 980       | 2156      |
| Rear axle weight                 | 1055      | 2321      |
| <b>ALL MARKETS</b>               | <b>kg</b> | <b>lb</b> |
| Trailer weight maximum — braked  | 1500      | 3300      |
| unbraked                         | 750       | 1650      |

Maximum permitted luggage compartment load with 5 passengers is 70 kg (154.3 lb).

## FUEL REQUIREMENTS

Only cars with 'S' compression ratio engine require 97 octane fuel.

Cars with 'L' compression ratio engines should use 94 octane fuel.

In USA use unleaded fuel with a minimum octane rating of 91 RON.

In the United Kingdom, use '4 Star' fuel.

If, of necessity, the car has to be operated on lower octane fuel, do not use full throttle otherwise detonation may occur with resultant piston trouble.

## RECOMMENDED HYDRAULIC FLUID

### Braking System

Castrol-Girling Universal Brake and Clutch fluid. This fluid exceeds SAE J1703/D specification.

**NOTE:** Check all pipes in the brake system at the start and finish of each winter period for possible corrosion due to salt and grit used on the roads.

MAINTENANCE SUMMARY—UK & EUROPE

| OPERATION  | Interval in Kilometres x 1000 | 1.6 | 12  | 24 |
|--|-------------------------------|-----|-----|----|
|  | Interval in Miles x 1000      | 1   | 7.5 | 15 |
| <b>PASSENGER COMPARTMENT</b>   |                               |     |     |    |
| Fit protection kit .....   |                               | X   | X   | X  |
| Check condition and security of seats and seat belts .....   |                               | X   | X   | X  |
| Check operation of seat belt warning system .....  |                               | X   |     |    |
| Check footbrake operation .....  |                               | X   | X   | X  |
| Drive on lift, stop engine .....   |                               | X   | X   | X  |
| Check operation of lamps .....   |                               | X   |     |    |
| Check operation of horns .....   |                               | X   |     |    |
| Check operation of warning indicators .....  |                               | X   |     |    |
| Check operation of windscreen wipers .....   |                               | X   |     |    |
| Check operation of windscreen washers .....  |                               | X   |     |    |
| Check security of handbrake — release fully after checking .....                                     |                               | X   | X   | X  |
| Check rear-view mirrors for security and function .....  |                               | X   |     |    |
| Check operation of boot lamp .....   |                               | X   |     |    |
| <b>EXTERIOR</b>  |                               |     |     |    |
| Open bonnet — fit wing covers .....  |                               | X   | X   | X  |
| Raise lift to convenient working height with wheels free to rotate .....                             |                               | X   | X   | X  |
| Mark stud to wheel relationship .....  |                               |     | X   | X  |
| Remove front wheels .....  |                               |     | X   |    |
| Remove road wheels — front and rear .....  |                               |     |     | X  |
| Check that tyres are the correct size and type .....   |                               | X   | X   | X  |
| Check tyre tread depth .....   |                               | X   | X   | X  |
| Check tyres visually for external lumps, bulges and uneven wear .....                                |                               | X   | X   | X  |
| Check tyres visually for external exposure of ply or cord .....                                      |                               | X   | X   | X  |
| Check/adjust tyre pressures .....  |                               | X   | X   | X  |
| Inspect brake pads for wear and discs for condition .....  |                               |     | X   | X  |
| Adjust front hub bearing end-float .....   |                               |     |     | X  |
| Grease hubs .....  |                               |     |     | X  |
| Check for oil leaks from steering and fluid leaks from suspension system .....                       |                               | X   | X   | X  |
| Check condition and security of steering unit joints and gaiters .....                               |                               | X   | X   | X  |
| Refit road wheels in original position .....   |                               |     | X   | X  |
| Check tightness of road wheel fastenings .....   |                               | X   | X   | X  |
| <b>UNDERBODY</b>   |                               |     |     |    |
| Raise lift to convenient height .....  |                               | X   | X   | X  |
| Drain engine oil .....   |                               | X   | X   | X  |
| Check/top-up gearbox oil .....   |                               | X   | X   | X  |
| Change gearbox oil .....   |                               | X   |     |    |
| Grease all points excluding hubs .....   |                               |     | X   | X  |
| Check/top-up rear axle/final drive oil .....   |                               | X   | X   | X  |
| Check visually hydraulic hoses, pipes and unions for chafing, cracks, leaks and corrosion .....      |                               | X   | X   | X  |
| Check exhaust system for leakage and security .....  |                               | X   | X   | X  |
| Lubricate handbrake mechanical linkage and cables .....  |                               | X   |     | X  |
| Check condition of handbrake pads .....  |                               |     |     | X  |
| Check tightness of propshaft coupling bolts .....  |                               | X   |     | X  |
| Check security of accessible engine mountings .....  |                               | X   |     |    |
| Check condition and security of steering unit, joints and gaiters .....                              |                               | X   | X   | X  |
| Check security and condition of suspension fixings .....   |                               | X   | X   | X  |
| Check steering rack for oil leaks .....  |                               | X   | X   | X  |
| Check power steering for leaks, hydraulic pipes and unions for chafing, corrosion and security ..... |                               | X   | X   | X  |
| Check shock absorbers for fluid leaks .....  |                               | X   | X   | X  |
| Renew engine oil filter element .....  |                               |     | X   | X  |
| Refit engine drain plug .....  |                               | X   | X   | X  |
| Check for oil leaks — engine and transmission .....  |                               | X   | X   | X  |
| Lower lift .....   |                               | X   | X   | X  |

# MAINTENANCE

## MAINTENANCE SUMMARY — UK & EUROPE

| OPERATION  | Interval in Kilometres x 1000<br>Interval in Miles x 1000 | 1.6<br>1 | 12<br>7.5 | 24<br>15 |
|--|---|----------|-----------|----------|
| ENGINE COMPARTMENT   |   |          |           |          |
| Fit exhaust extractor pipe .....   |   | X        | X         | X        |
| Fill engine with oil .....   |   | X        | X         | X        |
| Lubricate accelerator control linkage and pedal pivot .....  |   | X        |           |          |
| Renew air cleaner element .....  |   |          |           | X        |
| Check security of accessible engine mountings .....  |   | X        |           |          |
| Check driving belts; adjust or renew .....   |   | X        |           | X        |
| Check and adjust spark plugs .....   |   |          | X         |          |
| Renew spark plugs .....  |   |          |           | X        |
| Check/top-up battery electrolyte .....   |   | X        | X         | X        |
| Clean and grease battery connections .....   |   | X        | X         | X        |
| Check/top-up clutch fluid reservoir .....  |   | X        | X         | X        |
| Check/top-up brake fluid reservoir .....   |   | X        | X         | X        |
| Check brake servo hose(s) for security and condition .....   |   | X        | X         | X        |
| Check/top-up windscreen washer reservoir .....   |   | X        |           |          |
| Check cooling and heater system for leaks and hoses for security and condition .....                                     |   | X        | X         | X        |
| Check/top-up cooling system .....  |   | X        |           |          |
| Renew fuel filter .....  |   |          |           | X        |
| Clean engine breather filter (where applicable) .....  |   |          |           | X        |
| Check crankcase breathing system for leaks, hoses for security and condition .....                                       |   | X        |           | X        |
| Check/top-up fluid in power steering reservoir; check security and condition<br>of oil pressure hose at oil filter ..... |   | X        | X         | X        |
| Run engine and check for sealing of oil filter; stop engine .....  |   |          | X         | X        |
| Check/top-up engine oil .....  |   |          | X         | X        |
| Connect electronic instruments and check data .....  |   | X        |           | X        |
| Lubricate distributor (not cam wiping pad) — run engine .....  |   | X        |           | X        |
| Check ignition timing .....  |   | X        | X         | X        |
| Check distributor automatic advance .....  |   | X        |           | X        |
| Check advance increases as vacuum pipe is reconnected .....  |   | X        |           | X        |
| DOOR AND WINDOW MECHANISMS   |   |          |           |          |
| Lubricate all locks, hinges and door check mechanisms (not steering lock) .....  |   | X        |           | X        |
| Check operation of all door, bonnet and boot locks .....   |   | X        |           |          |
| Check operation of window controls .....   |   | X        |           |          |
| Check and if necessary renew windscreen wiper blades .....   |   |          | X         | X        |
| UNDER BONNET   |   |          |           |          |
| Check/adjust engine idle speed; stop engine — disconnect instruments .....   |   | X        |           | X        |
| Check power steering system for leaks, hydraulic pipes and unions for chafing and corrosion .....                        |   | X        | X         | X        |
| Check for oil leaks from engine and transmission .....   |   | X        | X         | X        |
| Re-check tension if driving belt has been renewed .....  |   | X        |           | X        |
| Remove wing covers .....   |   | X        | X         | X        |
| Fill in details and fix appropriate Unipart underbonnet stickers .....   |   | X        | X         | X        |
| Close bonnet .....   |   | X        | X         | X        |
| Remove exhaust extractor pipe .....  |   | X        | X         | X        |
| SPARE WHEEL  |   |          |           |          |
| Remove spare wheel .....   |   | X        | X         | X        |
| Check that tyre complies with manufacturer's specification .....   |   | X        | X         | X        |
| Check tyre tread depth .....   |   | X        | X         | X        |

# MAINTENANCE SUMMARY — UK & EUROPE

| OPERATION   | Interval in Kilometres x 1000<br>Interval in Miles x 1000 | 1.6<br>1 | 12<br>7.5 | 24<br>15 |
|---|---|----------|-----------|----------|
| <b>SPARE WHEEL cont.</b>  |   |          |           |          |
| Check tyre visually for external exposure of cord or ply .....          |   | X        | X         | X        |
| Check tyre visually for external lumps or bulges .....                  |   | X        | X         | X        |
| Check/adjust tyre pressure .....  |   | X        | X         | X        |
| Refit spare wheel .....   |   | X        | X         | X        |
| <b>MISCELLANEOUS</b>  |   |          |           |          |
| Check/adjust headlamp alignment .....                                   |   | X        |           | X        |
| Check/adjust front wheel alignment .....                                |   | X        |           | X        |
| Drive off lift .....  |   | X        | X         | X        |
| Carry out road or roller test .....                                     |   | X        | X         | X        |
| Check operation of seat belt inertia mechanism .....                    |   | X        | X         | X        |
| Ensure cleanliness of controls, door handles, steering wheel, etc ..... |   | X        | X         | X        |
| Remove protection kit .....   |   | X        | X         | X        |
| Report additional work required .....                                   |   | X        | X         | X        |

## At 18 month intervals

Renew brake fluid

## At 48 000 km (30 000 miles) intervals

Change final drive oil

Change coolant ensuring that the correct anti-freeze content is present upon replenishment, i.e. 40% all UK and RHD export markets, 55% all other markets.

Change gearbox oil

## At 3 years or 60 000 km (37 500 miles) intervals — whichever is the sooner

Renew all fluid seals in hydraulic system; examine and renew if necessary all flexible hoses

Examine working surfaces of master cylinder and calipers. Renew if necessary

## OPTIONAL SERVICES

| OPERATION   | Interval in Kilometres x 1000<br>Interval in Miles x 1000 | 12<br>7.5 | 24<br>15 |
|---|---|-----------|----------|
| Check operation of lamps .....  |   |           | X        |
| Check operation of horns .....  |   |           | X        |
| Check operation of warning indicators .....                                     |   |           | X        |
| Check operation of windscreen wipers .....                                      |   |           | X        |
| Check operation of windscreen washers .....                                     |   |           | X        |
| Check operation of window controls .....  |   | X         | X        |
| Check sunroof and controls for correct operation (if fitted) .....              |   |           | X        |
| Check operation of headlamp wipe/wash (if fitted) .....                         |   |           | X        |
| Check rear view mirrors for security and function .....                         |   |           | X        |
| Check operation of boot lamp .....  |   |           | X        |
| Check/top-up windscreen washer reservoir .....                                  |   |           | X        |
| Check/top-up cooling system .....   |   | X         | X        |
| Check operation of all door, bonnet and boot locks .....                        |   | X         | X        |
| Check operation of cruise control (if fitted) .....                             |   |           | X        |
| Lubricate all locks, hinges and door check mechanisms (not steering lock) ..... |   | X         |          |
| Clean aerial mast .....   |   | X         |          |
| Check/adjust headlamp alignment .....   |   | X         |          |
| Check/adjust front wheel alignment .....  |   | X         |          |



# MAINTENANCE

## MAINTENANCE SUMMARY — NORTH AMERICAN MARKETS

| Service<br>Code<br>Letter | Distance x 1000 in miles and kilometres                  |     |     |    |      |    |      |    |      |
|---------------------------|--|-----|-----|----|------|----|------|----|------|
|                           | The period between services should not exceed 12 months. |     |     |    |      |    |      |    |      |
| <b>A</b>                  | Km   | 1.5 |     |    |      |    |      |    |      |
|                           | Miles  | 1   |     |    |      |    |      |    |      |
| <b>B</b>                  | Km   |     | 12  |    | 36   |    | 60   |    | 92   |
|                           | Miles  |     | 7.5 |    | 22.5 |    | 37.5 |    | 52.5 |
| <b>C</b>                  | Km   |     |     | 24 |      |    |      | 72 |      |
|                           | Miles  |     |     | 15 |      |    |      | 45 |      |
| <b>D</b>                  | Km   |     |     |    |      | 48 |      |    | 96   |
|                           | Miles  |     |     |    |      | 30 |      |    | 60   |

| OPERATION DESCRIPTION  | SERVICE |              |   |   |
|--|---------|--------------|---|---|
|  | A       | B            | C | D |
| <b>LUBRICATION</b>   |         |              |   |   |
| Lubricate all grease points .....  |         | X            | X | X |
| Renew engine oil and engine oil filter .....   | X       | X            | X | X |
| Check/top-up brake fluid reservoir .....   | X       | X            | X | X |
| Check/top-up gearbox oil .....   | X       | X            | X | X |
| Change gearbox oil .....   | X       |              |   | X |
| Check battery condition .....  | X       | X            | X | X |
| Check/top-up cooling system .....  | X       | X            | X | X |
| Check/top-up rear axle oil .....   | X       | X            | X | X |
| Check/top-up clutch fluid reservoir .....  | X       | X            | X | X |
| Lubricate all locks and hinges (not steering lock) .....                                       | X       | X            | X | X |
| Check/top-up power steering reservoir .....  | X       | X            | X | X |
| <b>ENGINE</b>  |         |              |   |   |
| Check all driving belts — adjust .....   |         |              |   | X |
| Renew air cleaner element .....  |         |              |   | X |
| Check security of engine mountings .....   | X       |              |   |   |
| Check for oil leaks .....  | X       | X            | X | X |
| Renew air pump filter .....  |         | 52.5<br>only |   |   |
| <b>IGNITION</b>  |         |              |   |   |
| Renew spark plugs .....  |         |              |   | X |
| Lubricate distributor .....  |         |              |   | X |
| <b>FUEL AND EXHAUST SYSTEMS</b>  |         |              |   |   |
| Check fuel system for leaks, pipes and unions for chafing and corrosion .....                  | X       | X            | X | X |
| Check exhaust system for leaks and security .....  | X       | X            | X | X |
| Renew oxygen sensor .....  |         |              |   | X |
| Renew fuel filter .....  |         | 52.5<br>only |   |   |
| <b>TRANSMISSION, BRAKES, STEERING AND SUSPENSION</b>   |         |              |   |   |
| Check condition and security of steering unit, joints and gaiters .....                        |         | X            | X | X |
| Inspect brake pads for wear and discs for condition .....                                      |         | X            | X | X |
| Check brake servo hoses for security and condition .....                                       | X       | X            | X | X |
| Check/adjust front wheel alignment .....   | X       | X            | X | X |
| Check foot and hand brakes .....   | X       |              |   |   |
| Check visually brake hydraulic pipes and unions for cracks, chafing, leaks and corrosion ..... | X       | X            | X | X |
| Check/adjust front hub bearing end float .....   |         |              | X | X |
| Check tightness of propeller shaft coupling bolts .....  |         |              | X | X |

| OPERATION DESCRIPTION  | SERVICE |   |   |   |
|--|---------|---|---|---|
|  | A       | B | C | D |
| <b>WHEELS AND TYRES</b>  |         |   |   |   |
| Check tyres for tread depth and visually for external cuts in fabric, exposure of ply or cord structure, lumps or bulges ..... | X       | X | X | X |
| Check that tyres comply with manufacturer's specification .....  | X       | X | X | X |
| Check/adjust tyre pressure, including spare wheel .....  | X       | X | X | X |
| Check tightness of road wheel fastenings .....   | X       | X | X | X |
| <b>ELECTRICAL</b>  |         |   |   |   |
| Check/adjust operation of washers and top up reservoir .....   | X       | X | X | X |
| Check function of original equipment, i.e. lamps, horns, wipers and all warning indicators .....                               | X       | X | X | X |
| Check wiper blades and arms; renew if necessary .....  | X       | X | X | X |
| Check/adjust headlamp alignment .....  | X       | X | X | X |
| <b>BODY</b>  |         |   |   |   |
| Check operation, security and operation of seats and seat belts .....  | X       | X | X | X |
| Check operation of all door, bonnet and luggage compartment locks .....  | X       | X | X | X |
| Check operation of window controls .....   | X       | X | X | X |
| <b>GENERAL</b>   |         |   |   |   |
| Road/roller test and check function of all instrumentation .....   | X       | X | X | X |
| Report additional work required .....  | X       | X | X | X |

**At 18 month intervals**

Renew brake fluid

**At 48 000 km (30 000 mile) intervals**

Change final drive oil

Change coolant ensuring that 55% anti-freeze content is present upon replenishment.

Change gearbox oil.


**At 3 years or 60 000 km (37 500 miles) intervals — whichever is the sooner**

Renew all fluid seals in hydraulic system; examine and renew if necessary all flexible hoses.

Examine working surfaces of master cylinder and calipers. Renew if necessary.


SERVICE TOOLS — Section 99  
ENGINE

MS53A




Engine support bracket

18G134-8




Rear main oil seal installer

MS204




Valve seat cutter

18G106A




Valve spring compressor

MS150-8




Expandable pilot

18G1432




Valve guide remover/replacer

18G1434




Jackshaft inner bearing  
remover/replacer  
(2-part tool)

18G1435




Dummy camshaft caps

18G1436




Timing chain tensioner restrainer  
and crankshaft pulley remover

18G1437




Front pulley lock

18G55A/38U3



Piston ring clamp

MS76




Basic handle set

## SERVICE TOOLS

---

18G1433




---

Camshaft timing tool

---

18G1468




---

Auxiliary drives oil seal remover

---

18G1469




---

Auxiliary drives oil seal replacer

---


## PROPSHAFT AND FINAL DRIVE

SL14-3




Adaptor remover differential bearing cone

SL47-3




Axle shaft bearing remover/  
replacer adaptor

SL550-8




Adaptor/replacer drive pinion outer bearing cup

SL15A




Remover/replacer drive shaft bearing cone

SL3




Pinion setting gauge

SL550-9




Adaptor/replacer drive pinion inner bearing cup

JD1D




Hub remover

18G1205




Propellor shaft flange wrench

SL47-1




Pinion bearing cone remover/adaptor

SL550-1



Replacer diffential bearing cone


18G1428



Pinion oil seal installer


## STEERING AND FRONT SUSPENSION

JD10




Power steering test set

JD10-2




Adaptor hydraulic pressure test

JD36A




Steering rack checking fixture

S355




Pow-A-Rak nut wrench

18G1259




Assembly pilot steering rack pinion

606602




Ring expander for steering box valve and worm seals

606603 (JD33)




Ring compressor for steering box valve and worn seals

JD24




Steering joint taper separator

JD6G




Front coil spring compressor

18G1259




Assembly pilot steering rack pinion

18G1445



Power steering pump drivenog — remover/replacer


18G1446



Steering rack alignment pin


## REAR SUSPENSION

JD11B




Adaptor dismantler dampers spring unit

JD16C




Remover/replacer rear hub outer bearing

JD20A-1




Rear hub inner and outer cup remover/replacer adaptor

JD13A




Rear hub end float gauge

JD15




Replacer — Rear hub master spacer and bearing

JD21




Torque arm bush remover/replacer

JD14




Rear wishbone pivot dummy shaft

JD1D




Hub remover

JD25B



Rear camber setting links

JD20A




Bearing remover main tool

SERVICE TOOLS

BRAKES


18G672



Replacer disc brake piston seal

AIR-CON


18G1363



Air-con linkage setting tool

ELECTRICAL


18G1001 (600964) (P9074A)



Spanner for fuel tank unit


GENERAL

47




Multi-purpose hand press

370




Adaptor plates

MS68




Torque screw wrench

18G134 (550)



Driver handle

18G681 (CBW548) & (CBW548-1)




Torque screwdriver


All service tools listed are available from :  
V. L. Churchill & Co. Limited  
P.O. Box 3  
Daventry  
Northamptonshire NN11 4NF







**XJ-S 3·6  
XJ-SC 3·6  
SERVICE  
MANUAL**





## BOOK 2

Containing  
Section

12 ENGINE

XJ-S 3·6  
XJ-SC 3·6

# SERVICE MANUAL

---

## INTRODUCTION

This Service Manual covers the Jaguar XJ-S 3.6 and XJ-SC 3.6. It is primarily designed to assist skilled technicians in the efficient repair and maintenance of this range of Jaguar cars.

Using the appropriate service tools and carrying out the procedures as detailed will enable the operations to be completed within the time stated in the 'Repair Operation Times'.

The Service Manual has been produced in 9 separate books; this allows the information to be distributed throughout the specialist areas of the modern service facility.

A table of contents in Book 1 lists the major components and systems together with the section and book numbers. The cover of each book depicts graphically and numerically the sections contained within that book.

The title page of each book carries the part numbers required to order replacement books, binders or complete Service Manuals. This can be done through the normal channels.

The contents section of each book lists the repair operations in the section or sections contained within that book. Each operation is given an operation number that corresponds with those listed in the Repair Operation Times.

The method described on the page number listed against the operation will be the one we consider will meet the requirements of safety and enable the operation to be carried out in the time specified in the Repair Operation Times.

Where no page number is given against an operation, we feel that the method is so obvious as to warrant no explanation. It is, however, included so that a warranty time can be given in the Repair Operation Times.

Extensive research has gone into the diagnosis of faults and where appropriate this is covered in the various areas of the manual. By following the sequence of the diagnosis charts, speedy isolation of faults may be expected, and consequent correction will reduce the vehicle off-the-road time to the minimum.

### Service Tools

Where performance of an operation requires the use of a service tool the tool number is quoted under the operation heading and is repeated in, or following, the instruction involving its use. A list of all necessary tools is included in Book 1, Section 99.

### References

References to the LH or RH side in the manual are made when viewing from the rear. With the engine and gearbox assembly removed the timing cover end of the engine is referred to as the front. A key to abbreviations and symbols is given in Book 1, Section 01.

## REPAIRS AND REPLACEMENTS

When service parts are required it is essential that only genuine Jaguar or Unipart replacements are used.

Attention is particularly drawn to the following points concerning repairs and the fitting of replacement parts and accessories.

1. Safety features embodied in the vehicle may be impaired if other than genuine parts are fitted. In certain territories, legislation prohibits the fitting of parts not to the vehicle manufacturer's specification.
2. Torque wrench setting figures given in this Service Manual must be strictly adhered to.
3. Locking devices, where specified, must be fitted. If the efficiency of a locking device is impaired during removal it must be replaced.
4. Owners purchasing accessories while travelling abroad should ensure that the accessory and its fitted location on the vehicle conform to mandatory requirements existing in their country of origin.
5. The vehicle warranty may be invalidated by the fitting of other than genuine Jaguar or Unipart parts. All Jaguar and Unipart replacements have the full backing of the factory warranty.
6. Jaguar Distributors and Dealers are obliged to supply only genuine service parts.

## SPECIFICATION

Purchasers are advised that the specification details set out in this Manual apply to a range of vehicles and not to any one. For the specification of a particular vehicle, purchasers should consult their Distributor or Dealer.

The Manufacturers reserve the right to vary their specifications with or without notice, and at such times and in such manner as they think fit. Major as well as minor changes may be involved in accordance with the Manufacturer's policy of constant product improvement.

Whilst every effort is made to ensure the accuracy of the particulars contained in this Manual, neither the Manufacturer nor the Distributor or Dealer, by whom this Manual is supplied, shall in any circumstances be held liable for any inaccuracy or the consequences thereof.

## COPYRIGHT

© Jaguar Cars Ltd. 1983

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, electronic, mechanical, photocopying, recording or other means without prior written permission of Jaguar Cars Ltd., Service Department, Radford, Coventry CV6 3GB.

## CONTENTS


| Operation  | Operation No. | Page No. |
|--|---------------|----------|
| Camshafts — Renew .....                                | 12.13.01      | 12—28    |
| Camshaft LH — Renew .....                              | 12.13.02      | 12—28    |
| Camshaft RH — Renew .....                              | 12.13.03      | 12—28    |
| Camshaft cover — Renew .....                           | 12.29.42      | 12—22    |
| Camshaft cover gasket — Renew .....                    | 12.29.40      | 12—22    |
| Camshaft cover plug well seals — Renew .....           | 12.29.51      | 12—22    |
| Cam follower one — Renew .....                         | 12.29.53      | 12—36    |
| Cam follower set — Renew .....                         | 12.29.57      | 12—36    |
| Con rod set — Renew .....                              | 12.17.12      | 12—29    |
| Con rod bearing set — Renew .....                      | 12.17.16      | 12—29    |
| Crankshaft damper — Renew .....                        | 12.21.09      | 12—24    |
| Crankshaft end float — Check and adjust .....          | 12.21.26      | 12—22    |
| Crankshaft front oil seal — Renew .....                | 12.21.14      | 12—23    |
| Crankshaft pulley — Renew .....                        | 12.21.01      | 12—31    |
| Crankshaft pulley air conditioning drive .....         | 12.21.08      | 12—23    |
| Crankshaft rear oil seal — Renew .....                 | 12.21.20      | 12—44    |
| Crankshaft rear oil seal housing gasket — Renew .....  | 12.21.21      | 12—44    |
| Cylinder block — Renew .....                           | 12.25.04      | 12—43    |
| Cylinder head — Renew .....                            | 12.29.10      | 12—36    |
| Cylinder head casting — Renew .....                    | 12.29.15      | 12—36    |
| Cylinder head gasket — Renew .....                     | 12.29.02      | 12—36    |
| Cylinder head — Overhaul .....                         | 12.29.19      | 12—36    |
| Cylinder head rear blanking plate gasket — Renew ..... | 12.29.16      | 12—22    |
| Cylinder pressures — Check .....                       | 12.25.01      | 12—44    |
| Distributor drive shaft — Renew .....                  | 12.10.22      | 12—23    |
| Engine assembly — Renew .....                          | 12.41.01      | 12—43    |
| Engine mounting front LH — Renew .....                 | 12.45.01      | 12—26    |
| Engine mounting front RH — Renew .....                 | 12.45.03      | 12—26    |
| Engine mounting rear centre — Renew .....              | 12.45.08      | 12—26    |
| Engine mounting set — Renew .....                      | 12.45.13      | 12—26    |
| Engine oil — Drain and Refill .....                    | 12.60.00      | 12—21    |
| Engine remove change ancillaries and refit .....       | 12.41.02      | 12—45    |
| Engine strip and rebuild — Renew .....                 | 12.41.05      | 12—45    |
| Flywheel — Renew .....                                 | 12.53.07      | 12—44    |
| Gasket engine to oil sump — Renew .....                | 12.60.38      | 12—19    |

## ENGINE

---

| Operation  | Operation No. | Page No. |
|--|---------------|----------|
| Intermediate sprocket seal to timing cover — Renew ..... | 12.65.07      | 12—17    |
| Main bearings set — Renew .....                          | 12.21.39      | 12—31    |
| Oil cooler — Renew .....                                 | 12.60.68      | 12—20    |
| Oil cooler return hose — Renew .....                     | 12.60.76      | 12—24    |
| Oil cooler supply hose — Renew .....                     | 12.60.74      | 12—24    |
| Oil filler tube — Renew .....                            | 12.60.11      | 12—20    |
| Oil filler tube seal — Renew .....                       | 12.60.12      | 12—20    |
| Oil filler tube seal housing gasket — Renew .....        | 12.60.13      | 12—20    |
| Oil filler cap — Renew .....                             | 12.60.10      | 12—20    |
| Oil filter cartridge — Renew .....                       | 12.60.04      | 12—20    |
| Oil filter head gasket — Renew .....                     | 12.60.03      | 12—19    |
| Oil pick-up strainer — Renew .....                       | 12.60.20      | 12—21    |
| Oil pressure relief valve — Renew .....                  | 12.60.56      | 12—25    |
| Oil pressure switch — Renew .....                        | 12.60.50      | 12—19    |
| Oil pump — Overhaul .....                                | 12.60.32      | 12—22    |
| Oil pump — Renew .....                                   | 12.60.26      | 12—21    |
| Oil pump drive chain — Renew .....                       | 12.60.28      | 12—26    |
| Oil pump drive chain damper — Renew .....                | 12.60.29      | 12—26    |
| Oil pump drive — Renew .....                             | 12.60.30      | 12—26    |
| Oil pump pipe 'O' rings — Renew .....                    | 12.60.27      | 12—21    |
| Oil sump — Renew .....                                   | 12.60.44      | 12—19    |
| Piston assembly one — Renew .....                        | 12.17.02      | 12—29    |
| Piston assembly set — Renew .....                        | 12.17.03      | 12—29    |
| Piston rings one piston set — Renew .....                | 12.17.07      | 12—29    |
| Piston rings engine set — Renew .....                    | 12.17.08      | 12—29    |
| Seal distributor drive shaft front gasket — Renew .....  | 12.10.31      | 12—17    |
| Seal distributor drive shaft rear gasket — Renew .....   | 12.10.32      | 12—24    |
| Seals set 'inlet valves' — Renew .....                   | 12.29.90      | 12—36    |

| Operation                                     | Operation No. | Page No. |
|---|---------------|----------|
| Timing chain — Renew .....                    | 16.65.14      | 12—17    |
| Timing chain dampers set — Renew .....        | 12.65.48      | 12—17    |
| Timing chain lower — Renew .....              | 12.65.16      | 12—17    |
| Timing chain tensioner lower — Renew .....    | 12.65.30      | 12—17    |
| Timing chain tensioner upper — Renew .....    | 12.65.25      | 12—17    |
| Timing chain upper — Renew .....              | 12.65.15      | 12—17    |
| Timing cover gasket — Renew .....             | 12.65.04      | 12—17    |
| Timing gear camshaft — Renew .....            | 12.65.24      | 12—17    |
| Timing gear cover — Renew .....               | 12.65.01      | 12—17    |
| Timing gear crankshaft — Renew .....          | 12.65.25      | 12—17    |
| Timing gears — Renew .....                    | 12.65.22      | 12—17    |
| Valve clearances — Check .....                | 12.29.47      | 12—28    |
| Valve clearances — Check and adjust .....     | 12.29.48      | 12—28    |
| Valve springs exhaust — Renew .....           | 12.29.92      | 12—36    |
| Valve springs inlet — Renew .....             | 12.29.91      | 12—36    |
| Valve springs inlet and exhaust — Renew ..... | 12.29.65      | 12—36    |
| Valve exhaust — Renew .....                   | 12.29.64      | 12—36    |
| Valve inlet — Renew .....                     | 12.29.63      | 12—36    |
| Valves set — Renew .....                      | 12.29.62      | 12—36    |





### 3.6 4 VALVE ENGINE

|                   |                                   |
|-------------------|-----------------------------------|
| Configuration     | In line 6 cylinder                |
| Bore              | 91 mm                             |
| Stroke            | 92 mm                             |
| Capacity          | 3590 cc                           |
| Compression ratio | 9.6:1 (Europe)<br>8.2:1 (Federal) |

The new slant 6 cylinder engine is of an all alloy construction. The cylinders are of an in-line configuration and have a cubic capacity of 3590 cc. The engine is canted over at 15° from the vertical to the RH side of the vehicle ensuring there is ample room for the induction manifolds necessary to provide low speed flexibility and torque output.

### ENGINE CONSTRUCTION

The skirted design crankcase is manufactured in cast aluminium alloy with shrink fit dry cast iron cylinder liners.

The crankshaft is manufactured from SG cast iron and is nitro carburise treated to enable a very high quality finish on the bearing surfaces and increase the life of the journals. The crankshaft is supported by seven iron bearing caps having bearings, which are lead bronze on split steel backed shells with a lead indium overlay.

Crankshaft end float is controlled by half thrust washers fitted on each side of the centre main bearing journal.

The connecting rods are manufactured from manganese molybdenum steel, forged in an 'H' section. The small end bushes are lead bronze with steel backing, machined to size after pressing into connecting rod.

The big end bearings are of a lead bronze alloy on split steel backed shells and with lead indium overlay.

The pistons are manufactured from aluminium alloy and have either a raised or dished crown to produce the alternative compression ratios required to suit varying market needs. Each piston has a spring assisted micro land oil control ring situated below a barrel faced chrome plated compression ring and an externally stepped taper faced secondary ring.

The pistons are internally strutted for thermal control and run on hardened steel gudgeon pins offset from the centre line of the piston towards the thrust face.

The cylinder head is cast from aluminium alloy with pent roof shaped combustion chambers with crossflow valve porting.

Running directly in the cylinder head are two cast iron camshafts retained by machined aluminium caps. Each camshaft uses chilled cams to drive two valves per cylinder via chilled cast iron bucket tappets with shim adjustment, control of each of the four valves per cylinder is maintained by single valve springs.

The camshafts are operated by a two stage 'duplex' chain drive from the crankshaft. Each stage is controlled by a hydraulic tensioner operating through a pivoted rubber faced curved tensioner blade.

The first stage incorporates a three point drive via the crankshaft, intermediate shaft and auxiliary shaft.

The intermediate shaft is live and provides a 0.75 x crankspeed drive through the timing cover. This drive access is blanked off.

The 'live' auxiliary shaft is driven at crankshaft speed and is situated on the RH side of the engine (looking from rear). In addition to driving the distributor via a set of 2:1 reduction spiral gears, it provides

external drives for:

- The power assisted steering pump at the rear.
- The air injection pump drive pulley at the front. On non air injection engines this drive is blanked off.

The second stage is a three point drive via the intermediate shaft and two camshafts. The 2:1 reduction ratio from crankspeed is achieved by the combined ratio of the intermediate and camshaft sprocket sizes.

The oil pump is a rotor type mounted on the underside of the front of the crankcase and driven by a 'simplex' chain from the crankshaft nose. The pump incorporates a built in pressure relief valve which is accessible via a plug at the front of the sump.

Below the line of the crankcase are two windage trays; these prevent oil being sucked up and thrown into the crankcase; this alleviates windage and power losses.

Above the sump oil level is a sump tray and baffle assembly to prevent oil surge.

At the rear of the crankshaft is a new design of lip type oil seal which provides a high degree of oil retention. It also allows the use of higher engine speed and easier serviceability as opposed to the conventional asbestos rope seal.

## LUBRICATION SYSTEM

Oil is drawn from the sump via a gauze filter. Pressurised oil, having been regulated by a relief valve, is then fed via internal galleries on the LH side of the cylinder block. An adaptor block is fitted between the cylinder block and the oil filter housing which diverts the full oil flow through the oil cooler prior to filtering. A balance valve is fitted which bypasses the oil cooler circuit when a pressure differential of 10 to 15 lb/in<sup>2</sup> occurs.

Pressurised and filtered oil is fed into the main oil gallery, the seven main bearings are fed and thence via crankshaft drillings to the big end bearings.

The intermediate shaft, auxiliary shaft and camshaft bearings are pressure lubricated by means of internal drillings directly fed from the front of the main oil gallery.

**NOTE:** Oil coolers are specified on all models to date, but if at any time a cooler is not required, then the oil filter housing can be bolted directly to the cylinder block through omitting the oil cooler adaptor.

## SPS JOINT CONTROL SYSTEM


A feature of the engine is the adoption of the SPS system on the cylinder head bolts. This system ensure that the joints receive maximum clamp load for a given fixing size and type of material by tightening the fixing

to its particular yield point. This greatly helps to prevent any premature cylinder head gasket failures.

Apart from the cylinder head the manifolds and the auxiliary housing, the engine is gasketless. The use of a rubber sealing material on all other joints ensures a leak free engine.

**NOTE:** The SPS system in service requires the nut or bolt to be set to a specified torque initially, the fastening then has to be rotated clockwise through exactly 90°. The accuracy of this cannot be too highly stressed.

It is therefore recommended that a tool is manufactured to aid the turning of the fixing through exactly 90°. A suggested tool is illustrated below.



## CRANKCASE BREATHER

Blowby gases are recycled via the induction system to maintain a crankcase depression and so prevent their escape to the atmosphere.

A dual system is employed by means of:

- An oil filler stack pipe which vents into the crankcase.
- A baffled vent from the cam box cover, the pipe from which connects the air cleaner casing (clean side) with a feed branch via a water heated restrictor into the plenum chamber.

In this way, a crankcase depression is maintained under both closed and open throttle workload conditions.

## CYLINDER HEAD DESIGN

The advantage of four valves per cylinder are: although the valves are smaller in diameter than on a conventional engine combined they have a greater effective area and, also being lighter, the operating gear has less stress applied to it. This design also increases the power at high engine revs and allows an efficient combustion of the fuel.

It also allows the sparking plug to be situated in its ideal central position which also creates efficient combustion and consequently enhances fuel economy.

## COOLANT SYSTEM

The engine is liquid cooled by a mixture of water and anti-freeze circulating around the coolant passages. The coolant pump is mounted on the LH side of the cylinder block and is driven from the crankshaft nose by a three point belt drive (which includes the alternator). The pump is a fully assembled bolt on unit. The coolant is fed into the cylinder block at two places via an external delivery pipe. The coolant is drawn from the cylinder head via a self-contained thermostat housing back to the radiator or recirculated according to the thermostat position.

## SEALANTS

The sealant used on all gasketless joints on this engine must be the Marston compound supplied by Unipart known as Hylosil 101, a white **amine** cure system rubber. Should this not be available an **amine** cure sealant **must be used**.

Under no circumstances should any acidtoxy cure system be used.

## SERVICE TOOLS

|   |           |
|---|-----------|
| Auxiliary shaft oil seal remover                                | 18G 1468  |
| Auxiliary shaft oil seal replacer                               | 18G 1469  |
| Rear main oil seal installer                                    | 18G 134-8 |
| Timing chain tensioner restrainer and crankshaft pulley remover | 18G 1436  |
| Camshaft timing tool  | 18G 1433  |
| Jackshaft inner bearing remover (2 part tool)                   | 18G 1434  |
| Piston ring clamp   | 18G 55A   |
| Valve spring compressor   | 18G 106A  |
| Valve guide remover/replacer                                    | 18G 1432  |
| Front pulley lock   | 18G 1437  |
| Dummy camshaft caps   | 18G 1435  |
| Remover/replacer P.A.S. pump drive and flange                   | 18G 1445  |
| Valve seat cutters  | MS 204    |
| Pilot   | MS 150-8  |
| Handle kit  | MS 76     |

| DESCRIPTION  | THREAD SIZE          | SPANNER SIZE         | TIGHTENING TORQUE |              |          |
|--|----------------------|----------------------|-------------------|--------------|----------|
|  |                      |                      | Nm                | kgf/cm       | lbf/ft   |
| Adjust bolt to compressor — Flange headed bolt . . .                     | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Adjusting bolt, mounting bracket — Flange headed bolt . . . . .          | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Adjust bolt to sleeve — Nut . . . . .                                    | $\frac{3}{8}$ UNF    | $\frac{9}{16}$ in AF | 12,2 to 13,6      | 1,26 to 1,4  | 9 to 10  |
| Adjust sleeve — Nut . . . . .  | $\frac{3}{8}$ UNF    | $\frac{9}{16}$ in AF | 12,2 to 13,6      | 1,26 to 1,4  | 9 to 10  |
| Adjusting bolt to timing cover — Nut . . . . .                           | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Alternator pivot bolt — Nut . . . . .                                    | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Air conditioning adaptor to throttle body — Flange headed bolt . . . . . | M6                   | 8 mm                 | 9,5 to 12,2       | 0,98 to 1,26 | 7 to 9   |
| Air conditioning ass to adaptor plate — Flange headed setscrew . . . . . | M6                   | 8 mm                 | 9,5 to 12,2       | 0,98 to 1,26 | 7 to 9   |
| Air pump mounting — Nut . . . . .  | M14                  | 22 mm                | 30 to 40          | 3,10 to 4,2  | 22 to 30 |
| Air pump to filter — Clip . . . . .                                      | M6                   | 8 mm                 | 2,4               | 0,24         | 1.75     |
| Air pump to switching valve — Clip . . . . .                             | M6                   | 8 mm                 | 2,4               | 0,24         | 1.74     |
| Air temperature sensor . . . . .   | M10                  | 19 mm                | 49 to 54          | 5,04 to 5,6  | 36 to 40 |
| Auxiliary shaft pulley — Nut . . . . .                                   | M12                  | 19 mm                | 57 to 64          | 5,9 to 6,53  | 42 to 47 |
| Baffle tray — Flange headed setscrew . . . . .                           | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Base plate to pedestal — Setscrew . . . . .                              | M6                   | 8 mm                 | 9,5 to 12,2       | 0,98 to 1,26 | 7 to 9   |
| Bearing housing to body — Flange headed setscrew                         | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Bracket to compressor — Flange headed setscrew . .                       | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Bracket to compressor — Flange headed setscrew . .                       | M10                  | 13 mm                | 49 to 54          | 5,04 to 5,6  | 36 to 40 |
| Bracket to cylinder block — Flange headed bolt . . .                     | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Bracket to sump — Flange headed setscrew . . . . .                       | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Breather pipe to air cleaner — Clip . . . . .                            | M6                   | 8 mm                 | 2,4               | 0,24         | 1.75     |
| Breather pipe to independent manifold — Clip . . . .                     | M4                   | 6 mm                 | 0,51              | 0,051        | 0.38     |
| Button head socket screw . . . . .                                       | M5                   | 3 mm                 | 1,7               | 0,17         | 1.25     |
| By-pass elbow — Flange headed setscrew . . . . .                         | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| By-pass hose — Hose clip . . . . .                                       | M6                   | 8 mm                 | 2,4               | 0,24         | 1.74     |
| Cable abutment bracket — Flange headed setscrew                          | M6                   | 8 mm                 | 9,5 to 12,2       | 0,98 to 1,26 | 7 to 9   |
| Cam cover assembly — Flange headed setscrew . . .                        | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Cam cover to filler pipe — Clip . . . . .                                | M6                   | 8 mm                 | 2,4               | 0,24         | 1.75     |
| Camshaft coupling assembly — Setscrew . . . . .                          | $\frac{3}{4}$ UNF    | $\frac{9}{16}$ in AF | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Cap to head — Flange headed bolt . . . . .                               | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Check valve to valve switching — Clip . . . . .                          | M6                   | 8 mm                 | 2,4               | 0,24         | 1.75     |
| Clamp plate to compressor — Flange headed bolt . .                       | M10                  | 13 mm                | 49 to 54          | 5,04 to 5,6  | 36 to 40 |
| Connecting rod nut . . . . .   | $\frac{3}{8}$ in UNF | $\frac{1}{2}$ in AF  | 52 to 55          | 5,5 to 5,8   | 39 to 41 |
| C S inj — Socket head counter-sunk screw . . . . .                       | M6                   | 8 mm                 | 9,5 to 12,2       | 0,98 to 1,26 | 7 to 9   |
| Cover to adaptor — Taptite screw . . . . .                               | M5                   | 8 mm                 | 5,4 to 8,1        | 0,50 to 0,83 | 4 to 6   |
| Cover to cylinder head — Screw . . . . .                                 | M6                   | 8 mm                 | 9,5 to 12,2       | 0,98 to 1,26 | 7 to 9   |
| Cover to housing — Flange headed setscrew . . . .                        | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |

# ENGINE

| DESCRIPTION   | THREAD SIZE           | SPANNER SIZE          | TIGHTENING TORQUE  |              |          |
|---|-----------------------|-----------------------|--|--------------|----------|
|   |                       |                       | Nm   | kgf/cm       | lbf/ft   |
| Crank pulley to damper — Flange headed bolt . . . .   | M8                    | 10 mm                 | 23 to 27   | 2,38 to 2,8  | 17 to 20 |
| Crankshaft bolt . . . . .   | $\frac{3}{4}$ in UNF  | $1\frac{5}{16}$ in AF | 203,4  | 20,8         | 150      |
| Cylinder head — Bolt . . . . .  | $\frac{7}{16}$ in UNC | $\frac{11}{16}$ in AF | Initial torque 38 to 40 lbf/ft and 90° angle (see note SPS system 12-6). |              |          |
| Cylinder head to timing cover — Flange headed bolt  | M8                    | 10 mm                 | 23 to 27   | 2,38 to 2,8  | 17 to 20 |
| Damper distance piece — Setscrew . . . . .  | M8                    | 10 mm                 | 23 to 27   | 2,38 to 2,8  | 17 to 20 |
| Damper/distance piece to cylinder block — Bolt . . . .  | M8                    | 10 mm                 | 23 to 27   | 2,38 to 2,8  | 17 to 20 |
| Damper to cylinder block — Setscrew . . . . .   | M8                    | 10 mm                 | 23 to 27   | 2,38 to 2,8  | 17 to 20 |
| Damper to saddle — Setscrew . . . . .   | M8                    | 10 mm                 | 23 to 27   | 2,38 to 2,8  | 17 to 20 |
| Distance piece to block — Flange headed bolt . . . .  | M8                    | 10 mm                 | 23 to 27   | 2,38 to 2,8  | 17 to 20 |
| Distributor clamp plate to timing cover —<br>Flange headed setscrew . . . . .                               | M6                    | 8 mm                  | 9,5 to 12,2  | 0,98 to 1,26 | 7 to 9   |
| Drain plug . . . . .  | M20                   | 30 mm                 | 41 to 47   | 4,2 to 4,9   | 30 to 35 |
| End plate to cylinder head — Flange headed setscrew   | M8                    | 10 mm                 | 23 to 27   | 2,38 to 2,8  | 17 to 20 |
| Engine dipstick — Flange headed setscrew . . . . .  | M6                    | 8 mm                  | 9,5 to 12,2  | 0,98 to 1,26 | 7 to 9   |
| Engine dipstick — Taptite screw . . . . .   | $\frac{1}{4}$ UNC     | $\frac{3}{8}$ in AF   | 5,4 to 8,1   | 0,56 to 0,83 | 4 to 6   |
| Exhaust manifold to head — Flange headed bolt . . .   | M10                   | 13 mm                 | 49 to 54   | 5,04 to 5,6  | 36 to 40 |
| Exhaust pressure switch and solenoid vacuum valve to<br>speed control actuator — Flange headed setscrew . . | M5                    | 10 mm                 | 1,7  | 0,17         | 1,25     |
| Extra air valve — Nut . . . . .   | M6                    | 8 mm                  | 9,5 to 12,2  | 0,98 to 1,26 | 7 to 9   |
| Fan drive unit to water pump pulley — Nut . . . . .   | M8                    | 10 mm                 | 23 to 27   | 2,38 to 2,8  | 17 to 20 |
| Fan to drive unit — Setscrew . . . . .  | $\frac{5}{16}$ in UNC | $\frac{1}{2}$ in AF   | 13,6   | 1,4          | 10       |
| Filler pipe to breather pipe — Clip . . . . .   | M6                    | 8 mm                  | 2,4  | 0,24         | 1,75     |
| Filter head to cylinder block — Flange headed setscrew  | M8                    | 10 mm                 | 23 to 27   | 2,38 to 2,8  | 17 to 20 |
| Filter head to cylinder block — Flange headed bolt . .  | M8                    | 10 mm                 | 23 to 27   | 2,38 to 2,8  | 17 to 20 |
| Filter to air pump — Flange headed setscrew . . . . .   | M8                    | 10 mm                 | 23 to 27   | 2,38 to 2,8  | 17 to 20 |
| Flywheel  | M12                   | 17 mm                 | 98   | 10,08        | 72       |
| Front pivot to mounting bracket — Flange<br>headed setscrew . . . . .                                       | M10                   | 13 mm                 | 49 to 54   | 5,04 to 5,6  | 36 to 40 |
| Fuel rail — Flange headed setscrew . . . . .  | M6                    | 8 mm                  | 9,5 to 12,2  | 0,98 to 1,26 | 7 to 9   |
| Heater feed — Adaptor . . . . .   | $\frac{3}{4}$ BSPF    | $\frac{7}{16}$ WHIT   | 49 to 54   | 5,04 to 5,6  | 36 to 40 |
| High tension lead clip to cover — Flange headed<br>setscrew . . . . .                                       | M6                    | 8 mm                  | 9,5 to 12,2  | 0,98 to 1,26 | 7 to 9   |
| Hose to air pipe — Clip . . . . .   | M6                    | 8 mm                  | 2,4  | 0,24         | 1,75     |
| Hose to backplate and air pipe — Clip . . . . .   | M6                    | 8 mm                  | 2,4  | 0,24         | 1,75     |
| Hose to EA valve — Clip . . . . .   | M6                    | 8 mm                  | 2,4  | 0,24         | 1,75     |
| Hose to elbow — Clip . . . . .  | M6                    | 8 mm                  | 2,4  | 0,24         | 1,75     |
| Hose to housing — Clip . . . . .  | M6                    | 8 mm                  | 2,4  | 0,24         | 1,75     |
| Hose to pipe — Clip . . . . .   | M6                    | 8 mm                  | 2,4  | 0,24         | 1,75     |
| Housing to cylinder block — Flange headed setscrew  | M8                    | 10 mm                 | 23 to 27   | 2,38 to 2,8  | 17 to 20 |
| Housing to cylinder block — Flange headed bolt . . .  | M8                    | 10 mm                 | 23 to 27   | 2,38 to 2,8  | 17 to 20 |

| DESCRIPTION  | THREAD SIZE          | SPANNER SIZE         | TIGHTENING TORQUE |              |            |
|--|----------------------|----------------------|-------------------|--------------|------------|
|  |                      |                      | Nm                | kgf/cm       | lbf/ft     |
| Housing to cylinder block — Capscrew . . . . .                                   | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Housing to cylinder head — Flange headed bolt . . .                              | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Housing to cylinder block — Flange headed setscrew                               | M6                   | 8 mm                 | 9,5 to 12,2       | 0,98 to 1,26 | 7 to 9     |
| Housing to cylinder head — Flange headed setscrew                                | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Induction manifold to head — Flange headed bolt . .                              | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Induction manifold to head — Nut . . . . .                                       | M8                   | 13 mm                | 12 to 16          | 1,26 to 1,66 | 9 to 12    |
| Inlet elbow — Flange headed setscrew . . . . .                                   | M6                   | 8 mm                 | 9,5 to 12,2       | 0,98 to 1,26 | 7 to 9     |
| Magnetic clutch assembly — Setscrew . . . . .                                    | M5                   | 8 mm                 | 5,4 to 8,1        | 0,56 to 0,83 | 4 to 6     |
| Main bearing caps — Bolt . . . . .   | M12                  | 17mm                 | 136 to 142        | 13,8 to 14,6 | 100 to 105 |
| Mounting bracket to block — Flange headed setscrew . . . . .                     | M10                  | 13 mm                | 49 to 54          | 5,04 to 5,6  | 36 to 40   |
| Mounting bracket to timing cover —<br>Flange headed setscrew . . . . .           | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Mounting bracket to timing cover and block —<br>Flange headed setscrew . . . . . | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Oil drilling blank — Setscrew . . . . .  | M8                   | 6 mm                 | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Oil filler housing — Flange headed setscrew . . . . .                            | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Oil filler to support bracket — Flange headed setscrew                           | M6                   | 8 mm                 | 9,5 to 12,2       | 0,98 to 1,26 | 7 to 9     |
| Oil filter can . . . . .   | 1 in UNF             | —                    | 8,1               | 0,83         | 6          |
| Oil filter head — Threaded insert . . . . .                                      | 1 in UNF             | —                    | 8,1               | 0,83         | 6          |
| Oil gallery blank — Setscrew . . . . .   | $\frac{3}{8}$ in UNC | $\frac{9}{16}$ in AF | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Oil pick-up to carrier — Flange headed setscrew . . .                            | M6                   | 8 mm                 | 9,5 to 12,2       | 0,98 to 1,26 | 7 to 9     |
| Oil pipe carrier to cylinder block — Flange headed bolt                          | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Oil pump to cylinder block — Flange headed bolt . . .                            | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Oil sump to cylinder block — Flange headed bolt . . .                            | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Oil sump to timing cover — Flange headed bolt . . . .                            | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Pedestal to body . . . . .   | M6                   | 8 mm                 | 9,5 to 12,2       | 0,98 to 1,26 | 7 to 9     |
| Pipe to manifold — Flange headed setscrew . . . . .                              | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Pivot bracket to cylinder block — Bolt . . . . .                                 | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Pivot plate to cylinder block — Bolt . . . . .                                   | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Plate to adaptor — Taptite screw . . . . .                                       | M5                   | 8 mm                 | 5,4 to 8,1        | 0,56 to 0,83 | 4 to 6     |
| Plate to timing cover — Setscrew . . . . .                                       | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Plate to timing cover — Setscrew . . . . .                                       | M6                   | 8 mm                 | 9,5 to 12,2       | 0,98 to 1,26 | 7 to 9     |
| Pressure regulator to fuel rail — Thin nut . . . . .                             | M16                  | 24 mm                | 10,8              | 1,12         | 8          |
| Pump to adaptor — Flange headed setscrew . . . . .                               | M10                  | 13 mm                | 49 to 54          | 5,04 to 5,6  | 36 to 40   |
| Pump to engine — Flange headed setscrew . . . . .                                | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| Rail to cylinder block — Flange headed setscrew . . .                            | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |
| RR cover to cylinder head — Flange headed setscrew                               | M8                   | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20   |

| DESCRIPTION  | THREAD SIZE        | SPANNER SIZE         | TIGHTENING TORQUE |              |          |
|--|--------------------|----------------------|-------------------|--------------|----------|
|  |                    |                      | Nm                | kgf/cm       | lbf/ft   |
| Rear pivot to mounting bracket — Flange headed setscrew . . . . .            | M10                | 13 mm                | 49 to 54          | 5,04 to 5,6  | 36 to 40 |
| Retainer bracket — Flange headed setscrew . . . . .                          | M6                 | 8 mm                 | 9,5 to 12,2       | 0,98 to 1,26 | 7 to 9   |
| Relief valve — Access plug . . . . .   | M42                | 42mm                 | 68 to 75          | 6,9 to 7,66  | 50 to 55 |
| Selector lever to shaft — Nut . . . . .                                      | M10                | 17 mm                | 49 to 54          | 5,04 to 5,6  | 36 to 40 |
| Sleeve to adjustment bolt — Nut . . . . .                                    | $\frac{3}{8}$ UNF  | $\frac{9}{16}$ in AF | 12,2 to 13,6      | 1,26 to 1,4  | 9 to 10  |
| Sleeve to alternator — Flange headed bolt . . . . .                          | M8                 | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Sleeve to pump — Flange headed setscrew . . . . .                            | M8                 | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Sprocket to hub — Setscrew . . . . .   | M6                 | 8 mm                 | 9,5 to 12,2       | 0,98 to 1,26 | 7 to 9   |
| Starter motor to adaptor — Flange headed bolt . . . . .                      | M10                | 13 mm                | 49 to 54          | 5,04 to 5,6  | 36 to 40 |
| Stiffener plate to adaptor — Flange headed setscrew                          | M10                | 13 mm                | 49 to 54          | 5,04 to 5,6  | 36 to 40 |
| SA valve to air pipe hose — Clip . . . . .                                   | M6                 | 8 mm                 | 2,4               | 0,24         | 1,75     |
| Temperature switch (air injection only) . . . . .                            | M6                 | 8 mm                 | 9,5 to 12,2       | 0,98 to 1,26 | 7 to 9   |
| Thermo time switch . . . . .   | M14                | 24 mm                | 15                | 1,55         | 11       |
| Throttle body to manifold — Setscrew . . . . .                               | M8                 | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Throttle spindle assembly — Nut . . . . .                                    | $\frac{5}{16}$ UNF | $\frac{1}{2}$ in AF  | 4,1               | 0,42         | 3        |
| Throttle spindle assembly — Setscrew . . . . .                               | $\frac{1}{8}$ WHIT | 2 BA                 | 0,17              | 0,017        | 0,125    |
| Throttle switch — Setscrew . . . . .   | M4                 | 7 mm                 | 0,45              | 0,045        | 0,33     |
| Timing cover to cylinder block — Flange headed bolt                          | M8                 | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Timing disc to damper — Flange headed setscrew . . . . .                     | M6                 | 8 mm                 | 9,5 to 12,2       | 0,98 to 1,26 | 7 to 9   |
| Timing indicator — Setscrew . . . . .  | M8                 | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Trans adaptor — Flange headed bolt . . . . .                                 | M10                | 13 mm                | 49 to 54          | 5,04 to 5,6  | 36 to 40 |
| Trans adaptor — Flange headed setscrew . . . . .                             | M10                | 13 mm                | 49 to 54          | 5,04 to 5,6  | 36 to 40 |
| Transfer unit to adaptor — Bolt . . . . .                                    | M10                | 13 mm                | 49 to 54          | 5,04 to 5,6  | 36 to 40 |
| Water drain cylinder block — Plug . . . . .                                  | M20                | 30 mm                | 75 to 81          | 7,66 to 8,4  | 55 to 60 |
| Water pump and timing cover to cylinder block — Flange headed bolt . . . . . | M8                 | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |
| Water pump to rail — Hose clip . . . . .                                     | M6                 | 8 mm                 | 2,4               | 0,24         | 1,75     |
| Water temperature sensor . . . . .   | M12                | 19 mm                | 13,6              | 1,4          | 10       |
| Windage tray — Flange headed setscrew . . . . .                              | M8                 | 10 mm                | 23 to 27          | 2,38 to 2,8  | 17 to 20 |

## ENGINE FAULT FINDING

| SYMPTON   | POSSIBLE CAUSE                                     | CHECK   | REMEDY   |
|---|--|---|--|
| Engine spits back into air box                  | Excessively weak mixture                           | Check CO reading of gases leaving the exhaust pipe  | Adjust mixture   |
|   | Air leaking into induction manifold                | Listen for leaks (whistling), spray 'easy start' around suspect area, the engine speed will increase if there is an air leak  | Replace gasket or manifold   |
| Engine backfires                                | Air leakage into/from the exhaust system           | Check for leaks or blows in the system  | Repair leaks or replace system if necessary                                |
|   | Leakage past valves and guides                     | Check HC reading of exhaust gases and also check for crankcase fumes  | Remove the cylinder head and overhaul                                      |
|   | Ignition timing retarded                           | Check ignition timing   | Adjust ignition timing   |
|   | Mixture too weak                                   | Check CO level from exhaust pipe  | Adjust mixture   |
|   | Incorrect valve timing                             | Check camshaft timing   | Adjust camshaft timing   |
|   | Valves sticking open                               | Check valve clearances  | Adjust valve clearances  |
|   |  | Check for wear or gum in valve guides   | Replace guides or decarbonise the cylinder head                            |
|   |  | Check for poor seating of valves  | Overhaul the cylinder head   |
| Engine fails to idle                            | Insufficient air supply from idle adjustment screw | Ensure the screw is not wound right in  | Wind the screw out until engine idles satisfactorily                       |
|   | Incorrect ignition timing                          | Check ignition timing   | Adjust ignition timing   |
|   | Valve clearances insufficient                      | Check clearances  | Adjust clearances  |
|   | Faulty cylinder head gasket                        | Check for leaks into the oil and water  | Replace the gasket   |
|   | Exhaust system blocked                             | Check for restrictions  | Remove the restrictions or replace components as necessary                 |
| Engine fails to rotate when attempting to start | Battery leads loose or terminals corroded          | Check the condition of the leads and terminals  | Clean and tighten as necessary   |
|   | Battery discharged                                 | Check condition of battery with hydrometer  | Charge or replace as necessary   |
|   | Starter motor inoperative                          | If the lights dim when ignition switch is operated, the starter may be jammed in the starter ring gear  | Remove starter motor, free off pinion and refit                            |
|   |  | Check for loose and dirty connections to the starter motor  | Clean/tighten and/or replace as necessary                                  |
| Engine rotates but will not fire                | Starter motor speed too low                        | Check battery leads and terminals   | Tighten and clean leads as necessary                                       |
|   |  | Check the state of the battery charge   | Charge battery or fit replacement  |
|   | Faulty ignition system                             | Using plug load pliers, hold the plug lead approximately 16 mm from the cylinder head and crank the engine, check that a good blue spark jumps the gap between the end of the plug lead and the cylinder head | If no spark, a yellow or white spark is evident, check the ignition system |
|   |  | If the spark is adequate, remove the sparking plugs   | Clean and regap the sparking plugs, replace if worn out                    |

| SYMPTOM         | POSSIBLE CAUSE  | CHECK   | REMEDY   |
|-----------------|---|---|--|
|                 | Fuel system defect  | Remove cold start injector, connect the white and green wires to earth. Crank the engine and check that fuel is emitted from the injector (ensure a suitable receptacle is available to collect the fuel) | If no fuel is emitted, refer to fuel injection section |
| Overheating     | Thermostat stuck closed   | Remove thermostat and carry out boiling water check   | Change thermostat                                      |
|                 | Faulty gauge  | Check with fast check equipment   | Fit new gauge  |
|                 | Faulty transmitter  | If other equipment in circuit OK fit new transmitter  | Fit new transmitter                                    |
|                 | Radiator blocked  | Check for uneven heat in radiator, i.e. hot and cold spots plus water emission from overflow pipe   | Flush or change radiator                               |
|                 | Too high concentration of anti-freeze                           | Remove the header tank cap and check concentration with a hydrometer  | Drain coolant and fill with correct concentration      |
|                 | Fan belt slack  | Check tension   | Retension the belt                                     |
|                 | Fan belt broken   | Open bonnet and check visually  | Fit new belt   |
|                 | Water pump seized   | Remove drive belt and turn pulley   | Change water pump                                      |
|                 | Insufficient coolant  | Remove header tank cap and check coolant level visually   | Top-up coolant   |
|                 | Incorrect ignition timing                                       | Check ignition timing   | Adjust ignition timing                                 |
|                 | Fuel/air mixture too weak                                       | Check CO/HC levels  | Adjust mixture   |
|                 | Incorrect thermostat  | Remove thermostat and visually check temperature reading  | Change thermostat                                      |
|                 | Collapsed hoses   | Start engine, run until normal temperature is attained and visually check the hoses for collapsing  | Fit new hoses  |
|                 | Cylinder head gasket leaking                                    | Remove head tank cap, fill tank with water. Run engine until hot, rev engine and return to idle; check for bubbles in water   | Change head gasket                                     |
|                 | Incorrect valve timing  | Check valve timing with Service Tool 18G 1433   | Reset valve timing                                     |
|                 | Cylinder block waterways restricted/<br>restricted coolant flow |   |  |
|                 | Radiator cap spring weak  | Fit cap to pressure testing equipment and check spring release pressure   | Fit new cap  |
| At tick over    | Viscous fan free wheeling                                       | Run engine and visually check that the large fan is turning   | Fit new viscous coupling                               |
| No oil pressure | Oil pump drive chain broken/not fitted                          | Remove sump and check visually  | Fit new chain  |
|                 | Faulty gauge  | Check with fast check equipment   | Change gauge   |
|                 | No oil in sump  | Dip oil   | Fill with oil  |
|                 | Blocked pick-up pipe strainer                                   | Remove sump and pick-up pipe  | Clean pick-up strainer                                 |



| SYMPTON                         | POSSIBLE CAUSE                      | CHECK  | REMEDY   |
|---------------------------------|-------------------------------------|--|--|
| Too cold                        | Thermostat stuck open               | Remove thermostat  | Fit new thermostat                                       |
|                                 | Auxiliary fan remains operational   | Check relay circuit<br>Check radiator fan thermostat<br>Check diode  | Fit new relay<br>Fit new fan thermostat<br>Fit new diode |
|                                 | Faulty gauge                        | Check with fast check equipment  | Change gauge   |
|                                 | Faulty transmitter                  | If all other equipment OK, fit new transmitter   | Fit new transmitter                                      |
|                                 | Thermostat missing                  | Remove thermostat housing  | Fit new thermostat                                       |
|                                 | Wrong temperature rated thermostat  | Remove thermostat housing and visually check rate  | Fit correct thermostat                                   |
| Loosing oil (leaking)           | Worn front oil seal                 | Wipe clean, run engine and visually check  | Fit new seal   |
|                                 | Worn rear oil seal                  | Wipe bell housing clean, run engine and visually check   | Remove gearbox and fit new seal                          |
|                                 | Leaking gaskets                     | Visual (except head gasket see head gasket blown)  | Change gasket or reseal                                  |
|                                 | Cylinder block cracked              | Visual   | Change cylinder block                                    |
| Detonation knock (pinking)      | Ignition timing too far advanced    | Check ignition timing  | Reset ignition timing                                    |
|                                 | Head gasket blown                   | Dip engine oil and check for ingress of water. Remove header tank cap, rev engine and check for bubbles in water | Change head gasket                                       |
|                                 | Thermostat stuck (shut) overheating | Remove thermostat and carry out boiling water test   | Fit new thermostat                                       |
|                                 | Mixture too weak                    | Check with CO/HC meter   | Adjust mixture   |
|                                 | No water in engine/radiator         | Remove header tank cap and check water level   | Fill with water  |
|                                 | Engine running too hot              | —  | See overheating fault finding                            |
|                                 | Valve timing incorrect              | Check valve timing   | Adjust valve timing                                      |
|                                 | No water in engine/radiator         | Remove header tank cap and check water level   | Fill with water  |
|                                 | Engine running too hot              | —  | See overheating fault finding                            |
|                                 | Valve timing incorrect              | Check valve timing   | Adjust valve timing                                      |
|                                 | Incorrect octane fuel               | If all other checks OK, this could be the cause  | Fill with correct octane fuel                            |
| Excessive noise from valve gear | Excessive valve clearance           | Check valve clearances   | Adjust valve clearances                                  |
|                                 | Broken valve spring(s)              | Remove valves and check springs  | Replace as necessary                                     |
|                                 | Broken valve guide                  | Remove valves and check guides   | Replace as necessary                                     |
|                                 | Broken valve seat insert            | Remove valves and check inserts  | Replace as necessary                                     |
|                                 | Lack of lubrication                 | Check oil pressure   | See insufficient oil pressure fault finding              |
|                                 | Valve clash                         | Check valve timing   | Adjust valve timing                                      |

| SYMPTON                   | POSSIBLE CAUSE                                    | CHECK   | REMEDY  |
|---------------------------|---|---|---|
|                           | Worn camshafts                                    | Valve clearances and lack of lubrication                                      | Adjust valve clearances — see insufficient oil pressure   |
|                           | Worn camshaft drive chains/tensioners             | Remove front timing cover and check for wear                                  | Replace as necessary                                      |
| Insufficient oil pressure | Oil requires changing                             | Dip oil, check colour and viscosity   | Change oil  |
|                           | Main oil gallery seals leaking or gallery blocked | If all other checks OK, this could be a cause                                 | Fit new 'O' rings or clear oil gallery                    |
|                           | Worn crankshaft journals                          | Listen for rumble or knock  | Change crankshaft   |
|                           | Excessive crankshaft endfloat                     | Fit dial gauge and measure  | Remove sump and fit oversize thrust washers               |
|                           | Worn main bearing shells                          | Listen for rumble   | Check crankshaft journals for wear and fit new shells     |
|                           | Worn oil pump                                     | Remove oil pump and check the clearances                                      | Fit new oil pump  |
|                           | Oil cooler valve stuck shut                       |   |   |
|                           | Oil pressure relief valve sticking open           | Remove valve and check for sticking   | Fit new valve   |
|                           | Oil pressure relief valve spring too weak         | Remove spring and check spring rates  | Fit new spring  |
|                           | Insufficient oil in sump                          | Dip oil   | Top-up as required  |
|                           | Faulty gauge                                      | Check gauge with fast check equipment   | Fit new gauge   |
|                           | Engine overheating                                | —   | See overheating fault finding                             |
|                           | Wrong specification oil (too thin)                | Dip oil and check viscosity   | Change oil and filter                                     |
|                           | Water in oil                                      | Dip oil and check if oil is a milky white colour                              | Change oil and check for blown head gasket                |
|                           | Cracked oil pump housing                          | Remove the sump and check visually  | Change the pump   |
|                           | Blocked oil pick-up pipe strainer                 | Remove sump and check visually  | Remove oil pick-up pipe and clean strainer                |
|                           | Oil pump pipe 'O' rings leaking or missing        | Remove sump and pipes and check 'O' ring condition                            | Fit new 'O' rings   |
| Oil pressure too high     | Relief valve stuck shut                           | Remove valve and check for sticking   | Clean or replace the valve                                |
|                           | Wrong pressure relief valve spring                | Remove spring and check the rate  | Fit new spring  |
|                           | Incorrect grade engine oil                        |   | Drain engine oil and fill with correct oil                |
|                           | Gauge or transmitter fault                        | Check gauge with fast check equipment, if OK fit new transmitter              | Fit new gauge or transmitter                              |
|                           | Engine temperature too low                        | Check operation of the thermostat (stuck open) or oil cooler valve stuck open | Fit new thermostat or valve                               |
| Loss of power             | Burned valves                                     | Check compressions  | Remove cylinder head and change valves                    |
|                           | Sticking valves                                   | Check compressions  | Remove cylinder head and replace valves/guides or springs |

| SYMPTON   | POSSIBLE CAUSE                  | CHECK  | REMEDY  |
|---|---------------------------------|--|---|
|   | Poor engine tune                | Check engine tune  | Adjust as necessary   |
|   | Insufficient valve clearance    | Check valve clearance  | Adjust as necessary   |
|   | Fuel injection fault            | Refer to fuel injection section  |   |
|   | Low compression in cylinders    | Check compressions   | Rebore/rering as necessary  |
|   | Ignition fault                  | Refer to electrical section  |   |
|   | Camshaft timing incorrect       | Check camshaft timing using Service Tool 18G 1433  | Adjust camshaft timing  |
|   | Incorrect grade fuel            |  | Drain fuel and refill with correct octane   |
|   | Partial seizure of engine       | Remove spark plugs and rotate engine   | Overhaul engine as necessary  |
|   | Worn camshaft                   | Remove camshaft and check for wear   | Replace camshaft  |
| Rough running normal engine speed (less than 6 cylinders) | Sticking valves                 | Check compressions   | Change valves, springs or guides  |
|   | Broken valve springs            | Check compressions   | Change valve springs and check for bent valves  |
|   | Piston fault                    | Check compressions   | Change pistons  |
|   | Head gasket blown               | Check compressions and water level   | Change head gasket  |
|   | Valve burned out                | Check compressions   | Change valve  |
|   | Valve seat burned out           | Check compressions   | Cut or change valve seat  |
|   | Ignition fault                  | Refer to electrical section  |   |
|   | Fuel injection fault            | Refer to fuel injection section  |   |
|   | Air leaking into inlet manifold | Run engine and listen for whistling spray easy start around suspect area. If engine speed increases, confirmed | Change gasket or manifold   |
|   | Blowing exhaust                 | Run engine and check for leaks   | Repair leak or change exhaust   |
| Noisy Chains  | Low oil pressure                | Take reading from gauge when engine is hot   | See insufficient oil pressure   |
|   | Tensioners not released         | Remove camcover and check tension of chain (top chain). Remove timing cover to check bottom chain tension      | Insert 3 mm Allen key and turn tensioner anti-clockwise, compress tensioner to release bottom chain |
|   | Chains worn                     | Check visually/remove and check for wear   | Replace as necessary  |
|   | Sprockets worn                  | Check visually   | Replace as necessary  |
|   | Tensioner worn                  | Check visually   | Replace as necessary  |
| Rough idle  | Valve timing incorrect          | Check camshaft timing using Service Tool 18G 1433  | Adjust camshaft timing  |
|   | Incorrect mixture               | Check CO/HC reading for exhaust  | Adjust mixture  |
|   | Incorrect ignition timing       | Check ignition timing  | Adjust ignition timing  |
|   | Valve clearances insufficient   | Check valve clearances   | Adjust valve clearances   |

## ENGINE

| SYMPTON     | POSSIBLE CAUSE  | CHECK  | REMEDY  |
|-------------|---|--|---|
|             | Valve burned out<br>Ignition fault<br>Fuel injection fault  | Check compressions<br>Refer to electrical section<br>Refer to fuel injection section   | Change valve  |
| Burning oil | Worn cylinder bores<br>Worn valve guides<br>Worn inlet valve seals<br>Worn piston rings<br>Leaking cylinder head gasket<br>Engine oil wrong specification | Check wear with a comparitor<br>Insert valve in guide and check side movement<br>Remove seals and check for splits or wear<br>Measure rings in bore<br>Check for blue smoke from exhaust | Rebore cylinders as necessary<br>Change valve guides as necessary<br>Replace in sets<br>Replace rings in sets and rebore as necessary<br>Replace head gasket<br>Drain oil and refill with the correct viscosity |

## TIMING CHAINS, DAMPERS, TENSIONERS AND SPROCKETS

### Overhaul

Depressurise the fuel system, remove the bonnet and drain the coolant.

Remove the cylinder head assembly.

Drain the engine oil, remove the crankshaft damper (1, Fig. 1), timing cover (2, Fig. 1) and remove the upper timing chain.




Fig. 1

Remove the lower timing chain tensioner (1, Fig. 2), the intermediate sprocket (2, Fig. 2), remove the oil pump drive chain and damper (3, Fig. 2) and remove the lower timing chain (4, Fig. 2).




Fig. 2

Remove the crankshaft sprocket (5, Fig. 2) and all remaining dampers and spacers (6, Fig. 2).




Fig. 3

Remove the oil seal (1, Fig. 3) from the power assisted steering end of the distributor drive gear shaft using Service Tool 18G 1468. Remove the shaft securing circlip (2, Fig. 3), the drive gear sprocket and thrust washer. Remove the three distributor drive gear housing bearing set screws (3, Fig. 3), remove the housing (4, Fig. 3) and discard the gasket.




Fig. 4

Inspect all the components for wear, chipped teeth or wear marks on the gears and chains for stretch or picking up. The checking of stretch is demonstrated in Fig. 4, the second check for the chain is to pull it slowly over an outstretched forefinger, the chain should run evenly over the finger, if it picks up or runs jerkily over the finger, the chain should be changed; if any of the components are suspect then they must be renewed.




Fig. 5

Check the hydraulic tensioners for wear and scored bores, the spring for tension and also that the oil feed hole (1, Fig. 5) is clear in the end of the piston.

Check the dampers for wear; if any rubber surface has been broken by the chain the component must be replaced.




Fig. 6

Check the crankdamper/oil seal spacer for grooving and ensure that the wear does not exceed the limits set.

Locate the legs of service tool (1, Fig. 6)




Fig. 7

18G 1434 behind the centre bearing shell in the centre of the cylinder block (1, Fig. 7). Pull the centre peg outward (1, Fig. 8) and tighten the nut (2, Fig. 8) until the bearing and tool (2, Fig. 6) appear from the cylinder block.

All component sizes and tolerances are listed below.




Fig. 8

Remove the remaining bushes from the front cover and distributor drive shaft housing, using Service Tool 18G 1434. Fit new bushes using Service Tool 18G 1434(4) ensuring that the oil feed holes in the bushes are lined up with the holes (1, Fig. 9) in the cylinder block.




Fig. 9

Apply 'Hylsil' to the timing cover blanking plates and fit the plates to the cover.

Fit a new gasket to the distributor drive gear housing, align and fit the housing to the cylinder block, apply 'Hylomar' to the securing screws, fit and tighten. Clean the drive gear and thrust washer, lubricate the shaft and fit the shaft to the housing, fit the thrust washer and secure with a circlip. Lubricate the oil seal mounting face and the outer edge of the seal and using Service Tool 18G 1469 (1, Fig. 10), fit and seat the oil seal (2, Fig. 10).

**NOTE:** Under no circumstances must the seal insert be removed prior to fitting the seal.




Fig. 10

Assemble the lower pivoting damper (1, Fig. 11) to the spacers, tab washer, bracket and securing bolts (2, Fig. 11), and fit the assembly to the engine.

Refit the lower timing chain (3, Fig. 11), sprockets (4, Fig. 11) and dampers (5, Fig. 11), refit and release the lower timing chain tensioner (6, Fig. 11).




Fig. 11

Refit the upper timing chain (7, Fig. 11), place between the guides and secure with an elastic band (8, Fig. 11).




Fig. 12

Refit the oil pump drive chain and damper. Coat the mating face of the timing cover with 'Hylsil'. Refit the timing cover (1, Fig. 12), the oil seal/crankshaft spacer and crankshaft damper assembly. Refit the cylinder head.

## Camshaft Sprocket

|   |   |
|---|---|
| No. of teeth                                      | 30  |
| Pitch of teeth                                    | 9,525 mm (0.375 in)                             |
| Pitch circle diameter                             | 91,135 mm (3.588 in)                            |
| Internal serrations                               | 131   |
| Pitch circle diameter                             | 66,675 mm (2.625 in)                            |
| Pitch of teeth                                    | 1,60 mm (0.063 in)                              |
| O/D of sprocket                                   | 95,25 mm $\pm$ 0,050 mm (3.75 in $\pm$ .002 in) |
| Total width                                       | 18,653 mm ( $\frac{47}{8}$ in)                  |
| Total width across both teeth                     | 15,341 to 15,570 mm (0.604 to 0.613 in)         |
| Concentricity of teeth and sprocket not to exceed | 0,076 mm (0.003 in)                             |

## Crankshaft Sprocket

|  |  |
|--|--|
| No. of teeth                                       | 21                                     |
| Pitch  | 9,525 mm (0.375 in)                    |
| Pitch circle diameter                              | 63,906 mm (2.516 in)                   |
| Root diameter                                      | 57,556 mm (2.266 in)                   |
| Roller diameter                                    | 6,35 mm (0.25 in)                      |
| Measured over $\varnothing$ 6,35 mm (0.25 in) pins | 70,008 to 69,95 mm (2.759 to 2.754 in) |
| Tooth profile cut to                               | BS228                                  |
| Internal diameter                                  | 42,875 to 42,857 mm                    |
| Overall diameter                                   | 67,87 to 67,77 mm                      |
| Width across 1 tooth                               | 5,33 to 5,10 mm                        |
| Width across all the teeth                         | 38,43 to 38,0 mm                       |
| Width across 2 teeth (timing chain)                | 15,57 to 15,34 mm                      |

## Crankshaft damper oil seal spacer

|                  |  |
|------------------|--|
| Inside diameter  | 42,875 to 42,860 mm (1.688 to 1.6874 in) |
| Outside diameter | 57,00 to 51,81 mm (2.047 to 2.040 in)    |
| Width            | 17,1 to 16,9 mm                          |

## Intermediate shaft bush

|                               |   |
|-------------------------------|---|
| Inside diameter (when fitted) | 22,010 to 21,964 mm (0.8665 to 0.8647 in) |
| Outside diameter              | 25,083 to 25,057 mm (0.9875 to 0.9865 in) |
| Width                         | 17,25 to 16,25 mm (0.679 to 0.659 in)     |
| Press fit                     | 0,036 to 0,083 mm (0.0015 to 0.0033 in)   |
| Shaft size                    | 22 mm (0.8645 to 0.8637 in)               |
| Running clearance             | 0,071 to 0,005 mm (0.0028 to 0.0002 in)   |
| Material                      | Vandervell No. L10083/3                   |

## Intermediate sprocket inner teeth

|   |                                       |
|---|---------------------------------------|
| Number of teeth                                       | 28                                    |
| Pitch   | 9,525 mm (0.375 in)                   |
| Pitch circle diameter                                 | 85,063 mm (3.349 in)                  |
| Root diameter   | 78,7 mm (3.099 in)                    |
| Roller diameter                                       | 6,35 mm (0.25 in)                     |
| Measurement over $\varnothing$ 6,35 mm (0.25 in) pins | 91,41 to 91,29 mm (3.599 to 3.594 in) |
| Tooth profile cut to                                  | BS228                                 |
| Width across the depth                                | 15,57 to 15,34 mm (0.613 to 0.604 in) |
| Overall diameter                                      | 89,2 to 89,1 mm (3.512 to 3.508 in)   |

## Intermediate sprocket outer teeth

|   |                                       |
|---|---------------------------------------|
| Number of teeth                                       | 20                                    |
| Pitch   | 9,525 mm (0.375 in)                   |
| Pitch circle diameter                                 | 60,884 mm (2.397 in)                  |
| Root diameter   | 54,53 mm (2.147 in)                   |
| Roller diameter                                       | 6,35 mm (0.25 in)                     |
| Measurement over $\varnothing$ 6,35 mm (0.25 in) pins | 67,23 to 67,11 mm (2.647 to 2.642 in) |
| Tooth profile cut to                                  | BS 228                                |
| Overall diameter                                      | 65,07 to 64,97 mm (2.562 to 2.558 in) |
| Width across both teeth                               | 15,57 to 15,34 mm (0.613 to 0.604 in) |
| Total width of sprocket                               | 48,8 to 48,7 mm (1.921 to 1.917 in)   |

Refit the thermostat housing and the air cleaner element. Refill the engine with oil and coolant, adjust the ignition timing and refit the bonnet.



**Primary timing chain**

|                 |                      |
|-----------------|----------------------|
| Pitches         | 80                   |
| Roller diameter | 6,35 mm (0.25 in)    |
| Pitch           | 9,525 mm (0.375 in)  |
| Type            | Endless duplex chain |

**Secondary timing chain**

|                 |                      |
|-----------------|----------------------|
| Pitches         | 86                   |
| Roller diameter | 6,35 mm (0.25 in)    |
| Pitch           | 9,525 mm (0.375 in)  |
| Type            | Endless duplex chain |

**Oil pump chain**

|                 |                       |
|-----------------|-----------------------|
| Pitches         | 52                    |
| Roller diameter | 6,35 mm (0.25 in)     |
| Pitch           | 9,525 mm (0.375 in)   |
| Type            | Endless simplex chain |

**Dampers and tensions**

|                  |        |            |
|------------------|--------|------------|
| Backing material | Steel  | BS1449 CR4 |
| Damper material  | Rubber |            |

**Hydraulic chain tension housing**

|               |                                       |
|---------------|---------------------------------------|
| Bore diameter | 21,38 to 21,36 mm (0.842 to 0.841 in) |
|---------------|---------------------------------------|

**Hydraulic chain tensioner**

|  |   |
|--|---|
| Overall length                               | 45 mm (1.771 in)                          |
| Overall length to bottom of groove in piston | 41 mm (1.614 in)                          |
| Diameter                                     | 21,349 to 31,336 mm (0.8405 to 0.8400 in) |
| Width of groove in piston                    | 15 mm (0.59 in)                           |
| Non return valve primary ball diameter       | 4,762 mm (0.1875 in)                      |
| Ball free movement                           | 0,74 to 0,45 mm (0.29 to 0.18 in)         |

**Non return valve secondary**

|                    |                                     |
|--------------------|-------------------------------------|
| Ball diameter      | 4,762 mm (0.1875 in)                |
| Ball free movement | 0,74 to 0,45 mm (0.029 to 0.018 in) |

**OIL FILTER HEAD GASKET****Renew**

Place suitable drain tin under the oil filter. Remove the oil filter cartridge (1, Fig. 13), remove the oil cooler pipe clamp nut and clamp, note the position of, and disconnect the pipes from the oil supply housing, remove and discard the 'O' rings. Remove the oil filter head securing bolts (2, Fig. 13) and remove the inner (3, Fig. 13) and outer (4, Fig. 13) housings. Thoroughly clean the housings, the oil cooler pipes and the cylinder block face.

Apply 'Hylosil' to the outer housing (4, Fig. 13), align the inner housing (3, Fig. 13) with the outer housing, fit the securing bolts to the housing assembly, apply 'Hylosil' to the inner housing, align the assembly to the aperture in the cylinder block and tighten the securing bolts (2, Fig. 13).

Fit new 'O' rings to the oil cooler pipes, lubricate and connect the pipes to the housing, fit the clamp plate, fit a new oil filter (1, Fig. 13), start engine, wait for oil pressure light to extinguish, switch off engine and let stand for 30 seconds; check the engine oil level and top-up as necessary.




Fig. 13

**OIL SUMP****Renew**

Remove the air cleaner element, the alternator, the front crossmember and drain the engine oil. Position the steering rack to allow access to the sump securing bolts. Remove the dipstick tube and the adaptor plate to sump securing bolts and the sump securing bolts (1, Fig. 14) leaving two loose. Remove the engine earth strap, the remaining sump bolts and lower the sump (2, Fig. 14).

Apply 'Hylosil' to the new sump and clean the gasket face on the cylinder block (3, Fig. 14). Lift the sump (2, Fig. 14) into position and secure with the bolts (1, Fig. 14). Fit the engine earth strap and adaptor plate. Refit the dipstick tube. Reposition the steering rack under the sump and refit the front crossmember, the alternator and the air cleaner. Refill the engine with oil.




Fig. 14

**OIL PRESSURE SWITCH/TRANSMITTERS****Renew**

Remove the air cleaner element, disconnect the feed wire (1, Fig. 15, 16) and remove the switch (2, Fig. 15, 16).

Fit the new switch to the cylinder block, reconnect the feed wire and air cleaner element. Start the engine and ensure that either the oil pressure warning light extinguishes or the pressure gauge is operating.

**NOTE:** Oil pressure transmitter Fig. 16 and oil pressure warning light Fig. 15.




Fig. 15




Fig. 16

## OIL FILTER CANISTER

### Renew

Place a suitable drain tin under the filter and remove the filter canister (1, Fig. 17). Clean the oil filter mounting face, lubricate the rubber seal on the new filter with clean engine oil. Fit and tighten the filter canister using only the hand pressure and on no account use an oil filter strap designed for removal of canisters. Start the engine, wait for the oil light to extinguish, switch engine off, wait for 30 seconds, check the oil level and top-up as necessary.

**NOTE:** Normal tightening torque of oil filter is:  $\frac{3}{8}$  to  $\frac{1}{2}$  turn after initial contact.

### Canister Specification

|                                  |   |
|----------------------------------|---|
| Maximum working pressure         | 100 lb/in <sup>2</sup>  |
| Relief valve setting             | 0.9 to 1.1 kgf/cm <sup>2</sup> (13 to 16 lb/in <sup>2</sup> ) |
| Canister to withstand            | 17.60 kgf/cm <sup>2</sup> (250 lb/in <sup>2</sup> ) pressure  |
| Element filtration area          | 3555 cm <sup>2</sup> (551 in <sup>2</sup> )                   |
| Canister diameter                | 95.70 mm (3.768 in)   |
| Canister length                  | 148.00 to 145.50 mm (5.827 to 5.728 in)                       |
| Canister case material thickness | 24 SWG  |
| Adaptor thread                   | 1 in 12UNF — 2B   |

## OIL COOLER

### Renew

Remove the horn/bracket assembly, place a drain tray beneath the oil cooler and position a splash guard to prevent oil splashing through the front radiator grille. Slacken and remove the oil cooler pipe unions to drain the oil. Remove the oil cooler securing nuts (1, Fig. 18) and remove the cooler assembly (2, Fig. 18).

Discard the cooler pipe 'O' rings, remove the splash guard and drain tray. Clean the pipe unions.

Fit the new oil cooler (2, Fig. 18) to the mounting rubbers and start but do not tighten the oil cooler securing nuts (1, Fig. 18). Fit new 'O' rings to the cooler pipes, connect the pipes to the cooler and tighten the unions and the cooler mounting nuts.




Fig. 17

Refit the horn assembly to the vehicle and top-up the engine with oil. Run the engine and ensure there are no oil leaks.




Fig. 18

## OIL FILLER TUBE SEAL AND HOUSING GASKET

### Renew

Remove the air cleaner element, the oil filler cap (1, Fig. 19), slacken the oil filler tube to air cleaner backplate hose clips, disconnect and remove the hoses from the air cleaner backplate and manifold, remove the camshaft cover breather pipe. Remove the filler tube upper securing bolt, pull the tube (2, Fig. 19) from its lower housing (3, Fig. 19) and seal assembly (4, Fig. 19) and pull the tube down to ease removal, withdraw the tube and remove the seal from the lower housing. Remove the seal housing to cylinder block securing bolts (5, Fig. 19) and remove the housing, remove the baffle plate (6, Fig. 19), clean the housing, baffle plate, cylinder block mating face and filler tube.

Apply 'Hylosil' to the housing, align the baffle (6, Fig. 19) to the housing, apply 'Hylosil' to the baffle, fit a new filler tube seal (4, Fig. 19) to the housing and align the housing assembly (5, Fig. 19) to the cylinder block. Fit and tighten the housing securing bolts (5, Fig. 19), locate the filler tube (2, Fig. 19) in position from underneath, connect up the camshaft cover breather pipe and seat the filler tube into the lower housing. Fit and tighten the filler tube securing bolt. Connect the hoses to the manifold and air cleaner backplate, tighten all the hose clips, refit the filler cap (1, Fig. 19) and air filter. Check the engine oil level.




Fig. 19



## OIL PUMP

## Renew

Remove the air cleaner, the alternator and the front crossmember.

Drain the engine oil and remove the oil sump. Place a suitable drain tray under the oil transfer housing area and remove the transfer housing (1, Fig. 20). Remove the oil



Fig. 20




Fig. 21

pump pick-up pipes (1, Fig. 21), move the lock tabs away from the oil pump sprocket bolts (1, Fig. 22) and remove the bolts (2, Fig. 22) and remove the oil pump drive sprocket (3, Fig. 22), collecting the tab washers (4, Fig. 22) and shims.




Fig. 22

Remove the oil pump securing bolts (2, Fig. 23) and remove the pump (1, Fig. 23).



Fig. 23

Remove the oil pressure relief valve cap (1, Fig. 24), spring (2, Fig. 24), tube (3, Fig. 24) and valve (4, Fig. 24).

Clean the mating face in the cylinder block, the relief valve assembly, sprocket and shims.




Fig. 24

Lubricate the relief valve assembly and assemble into the pump and tighten the relief valve cap. Fit the oil pump to the engine and tighten the securing bolts. Move the drive chain as far rearward as possible, fit a shim pack of 0.015 in thickness to the oil pump, align the bolt holes, fit the drive sprocket and two securing bolts. Using a straight edge (1, Fig. 25), check the alignment of the oil pump drive sprocket (2, Fig. 25) and the crankshaft sprocket (3, Fig. 25). Remove and refit the pump drive




Fig. 25

sprocket as required in order to align the sprockets. When the alignment is satisfactory remove the pump sprocket, fit the chain to the sprocket and the sprocket and shims (4, Fig. 25) to the oil pump, fit the tab washer (4, Fig. 22) and bolts (2, Fig. 22), tighten the bolts and secure with the tab washer.

Fit new 'O' rings to the oil pump pick-up pipes (1, Fig. 26). Lubricate and refit the pipes to the pump. Apply 'Hylosil' to the transfer housing gasket face, fit and seat the housing (1, Fig. 20) and secure with the bolts.




Fig. 26

Refit the engine sump (1, Fig. 27), the crossmember, the alternator, the air cleaner element (Fig. 28) and refill the engine with oil.




Fig. 27



Fig. 28

## ENGINE OIL

## Drain and refill

Place a suitable tin under the sump rear drain plug, release the plug and collect the oil in the container. Clean the sump plug, remove the drain tin, fit and tighten the sump plug.

Remove the engine filler cap and refill the engine with oil. Refit the oil filler cap. Run the engine to temperature, switch the engine off. Leave for 30 seconds. Remove the dipstick and check the oil level and adjust the oil accordingly.

## OIL PUMP

## Overhaul

Remove the oil pump and remove the body securing bolts. Remove the pump body, the pump outer rotor, the backplate securing bolts, the backplate and the bearing shell, clean all the component parts of the pump. Check all the clearances and components for undue wear (Fig. 29 & 30).

Clean and lubricate all the component parts, fit the bearing shell to the housing, apply sealant to the backplate gasket face, fit the backplate and securing bolts, fit the outer rotor and refit the oil pump to the engine.




Fig. 29




Fig. 30

Outer rotor O/D  
Outer rotor width  
Inner rotor width  
Clearance outer rotor to body (Fig. 29)  
Material  
Oil pump body rotor bore  
End float (Fig. 30)  
2 horn clearance  
3 horn clearance

CYLINDER HEAD — REAR  
BLANKING PLATE GASKET

## Renew

Drain the coolant and remove the securing bolts (1, Fig. 32), disconnect the injector harness and remove the blanking plate (2, Fig. 32). Clean the blanking plate and using a straight edge check the plate for flatness. Apply 'Hylosil' to the gasket face and carefully align the plate to the cylinder head. Fit the securing bolts and 'P' clip. Reconnect the injector harness and refill the engine with coolant.

## CAMSHAFT COVER GASKETS

## Renew

Disconnect the spark plug leads, and the breather hose from the camshaft cover. Remove the seven camshaft cover securing screws (1, Fig. 31) and washers. Remove and discard the gaskets and the half moon seals from the rear of the cylinder head.

Clean the camshaft cover and the cylinder head mating face.

Apply sealant to and fit the new half moon seals to the cylinder head.

Fit new plug well seals and camshaft cover gasket (2, Fig. 31) to the camshaft cover (3, Fig. 31), fit and align the cover to the cylinder head and secure with the seven screws (1, Fig. 31) and washers.

Reconnect the breather hose to the cover and tighten the clip.

Reconnect the plug leads.




Fig. 31

## CRANKSHAFT END FLOAT

## Check and adjust

Remove the alternator, the air cleaner element, the front crossmember and drain the engine oil. Remove the engine sump, the oil pump pick-up pipes (1, Fig. 33) and remove the crankshaft windage trays (2, Fig. 33).




Fig. 33

Mount a suitable dial gauge and zero; with the use of suitable levers, measure the crankshaft endfloat; this should be 0.004 to 0.010 in.

Should the endfloat exceed this, remove the centre main bearing cap, remove the thrust washers and replace with suitable oversized thrust washers; these are available in 0.005 in and 0.010 in. These can be added to reduce the endfloat by 0.005 to 0.010 in, 0.015 in and 0.020 in (the oversizes are marked on the steel side of the thrust washer).

**NOTE:** When refitting the thrust washers, ensure that the bearing face (grooved) and not the steel side contacts the crankshaft.

Recheck the endfloat and if satisfactory, clean the main bearing cap and bearing, lubricate with clean engine oil, refit the cap and bearing assembly, remove the dial gauge and torque up the main bearing cap. Clean and fit the crankshaft windage trays. Refit the oil pump pick-up pipes with new 'O' rings, coat the engine sump mating face with sealant and refit.

Refit the crossmember, alternator and the air cleaner element.

Refill the engine with new engine oil.

69,825 to 69,774 mm (2.749 to 2.747 in)  
27,975 to 27,962 mm (1.1014 to 1.1009 in)  
27,975 to 27,962 mm (1.1014 to 1.1009 in)  
0.2 mm (0.010 in)  
Cast iron grade 12  
69,951 to 69,926 mm (2.7539 to 2.7529 in)  
0.1 mm (0.005 in)  
0.2 mm (0.010 in)  
0.2 mm (0.010 in)




Fig. 32

## CRANKSHAFT FRONT OIL SEAL

### Renew

Remove the air conditioning crankshaft drive pulley and remove the crankshaft damper (1, Fig. 34).




Fig. 34

Remove the oil seal (1, Fig. 35) from the timing cover. Remove the woodruff key and the crankshaft oil seal/crankshaft damper spacer (2, Fig. 35), clean the oil seal face, crankshaft and keyway, key and oil seal/crankshaft damper spacer. Lubricate the oil seal and fit to the front cover and




Fig. 35

ensure that the seal is flush with the front cover (1, Fig. 36). Inspect the edges of the oil seal/crankshaft damper spacer for nicks, burrs and wear marks and replace if suspect, oil and fit the spacer. Refit the woodruff key and the crankshaft damper. Fit the pulley to the crankshaft.




Fig. 36

## CRANKSHAFT PULLEY AIR CONDITIONING DRIVE

### Renew

Slacken the compressor link arm adjusting nuts and bolts, raise the vehicle on a ramp, slacken the compressor front link bolt and pivot the compressor towards the engine. Remove the compressor drive belt and remove the pulley securing bolts (1, Fig. 37).




Fig. 37

Remove the pulley by moving it forwards and to the LH side of the damper.

Fit and align the new pulley to the crankshaft damper and tighten the securing bolts.

Move the compressor away from the engine and fit the drive belt. Tighten the adjusting nut to give the correct belt tension.

Tighten the link arm lock nuts, pivots and bolts.

## DISTRIBUTOR DRIVE SHAFT

### Renew

Depressurise the fuel system, drain the coolant and remove the air cleaner element. Remove the thermostat housing gasket and




Fig. 38

cylinder head gasket. Drain the engine oil. Remove the crankshaft damper, timing cover gaskets, upper timing chain and lower chain tensioner and remove the intermediate sprocket.

Remove the power-assisted steering pump housing to distributor drive shaft housing securing bolts (1, Fig. 38), remove the power-assisted steering pump drive coupling and remove the distributor drive shaft rear oil seal using Service Tool 18G 1468. Using right-angled circlip pliers remove the drive shaft securing circlip, lift the timing chain off the drive shaft gear, remove the drive shaft (2, Fig. 38) and collect the thrust washer (3, Fig. 38).

Clean the distributor drive shaft and bearing housing (4, Fig. 38), thrust washer, drive coupling and pump shaft.

Check for wear and if necessary change the distributor shaft bushes (5, Fig. 38) using Service Tool 18G 1434.

Refit the housing (4, Fig. 38) with new gasket (6, Fig. 38) and secure with the bolts (1, Fig. 38).

Lubricate the drive shaft and refit the shaft into the housing, engaging the chain with the gear as it is fitted. Lubricate and fit the thrust washer (3, Fig. 38) and secure with the circlip.

Lubricate new oil seal and using Service Tool 18G 1469, fit and seat the drive shaft rear oil seal.

**NOTE:** Under no circumstances must the plastic seal insert be removed prior to fitting the seal.

Fit the drive coupling to the power-assisted steering pump, align the pump shaft with the distributor shaft, connect the pump shaft to the drive shaft and tighten the pump housing securing bolts.

Refit the intermediate sprocket, the lower timing chain tensioner, the upper timing chain, the timing cover crankshaft damper, cylinder head gasket, thermostat housing gasket and the air cleaner element. Refill the cooling system. Refill the engine with oil, start the engine and adjust the ignition timing.



## DISTRIBUTOR DRIVE SHAFT SEAL

### Renew

Remove the power steering pump drive coupling and remove the distributor drive shaft oil seal using Service Tool 18G 1468. Clean and lubricate the new seal and mating faces. Using Service Tool 18G 1469 (1, Fig. 39), fit and fully seat the drive shaft seal (2, Fig. 39).

**NOTE:** Under no circumstances must the plastic seal insert be removed prior to fitting of the seal.

Refit the power steering pump drive coupling.




Fig. 39

## CRANKSHAFT DAMPER

### Renew

**NOTE:** Under no circumstances must the engine be rotated anti-clockwise (viewed from the front) until Service Tool 18G 1436 is fitted and tensioned.

Remove the air conditioning drive pulley, slacken the alternator drive belt adjusting nut, the link arm adjusting nut, bolt and alternator pivot bolt. Lift the alternator and remove the drive belt, disconnect the plug leads and the HT lead from the ignition coil. Remove the distributor cap and turn the engine to TDC No. 1 cylinder. Disconnect the distributor




Fig. 40

amplifier block connector and the advance/retard pipe, remove the distributor and place tape over the aperture. Remove the upper chain tensioner valve and using a 3 mm Allen key, retract the tensioner by rotating the key clockwise until the tensioner is in the 'park' position, and remove the tensioner assembly (1, Fig. 40). Fit the Service Tool 18G 1436 (1, Fig. 41) to the cylinder head and tighten the centre bolt (2, Fig. 41) until a pressure of 2 to 4 lbs is exerted on the chain by the tensioner.



Fig. 41

Remove the spoiler/under tray to inner wheel arch cover.

Fit Service Tool 18G 1837 to the front crankshaft damper (1, Fig. 42) and tighten the securing bolts (2, Fig. 42). Wedge the tool against the front crossmember (3, Fig. 42) and remove the damper retaining




Fig. 42

bolt. Remove Service Tool 18G 1837 from the damper and Service Tool 18G 1836 from the cylinder head, refit the upper




Fig. 43

tensioner assembly with a new gasket and 'O' ring and release by turning the tensioner anti-clockwise using a 3 mm Allen key. Fit the tensioner valve and secure with the clamp.

Fit Service Tool 18G 1436 to the damper (1, Fig. 43) and tighten the securing bolts (2, Fig. 43). Tighten the centre bolt, withdraw the pulley from the crankshaft and remove the tool.

Remove the timing plate securing bolts and remove the timing plate.

Refit the timing plate to the new damper and tighten the securing bolts, fit the damper to the engine, start the damper securing bolt and fit Service Tool 18G 1437. Wedge the tool against the front crossmember, torque up the securing bolt and remove Service Tool 18G 1437.

Reposition the alternator drive belt over the pulleys and refit the air conditioning belt.

Refit the spoiler/under tray. Tension the alternator drive belt and tighten all the securing bolts and nuts. Tension the air conditioning drive belt and tighten the securing bolts.

Fit a new 'O' ring to the distributor, turn the engine to TDC No. 1 cylinder and refit the distributor.

Refit the advance and retard pipe and reconnect the distributor amplifier block connector, refit the distributor cap, leads and HT lead to the ignition coil, start the engine and reset the ignition timing.

## OIL COOLER SUPPLY AND RETURN HOSES

### Replace

Remove the air cleaner assembly, place a drain tray in position, remove the hose to oil filter head clamp nut, clamp and rubbers. Disconnect and remove the horn assembly. Place a drain tray beneath the oil cooler and cooler union, place a splash guard to prevent oil splashing through the front radiator grille. Slacken the supply and return pipes from the cooler and cooler union nuts and drain the oil. Remove the top rail to fan cowl securing nuts, displace the harness clips, displace the fan cowl from the top rail and remove the receiver/drier. Remove the top rail securing nuts and bolts and displace the earth leads, lift the top rail off and position over the engine. Remove the receiver/drier clamp nuts, bolts and clamps from the receiver/drier. Lift the condenser from its mounting position, disconnect the thermostatic switch feed wires and remove the supply and return hoses from the vehicle. Discard the 'O' rings.

Fit the new hoses in position, lubricate and fit the 'O' rings to the connectors, connect the hoses to the oil cooler and tighten the connections. Connect the horn wires and secure the horn assembly to the front panel. Align and fit the hose clamp rubbers, refit the clamp and secure with the bolt. Reconnect the radiator thermostatic switch feed wires. Refit the condenser to its mounting rubbers, position the clamps over the

receiver/drier. Position the earth wires and bolt the top rail into position. Refit the fan cowl over the studs, fit the harness clips to the studs, fit the top rail and secure with the nuts.

Reposition the receiver/drier clamps and secure with the nuts. Connect the supply and return hoses to the filter head.

Refit the clamp plate and secure with nut, refit the air cleaner element and remove the splash guard and drain trays and top-up the engine with oil.

## OIL PRESSURE RELIEF VALVE ASSEMBLY

### Check and overhaul or renew

Jack up the front of the vehicle and place on two stands, partially drain the engine oil from the front drain plug (1, Fig. 44).

Relief valve:

|                       |  |
|-----------------------|--|
| O/D                   | 17,98 to 17,95 mm (0.7079 to 0.7067 in)    |
| I/D                   | 15,00 to 14,50 mm (0.591 to 0.571 in)      |
| Overall length        | 35 mm (1.378 in)                           |
| Working length        | 30 mm (1.181 in)                           |
| Bore depth            | 27 mm (1.063 in)                           |
| Material              | ENIA                                       |
| Cyanide Harden        | 0,020 to 0,013 mm (0.008 to 0.005 in) deep |
| Mandrel: Length       | 57 mm (2.244 in)                           |
| Diameter              | 11,11 mm (0.437 in)                        |
| Material              | Steel tube to BS970 (CDS2 or ERW1)         |
| Spring Wall thickness | 1,63 (0.064 in, 16 SWG)                    |
| Free length           | 1,22 (0.048, 18 SWG)                       |
| Outside diameter      | 106 mm (4.173 in)                          |
|                       | 16,34 mm (0.643 in)                        |

### SPRING SPECIFICATION

|                     |                            |
|---------------------|----------------------------|
| Wire diameter       | 2,34 mm (0.092 in, 13 SWG) |
| Mean diameter coils | 14,0 mm (0.551 in)         |
| Total No. of coils  | 26                         |
| No. Active Coils    | 24                         |
| Helix of coil       | Left                       |
| Spring rate         | 4,49 N/mm (25.65 lb/in)    |

Remove the oil pressure relief valve plug (1, Fig. 45) and collect the valve (2, Fig. 45) spring (3, Fig. 45) and mandrel (4, Fig. 45). Check the valve spring and mandrel for wear, scoring or pitting with the specification below.




Fig. 44

J12-184




Fig. 45

J12-185

|               | Length |        | Load  |       | Stress            |                    |
|---------------|--------|--------|-------|-------|-------------------|--------------------|
|               | mm     | inches | kg    | lbs   | N/mm <sup>2</sup> | lb/in <sup>2</sup> |
| Fitted        | 76,00  | 2.992  | 13,74 | 30.29 | 472               | 68.395             |
| Valve opening | 72,00  | 2.835  | 15,58 | 34.35 | 535               | 77.543             |
| Max opening   | 62,00  | 2.441  | 20,15 | 44.43 | 692               | 100.304            |
| Solid (ref)   | 60,80  | 2.392  | 20,71 | 45.66 | 711               | 103.083            |

### Material

BS. 970/735/A50 (EN.47) Spring steel wire. Ends to be close coiled and ground square to axis, feather edges to be removed to a minimum thickness of 0.5 mm (0.020 in).

### Heat treatment

To be heat stabilised such that when compressed to valve opening position for 24 hours at 150°C, relaxation of load must not exceed 2.5%.

If any of the components are suspect, they should be replaced.

Lubricate and assemble the mandrel, spring and valve, fit and tighten the relief valve plug.

Refit and tighten the sump plug.

Lower the vehicle, open the bonnet and top-up the engine with oil.

## ENGINE MOUNTING SET

## Renew

Remove the air cleaner element.  
Remove the upper engine mounting securing nut (1, Fig. 46) and washer, support the engine with a jack.

**NOTE:** Ensure that the fan does not come into contact with the fan cowl.

Remove the LH engine mounting bracket from the cylinder block, remove the mounting (2, Fig. 46) and packing from the bracket. Fit new mounting and packing to the bracket, fit the bracket to the cylinder block and tighten the securing bolts.




Fig. 46

Take the weight of the engine with a jack. Remove the RH mounting nuts from the crossmember (1, Fig. 47) and engine (2, Fig. 47), remove the mounting and packer from the bracket (3, Fig. 47), fit a new mounting with the packer to the bracket. Fit the assembly to the engine and secure. Lower the engine, ensure that it is positioned on the mountings without causing any undue strain to the rubber blocks and tighten the securing nuts.




Fig. 47

Fit the engine retaining Service Tool MS 53 across the wing channels (1, Fig. 48), fit the engine support hook, a lifting eye and take the weight of the engine.

Jack up the front of the vehicle and place on stands, remove the intermediate heat shield, remove the rear mounting securing nut (1,




Fig. 48

Fig. 49), take the weight of the gearbox with a jack and remove the rear mounting to body securing bolts (2, Fig. 49). Remove the rear mounting assembly (3, Fig. 49) and collect the spacers, spring and micron insert. Remove the nuts and bolts (4, Fig. 49) securing the mounting rubber to the plate and remove the mounting (5, Fig. 49).

Fit a new mounting to the bracket and secure with the nuts and bolts. Fit a new micron insert, fit the spring and using a jack fit, seat and secure the rear mounting to the body.




Fig. 49

**NOTE:** Ensure that the spring is seated in the gearbox spring pan.

Lower the jack and ensure that the gearbox is central over the mounting, finally tighten the mounting securing bolts.

Remove Service Tool MS 53 and the lifting eye, fit and seat the rear mounting centre spacers, tighten and secure with the mounting nut. Refit the intermediate heat shield and lower the vehicle.

## OIL PUMP DRIVE CHAIN AND DAMPER

## Renew

Remove the engine and the gearbox from the vehicle; detach the gearbox from the engine and fit the engine to a stand. Remove the distributor and disconnect the leads from the sparking plugs.

Remove the camshaft cover and the upper chain tensioner assembly; discard the 'O' rings and gaskets. Knock the camshaft top sprocket lock tabs away from the bolts, remove the sprocket securing bolts and collect the four tab washers, remove the camshaft sprockets from the cylinder head. Position the chain between the upper dampers (1, Fig. 50) and fit an elastic band (2, Fig. 50) across the upper dampers retaining the chain and the pivoting damper

(3, Fig. 50) during the cylinder head removal.




Fig. 50

Remove the cylinder head/camshaft bearing cap securing bolts (1, Fig. 51), remove the cylinder head assembly.




Fig. 51

Remove the flywheel and fit slave bolts to the rear of the crankshaft (1, Fig. 52) and using a suitable bar (2, Fig. 52) to stop the crankshaft rotating, remove the securing bolt and damper assembly.

**NOTE:** Ensure that the engine does not rotate anti-clockwise (viewed from the front).




Fig. 52

Turn the engine over in the stand and remove the sump pan securing bolts and sump.

Knock down the oil pump sprocket lock tabs, remove the bolts and tab washers and collect sprocket. Remove the timing cover securing bolts (1, Fig. 53) and timing cover assembly (2, Fig. 53). Remove the oil pump drive chain and damper, remove the crankshaft damper woodruff key and remove the crankshaft damper/oil seal spacer.






Fig. 53

Remove the front oil seal from the timing cover, clean and inspect the oil pump drive sprocket. Lubricate the oil pump drive chain, fit the chain to the sprocket and the chain/sprocket assembly to the crankshaft sprocket, align the sprocket securing holes, fit and tighten the sprocket securing bolts (1, Fig. 54), and secure with the tab washer




Fig. 54

(2, Fig. 54). Fit a new chain damper and take any slack out of the chain, tighten the securing bolts, fit the front oil seal to the timing cover, apply 'Hylosil' to the timing cover mating face, fit the cover and secure with the fixing bolts. Lubricate the oil seal/crankshaft damper spacer and push onto the crankshaft. Fit and seat the woodruff key to the crankshaft and fit the damper to the crankshaft. Stop the crankshaft from turning using the slave bolts and a suitable bar, fit the crankshaft damper securing bolt and tighten up to the correct torque.

Remove the slave bolts, clean the sump mating faces and coat with 'Hylosil', fit the sump to the engine and torque up the bolts. Turn the engine to TDC, the upper chain should be supported during this operation, and reposition it between the dampers (1, Fig. 55).




Fig. 55

Ensure that both the top of the cylinder block and the mating face of the cylinder head are clean and dry and fit a new cylinder head gasket.

Check that both camshafts are on TDC using Service Tool 18G 1433. Fit the cylinder head assembly to the cylinder block; fit the chain damper and pedestal assembly and insert the cylinder head attachment bolts. Tighten the bolts to a torque figure of 38 to 40 lb ft and then turn the bolt clockwise through exactly 90°; carry this out in the sequence illustrated (Fig. 56).

**NOTE:** To assist the accuracy of the rotation through 90° a suggested tool is illustrated on page 12—6.




Fig. 56

Lift the timing chain and remove the elastic band, position the chain over the ends of the camshafts. Fit and engage the camshaft drive sprockets to the chain and the camshafts ensuring that all the chain 'slack' is to the pivoting tensioner side.

Strip the upper tensioner and inspect its component parts (1, Fig. 57) for wear or




Fig. 57

damage. Check that the ball is free in the non return valve. Fit new 'O' rings to the valves lubricate the rings and insert the assembly into the position housing. Lubricate the snail, spring and mandrel and assemble to the piston. Engage the snail with the guide and rotate clockwise and depress the snail until the peg is engaged in the 'park' position on the snail, fit the assembly into the piston housing. Fit a new

'O' ring to the housing and lubricate, fit a new gasket to the housing and fit the assembly to the cylinder head, ensuring that the tensioner is properly engaged on the pivoting guide. Fit but do not tighten the




Fig. 58

tensioner securing bolt, fit the valve retainer securing bolt (four threads only) (1, Fig. 58). Fit new 'O' rings to the valve assembly and lubricate. Release the tensioner using a 3 mm Allen key and turn it anticlockwise, fit the valve assembly (2, Fig. 58), engage the retainer plate (3, Fig. 58) and fully tighten the securing bolt.




Fig. 59

Remove the inner sprocket securing clip (1, Fig. 59), remove the inner sprocket and align the holes in the inner sprocket with the holes in the camshaft (2, Fig. 59). Fit the tab washers (1, Fig. 60) and securing bolts (2, Fig. 60), but do not fully torque up the bolts,




Fig. 60

refit the inner sprocket securing clip. Repeat for the other camshaft sprocket. Tighten all the sprocket securing bolts (1, Fig. 61), knock up the lock tabs (2, Fig. 61), position the upper chain upper damper (3, Fig. 61) and tighten the securing bolts (4, Fig. 61) and knock up the lock tabs (5, Fig. 61).




Fig. 61

Fit the plug well seals (1, Fig. 62), the camcover gasket (2, Fig. 62), and the half moon seals (3, Fig. 62) to the cylinder head, fit the camcover (4, Fig. 62) to the engine, fit and tighten the securing screws (5, Fig. 62).




Fig. 62

Check the gap of new sparking plugs and fit to cylinder head, tightening to a torque of 25 lb/ft 3.5 kg/m.

Fit a new 'O' ring to the distributor, lubricate the 'O' ring and gear, turn the rotor arm to the position illustrated in Fig. 123 and fit the distributor in the position shown.

Fit the distributor clamp plate securing bolt, leave the clamp plate securing bolt slightly slack. Fit the distributor cap and tighten the securing screws. Connect the sparking plug leads in the firing order 1, 5, 3, 6, 2, 4.

**NOTE:** The distributor turns clockwise as viewed from the top.

Refit the water pump and the gearbox, remove the engine from the stand and refit the engine to the vehicle.

## VALVE CLEARANCES

### Check and adjust

Drain the coolant and remove the camshaft cover.

Rotate the engine as necessary to measure the valve clearances between the heel of the camshaft and the cam followers (1, Fig. 63), this should be 0.012 to 0.014 in.




Fig. 63

Should the clearances be incorrect, remove the camshafts and cam followers. Remove all the shims or only those requiring adjustment, check the size of the existing shims with a micrometer and note the reading. Calculate the size of the shim required, following the examples below.

| EXCESSIVE CLEARANCE                | INCHES |
|------------------------------------|--------|
| Size of existing shim              | 0.100  |
| Plus the actual clearance noted    | 0.019  |
|                                    | 0.119  |
| Less the specified valve clearance | 0.013  |
| = required shim size               | 0.106  |
| INSUFFICIENT CLEARANCE             | INCHES |
| Size of existing shim              | 0.107  |
| Plus the actual clearance noted    | 0.010  |
|                                    | 0.117  |
| Less the specified valve clearance | 0.013  |
| = required shim size               | 0.104  |

Refit the cam followers and camshafts, and camshaft cover using new seals and gaskets, refill the cooling system, check and if necessary adjust the ignition timing.

**NOTE:** See page 12-54 for available shim sizes.

**NOTE:** To enable the camshafts to be rotated in position, enabling the valve clearances to be checked, without connecting the timing chains and sprockets, the following procedure must be strictly adhered to.

LH and RH refers to the engine being viewed from the front of the cylinder head.

1. Set the crankshaft at 60° BTDC. Dead Centre.
2. Turn the LH camshaft until the No. 3 cylinder valves and No. 6 cylinder valves are 'on the rock' i.e. one set of valves just opening and the other just closing.
3. The RH camshaft can now be rotated and the valve clearances checked.
4. Rotate the RH camshaft to TDC (i.e. groove in the camshaft to the top).
5. Turn the LH camshaft to TDC.
6. Turn the RH camshaft until No. 2 cylinder valves and No. 6 cylinder valves are 'on the rock'.
7. The LH camshaft can now be rotated and the valve clearances checked.
8. Rotate the LH camshaft to TDC.
9. Rotate the RH camshaft to TDC.
10. Rotate the crankshaft to TDC.

**NOTE:** To set the camshafts at TDC use Service Tool 18G 1433.

## CAMSHAFTS

### Renew

Drain the coolant and remove the camshaft cover, remove the torquatrol unit securing nuts and remove the torquatrol unit from the studs. Turn the engine over until No. 1 cylinder is at TDC on its firing stroke.

Disconnect the HT lead from the coil and remove the distributor cap, disconnect the amplifier block connector and advance/retard vacuum pipe.

Note the position of the rotor arm relative to the distributor body, and the position of the body relative to the cylinder head; remove the distributor and block off aperture to prevent the ingress of dirt and dust.

Release the lock tabs (1, Fig. 64) on the camshaft sprocket securing bolts and slacken the securing bolts (2, Fig. 64).




Fig. 64

Remove the upper chain tensioner valve clamp bolt (1, Fig. 65), remove the clamp (2, Fig. 65) and valve (3, Fig. 65). Using a 3 mm Allen key wind back the tensioner (turn clockwise) until the snail engages in the 'park' position. Remove the tensioner housing securing bolt and remove the




Fig. 65

tensioner assembly (1, Fig. 66). Remove and discard the 'O' ring (2, Fig. 66) and gasket (3, Fig. 66), remove the camshaft sprocket securing bolts, collect the tab washers and remove the sprockets.




Fig. 66






Fig. 67

Remove the cylinder head bolt from the RH No. 2 camshaft cap (1, Fig. 67), remove the remaining two bolts securing the camshaft cap, and remove the cap.

Fit the spacer Service Tool 18G 1435 (2, Fig. 67) to the cylinder head, fit and tighten the cylinder head bolt to specified torque.

Repeat the procedure for cap numbers 3, 4, 5 and 6 (3, Fig. 67).




Fig. 68

Remove the upper chain upper damper pedestal securing bolts (1, Fig. 68) and remove the pedestal assembly (2, Fig. 68) and fit the two spacer Service Tools 18G 1435 (4, Fig. 67).

Remove the head bolt from No. 7 camshaft cap and remove Nos. 7 and 1 camshaft cap securing bolts alternately until the camshaft is free and lift the camshaft from the cylinder head and fit spacer tool 18G 1435 to No. 9 cap bolt and retorque the cylinder head bolts (5, Fig. 67).

Clean new camshaft, oil the journals and install in the cylinder head. Fit the camshaft at approximately TDC.

Start No. 1 camshaft cap securing bolts. Remove No. 7 cylinder head bolt and spacer, refit No. 7 camshaft cap and bolt, but do not tighten. Pull down No. 1 and 7 camshaft caps alternately until the camshaft is fully down. Tighten the cylinder head bolt.

Remove No. 4 cylinder head bolt and remove the spacer, lubricate the cap, fit and tighten the cap securing bolts, tighten the cylinder head bolt.

Repeat the above procedure for Nos 2, 3, 5 and 6 caps and using Service Tool 18G 1433 set the camshaft to TDC.

Repeat the procedure for the other camshaft.

Position the chain over the sprockets and align the sprockets to the camshafts, move the blank in the chain to the tensioner side, fit the oil pressure simulator Tool 18G 1436 and tension the chain (tighten the tool to apply a pressure of 2 - 4 lbs).

Remove the clip securing the sprocket inner wheel and align the securing bolt holes, fit the tab washers and securing bolts, knock up the tab washers and refit the securing clip.

Repeat the procedure for the second camshaft.

Turn the engine over and check all the valve clearances.

Should any of the clearances be incorrect, remove the camshafts as previously described, and using a suitable magnet remove the relevant cam followers (1,




Fig. 69

Fig. 69). Remove the shims requiring adjustment; check with a micrometer the size of the existing shims and note the reading. Calculate the size of shim required, following the example below for either excessive clearance or insufficient clearance.

#### EXCESSIVE CLEARANCE INCHES

|                                    |       |
|------------------------------------|-------|
| Size of existing shim              | 0.100 |
| Plus the actual clearance noted    | 0.019 |
|                                    | 0.119 |
| Less the specified valve clearance | 0.013 |
| = required shim size               | 0.106 |

#### INSUFFICIENT CLEARANCE INCHES

|                                    |       |
|------------------------------------|-------|
| Size of existing shim              | 0.107 |
| Plus the actual clearance noted    | 0.010 |
|                                    | 0.117 |
| Less the specified valve clearance | 0.013 |
| = required shim size               | 0.104 |

Remove the oil pressure simulator tool 18G 1436. Fit and seat the tensioner assembly to the damper. Fit the top tensioner securing bolt, fit new 'O' rings to the valve and lubricate.

Using a 3 mm Allen key, fully release the chain tensioner (turn anti-clockwise). Fit the valve, position the clamp over the valve and secure with the retaining bolt. Remove the tape from the distributor aperture, fit and lubricate the 'O' ring and drive gear, refit the distributor.

Reconnect the amplifier block connector, refit the distributor cap, plug leads and the HT lead to the coil.

Refit the torquatrol fan unit and secure with the nuts. Refit the gaskets to the camshaft cover, fit the cover and secure with the seven screws.

Refill the engine cooling system, reset the ignition timing and refit the distributor advance/retard pipe.

## PISTONS AND CONNECTING RODS ENGINE SET

### Replace

Remove the engine from the vehicle and fit to a stand.

Disconnect the plug leads, remove the distributor assembly, remove the camshaft cover. Turn the engine over to TDC firing on No. 1 cylinder, remove the upper chain tensioner assembly (1, Fig. 70).




Fig. 70

Remove the camshaft securing bolts and sprockets.

Position the chain between the upper chain dampers, secure the dampers with an elastic band. Remove the cylinder head/camshaft cap securing bolts and remove the cylinder head assembly.




Fig. 71

Remove oil sump securing bolts and sump. Remove the oil pump pick-up pipes and windage trays.

Slacken the big-end connecting rod nuts (1, Fig. 71), in piston and connecting rod pairs, following in sequence (i.e. 1 & 6, 2 & 5, 3 & 4 cylinders) and push the pistons up and through the top of the cylinder block.

Remove the gudgeon pin circlips (1, Fig. 72) from each piston, remove the gudgeon pin (2, Fig. 72) and separate the piston (3, Fig. 72) from the connecting rod (4, Fig. 72).




Fig. 72

**NOTE:** Check the connecting rods for out of balance, twist (Fig. 73) and bend (Fig. 74). If any connecting rod is bent, twisted or out of balance with the other five, then the complete set must be renewed.




Fig. 73




Fig. 74

Insert the new piston rings into the cylinder bores (1, Fig. 75) ensuring they are square in the cylinders and check the gap using a feeler gauge (2, Fig. 75); if the gap is insufficient, then a small flat file can be used on the butting ends of the ring. Ensure that after filing that no burrs remain.




Fig. 75

**NOTE:** Ensure that the piston is fitted correctly to the connecting rod (Fig. 76).




Fig. 76

Lubricate the small end bush and slide the gudgeon pin (1, Fig. 77) through the piston (2, Fig. 77) and connecting rod and secure with the circlips (3, Fig. 77).




Fig. 77

Fit the rings to the pistons ensuring the gaps are positioned as Fig. 78. Lubricate and compress the rings using Service Tool 18G 55A (1, Fig. 79). Insert the piston skirt into the bore, and using a suitable implement carefully tap the piston into the cylinder bore, ensuring that the connecting rod does not foul either the cylinder block or



Fig. 78

crankshaft. Lubricate and fit the big end bearing shells to the connecting rod and the connecting rod cap. Pull the connecting rod and bearing carefully onto the crankshaft



Fig. 79

and fit the connecting rod cap to the rod. Fit and tighten the connecting rod cap nuts to a torque of 39-41 lbf/ft. Repeat the operation for the remaining five pistons.

**NOTE:** Ensure the connecting rod caps are fitted as in (1, Fig. 98).

Clean and fit the crankshaft windage trays (1, Fig. 80) and tighten the securing bolts. Clean the oil pump pick-up pipes, fit and lubricate the new 'O' rings, smear the oil transfer housing to cylinder block gasket face with 'Hylosil', fit and seat the assembly (2, Fig. 80) to the cylinder block. Clean the sump, smear the mating face with 'Hylosil', fit and torque up the sump securing bolts.




Fig. 80

Support the top timing chain and turn the engine over to TDC No. 1 cylinder using a suitable dial test indicator (1, Fig. 81) and position the timing chain between the dampers.






Fig. 81

Clean the cylinder head gasket faces, the upper damper and camshaft sprockets. Ensure the camshafts are still at TDC using the Service Tool 18G 1433 (1, Fig. 82).




Fig. 82

Fit the cylinder head gasket and cylinder head, fit and tighten the cylinder head securing bolts to a torque of 38-40 lbf/ft and then rotate the bolt clockwise through exactly 90° in the correct sequence (Fig. 56). Tighten the front three bolts.

**NOTE:** To assist accuracy of rotation through 90° a suggested tool is illustrated on page 12—6.

Fit the top chain damper and pedestal assembly (1, Fig. 83), engage the chain with




Fig. 83

the sprocket teeth and fit the sprockets to the camshafts, rotate the sprockets to ensure any chain slack is to the tensioner side of the engine. Fit Service Tool

18G 1436 to the engine and tighten the securing bolts (1, Fig. 84), tighten the tensioning bolt (2, Fig. 84) to create a pressure on the tensioner of 2 - 4 lb.




Fig. 84

Remove the inner sprocket clips (1, Fig. 85), lift out the inner serrated portion (2, Fig. 85) and refit, aligning the holes with those in the camshaft (1, Fig. 86). Fit the securing bolts




Fig. 85




Fig. 86

(1, Fig. 87) and locktab washers (2, Fig. 87), refit the inner sprocket securing clips (2, Fig. 86), tighten the securing bolts and knock-up the locktabs (3, Fig. 87).

Remove the Service Tool 18G 1436, overhaul the tensioner assembly, lubricate the assembly, fit a new gasket and engage the tensioner with the upper damper. Fit but do not tighten the securing bolt (1, Fig. 88), fit new 'O' rings to the valve (2, Fig. 88), lubricate and release the tensioner using a 3 mm Allen key by turning anticlockwise, fit the valve, secure the valve with the retaining plate (3, Fig. 88), and bolt (4, Fig. 88).




Fig. 87




Fig. 88

Clean the camshaft cover and fit new plug well seals, cover gasket and half moon seals, smear with sealant and fit to the cylinder head. Fit and secure the camshaft cover with the seven screws. Refit the distributor.

Refit the distributor cap and connect the spark plug and HT leads. Refit the engine to the vehicle, refill the engine with oil and coolant and reset the ignition timing.

Refit the engine to the vehicle.

## CRANKSHAFT

### Renewal

Remove the engine assembly and fit to a stand. Remove the cylinder head.

Using Service Tool 18G 1437 (1, Fig. 89) to hold the crankshaft damper, remove the damper securing bolt.




Fig. 89

J12 378

Remove the oil sump, the oil pump pick-up pipe assemblies (1, Fig. 90), crankshaft windage trays (2, Fig. 90) and oil pump (3, Fig. 90).




Fig. 90

Remove the engine timing cover securing bolts (1, Fig. 91) and remove the cover assembly (2, Fig. 91).




Fig. 91

Slacken the oil pump drive chain damper securing bolts (1, Fig. 92) and move the damper (2, Fig. 92) clear of the chain.




Fig. 92

Remove the oil pump drive chain, remove the elastic band from the upper dampers and remove the upper timing chain. Remove the lower tensioner securing bolts (1, Fig. 93) and remove the tensioner (2, Fig. 93).




Fig. 93

Release the lower chain fixed damper securing bolt lock tabs (1, Fig. 94), remove the bolts (2, Fig. 94) and collect the damper (3, Fig. 94) and tab washer. Repeat for the remaining fixed and pivot dampers and remove the lower chain and intermediate sprocket.




Fig. 94

Remove seal/crankshaft damper spacer, the crank damper woodruff key (1, Fig. 95), oil the crankshaft sprockets (2, Fig. 95) and the inner woodruff key.




Fig. 95

Remove the rear oil seal housing securing bolts (1, Fig. 96) and remove the housing (2, Fig. 96).




Fig. 96

Remove the connecting rod cap securing nuts (1, Fig. 97), remove the bearing caps in pairs (i.e. 1-6, 2-5, 3-4), turning the crankshaft for access as required. As each




Fig. 97

connecting rod cap is removed ensure that each rod and cap are identified to each other (1, Fig. 98), as this will be necessary during assembly. Also as each cap is removed its relative connecting rod and




Fig. 98

piston assembly should be pushed up the bore to enable the crankshaft to be rotated to remove the remaining caps. Care should be taken not to push the piston too far up the cylinder bore as this will release the piston rings.

Ensuring that the main bearing caps are marked relative to the cylinder block (1, Fig. 99), remove the main bearing cap bolts, the caps (1, Fig. 100) and carefully lift out the crankshaft (2, Fig. 100). Remove and discard the bearing shells and the thrust washers.




Fig. 99




Fig. 100

Clean the bearing caps and the cylinder block main bearing housings.

Fit the new bearing shell halves to the cylinder block (1, Fig. 101) and lubricate with clean engine oil.




Fig. 101

Clean and polish the crankshaft journals, lubricate and carefully assemble the crankshaft into the cylinder block, fit the thrust washers ensuring that the steel side of the washer is mated to the cylinder block (1, Fig. 102).




Fig. 102

Rotate the crankshaft to ensure that it turns freely, fit the main bearing shells into the main bearing caps, lubricate and fit to the cylinder block, start the securing bolts and very carefully tap the main bearing caps to ensure they are seated in the cylinder block, rotate the crankshaft to ensure that it still turns freely, pull down each bearing cap individually and torque up the bolts, rotate the crankshaft between pulling down each bearing cap in order (Fig. 103).




Fig. 103

Check the crankshaft end float (1, Fig. 104), the tolerance is 0.004 to 0.010 in; should the end float exceed this, oversize thrust washers are available in 0.005 in and 0.010 in and should be fitted accordingly to ensure that the end float is within these tolerances.




Fig. 104

#### Excessive end float

e.g.

|                                |                         |
|--------------------------------|-------------------------|
| End float measured             | (A) 0.023 in            |
| Oversize thrust washers fitted | (B) 0.000 in (standard) |
| End float required             | (C) 0.007 in            |

$$\therefore A - C = \text{Thrust washer size required} = 0.016$$

$$\therefore \text{Thrust washer sizes to be fitted:} = 0.010 \text{ in} + 0.005 \text{ in}$$

$$\therefore \text{End float achieved:} = 0.023 - 0.015 \text{ in} = 0.008 \text{ in}$$

#### Insufficient end float

|                               |              |
|-------------------------------|--------------|
| End float measured            | (A) 0.003 in |
| Oversize thrust washer fitted | (B) 0.010 in |
| End float required            | (C) 0.007 in |

$$\therefore C - A = \text{Thrust washer size required} = 0.004 \text{ in}$$

$$\therefore \text{Thrust washer size to be fitted:} = 0.005 \text{ in}$$

$$\therefore \text{End float achieved is:} = 0.003 \text{ in} + 0.005 \text{ in} = 0.008 \text{ in}$$



## DO NOT REMOVE THE PLASTIC 'O' RING PROTECTOR FROM THE SEAL PRIOR TO FITTING TO THE ENGINE

Carefully remove the old rear oil seal from the housing, clean the housing and lubricate the seal mounting face and using tool No. 18G 1293A/1 (1, Fig. 105) and 18G 134 (2, Fig. 105) fit the seal (3, Fig. 105) to the housing (4, Fig. 105). Smear the gasket




Fig. 105

face with 'Hylosil', locate the plastic protector 'O' ring (1, Fig. 106) onto the end of the crankshaft (2, Fig. 106) and push the rear seal housing (3, Fig. 106) over the crankshaft and up to the rear cylinder block




Fig. 106

face. Fit the bolts, check that the sump face and the cylinder block (1, Fig. 107) are flush, and tighten the bolts.




Fig. 107

Fit a new bearing shell to the connecting rod, lubricate and fit it to the crankshaft. Fit a bearing shell to the big end cap, lubricate and fit to the connecting rod. Fit and torque up the nuts. Turn the crankshaft over and ensure that there are no 'tight' spots, i.e. the crankshaft rotates freely. Repeat this procedure for the remaining five cylinders. Clean and inspect for wear or damage all the timing gears, chains, guides and tensioners; should any be suspect replacement is essential.

Fit and seat the crankshaft sprocket woodruff key and fit the sprocket (1, Fig. 108) to the crankshaft (2, Fig. 108). Lubricate the lower timing chain, fit the chain to the intermediate sprocket, fit the chain to the lower sprocket, and then assemble the intermediate sprocket and chain to the cylinder block. Should the intermediate sprocket be worn or damaged, the assembly must be replaced.




Fig. 108

Fit the spacers (1, Fig. 109) to the lower pivoting damper (2, Fig. 109) and fit the assembly (3, Fig. 109) to the cylinder block, fit a tab washer (4, Fig. 109) and bolts (5, Fig. 109), tighten the bolts and knock the tabs up to secure the bolts.




Fig. 109

Clean the lower tensioner assembly, remove the ball valve (1, Fig. 110) and ensure that the bottom of the housing is clean (2, Fig. 110), check that the ball valve is free by shaking it to ensure it rattles. If it does not, replace the valve assembly. If it does, renew and lubricate the 'O' ring (3, Fig. 110), and press the valve back into the housing. The ball free movement is 0.74 to 0.45 mm (0.029 to 0.018 in).

Inspect the housing and hydraulic tensioner (4, Fig. 110) for wear or scoring. Also check that the oil hole (5, Fig. 110) is clear in the end of the piston. Lubricate the component parts. Assemble the tensioner by pressing and twisting the snail clockwise until the pawl locks in the 'park' position. Insert the tensioner assembly into the housing and fit the housing to the cylinder block. Fit and tighten the securing bolts (6, Fig. 110).




Fig. 110

Fit the lower static damper, fit the tab washers and bolts, tighten the bolts and knock up the tabs.

Release the tensioner by pushing the pivoting damper away from the chain, thus pushing the tensioner back into the housing, releasing the snail, and tensioning the chain.

Fit the upper static damper pedestal securing bolts and tab washer (1, Fig. 111) and the damper (2, Fig. 111). Secure with the tab washer (3, Fig. 111) and tighten the damper securing bolts, finally tighten the damper pedestal securing bolt and knock up the tabs.

Fit a dial gauge to the top of the cylinder block, and turn the engine over until No. 1 on 6 pistons are at TDC. Lubricate the upper chain (4, Fig. 111) and fit it to the intermediate sprocket (5, Fig. 111), fit and engage an elastic band (6, Fig. 111) around the upper dampers to secure the chain.




Fig. 111

Lubricate the oil pump drive chain, fit the chain to the crankshaft sprocket and lodge in the correct position.

Remove the crankshaft front oil seal and remove the distributor drive gear shaft seal using Service Tool 18G 1468. Lubricate the

new distributor drive shaft seal and fit to the cover using Service Tool 18G 1469 (Fig. 112). Fit the crankshaft front oil seal to the cover ensuring that the front edge of the seal is flush with the timing cover (Fig. 113).




Fig. 112




Fig. 113

Smear the cylinder block timing cover face with "Hylosil", lubricate the bearing shells and carefully fit the timing cover to the engine ensuring that the timing cover/cylinder head mating face is flush with the cylinder block (1, Fig. 114), fit and tighten the securing bolts. Lubricate and fit the oil seal distance piece. Fit and seat the damper woodruff key.




Fig. 114

Remove the oil pump pressure relief valve retaining nut (1, Fig. 115), remove the spring, tube and valve, clean and check for wear or scoring. Remove the pump body securing bolts and remove the outer rotor. Remove the backplate securing bolts, remove the backplate, and remove the

bearing shell from the housing. Clean all dismantled parts and check for obvious wear or scoring.

Fit the outer rotor and check the clearance between the rotor and the oil pump housing. Should any clearance exceed the specified tolerances the assembly, i.e. rotor outer housing assembly, must be replaced. Lubricate the bearing shell and fit to the pump housing. Smear backplate gasket face with sealant and fit the backplate and tighten the securing bolts.




Fig. 115

Lubricate the pump inner and outer rotors (2, Fig. 115), the bearing and the housing. Fit the outer rotor, smear the gasket face with sealant, fit the seal to the pump body and tighten the securing bolts. Lubricate and assemble the relief valve (3, Fig. 115), spring (4, Fig. 115) and tube (5, Fig. 115) to the pump. Fit and tighten the relief valve cap.

Fit the oil pump to the engine (1, Fig. 116) and tighten the securing bolts (2, Fig. 116).




Fig. 116

Clean oil pump drive sprocket, offer up the sprocket to the oil pump drive flange (1, Fig. 117), place a straight edge between the crankshaft sprocket and the oil pump drive sprocket (2, Fig. 117) and shim out the oil pump drive sprocket until the two sprockets are perfectly in line. Once the necessary shim pack has been selected, fit the shims to the oil pump (3, Fig. 117), locate the sprocket in the drive chain, offer up the sprocket to the pump and align the securing bolt holes, fit the tab washers and the securing bolts, tighten the bolts and knock up the lock tabs, position the oil pump chain damper to take the slack out of the chain and tighten the securing bolts.




Fig. 117

Clean and fit crankshaft windage trays (1, Fig. 118) and tighten the securing bolts. Clean all oil pick-up pipes and housings. Fit new 'O' rings (1, Fig. 119) to the oil pick-up pipes. Fit the pick-up pipe to the housing and secure with the bolts. Lubricate the 'O' rings on the oil pipes and fit the pipes to the




Fig. 118




Fig. 119



housing. Smear the housing to the cylinder block gasket face with 'Hylosil', engage the pipes in the rear face of the oil pump, ensure that the 'O' rings enter the housing easily. Fit and tighten the housing securing bolts.

Smear the sump gasket face with 'Hylosil' and fit the sump to the engine and tighten the securing bolts.

Refit the crankshaft damper, fit Service Tool 18G 1437 to the damper and torque up the nut.

Refit the cylinder head, remove the engine from the stand and refit to the vehicle.

## CYLINDER HEAD

### Overhaul

Depressurise the fuel system, remove the bonnet, drain the coolant, jack up the front of the vehicle and place on two stands.

Remove the front exhaust pipe securing nuts and pull the exhaust clear of the manifold.

Lower the vehicle and support the exhaust. Disconnect the spark plug leads (1, Fig. 120) and the injector harness block connector. Fit a dummy lifting eye, remove the air cleaner element. Note the position of




Fig. 120

the air switching valve feed wires prior to disconnection and remove the thermostat housing (1, Fig. 121).




Fig. 121

Disconnect the hose from the pressure regulator and fit blanking plugs to the regulator and the hose.

Disconnect the fuel rail feed hose and fit blanking plugs.

Disconnect the distributor advance and retard pipe, the kickdown cable from the throttle linkage, and the throttle cable from the linkage (1, Fig. 122).

Remove the throttle cable bracket (2, Fig. 122) from the manifold.

Disconnect the brake servo hose, and the air conditioning pipes from the manifold.




Fig. 122

Slacken the ECU vacuum pipe hose from the manifold.

Remove the engine breather hose from the camshaft cover.

Remove the oil filler tube assembly and dipstick tube assemblies, also remove the heater valve to cylinder head hose.

Remove the camshaft cover and discard all the seals and gaskets.

Remove the fan and torquatrol unit from the drive pulley.

Turn the engine to TDC No. 1 cylinder, disconnect the HT lead from the ignition coil, remove the distributor cap, disconnect the distributor amplifier block connector (1, Fig. 123), remove the vacuum pipe (2, Fig. 123), note the position of the rotor arm (3, Fig. 123) relative to the distributor body and the distributor body to the cylinder head (4, Fig. 123) and remove the distributor assembly from the engine.




Fig. 123

Remove the camshaft cover.

Release the lock tabs from the bolts on the camshaft sprockets and slacken the bolts.

Slacken but do not remove the upper tensioner non return valve clamp securing bolt, move the clamp to one side and remove the valve from the housing. Using a 3 mm Allen key, rewind the top chain tensioner by engaging the key in the hexagon in the rear of the tensioner and turn clockwise until the tensioner locks in the 'park' position.

Remove the sprocket securing bolts and collect the tab washers, remove the sprockets, lift the chain, pivot the damper inwards and secure it with an elastic band, let the chain rest between the two dampers. Remove the cylinder head front securing bolts followed by the remainder, remove the upper damper and place to one side and lift the cylinder head off the cylinder block.

Remove and discard the cylinder head gasket, the exhaust sealing rings, the oil

filler tube seal and place the cylinder head on a bench ensuring that the oil filler tube is not trapped.

Remove the upper tensioner securing bolts and remove the tensioner, discard the 'O' ring and gasket.

Remove the sparking plugs and the inlet and exhaust manifolds.

Remove the camshaft cap securing bolts (1, Fig. 124), lift off the caps and remove the camshafts (2, Fig. 124).




Fig. 124

Using a magnet (1, Fig. 125), lift out the cam followers (2, Fig. 125), remove the




Fig. 125

shims, using Service Tool 18G 106A (1, Fig. 126), compress the valve springs and remove the spring retaining collars (2, Fig. 126). Release the tension on Tool 18G 106A and remove the top valve spring collars (1, Fig. 127), springs (2, Fig. 127) spring seats (3, Fig. 127) and the valves (4, Fig. 127); repeat this operation for the remaining 23 valves.






Fig. 126




Fig. 127

Remove the seals (5, Fig. 127) from the inlet valve guides and remove the cylinder head rear blanking plate (6, Fig. 127).

Clean all component parts and check for wear and also for burning of valves or seats. Check the cylinder head face for distortion, if any is evident a maximum of 0.021 mm (0.008 in) may be removed by grinding to salvage the cylinder head.

Taking care not to damage the inside surface of the combustion chambers, clean the cylinder head gasket surface and the inlet and exhaust ports. When using scrapers or wire brushes for removing carbon deposits, avoid scratching the valve faces and seats. A soft wire brush is the most suitable implement for this purpose. Clean all carbon and other deposits from the valve guide using a suitable valve guide brush. Thoroughly wash the cylinder head to ensure that all loose carbon is removed and dry off with a high pressure air line.

After cleaning and polishing each valve, examine the stems for straightness and wear, using a suitable tool (Fig. 128), and the faces for burns, pitting and distortion.

Renew valves which are excessively worn, bent or too badly pitted to be salvaged by refacing.




Fig. 128

J12 268

**NOTE:** No attempt should be made to clean up a burnt or badly pitted valve face by the extensive 'grinding in' of the valve to the seat.

Lightly lap the valves into the seats with a fine grinding compound. The reseating operation should leave the finished surfaces smooth. Excessive lapping will groove the valve face resulting in a poor seat when hot (see Fig. 138) for valve seat acceptability.

'A' Correctly seated

'B' Undesirable condition

'C' Method of rectification

To test the valves for concentricity with their seats, coat the face of the valve with Engineers' blue or similar, and rotate the valve against the seat. If the valve face is concentric with the valve stem, a mark will be made all round the face.

Should a mark be made on only one side of the face, the face is not concentric with the valve stem. Clean the valve and again coat with Engineers' blue and rotate the valve against the seat to ascertain that the valve guide is concentric with the valve seat, if not the seat must be recut.




Fig. 129

J12 269

Whenever valves are replaced, the seats must be recut prior to lapping of the valves. Check the valve guide wear by inserting a new valve into the guide to be checked; lift it 3 mm ( $\frac{1}{8}$  in) from its seat and rock it sideways. Movement of the valve across its seat must not exceed 0.5 mm (0.020 in) (A, Fig. 129). Should the movement exceed this tolerance, the valve guide must be replaced. This is achieved by using Service Tool 18G 1432 to drift out the old guide (1, Fig. 130). Ensure that the relevant service guide is selected prior to fitting (see chart).




Fig. 130

J12 270

Remove the old valve guide and ream the cylinder head to the relevant dimension — see chart. Coat guide with graphite grease, immerse the cylinder head in boiling water for 30 minutes, and fit the guide to the cylinder head (1, Fig. 131).

**NOTE:** To fit the guide the interference should not be sufficient to cause the use of excessive force.




Fig. 131

J12 271

| IDENTIFICATION FOR OVERSIZE | PART NO. | VALVE GUIDE OUTER DIMENSION | DIMENSION TO BE REAMED TO IN CYLINDER HEAD | APPLICATION |
|-----------------------------|----------|-----------------------------|--|-------------|
| Plain                       | C29388   | 0.5020 to 0.5015            | —  | Production  |
| 1 groove                    | C29389   | 0.5040 to 0.5035            | —  | Production  |
| 2 grooves                   | C29390   | 0.5070 to 0.5065            | 0.5055 to 0.5048                           | Service     |
| 3 grooves                   | C29391   | 0.5120 to 0.5115            | 0.5105 to 0.5098                           | Service     |

Note all dimensions in inches.

After fitting a valve guide, the valve seat must be recut using Service Tool MS 204 (1, Fig. 132). Should the insert need




Fig. 132

replacing, the old insert should be bored out until it collapses, the bore should then be measured and the insert ground down until an interference of 0.077 mm (0.003 in) (See 'General Specification Data' for dimensions) exists between the cylinder head and the




Fig. 133




Fig. 134

insert. The cylinder head should then be oven heated at 150° (300°F) for 30 mins and then fit the seal inserts and recut with Service Tool MS 204 when the cylinder head has cooled. Examine the cam followers for wear on the top face, these should be perfectly flat (see Fig. 133), check also for any sign of barrelling on the side faces (1, Fig. 134). Replace all followers

that are worn or suspect. Wash the cylinder head, the valves, spring, collets, cups and followers and air dry.

After the valve springs have been thoroughly washed, they must be examined for fatigue and distortion.

Test the valve springs for pressure, either by comparison with the figures given in the 'General Specification Data' using a recommended valve spring testing machine (Fig. 135), or by comparison with a new valve spring.

To test against a new valve spring, insert both valve springs end to end between the jaws of a vice or under a press with a flat metal plate interposed between the two springs. Apply a load to compress the




Fig. 135

springs partly and measure their comparative lengths (Fig. 136). If the distance 'A' is smaller than 'B' and 'A' is the old spring then it must be replaced.




Fig. 136

Distortion is determined by positioning it upright on a surface or table and the squareness of each end is determined by utilising a set square (Fig. 137).




Fig. 137

All valve springs which have diminished in length and/or are not square must be discarded and new replacements fitted.




Fig. 138

- A Correctly seated
- B Undesirable
- C Method of rectification

Oil all the valve chain components. Assemble the valves one at a time, ensuring that the valves are assembled to the valve seat they were lapped to. Fit the spring seat and new valve stem seals, fit the springs and top collar and using Service Tool 18G 106A, compress the spring until the retaining collets can be inserted through the collar, and locate in the valve stem. Before removing the valve spring compressor tool, ensure that the retaining collets (1, Fig. 139) are still securely located in the valve stem (2, Fig. 139). Replace the




Fig. 139

original shim in the top of the collar (1, Fig. 140) ensuring that it is not tipped (1, Fig. 141) or slightly on top of the collar, oil and fit the cam follower (1, Fig. 142).

**NOTE:** If the cylinder head has been overhauled to the extent of having the valve seats recut, use a shim size 0.010 in smaller than the original.

Repeat this operation for the remaining 23 valves.

Lubricate the camshafts and fit to the cylinder head, ensuring that they are fitted with the slot to the top and that the No. 1 cylinder camshaft lobes are facing each






Fig. 140




Fig. 141

other. Fit the camshaft caps and torque the securing bolts in the sequence (Fig. 143). Fit slave bolts to the front of the camshafts and measure the clearances between the heel of the camshaft (1, Fig. 144), and the cam followers (2, Fig. 144) turning the camshafts as necessary to measure all the clearances; these should be 0.012 to 0.014 in.

Should any of the clearances be incorrect, remove the camshaft caps, the camshafts and the cam followers using a suitable magnet. Remove all the shims or only those requiring adjustment; check with a micrometer the size of the existing shims and note the reading. Calculate the size of the shim required, following the example below for either excessive clearance or insufficient clearance.




Fig. 142




Fig. 143




Fig. 144

**NOTE:** See page 12-54 for a available shim sizes.

| EXCESSIVE CLEARANCE                | INCHES |
|------------------------------------|--------|
| Size of existing shim              | 0.100  |
| Plus the actual clearance noted    | 0.019  |
|                                    | 0.119  |
| Less the specified valve clearance | 0.013  |
| = required shim size               | 0.106  |
| INSUFFICIENT CLEARANCE             | INCHES |
| Size of existing shim              | 0.107  |
| Plus the actual clearance noted    | 0.010  |
|                                    | 0.117  |
| Less the specified valve clearance | 0.013  |
| = required shim size               | 0.104  |

Fit the shims as determined by the calculations to the appropriate valves and fit the cam followers; refit the camshafts, the camshaft caps and recheck the valve clearances.

**NOTE:** A final check of the valve clearances should be done once the cylinder head is fitted and torqued to the cylinder block.

Using Tool 18G 1433 set the inlet and exhaust camshafts to TDC (Fig. 145). Remove the camshaft slave bolts.




Fig. 145

Clean and check the upper chain upper damper for wear or scoring; should either of these conditions prevail, then the damper must be renewed.

Ensure that both No. 1 and No. 6 pistons are still at TDC and that both the top of the cylinder block and the cylinder head faces are scrupulously clean.

Clean and refit the inlet and exhaust manifolds ensuring that new gaskets are fitted to the exhaust manifolds, fit a new seal to the oil filler tube housing and new fire rings to the exhaust manifolds and fit both lifting eyes.

Fit the cylinder head assembly to the cylinder block, locating it on the dowels.

**NOTE:** Ensure that the oil filler tube and auxiliary air valve pipe do not foul and that no harnesses or pipes are trapped.

Fit the upper chain damper and pedestal assembly (1, Fig. 146) and fit the cylinder




Fig. 146

head attachment bolts. Tighten the bolts to a torque figure of 38 to 40 lbf ft and then turn the bolt clockwise through exactly 90°, carry this out in the sequence illustrated (Fig. 147).

**NOTE:** To assist the accuracy of the rotation through 90° a suggested tool is illustrated on page 12—6.

Fit and tighten the three front securing bolts.




Fig. 147

Lift the timing chain and remove the elastic band, position the chain over the ends of the camshafts. Fit and engage the camshaft drive sprockets to the chain and the camshafts ensuring that all the chain 'slack' is towards the pivoting tensioner.

Fit the oil pressure simulator tool 18G 1436 (1, Fig. 148) to the cylinder head and tighten the bolt (2, Fig. 148) finger tight to exert a pressure of 2 to 4 lb on the chain.



Fig. 148

Remove the inner sprocket securing clip (1, Fig. 149), remove the inner sprocket (2, Fig. 149) and align the holes in the inner sprocket with the holes in the camshaft. Fit the tab washers (3, Fig. 149) and securing bolts (4, Fig. 149) but do not fully torque up the bolts, refit the inner sprocket securing clip. Repeat for the other camshaft sprocket. Tighten all the sprocket securing bolts, knock up the lock tabs, position the upper chain upper damper (5, Fig. 149) and tighten the securing bolts (6, Fig. 149) and knock up the lock tabs (7, Fig. 149).




Fig. 149

Remove the oil pressure simulator tool. Strip the upper tensioner and inspect its component parts for wear or damage. Check that the ball is free in the non return valve and also that the base plate (1, Fig. 150) is adequately secured by the peening (2, Fig. 150). Fit new 'O' rings to the valve (3, Fig. 150) and lubricate the 'O' rings.




Fig. 150

Lubricate the snail (1, Fig. 151), spring (2, Fig. 151) and spring mandrel (3, Fig. 151) and assemble to the piston (4, Fig. 151). Engage the snail (1, Fig. 151) with the peg (5, Fig. 151) and rotate the snail (1, Fig. 151) clockwise and depress until the peg (5, Fig. 151) engages in the 'park' position in the snail (1, Fig. 151).




Fig. 151

Fit the assembly (1, Fig. 152) into the piston housing. Fit a new 'O' ring (2, Fig. 152) to the housing and lubricate, fit a new gasket (3, Fig. 152) to the housing and fit the assembly (4, Fig. 152) to the cylinder head, ensuring that the tensioner is engaged on the pivoting guide. Fit but do




Fig. 152

not tighten the tensioner securing bolt (1, Fig. 153), fit the valve retainer securing bolt (four threads only) (2, Fig. 153). Fully tighten the lower securing bolt, fit new 'O' rings to the valve assembly and lubricate. Release the tensioner using a 3 mm Allen key, fit the non return valve assembly (3, Fig. 153), engage the retainer plate (4, Fig. 153) and fully tighten the securing bolt (2, Fig. 153).





Fig. 153

Remove the baffle plate inside the camshaft cover and clean the camshaft cover and the baffle, refit the baffle to the cover and secure with the bolts. Fit the plug well seals (1, Fig. 154) and the camshaft cover gasket (2, Fig. 154), fit the half moon seals (3, Fig. 154) to the cylinder head and fit the camcover (4, Fig. 154) to the engine, fit and tighten the securing screws (5, Fig. 154).

Check the gap of the new sparking plugs (6, Fig. 154) and fit them to the cylinder head, tightening to a torque of 25 lbf ft






J12-293

Fig. 154

Fit the new 'O' ring to the distributor, lubricate the 'O' ring and gear, turn the rotor arm and the distributor to the position shown in Fig. 155 (TDC No. 1). Fit the distributor clamp plate securing bolt, leave the clamp plate securing bolt slightly slack.



J12-294


Fig. 155

Fit the distributor cap and tighten the securing screws. Connect the sparking plug leads in the firing order 1, 5, 3, 6, 2, 4.

**NOTE:** The distributor turns clockwise as viewed from the top.

Refit the torquatrol unit to the drive pulley. Reconnect the heater valve hose to the cylinder head and tighten the clip, reposition the dipstick tube and secure with the 'P' clip to the manifold bracket.

Reposition the oil filler tube (1, Fig. 156) into the lower housing (2, Fig. 156) and secure to the upper bracket. Refit the breather hose (1, Fig. 158) to the camshaft cover and tighten the clip, connect the hose (2, Fig. 158) to the manifold and air cleaner backplate and tighten the clips. Refit




J12-295

Fig. 156

the distributor advance/retard pipe; the ECU vacuum pipe, the brake servo hose, and the air conditioning pipes to the manifold and tighten the securing clips.

Refit the throttle cable (1, Fig. 157) to the throttle linkage (2, Fig. 157) and secure the throttle cable with the clip provided.


Reconnect the fuel feed hose (3, Fig. 158) to the fuel rail (4, Fig. 158) and tighten the nut; and refit the pressure regulator and hose (5, Fig. 158), secure with the clip.



J12-296

Fig. 157

Identify and reconnect the air switching valve feed wires, reposition the thermostat housing harness and refit the thermostat housing (1, Fig. 159).




J12-298

Fig. 159

Reconnect the injector block connectors (1, Fig. 160) and remove the dummy lifting eyes.

Refit the distributor block connector and connect the HT lead to the coil.



J12-299


Fig. 160

Raise the front of the vehicle and place on stands, reconnect the exhaust system to the manifolds ensuring that the fire rings are still in position in the manifolds.

Lower the vehicle, refit the air cleaner element (1, Fig. 161), refill the cooling system, check and reset the ignition timing and refit the bonnet.



Fig. 161



J12-297

Fig. 158




Fig. 162



## ENGINE AND GEARBOX

## Renew

Remove the front grille.

Remove the bonnet and support struts from the vehicle.

Drain the coolant.

Disconnect the heater valve hose from the cylinder head and the hose from the heater to water pump return pipe. Remove the securing nuts (1, Fig. 162) for the receiver/dryer clamping brackets and release the receiver/dryer (2, Fig. 162) from the radiator top rail. Disconnect the amplifier harness (3, Fig. 162), the coil and the amplifier from the radiator top rail. Remove the fan cowl securing nuts (4, Fig. 162) and pull the cowl (5, Fig. 162) clear of the radiator. Remove the top rail (6, Fig. 162). Remove the top hose (7, Fig. 162) from the thermostat housing, the bottom hose from the water pump outlet (8, Fig. 162) and the overflow pipe from the radiator (9, Fig. 162). Disconnect the thermostatic switch wires, lift the radiator from the vehicle and remove the fan cowl.

Completely remove the receiver/dryer mounting clamps (10, Fig. 162); remove the radiator auxiliary electric fan complete (11, Fig. 162). Remove the front engine bay tie bars (12, Fig. 162), the horns and brackets, disconnect the engine oil cooler pipes, collect the 'O' rings and remove the oil cooler radiator (13, Fig. 162), position the air conditioning radiator and receiver/dryer as far forward in the engine bay as possible.

Remove the oil cooler pipe securing bracket (14, Fig. 162) and secure the pipes to the engine (1, Fig. 168).

Remove the air conditioning compressor from the engine.

Disconnect the engine electrical 'white' block connectors (15, Fig. 162), disconnect the power steering pump from the drive, and remove the coupling.

Disconnect the high tension lead (16, Fig. 162) from the ignition coil and also the front RH harness plugs (17, Fig. 162).

Remove the water hoses from the expansion tank to the water pump and thermostat housing (18, Fig. 162).

Depressurise the fuel system and disconnect the fuel feed pipe from the fuel rail (19, Fig. 162).

Disconnect the throttle cable from the throttle tower (20, Fig. 162), remove the throttle support bracket from the inlet manifold (21, Fig. 162).

Remove the fuel pipe from the pressure regulator (24, Fig. 162).

Remove the brake servo, the air conditioning, and the ECU vacuum pipes (22, Fig. 162) from the inlet manifold, and disconnect the starter motor electrical feed wires.

Fit two suitable engine lifting eyes.

Using Service Tool MS 53, support the engine by the rear lifting eye (1, Fig. 163). Raise the front of the vehicle and place on stands. Remove the engine earth strap, slacken and remove the exhaust downpipe.




Fig. 163




Fig. 164

Disconnect the gear lever linkage (1, Fig. 164) and the electrical connections. Disconnect the speedometer transducer block connector and remove the intermediate heat shield.

Take the weight of the gearbox with a suitable jack and remove mounting (1, Fig. 165).




Fig. 165

Remove the rear heat shield and propeller shaft, place a plug in the gearbox output to prevent leakage.

Disconnect the clutch slave cylinder from the bell housing.

Lower the vehicle and remove Service Tool MS 53.




Fig. 166

Attach a suitable engine lifting sling, remove the front engine mounting securing nuts (Figs. 166 & 167) and manoeuvre the engine and gearbox from the vehicle (Fig. 168).




Fig. 167




Fig. 168

Remove the gearbox and all ancillaries from the engine, fit to the replacement engine and refit the gearbox.

Lift the engine and gearbox assembly into the engine bay, align the mountings and gently lower the engine mountings onto the mounting rubbers and secure with the washers and nuts. Remove the hoist and fit Service tool MS 53 (1, Fig. 163).

Raise the front of the vehicle and place on stands.

Take the weight of the gearbox with a suitable jack; lift into position and fit the gearbox rear mounting complete (1, Fig. 165). Remove the blanking plug in the rear of the gearbox; refit the propeller shaft and heat shield. Reconnect all the electrical connections to the gearbox and fit the intermediate heat shield. Reconnect the gear lever (1, Fig. 164), refit the exhaust down pipes and the engine earth strap.

Reconnect the heater return hose and the water valve hose to the cylinder head.

Reconnect the starter and solenoid feed wires (upper spade). Connect the ECU, the brake servo, and air conditioning vacuum pipes to the inlet manifold (22, Fig. 162).

Refit the throttle cable and secure with the clip (20, Fig. 162), refit the throttle support bracket (21, Fig. 162), slacken the locknut (23, Fig. 162) and adjust the cable to obtain the correct tension.

Refit the fuel hoses to the manifold.

Remove the plugs from the pressure regulator and hose and connect the hose and secure with a clip (24, Fig. 162).

Connect the engine harness (15, Fig. 162), the air conditioning compressor and thermal fuse block connectors (17, Fig. 162) and secure the harness with a ratchet clip.

Connect the HT lead to the coil (16, Fig. 162), clean the power assisted steering (PAS) pump mating face, fit the coupling to the pump, align the (PAS) pump shaft with the distributor drive shaft, connect the pump assembly and secure with the bolts.

Align the compressor to the mounting bracket and align all mating holes, fit the bolts and spacers and reposition the link arm, refit the compressor drive belt, tension and tighten all the securing bolts. Position the oil cooler pipes, the receiver/drier (10, Fig. 162) and secure the oil cooler pipes with the inner wing bracket (shortest pipe lowest) (14, Fig. 162).

Lubricate and fit new 'O' rings to the oil cooler pipes and fit to the oil cooler radiator. Align the oil cooler (13, Fig. 162) to its mounting studs and secure with the nuts. Refit the horn assembly to the lower panel. Position the condenser and brackets.

Fit the lower crosstube and spacers, repeat for the upper tube (12, Fig. 162). Fit the fan and frame assembly (11, Fig. 162) into position, fit the harness clip to the mounting frame, tighten the screw and securing bolts. Connect the fan motor block connector (3, Fig. 162).

Ensure the condenser is still secured by the mounting brackets and that the pipes run along the inner wing.

Fit the air conditioning vacuum pipe clamps (25, Fig. 162), refit the fan cowl (5, Fig. 162) assembly and engage in the mounting rubbers.

Position the radiator on its mountings and refit the bottom water hose and tighten the clip (8, Fig. 162).

Reconnect the thermostatic switch feed wires and the expansion tank to water pump hose and tighten the clip (18, Fig. 162).

Connect the top hose to the thermostat housing and tighten the clip (18, Fig. 162). Fit the top rail (6, Fig. 162) to the radiator, condenser and body, position the earth leads to the outer bolt holes (26, Fig. 162) and secure the rail with the bolts.

Reposition the fan cowl over the top rail studs, position the fuse holder over the LH stud (27, Fig. 162) and tighten the centre and LH securing nuts.

Identify and connect the amplifier block connectors (3, Fig. 162), position the harness to the top rail and secure with the harness clip (28, Fig. 162), secure the amplifier harness with ratchet clips.

Position the receiver/drier clamps (1, Fig. 162) over the top rail studs and secure with the nuts and bolts. Fit the bonnet struts, refit the air cleaner element.

Remove the two engine lifting eyes.

Refill the engine with coolant and oil.

Refit the bonnet and close.

## CRANKSHAFT REAR OIL SEAL

### Renew

Remove the gearbox, bell housing and flywheel, remove the rear oil seal housing securing bolts (1, Fig. 96) and remove the housing (2, Fig. 96).

### DO NOT REMOVE THE PLASTIC 'O' RING PROTECTOR FROM THE SEAL PRIOR TO FITTING THE ENGINE.

Carefully remove the old rear oil seal from the housing, clean the housing and lubricate the seal mounting face (1, Fig. 105) and using tool No. 18G 134-8 and 18G 134 (2, Fig. 105) fit the seal (3, Fig. 105), to the housing (4, Fig. 105). Smear the gasket face with 'Hylosil', locate the plastic protector 'O' ring (1, Fig. 106) onto the end of the crankshaft (2, Fig. 106) and push the rear seal housing (3, Fig. 106) over the crankshaft and up to the rear cylinder block face. Fit the bolts, check that the sump face (1, Fig. 106) is flush with the cylinder block (1, Fig. 107) and tighten the bolts.

Refit the flywheel and tighten to the recommended torque, refit the bell housing and the gearbox.

## CYLINDER PRESSURES

### Check

Run the engine until it reaches its normal operating temperature. Remove all the sparking plugs, open the throttle fully and crank the engine over on the starter motor.

**NOTE:** The engine speed should not drop below 300rpm. For pressures and differential drop between cylinders see Engine Tuning.

## FLYWHEEL

### Renew

Remove the gearbox and the bell housing. Remove the eight securing bolts (1, Fig. 168A) and remove the flywheel (2, Fig. 168A).

Remove the needle roller race (3, Fig. 168A), refit to the replacement flywheel.

Refit the flywheel to the crankshaft and torque up the bolts to the recommended torque figure, refit the bell housing and the gearbox.

Maximum material removal allowance to clean up the clutch face 1mm.




Fig. 168A



## ENGINE ASSEMBLY

## Overhaul

Remove the engine and gearbox from the vehicle; detach the gearbox from the engine remove all ancillaries and fit the engine to a stand. Remove the distributor and disconnect the plug leads from the sparking plugs.

Remove the camshaft cover and the upper chain tensioner assembly (1, Fig. 169); discard the 'O' rings and gaskets. Move the




Fig. 169

camshaft top sprocket lock tabs (1, Fig. 170) away from the bolts, remove the sprocket securing bolts (2, Fig. 170) and collect the four tab washers, and remove the camshaft sprockets from the cylinder head.




Fig. 170

Position the chain (1, Fig. 171) between the upper dampers and fit an elastic band (2, Fig. 171) across the upper dampers, retaining the chain and the pivoting damper (3, Fig. 171) during the cylinder head removal.




Fig. 171

Remove the cylinder head/camshaft bearing cap securing bolts (1, Fig. 172), remove the cylinder head assembly.




Fig. 172

Fit 18G 1437 Service Tool (1, Fig. 173) to the front pulley and remove the damper




Fig. 173




Fig. 174

securing bolt. Using Service Tool 18G 1436 (1, Fig. 174) secure to the damper with two bolts (2, Fig. 174) and remove the damper assembly.

Turn the engine over in the stand and remove the sump pan securing bolts and remove the sump (1, Fig. 175).




Fig. 175

Remove the oil pick-up securing bolts and remove the assembly (1, Fig. 176).




Fig. 176

Remove the crankshaft windage tray securing bolts and remove the trays (1, Fig. 177).




Fig. 177

Knock down the oil pump sprocket lock tabs (1, Fig. 178), remove the bolts (2, Fig. 178) and tabs and collect the sprocket (3, Fig. 178). Note the amount and the thickness of the spacing shims behind the oil pump sprocket. Remove the oil pump securing bolts and the pump assembly.




Fig. 178

Remove the timing cover securing bolts (1, Fig. 179) and remove timing cover assembly (2, Fig. 179).




Fig. 179

Remove the oil pump drive chain (1, Fig. 180) and the elastic band (2, Fig. 180) from the upper dampers.

Remove the upper timing chain (3, Fig. 180). Remove the oil pump drive chain damper securing bolts (4, Fig. 180), remove the damper and pedestal (5, Fig. 180).

Remove the lower chain tensioner securing bolts (6, Fig. 180) and remove the tensioner (7, Fig. 180).

Remove the lower tensioner pivoting damper securing bolts (8, Fig. 180), collect the tab washer (9, Fig. 180) and damper assembly (10, Fig. 180).

Remove the spacing tubes from the damper assembly and the lower chain fixed damper securing bolts (11, Fig. 180). Remove the tab washer (12, Fig. 180) and damper (13, Fig. 180).

Remove the upper fixed damper securing bolts (14, Fig. 180) and tab washer (15, Fig. 180), remove the damper (16, Fig. 180). Remove the upper pivoting damper pedestal securing bolts (17,




Fig. 180

Fig. 180), the pedestal and damper (18, Fig. 180).

Remove the intermediate sprocket and lower chain.

Remove the crankshaft damper woodruff key (1, Fig. 181) and spacer.

Remove the crankshaft sprocket (2, Fig. 181) and inner woodruff key.




Fig. 181

Remove the oil seal (1, Fig. 182) from the power assisted steering end of the distributor drive gear shaft using Service Tool 18G 1468. Remove the shaft securing circlip (2, Fig. 182), the drive gear sprocket and thrust washer.

Remove the three auxiliary drive gear bearing housing set screws (3, Fig. 182), remove the housing and discard the gasket.




Fig. 182

Remove the rear oil seal housing securing bolts (1, Fig. 183) and remove the housing complete with seal (2, Fig. 183).




Fig. 183

Turn the crankshaft until Nos. 1 and 6 connecting rod caps are accessible, slacken and remove the big end securing nuts (1, Fig. 184).

Remove the cap (2, Fig. 184) and carefully push the connecting rod (3, Fig. 184) and piston assembly out through the top of the cylinder block, repeat this procedure for Nos. 2 and 5 connecting rods and pistons and 3 and 4. Ensure that upon removal of connecting rods and caps they are not inter-mixed.




Fig. 184

Remove the main bearing cap securing bolts (2, Fig. 185), remove the caps (1, Fig. 185) and then carefully remove the crankshaft (3, Fig. 185), collect the bearing shells and thrust washers.




Fig. 185

Fit suitable bolts (1, Fig. 186) to the oil gallery plugs (2, Fig. 186) and pull to remove.




Fig. 186

Clean all the oil galleries, cylinder bores, dowels, distributor shaft mounting, main bearing cap and thrust faces.

Check the bore wear in the cylinder block with a suitable comparator (Fig. 187). This should be done in at least six positions in the bore (Fig. 188).

**NOTE:** Maximum bore wear normally occurs towards the top of the bore across its thrust access.






Fig. 187



J12 239


Fig. 188

Fig. 189 shows acceptable and unacceptable cylinder bore surface finishes. In all cases except A the cylinder block should be rebored, the sizes of O/S pistons are listed below. In the case of A the cylinder block should be honed using a suitable glaze buster (Fig. 190). Should the bore need to be inspected prior to removal of the cylinder head, a sparking plug may be removed and a suitable borescope may be used (Fig. 191).




A

B



C

D



E

Fig. 189





Fig. 190



J12 331

Fig. 191

**RING GAPS**

|                    |               |
|--------------------|---------------|
| Top compression    | 0.4 — 0.65 mm |
| Second compression | 0.4 — 0.65 mm |
| Oil control        | 0.3 — 0.55 mm |



If new piston rings are being fitted without reboring, deglaze the cylinder bores using a hone or 'glazebuster' without increasing the size of the bore; a deglazed bore will have a cross-hatched finish.

Remove the piston rings and clean the carbon and deposits from the piston crown and skirt. Using a suitable piston groove cleaner, ensure that all deposits are removed from the grooves. Examine the pistons for damage or excessive wear.

If gauge equipment is not available, the piston clearance can be measured using a long feeler gauge. Insert a long suitably sized feeler gauge down the RH side of the cylinder bore, insert the correct piston inverted into the cylinder bore, and position it with the gudgeon pin parallel with the axis of the crankshaft.

Push the piston down the cylinder until it reaches its tightest point in the bore; at this point, withdraw the feeler gauge; a steady resistance should be felt.

If standard sized pistons are being fitted, use pistons of the same grade as the markings on the cylinder block.

Fit the piston rings into the bores and check the clearance with a feeler gauge; should this clearance be insufficient, a small amount of material may be removed from either butting end of the ring using a carborundum stone. Following this operation, ensure that the edges of the ring are chamfered and that no burrs remain before refitting a ring back into a bore.

**NOTE:** Once these rings are correctly gapped, great care must be taken not to intermix them, and that each piston is numbered to its respective bore.

Fit the bearing shells to the connecting rods and fit each rod in turn to the crankshaft. Torque up the nuts and check the end float between the end face of the connecting rod and the journal shoulder (1, Fig. 192) the tolerance is given in General Specification.

Remove the connecting rods from the crankshaft and retain all parts in related sets.

Check the crankshaft journals for wear and ovality, the tolerances are:

|                   |   |
|-------------------|---|
| Main              | 76.231 mm (3.0012 in)   |
| Thrust width      | 36.233 to 36.208 mm<br>(1.4265 to 1.4255 in)                      |
| Big end tolerance | 52.987 mm (2.0861 in)<br>52.974 mm (2.0856 in)                    |
| Running clearance | 0.0010 to 0.0027 in<br>0.041 to 0.084 mm<br>(0.0016 to 0.0033 in) |

Should the tolerances be outside these dimensions, the crankshaft should be renewed.




Fig. 192

Prior to fitting the connecting rods to the pistons, check them for twist (Fig. 196) or bend (Fig. 197). If the out of or one is twisted or bent, the rods must be changed as a set.




Fig. 193




Fig. 194

Fit Service Tool No. 18G 1434 to the intermediate sprocket bearing (1, Fig. 195) and remove the bearing.




Fig. 195

Refit the new intermediate sprocket bearing (1, Fig. 196), ensuring that the oil feed hole lines up with the drilling (1, Fig. 197) in the cylinder block. Use Service Tool No. 18G 1434 (2, Fig. 196) with the flange towards the cylinder block and tap the end of the tool until the flange rests against the cylinder block.




Fig. 196




Fig. 197

Fit new 'O' rings to the oil gallery plugs, lubricate the rings and install the plugs into the cylinder block oil gallery.

Fit the main bearing shells to the cylinder block and lubricate with engine oil (Fig. 198). Clean the crankshaft and inspect the journals for marks and scratches, and if necessary polish them out using lapping tape, and also only move the tape in an anti-clockwise direction against the crankshaft; carefully lower the crankshaft into the cylinder block.




Fig. 198

Fit the thrust washers with the grooved side to the crankshaft (1, Fig. 199); mount a dial test indicator and check the crankshaft end float (1, Fig. 200). This should be 0.004 to 0.010 in. Should the end float exceed these




Fig. 199




Fig. 200

figures, then the standard sized thrust washers should be removed and replaced with oversize washers until the crankshaft endfloat is within these tolerances. Lubricate the crankshaft journals with engine oil.




Fig. 201




Fig. 202

Fit the remaining shells to the main bearing caps; lubricate the shells with clean engine oil and fit to the cylinder block. Note the caps are numbered to the cylinder block (Fig. 201), tighten the cap securing bolts in the sequence illustrated (Fig. 202), ensuring that after each cap is torqued down the crankshaft still spins freely with only hand pressure.

**DO NOT REMOVE THE PLASTIC 'O' RING PROTECTOR FROM THE SEAL PRIOR TO FITTING TO THE ENGINE.**

Carefully remove the old rear oil seal from the housing, clean the housing and lubricate the seal mounting face, and using tool No. 18G 134-8 fit the seal to the housing (1, Fig. 203). Smear the gasket face with




Fig. 203

'Hylosil', locate the plastic protector 'O' ring (1, Fig. 204) onto the end of the crankshaft (2, Fig. 204) and push the rear seal (3, Fig. 204) housing over the crankshaft and up to the rear cylinder block face. Fit the




Fig. 204

securing bolts (1, Fig. 205) and by adjusting the housing (2, Fig. 205) ensure that the face is flush with the cylinder block (Fig. 206) and tighten the securing bolts.






Fig. 205




Fig. 206

Fit dummy bolts (1, Fig. 207) to the rear of the crankshaft to assist rotation of the crankshaft.




Fig. 207

Fit the rings to the pistons. Lubricate the small end bushes and fit the rods to the pistons and secure with the circlips (1, Fig. 208), ensuring that the connecting rods are correctly fitted in the piston (Fig. 208).




Fig. 208

Oil the piston rings and the cylinder bores. Position the piston ring gaps as in (Fig. 209) and fit Service Tool 18G 55A to the piston (1, Fig. 210) and compress the rings, insert the piston in the bore with the marking



Fig. 209

'FRONT' facing towards the front of the engine and push the piston down in the bore, ensuring that the connecting rod is the correct side of the crankshaft. Fit the bearing to the connecting rod, oil and fit it to the crankshaft. Fit a bearing to the big end




Fig. 210

cap, oil and fit to the connecting rod. Note the cap and rod are numbered to each other, ensure they are fitted as (1, Fig. 211). Fit and torque up the nuts. Turn the crankshaft over and ensure that there are no tight spots. Repeat this procedure for the remaining five cylinders.




Fig. 211

Using Service Tool 18G 1434 remove the bearings from the timing cover (Fig. 212). Clean the cover and using Service Tool (1, Fig. 213), fit new bearings (2, Fig. 213) to the cover (3, Fig. 213).




Fig. 212




Fig. 213

Fit a new gasket to the auxiliary drive housing (1, Fig. 214), align and fit the housing to the cylinder block, apply 'Hylomar' to the securing screws (2, Fig. 214), fit and tighten the securing screws. Clean the drive gear and thrust washer, lubricate the shaft and fit the shaft (3, Fig. 214) to the housing, fit the thrust washer and secure with a circlip. Lubricate the oil seal mounting face and the outer edge of the seal and using Service Tool 18G 1469 (4, Fig. 214), fit and seat the oil seal (5, Fig. 214).




Fig. 214

Clean and inspect for wear or damage all the timing gears, chains, guides and tensioners.

Fit and seat the crankshaft sprocket woodruff key and push the sprocket (1, Fig. 215) onto the crankshaft. Lubricate the lower timing chain, fit the chain to the intermediate sprocket, fit the chain to the lower sprocket (2, Fig. 215), and then assemble the intermediate sprocket (3, Fig. 215) to the cylinder block.




Fig. 215

Fit the spacers to the lower pivoting damper (4, Fig. 215) and fit the assembly to the cylinder block, fit a tab washer and bolts, tighten the bolts and knock the tabs up to secure the bolts.

Clean the lower tensioner assembly, remove the ball valve and ensure that the bottom of the housing is clean, check that the ball valve is free by shaking and ensuring it rattles. If it does not, replace the valve assembly. If it does, renew the 'O' ring, lubricate the ring and press the valve back into the housing.

Inspect the housing and hydraulic tensioner for wear or scoring. Also check that the oil hole is clear in the end of the piston. Lubricate the component parts. Assemble the tensioner by pressing and twisting the snail clockwise until the peg locks in the 'park' position. Insert the tensioner assembly into the housing and fit the housing to the cylinder block (5, Fig. 215). Fit and tighten the securing bolts.

Fit the lower static damper (6, Fig. 215), fit the tab washers and bolts, tighten the bolts and knock up the tabs.

Release the tensioner by pushing the tensioner back into the housing and releasing; this should release the tensioner and so tension the chain.

Fit the oil pump drive chain damper and pedestal (7, Fig. 215). Fit but do not tighten the damper securing bolts. Fit the upper static damper (8, Fig. 215) and pedestal and fit the securing bolts. Fit the upper pivoting damper (9, Fig. 215) and tighten the damper securing bolts; finally tighten the damper pedestal securing bolt and knock up the tabs.

Fit a dial gauge to the top of the cylinder block, and turn the engine over until No. 1 on 6 pistons are at TDC (1, Fig. 216). Lubricate the upper chain and fit it to the intermediate sprocket; fit an elastic band to the upper dampers (10, Fig. 215).




Fig. 216

Lubricate the oil pump drive chain, fit the chain to the crankshaft sprocket and lodge in the correct position.

Remove timing cover blanking plates and pointer. Remove the front oil seal and distributor drive gear shaft seal. Lubricate the oil seals and fit to the cover ensuring that the crankshaft seal is flush with the front cover (1, Fig. 217). Fit the timing pointer, smear the blanking plate surfaces




Fig. 217

with 'Hylosil' and fit the blanking plates. Smear the cylinder block with 'Hylosil' lubricate the bearing shells and carefully fit the timing cover to the engine, ensuring the top face is flush with the top of the cylinder block (Fig. 218), fit and tighten the securing bolts. Lubricate the oil seal distance piece. Fit and seat the damper woodruff key.




Fig. 218

Remove the oil pump pressure relief valve retaining nut, remove the spring, tube and valve, clean and check for wear or scoring. Remove the pump body securing bolts and remove the outer rotor. Remove the backplate securing bolts, the backplate, and the bearing shell from the housing. Clean all dismantled parts and check for obvious wear or scoring.

Fit the outer rotor and check the clearance between the rotor and the oil pump housing. Should any clearance exceed the specified tolerances (see General Specification) the assembly, i.e. rotor outer housing assembly, must be replaced.

Lubricate the bearing shell (1, Fig. 219) and fit to the pump housing (2, Fig. 219). Smear backplate gasket face (3, Fig. 219) with sealant and fit the backplate and tighten the securing bolts (4, Fig. 219).

Lubricate the pump inner (5, Fig. 219) and outer rotors (6, Fig. 219), the bearing and the housing. Fit the outer rotor, smear the gasket face with sealant, fit and seat the pump body and tighten the securing bolts.




Fig. 219

Lubricate and assemble the relief valve (7, Fig. 219), spring (8, Fig. 219) and tube (9, Fig. 219) to the pump. Fit and tighten the relief valve cap (10, Fig. 219).

Fit the oil pump to the engine and tighten the securing bolts.



Clean oil pump drive sprocket, offer up the sprocket to the oil pump drive flange, place a straight edge (1, Fig. 220) between the crankshaft sprocket and the oil pump drive sprocket and shim out the oil pump drive sprocket until the two sprockets are perfectly in line. Once the necessary shim




Fig. 220

pack has been selected, fit the shims to the oil pump, locate the sprocket (1, Fig. 221) in the drive chain (2, Fig. 221), offer up the sprocket to the pump and align the securing bolt holes, fit the tab washers (3, Fig. 221) and the securing bolts (4, Fig. 221), tighten the bolts and knock up the lock tabs, position the oil pump chain damper and tighten the securing bolts.




Fig. 221

Clean and fit the crankshaft windage trays (1, Fig. 222) and tighten the securing bolts. Clean all the oil pick-up pipes and housings. Fit new 'O' rings to the oil pick-up pipes. Smear the pick-up gasket face with 'Hylosil' and fit the pick-up pipe to the housing and secure with the bolts. Lubricate the oil pipe 'O' rings and fit the pipes to the housing. Smear the housing (2, Fig. 222) to cylinder block gasket face with 'Hylosil', engage the




Fig. 222

pipes (3, Fig. 222) in the rear face of the oil pump, ensuring that the 'O' rings (1, Fig. 223) enter the housing easily. Fit and tighten the housing securing bolts.




Fig. 223

Remove the sump baffle securing bolts, remove the baffle, clean the sump and the baffle, refit the baffle and secure with the bolts. Smear the sump gasket face with 'Hylosil' and fit the sump (1, Fig. 224) to the engine and tighten the securing bolts.




Fig. 224

Place the cylinder head on suitable wooden blocks.

Remove the sparking plugs, the exhaust manifold securing bolts, the inlet manifolds and collect the gaskets.

Remove the camshaft cap securing bolts, lift off the caps and remove the camshafts.

Using a magnet, lift out the cam followers, remove the shims and using Service Tool 18G 106A (1, Fig. 225) compress the valve springs and remove the spring retaining collets (2, Fig. 225). Release the tension on Tool 18G 106A and remove the top collar, the springs, the spring seats and the valve; repeat this operation for the remaining 23 valves.




Fig. 225

Remove the seals from the inlet valve guides and remove the cylinder head rear blanking plate.

Clean all component parts and check for wear and also burning of valves or seats.

Taking care not to damage the inside surface of the combustion chambers, clean the cylinder head gasket surface and the inlet and exhaust ports. When using scrapers or wire brushes for removing carbon deposits, avoid scratching the valve faces and seats. A soft wire brush is the most suitable implement for this purpose. Clean all carbon and other deposits from the valve guides using a suitable valve guide brush. Thoroughly wash the cylinder head to ensure that all loose carbon is removed, dry off with a high pressure air line.

After cleaning and polishing each valve, examine the stems for straightness and wear, and the faces for burns, pitting or distortion.

Renew valves which are excessively worn, bent or too badly pitted to be salvaged by refacing.

**NOTE:** No attempt should be made to clean up a burnt or badly pitted valve face by the extensive 'grinding in' of the valve to the seat.

Lightly tap the valves into the seals with a fine grinding compound. The reseating operation should leave the finished surfaces smooth. Excessive tapping will groove the valve face resulting in a poor seat when hot.

To test the valves for concentricity with their seats, coat the face of the valve with Engineers' blue or similar, and rotate the valve against the seat. If the valve face is concentric with the valve stem, a mark will be made all round the face.



Should a mark be made on only one side of the face, the face is not concentric with the valve stem. Should the seat not be concentric the valve seat should be recut. Clean the valve and again coat with Engineers' blue and rotate the valve against the seat to ascertain that the valve guide is concentric with the valve seat.

Whenever valves are replaced, the seats must be recut prior to lapping of the valves. Check the valve guide wear by inserting a new valve into the guide to be checked; lift it 3 mm ( $\frac{1}{8}$  in) from its seat and rock it sideways. Movement of the valve across its seat (A, Fig. 226) must not exceed 0.5 mm (0.020 in) (Fig. 226). Should the movement




Fig. 226

exceed this tolerance, the valve guide must be replaced. This is achieved by using Service Tool 18G 1432 to drift out of the old guide (1, Fig. 227). Ensure that the relevant Service guide is selected prior to fitting.




Fig. 227

Ream the cylinder head to the relevant dimension (see chart). Coat the guide with graphite grease and fit to the cylinder head after it has been immersed in boiling water for 30 minutes (1, Fig. 228).




Fig. 228

After fitting a valve guide, the valve seat must be recut using Service Tool MS 204 (1, Fig. 229).




Fig. 229

**NOTE:** Should the valve seats need replacing see page 12—38.

Examine the cam followers for wear on the top face (Fig. 230) and any sign of barrelling on the side faces (Fig. 231).

Replace all followers that are worn or suspect. Wash the cylinder head, the valves, spring, collets, cups and followers and air dry.




Fig. 230





Fig. 231

After the valve springs have been thoroughly washed, they must be examined for fatigue and distortion.

Fatigue is determined by measuring its free length and distortion by positioning it upright on a surface plate or table and the squareness of each end is determined by utilising a set square (Fig. 232).




J12 370

Fig. 232

All valve springs which have diminished in length and/or are not square must be discarded and new replacements fitted.

Test the valve springs for pressure, either by comparison with the figures given in the 'General Specification Data', using a recommended valve spring testing machine (Fig. 233), or by comparison with a new valve spring.



J12 371

Fig. 233

| IDENTIFICATION FOR OVERSIZE | PART NO. | DIMENSION A      | DIMENSION TO BE REAMED TO IN CYLINDER HEAD | APPLICATION |
|-----------------------------|----------|------------------|--|-------------|
| Plain                       | C29388   | 0.5020 to 0.5015 | —  | Production  |
| 1 groove                    | C29389   | 0.5040 to 0.5035 | —  | Production  |
| 2 grooves                   | C29390   | 0.5070 to 0.5065 | 0.5055 to 0.5048                           | Service     |
| 3 grooves                   | C29391   | 0.5120 to 0.5115 | 0.5105 to 0.5098                           | Service     |

To test against a new valve spring, insert both valve springs to end between the jaws of a vice or under a press with a flat metal plate interposed between the two springs. Apply a load to compress the springs partly and measure their comparative lengths. If 'B' (Fig. 234) is new spring and distance 'A' is less than B then Spring A must be replaced as it is weak.




Fig. 234

Oil all the valve train components.

Assemble the valves one at a time, ensuring that the valves are assembled to the valve seat they were lapped to. Fit the spring seat and new valve stem seals, fit the springs and top collar and using Service Tool 18G 106A compress the spring until the retaining collets can be inserted through the collar, and locate in the valve stem. Before removing the valve spring compressor tool, ensure that the retaining collets (1, Fig. 235) are still located in the valve stem (2, Fig. 235). Replace the original shim in




Fig. 235

the top of the collar, ensuring that it is not tipped (1, Fig. 236) or slightly on top of the collar, and fit the cam follower. Repeat this operation for the remaining 23 valves.

**NOTE:** If the cylinder head has been overhauled to the extent of having the valve seats recut, use a shim size 0.010 in smaller than the original.




Fig. 236

Lubricate the camshafts and fit to the cylinder head, ensuring that they are fitted with the slot to the top and that the No. 1 cylinder camshaft lobes are facing each other. Fit the camshaft caps and torque up the securing bolts in the sequence (Fig. 237). Fit slave bolts to the camshafts and measure the clearances between the heel of the camshaft and the cam followers (1, Fig. 238) turning the camshafts as necessary to measure all the clearances. Valve clearances are 0.012 to 0.014 in.




Fig. 237




Fig. 238

Should any of the clearances be incorrect, remove the camshaft caps, the camshafts and the cam followers using a suitable magnet. Remove all the shims or only those requiring adjustment; check with a micrometer the size of the existing shims and note the reading. Calculate the size of the shim required following the example below for either excessive clearance or insufficient clearance.

## EXCESSIVE CLEARANCE

|                                    | INCHES |
|------------------------------------|--------|
| Size of existing shim              | 0.100  |
| Plus the actual clearance noted    | 0.019  |
|                                    | 0.119  |
| Less the specified valve clearance | 0.013  |
| = required shim size               | 0.106  |

## INSUFFICIENT CLEARANCE

|                                    | INCHES |
|------------------------------------|--------|
| Size of existing shim              | 0.107  |
| Plus the actual clearance noted    | 0.010  |
|                                    | 0.117  |
| Less the specified valve clearance | 0.013  |
| = required shim size               | 0.104  |

## SHIM SIZES

| Letter | Thickness |
|--------|-----------|
| A      | 0.085 in  |
| B      | 0.086 in  |
| C      | 0.087 in  |
| D      | 0.088 in  |
| E      | 0.089 in  |
| F      | 0.090 in  |
| G      | 0.091 in  |
| H      | 0.092 in  |
| I      | 0.093 in  |
| J      | 0.094 in  |
| K      | 0.095 in  |
| L      | 0.096 in  |
| M      | 0.097 in  |
| N      | 0.098 in  |
| O      | 0.099 in  |
| P      | 0.100 in  |
| Q      | 0.101 in  |
| R      | 0.102 in  |
| S      | 0.103 in  |
| T      | 0.104 in  |
| U      | 0.105 in  |
| V      | 0.106 in  |
| W      | 0.107 in  |
| X      | 0.108 in  |

Fit the shims as determined by the calculations to the appropriate valves; refit the camshafts and the camshaft caps and recheck the valve clearances.



**NOTE:** A final check of the valve clearances should be carried out with the cylinder head fitted to the cylinder block.

Using Tool 18G 1433 set the inlet and exhaust camshafts to TDC (1, Fig. 239).




Fig. 239

Remove the camshaft slave bolts and fit the lifting eye to the inlet manifold securing studs; fit and tighten the nuts.

Clean the exhaust manifolds; fit new manifold gaskets, fit the manifolds and the rear lifting eye, fit and tighten the securing nuts.

Clean and check the upper chain upper damper for wear or scoring; should either of these conditions prevail, then the damper must be removed from its pedestal and a new part fitted. Should this be necessary; when refitting the damper to the pedestal, fit but do not tighten the damper to pedestal securing bolts.

Clean the crankshaft damper (1, Fig. 240) and fit the assembly to the crankshaft; fit but do not tighten the damper securing bolt. Fit the front pulley lock, Service Tool No. 18G 1437 to the front damper and tighten the damper nut. Check the front damper run out (Fig. 241) and ensure it is not excessive. Ensure that both No. 1 and No. 6 pistons are still at TDC.




Fig. 240

Remove the camshaft inner sprocket securing clips (1, Fig. 243) and inner sprockets. Clean both the inner (2, Fig. 243) and outer (3, Fig. 243) sprockets and check the outer sprocket for wear and chips on the drive teeth and wear on the inner serrations. Also check the inner sprocket for wear on its outer serrations; replace any suspect items and assemble the sprockets and secure with the circlips. Ensure that both the top of the




Fig. 241

cylinder block and the mating face of the cylinder head are clean and dry and fit a new cylinder head gasket.




Fig. 242




Fig. 243

Fit the cylinder head assembly to the cylinder block; fit the chain damper and pedestal assembly and fit the cylinder head

attachment bolts. Tighten the bolts to a torque figure of 38 to 40 lb ft and then turn the bolt clockwise through, exactly 90°; carry this out in the sequence (Fig. 242).

**NOTE:** To assist the accuracy of the rotation through 90° a suggested tool is illustrated on page 12—6.

Lift the timing chain and remove the elastic band, position the chain over the ends of the camshafts. Fit and engage the camshaft drive sprockets (1, Fig. 244) with the chain and the camshafts ensuring that all the chain 'slack' is towards the pivoting tensioner.




Fig. 244

Strip the upper tensioner and inspect its component parts for wear or damage. Check that the ball is free in the non return valve (1, Fig. 245) and also that the peening securing the end plate is in good condition. Fit new 'O' rings to the valve (2, Fig. 245), fit the assembly into the piston housing.




Fig. 245

Lubricate the snail (1, Fig. 246), spring (2, Fig. 246) and spring mandrel (3, Fig. 246) and assemble to the piston (4, Fig. 246), ensure the bleed hole in the end of the piston is clear (1, Fig. 247).

Engage the snail (1, Fig. 246) with the peg and rotate the snail (1, Fig. 246) clockwise and depress until the peg engages in the 'park' position in the snail (1, Fig. 246).





Fig. 246



J12-385

Fig. 247

Fit a new 'O' ring (1, Fig. 248) to the housing and lubricate, fit a new gasket (2, Fig. 248) to the housing and fit the assembly (3, Fig. 248) to the cylinder head, ensuring that the tensioner is properly




Fig. 248

engaged on the pivoting guide. Fit but do not tighten the tensioner securing bolt (1, Fig. 249), fit the valve retainer securing bolt (2, Fig. 249) (four threads only). Fully tighten the lower securing bolt. Release the tensioner using a 3 mm Allen key, fit the valve assembly (3, Fig. 249), engage the retainer plate (4, Fig. 249) and fully tighten the securing bolt (2, Fig. 249).




Fig. 249

Remove the inner camshaft sprocket securing clip, remove the inner sprocket and align the holes in the inner sprocket with the holes in the camshaft. Fit the tab washers and securing bolts (1, Fig. 250) but do not fully torque up the bolts, refit the inner sprocket securing clip (2, Fig. 250). Repeat for the other camshaft sprocket. Tighten all

the sprocket securing bolts, knock up the lock tabs (3, Fig. 250), position the upper chain upper damper (4, Fig. 250) and tighten the securing bolts and knock-up the lock tabs (5, Fig. 250).




Fig. 250

Remove the baffle plate inside the camshaft cover and clean the camcover, and baffle, refit the baffle to the cover and secure with the bolts. Fit the plug well seals and the cam cover gasket, fit the half moon seals to the cylinder head and fit the camcover to the engine (1, Fig. 251), fit and tighten the securing screws (2, Fig. 251).




Fig. 251

Check gap of new sparking plugs and fit to cylinder head.

Fit a new 'O' ring to the distributor, lubricate the 'O' ring and gear, turn the rotor arm to the position illustrated in (Fig. 252) and fit the distributor in the position shown in (Fig. 252) (TDC No. 1). Fit the distributor clamp plate securing bolt, leave the clamp plate securing bolt, slightly slack. Reconnect the distributor/amplifier block connector (1, Fig. 252). Fit the distributor cap and tighten the securing screws. Connect the sparking plug leads in the firing order 1, 5, 3, 6, 2, 4.





Fig. 252

**NOTE:** The distributor turns clockwise as viewed from the top.

Remove the engine from the stand refit all ancillaries and refit the engine to the vehicle and reset the ignition timing.




J12-402

UK SPECIFICATION




## KEY FOR FIG. 253

- |                                 |                                  |                                  |
|---------------------------------|----------------------------------|----------------------------------|
| 1. Spark plug                   | 35. Engine mounting              | 69. Timing pointer               |
| 2. Camshaft cover               | 36. Thrust washer bearing        | 70. Closing plate                |
| 3. Plug well seal               | 37. Main bearing and cap         | 71. Bearing                      |
| 4. Camshaft cover gasket        | 38. Windage tray                 | 72. Closing plate                |
| 5. Half moon sealing plug       | 39. Main bearing cap             | 73. Bearing                      |
| 6. Camshaft cap                 | 40. Windage tray                 | 74. Auxillary shaft              |
| 7. Exhaust camshaft             | 41. Oil pick up                  | 75. Intermediate timing chain    |
| 8. Inlet camshaft               | 42. Sump baffle                  | 76. Intermediate sprocket        |
| 9. Spring retaining collar      | 43. Sump                         | 77. Upper timing chain           |
| 10. Valve spring                | 44. Oil drain plug               | 78. Upper pivoting chain damper  |
| 11. Valve stem seal             | 45. Oil pick up pipes            | 79. Upper static chain damper    |
| 12. Spring seat                 | 46. Alternator mounting bracket  | 80. Spacer                       |
| 13. Cam follower                | 47. Washer                       | 81. Bearing                      |
| 14. Shim                        | 48. Inspection plug              | 82. Sealing plug                 |
| 15. Collet                      | 49. Shim                         | 83. Connecting rod bearings      |
| 16. Cylinder closing plate      | 50. Oil pump drive sprocket      | 84. Connecting rod               |
| 17. Cylinder head               | 51. Lock tab plate               | 85. Piston                       |
| 18. Cylinder gasket             | 52. Oil pump                     | 86. Gudgeon pin                  |
| 19. Oil filler tube             | 53. Main bearing and cap         | 87. Circlip                      |
| 20. Exhaust valves              | 54. Woodruff key                 | 88. Piston rings                 |
| 21. Inlet valve                 | 55. Spacer                       | 89. Upper timing chain tensioner |
| 22. Small end bush              | 56. Oil pump chain tensioner     | 90. 'O' rings                    |
| 23. Connecting rod cap          | 57. Lower static chain damper    | 91. Locking plate                |
| 24. Cylinder block              | 58. Lower pivoting chain damper  | 92. One way valve                |
| 25. Water pipe                  | 59. Oil pump drive chain         | 93. Tensioner housing            |
| 26. Rear oil seal housing       | 60. Crankshaft sprocket          | 94. Gasket                       |
| 27. Rear oil seal               | 61. Lower chain tensioner        | 95. Upper spacer                 |
| 28. Oil filter housing          | 62. Timing chain cover           | 96. Chain upper damper           |
| 29. Oil filter                  | 63. Front crankshaft oil seal    | 97. Cylinder head securing bolt  |
| 30. Filler tube oil seal        | 64. Spacer                       | 98. Spring clip                  |
| 31. Filler tube mounting        | 65. Timing disc                  | 99. Inner sprocket               |
| 32. Baffle                      | 66. Crankshaft damper            | 100. Outer sprocket              |
| 33. Oil cooler take off housing | 67. Front pulley                 | 101. Front camshaft cap          |
| 34. Crankshaft                  | 68. Crankshaft front pulley bolt |                                  |




J12-390

Fig. 253



**XJ-S 3·6  
XJ-SC 3·6  
SERVICE  
MANUAL**







## **BOOK 3**

**Containing  
Sections**

**17 EMISSION CONTROL  
19 FUEL SYSTEM  
26 COOLING SYSTEM  
30 MANIFOLD & EXHAUST**

**XJ-S 3·6  
XJ-SC 3·6**

**SERVICE MANUAL**

---

## INTRODUCTION

This Service Manual covers the Jaguar XJ-S 3.6 and XJ-SC 3.6. It is primarily designed to assist skilled technicians in the efficient repair and maintenance of this range of Jaguar cars.

Using the appropriate service tools and carrying out the procedures as detailed will enable the operations to be completed within the time stated in the 'Repair Operation Times'.

The Service Manual has been produced in 9 separate books; this allows the information to be distributed throughout the specialist areas of the modern service facility.

A table of contents in Book 1 lists the major components and systems together with the section and book numbers. The cover of each book depicts graphically and numerically the sections contained within that book.

The title page of each book carries the part numbers required to order replacement books, binders or complete Service Manuals. This can be done through the normal channels.

The contents section of each book lists the repair operations in the section or sections contained within that book. Each operation is given an operation number that corresponds with those listed in the Repair Operation Times.

The method described on the page number listed against the operation will be the one we consider will meet the requirements of safety and enable the operation to be carried out in the time specified in the Repair Operation Times.

Where no page number is given against an operation, we feel that the method is so obvious as to warrant no explanation. It is, however, included so that a warranty time can be given in the Repair Operation Times.

Extensive research has gone into the diagnosis of faults and where appropriate this is covered in the various areas of the manual. By following the sequence of the diagnosis charts, speedy isolation of faults may be expected, and consequent correction will reduce the vehicle off-the-road time to the minimum.

### Service Tools

Where performance of an operation requires the use of a service tool the tool number is quoted under the operation heading and is repeated in, or following, the instruction involving its use. A list of all necessary tools is included in Book 1, Section 99.

### References

References to the LH or RH side in the manual are made when viewing from the rear. With the engine and gearbox assembly removed the timing cover end of the engine is referred to as the front. A key to abbreviations and symbols is given in Book 1, Section 01.

## REPAIRS AND REPLACEMENTS

When service parts are required it is essential that only genuine Jaguar or Unipart replacements are used.

Attention is particularly drawn to the following points concerning repairs and the fitting of replacement parts and accessories.

1. Safety features embodied in the vehicle may be impaired if other than genuine parts are fitted. In certain territories, legislation prohibits the fitting of parts not to the vehicle manufacturer's specification.
2. Torque wrench setting figures given in this Service Manual must be strictly adhered to.
3. Locking devices, where specified, must be fitted. If the efficiency of a locking device is impaired during removal it must be replaced.
4. Owners purchasing accessories while travelling abroad should ensure that the accessory and its fitted location on the vehicle conform to mandatory requirements existing in their country of origin.
5. The vehicle warranty may be invalidated by the fitting of other than genuine Jaguar or Unipart parts. All Jaguar and Unipart replacements have the full backing of the factory warranty.
6. Jaguar Distributors and Dealers are obliged to supply only genuine service parts.

## SPECIFICATION

Purchasers are advised that the specification details set out in this Manual apply to a range of vehicles and not to any one. For the specification of a particular vehicle, purchasers should consult their Distributor or Dealer.

The Manufacturers reserve the right to vary their specifications with or without notice, and at such times and in such manner as they think fit. Major as well as minor changes may be involved in accordance with the Manufacturer's policy of constant product improvement.

Whilst every effort is made to ensure the accuracy of the particulars contained in this Manual, neither the Manufacturer nor the Distributor or Dealer, by whom this Manual is supplied, shall in any circumstances be held liable for any inaccuracy or the consequences thereof.

## COPYRIGHT

© Jaguar Cars Ltd. 1983

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, electronic, mechanical, photocopying, recording or other means without prior written permission of Jaguar Cars Ltd., Service Department, Radford, Coventry CV6 3GB.

## CONTENTS

| Operation  | Operation No. | Page No. |
|--|---------------|----------|
| Adsorption canister — Renew .....                        | 17.15.13      | 17—6     |
| Air injection — Description .....                        | —             | 17—2     |
| Air pump — Renew .....                                   | 17.25.07      | 17—4     |
| Air pump belt — Adjust .....                             | 17.25.13      | 17—4     |
| Air pump clutch — Renew .....                            | 17.25.08      | 17—4     |
| Air switching valve — Renew .....                        | 17.25.38      | 17—5     |
| <br>Crankcase ventilation — Description .....            | —             | 17—3     |
| Crankcase throttle control orifice housing — Renew ..... | 17.10.12      | 17—6     |
| <br>Evaporative emission control — Description .....     | —             | 17—3     |
| Exhaust back pressure switch — Renew .....               | 17.25.48      | 17—5     |
| Exhaust check valve — Renew .....                        | 17.25.21      | 17—5     |
| Excess vacuum switch — Renew .....                       | 17.25.50      | 17—5     |
| <br>Idle relay — Renew .....                             | 19.22.53      | 17—6     |
| <br>Lambda disable relay — Renew .....                   | 19.22.15      | 17—6     |
| Lambda (oxygen) sensor — Renew .....                     | 19.22.16      | 17—6     |
| <br>Purge control valve — Renew .....                    | 17.15.39      | 17—5     |
| <br>Service interval counter — Renew .....               | 88.30.26      | 17—6     |
| Solenoid vacuum valve — Renew .....                      | 17.25.47      | 17—5     |
| <br>Thermal switch — Renew .....                         | 17.25.40      | 17—5     |
| Throttle micro switch — Renew .....                      | 17.25.43      | 17—5     |

## EMISSION CONTROL SYSTEM

## Air Injection System

The pump (1, Fig. 1) is a rotary vane positive displacement device, belt driven from the engine crankshaft. The pulley drives the pump via an electrically operated clutch which enables the pump to be disengaged. The pump air intake is cleaned by a separate renewable paper element filter.

The air switching valve (2, Fig. 1) is a normally closed vacuum operated valve, which simultaneously shuts off the secondary air duct when the air pump clutch is disengaged. The vacuum source is controlled by a solenoid vacuum valve (4, Fig. 1) and a thermal switch (5, Fig. 1).

A check valve (3, Fig. 1) fitted in the air delivery pipe protects the air pump from the back flow of harmful exhaust gas in the event that exhaust back pressure exceeds the air pump pressure due to, for example, a pump drive belt failure.

The solenoid vacuum valve (4, Fig. 1) is a three port device incorporating a filter on the atmospheric port. The valve is operated by an electrical solenoid and the atmospheric port is normally open.

The vacuum delay valve (6, Fig. 1) consists of a restrictor which delays the transfer of a vacuum signal, with an umbrella non-return valve.

The thermal switch (5, Fig. 1) contacts open with a rising temperature of 45°C and close with a falling temperature of 38°C. The

contacts are actuated by a temperature sensitive bimetallic disc, sensing the engine coolant temperature.

An exhaust back pressure switch (7, Fig. 1) consists of a diaphragm spring operated, normally closed microswitch. When the applied exhaust back pressure exceeds 11" hg, the switch contacts will open.

The throttle microswitch (8, Fig. 1) is in an open circuit position when the throttle is open and the pressure on the back blade and roller is released.

The vacuum switch (9, Fig. 1) consists of a diaphragm spring operated, normally closed microswitch. When the applied vacuum exceeds 20" hg the contacts will open.

## OPERATION OF AIR INJECTION

With the engine coolant temperature above 40°C and the throttle open, the electrical supply is broken to the lambda disable relay (10, Fig. 1), thus preventing the operation of feedback inhibit, the solenoid vacuum valve (4, Fig. 1) venting the air switch valve (2, Fig. 1) to atmosphere, and the air pump clutch preventing the operation of the clutch.

With the throttle closed, the throttle microswitch (8, Fig. 1) is also closed supplying battery voltage to the lambda disable relay activating the feedback inhibit and applying full load fuel, the solenoid vacuum valve, thus connecting the air switching panel to vacuum, and also to the

air pump clutch to operate the air pump. If the manifold vacuum is more than 20" hg, the vacuum switch (9, Fig. 1) will open or if the exhaust back pressure is greater than 11" hg, the pressure switch (7, Fig. 1) will open, thus interrupting the battery supply to the lambda disable relay, the solenoid vacuum valve and the magnetic clutch. The latter function is required in order to protect the air pump from exhaust gas back flow.

The diode (11, Fig. 1) prevents the energising and closing of the canister purge control valve. It also prevents the idle relay (12, Fig. 1) from being energised opening the relay contacts, preventing the application of full load fuel.

With the engine coolant temperature less than 38°C under all engine operating conditions, the thermal switch contacts are closed, so energising the idle relay, inhibiting the full load fuel, the lambda disable relay, activating the feedback inhibit, the solenoid vacuum valve connecting the air switching valve to vacuum and the air pump clutch connecting the air pump drive. Secondary air is supplied under all operating conditions until the engine coolant temperature exceeds 40°C or if the exhaust back pressure exceeds 11" hg.

A vacuum delay valve (6, Fig. 1) in the vacuum line to the solenoid vacuum valve prevents the air switch valve from interrupting the secondary air during acceleration modes, i.e. when the intake manifold vacuum falls below the minimum operating value of the switching valve.




Fig. 1




Fig. 2

### CRANKCASE CONTROL SYSTEM

To ensure that piston blow by gases do not escape from the engine crankcase, a depression is maintained in the crankcase under all operating conditions. This is achieved by scavenging from the camshaft case and crankcase via the oil sump filter tube (1, Fig. 2). The crankcase emissions collected are then fed into the engine intake manifold through a part throttle control orifice (2, Fig. 2) and the air cleaner collector box (3, Fig. 2).

To prevent possible icing up of the control orifice during cold weather the orifice is heated in a water heated housing mounted between the cold start injector and the intake manifold plenum chamber.

### EVAPORATIVE EMISSION CONTROL SYSTEM

In order to accommodate up to 10% fuel expansion, the maximum fuel level is limited. This is accomplished by extending the fuel filter inlet tube into the tank connecting into the tube pipe terminating in the tank at the maximum level. When the fuel expands the tank vents through pipes leading down from the LH and RH sides of the tank to the vapour separator (6, Fig. 3) located in the RH rear screen pillar. Any liquid fuel collected in the separator can drain back into the tank. Any excess vapour is directed to the charcoal cannister (1, Fig. 3) by means of a pipe running along the underside of the vehicle.

A pressure relief valve (5, Fig. 3) in the

#### KEY TO DIAGRAM


1. Part throttle control orifice housing
2. From the thermostat housing
3. To the coolant header tank
4. Camshaft cover
5. Oil filler tube
6. Air cleaner
7. Cold start injector
8. Control orifice
9. Coolant
10. Water inlet/outlet

vapour separator to storage cannister pipe controls the flow of vapour to the cannister. The cannister (1, Fig. 3) containing activated charcoal located in the LH front wheel arch is used to store hydrocarbon emissions from the fuel tank. Filter pads are fitted above and below the charcoal to prevent the ingress of foreign matter into the charcoal or the passage of charcoal into the purge line. Emissions from the fuel tank enter the top of the cannister and the purging air enters at the bottom of the cannister. The purging passes through the charcoal to the purge outlet at the top of the cannister.

Purging of the cannister is obtained by connecting the purge pipe to a vacuum source and drawing a controlled quantity of air through the charcoal contained in the cannister. The purge depression is obtained from ports located in the throttle housing in close proximity to the intake throttle disc (4, Fig. 3). The maximum purge of air flow rate is controlled by the size of the purge port located in the throttle housing. In order to inhibit cannister purging, a purge control valve (3, Fig. 3) is mounted in the purge line between the charcoal cannister and the purge port. The valve is operated by a

#### KEY TO DIAGRAM

1. Charcoal canister
2. Purge air inlet
3. Purge control valve
4. Purge port
5. Pressure relief valve
6. Vapour separator



J17 029

Fig. 3

thermal switch, sensing engine coolant temperature so that when the valve is energised, the purge flow is inhibited. The valve is also energised during engine cranking.

The pressure relief valve (5, Fig. 3) is used to control the transfer of vapour from the vapour separator to the storage cannister. The valve is designed to prevent flow from the tank until a pre-set pressure is exceeded. To allow flow from the cannister to the tank, a vacuum relief is also incorporated.

## CLOSED LOOP

In order to make the most of the performance of three-way catalytic convertors, it is necessary to achieve very close control of the engine fuelling level. This is accomplished by using a system in which the oxygen content of the exhaust gas, prior to the entry to the catalyst, is monitored and controlled by trimming of the fuelling level.

The sensor consists of a ceramic probe protected against mechanical influences by a housing which serves for the installation of the probe. The outer part of the ceramic body is located in the exhaust gas stream, while the inner part is in contact with ambient air. The ceramic body is basically zirconium dioxide and its inner and outer surfaces are coated with a thin permeable layer of platinum which acts as an electrode. The ceramic layer becomes conductive to oxygen ions at temperatures of about 300°C (572°F) and higher. If the oxygen content inside the probe differs from that outside an electrical voltage is developed between the two surfaces. Since the oxygen content in the exhaust stream varies with air/fuel ratio, so the voltage of the sensor may be used as a measure of the air/fuel ratio. This voltage is fed to the air/fuel controller unit which continuously adjusts the fuelling to maintain the air/fuel ratio close to the stoichiometric value.

## OXYGEN SENSOR SERVICE INTERVAL COUNTER

A warning light is incorporated in the fascia to alert the vehicle operator to the need to renew the oxygen sensor. The warning light is illuminated by the closing of contacts in the service interval counter (Fig. 4). The counter is driven by a small electric motor and the current to drive the motor is obtained from a pulse generator mounted in the vehicle transmission. The warning light is extinguished and the counter reset by fully depressing the reset button until a click is heard. As a bulb check function, the warning light is also illuminated when the starter motor is engaged.




Fig. 4


## CATALYTIC CONVERTORS

Catalytic convertors are fitted into the exhaust system to reduce carbon monoxide and hydrocarbon emissions. Twin outlets from the exhaust manifolds form a 'Y' piece in which is the exhaust gas oxygen sensor just above the first catalytic convertor. A second, oval, catalytic convertor is located under the vehicle floor.

The active constituents of the catalytic device are platinum and rhodium. In order for the device to function correctly, it is necessary to control very closely the oxygen concentration in the exhaust gas entering the catalyst. This is achieved by the use of a fuel control system which continuously monitors the oxygen content of the exhaust gas by means of the oxygen sensor and adjusts the fuelling level to obtain the required oxygen content.

Unleaded fuel must be used on catalyst equipped cars, and labels to indicate this are displayed on the instrument panel and below the fuel filler cap. The filler cap is designed to accommodate unleaded fuel pump nozzles only.

The emission control system fitted to this engine is designed to keep emissions within legislated limits, providing the engine is correctly maintained and is in sound mechanical condition.



## AIR PUMP

### Renew

Disconnect the battery earth lead.  
Disconnect the electrical cable block connector from the air pump clutch.  
Remove the air cleaner assembly from the air pump.

Disconnect the air outlet hose from the air pump.

Loosen the link arm trunnion bolt (1, Fig. 5), pivot bolt (2, Fig. 5) and adjusting nut (3, Fig. 5).

Loosen the air pump pivot nut and bolt (4, Fig. 5).

Pivot the air pump towards the engine until the drive belt can be removed from the air pump pulley.

Remove the link arm trunnion bolt and the air pump pivot bolt.

Remove the air pump assembly (5, Fig. 5).

Remove the clutch pulley securing nut (6, Fig. 5).

Remove the triangular plate (7, Fig. 5), clutch plate (8, Fig. 5) and spacer (9, Fig. 5). Remove the pulley housing from the air pump shaft (10, Fig. 5).

Remove the clutch coil retaining screws and remove the coil assembly.

On refitting, ensure the drive belt is adjusted to the correct tension. A load of 2,9 kgf (6.4 lbf) must give the belt a deflection of 5,6 mm (0.22 in) when applied on the longest stretch of the belt.

## AIR PUMP CLUTCH

### Renew

Disconnect the battery earth lead.

Remove the nut securing the pulley/clutch assembly.

Remove the clutch plates.

Loosen the air pump pivot bolts.

Loosen the adjusting locknut and adjust the air pump towards the engine until the belt can be removed.

Remove the pulley assembly.




Fig. 5



Remove the trunnion securing bolt and displace the adjusting rod towards the engine.  
Remove the three bolts securing the clutch coil.  
Disconnect the cable harness block connector and remove the clutch coil assembly.

## AIR SWITCHING VALVE

### Renew

Remove the inlet and outlet air hoses (1, Fig. 6).  
Remove the vacuum pipe (2, Fig. 6) and remove the air switching valve (3, Fig. 6).




Fig. 6

## EXHAUST CHECK VALVE

### Renew

Remove the hose to the air switching valve from the check valve (1, Fig. 7).  
Unscrew the check valve (2, Fig. 7) from the pipe connected to the manifold.




Fig. 7

## SOLENOID VACUUM VALVE

### Renew

Disconnect the battery earth lead.  
Note the position of and disconnect the vacuum pipes (1, Fig. 8).  
Disconnect the electrical cables.  
Remove the screw and spire nut securing the valve to the speed control actuator bracket (2, Fig. 8).  
Remove the valve from the bracket (3, Fig. 8).




Fig. 8

## EXHAUST BACK PRESSURE SWITCH

### Renew

Disconnect the battery earth lead.  
Remove the exhaust back pressure pipe.  
Disconnect the electrical cables.  
Remove the securing screw and spire from the speed control actuator bracket.  
Remove the back pressure switch.

## CANISTER PURGE CONTROL VALVE

### Renew

Disconnect the battery earth lead.  
Disconnect the electrical cable connectors (1, Fig. 9).  
Remove the clip securing the purge hose to the inner wing.  
Disconnect the hose from the control valve.  
Disconnect and remove the valve assembly from the throttle housing hose (2, Fig. 9).




Fig. 9

## THERMAL SWITCH

### Renew

**CAUTION: This operation must only be carried out on a cold or cool engine.**

Disconnect the battery earth lead.  
Carefully remove the pressure cap from the remote header tank to release any cooling system residual pressure.




Fig. 10

Disconnect the electrical cables from the lucar connectors (1, Fig. 10).  
Drain some of the coolant into a suitable container.  
Unscrew and remove the thermal switch (2, Fig. 10).  
On refitting, smear the thread of the thermal switch with a suitable sealant.  
Refill cooling system with coolant.

## EXCESS VACUUM SWITCH

### Renew

Disconnect the battery earth lead.  
Remove the vacuum hose from the vacuum switch (1, Fig. 11).  
Disconnect the electrical cable connectors (2, Fig. 11).  
Remove the vacuum switch securing nut and bolt (3, Fig. 11).  
Remove the vacuum switch (4, Fig. 11).




Fig. 11

## THROTTLE MICRO SWITCH

### Renew

Disconnect the battery earth lead.  
Disconnect the electrical cable connectors from the switch (1, Fig. 12).  
Remove the switch securing screws.  
Remove the switch and plates (2, Fig. 12).  
On refitting, connect a battery and test lamp to the switch contacts. Adjust the switch so that the light is on only when the throttle is closed.




Fig. 12

## ADSORPTION CANISTER

### Renew

Remove the LH front road wheel.  
Remove the inner wheel arch cover securing nuts and bolts.  
Remove the cover securing drive fasteners and remove the cover.  
Disconnect the canister hoses.  
Remove the canister securing clamp nut and bolt.  
Open the clamp and remove the canister.

## PART THROTTLE CONTROL ORIFICE HOUSING

### Renew

**CAUTION:** This operation must only be carried out on a cold or cool engine.

Carefully remove and refit the pressure cap from the remote header tank.  
Remove the breather hose pipe from the housing.  
Remove the cold start securing screws and carefully displace the cold start injector from the housing.  
Displace the housing above the engine level and disconnect the cooling hoses, which also must be kept above engine level to prevent spillage of coolant.  
Remove the orifice housing and discard the gaskets.

## IDLE RELAY

### Renew

Disconnect the battery earth lead.  
Remove the two screws securing the relay cover and remove the cover.  
Withdraw the relay cable block connector from the retaining bracket.  
Withdraw the relay from the block connector.

## LAMBDA (OXYGEN) DISABLE RELAY

### Renew

Disconnect the battery earth lead.  
Remove the two screws securing the relay cover and remove the cover.  
Withdraw the relay cable block connector from the retaining bracket.  
Withdraw the relay from the block connector.

## SERVICE INTERVAL COUNTER

### Renew

Disconnect the battery earth lead.  
Remove the trim pad from the LH side of the boot.  
Remove the nuts and screws securing the interval counter (1, Fig. 13).  
Disconnect the cable harness block connector (2, Fig. 13) and the single cable connector (3, Fig. 13).  
Remove the service interval counter (4, Fig. 13).




Fig. 13

## LAMBDA (OXYGEN) SENSOR

### Renew

Disconnect the battery earth lead.  
Disconnect the oxygen sensor electrical cable connector.  
Unscrew and remove the sensor from the down exhaust down pipe.  
On refitting new sensor, smear the sensor with anti-seize compound.

## CONTENTS

| Operation   | Operation No. | Page No. |
|---|---------------|----------|
| Air cleaner assembly — Renew .....                | 19.10.01      | 19—17    |
| Air cleaner element — Renew .....                 | 19.10.08      | 19—17    |
| Air temperature sensor — Description .....        | —             | 19—8     |
| Air temperature sensor — Test and renew .....     | 19.22.22      | 19—18    |
| Auxiliary air valve — Description .....           | —             | 19—9     |
| Auxiliary air valve — Test and renew .....        | 19.20.16      | 19—17    |
| Cold start enrichment — Description .....         | —             | 19—8     |
| Cold start injector — Test and renew .....        | 19.60.06      | 19—19    |
| Cold start system — Description .....             | —             | 19—10    |
| Coolant temperature sensor — Description .....    | —             | 19—8     |
| Coolant temperature sensor — Test and renew ..... | 19.22.18      | 19—17    |
| Electronic control circuit — Diagram .....        | —             | 19—6     |
| Electronic control component layout .....         | —             | 19—7     |
| Electronic control — Fault finding .....          | —             | 19—13    |
| Electronic control — Schematic diagram .....      | —             | 19—5     |
| Electronic control unit — Description .....       | —             | 19—8     |
| Electronic control unit — Renew .....             | 19.22.34      | 19—20    |
| Fuel cut off inertia switch — Renew .....         | 19.22.09      | 19—21    |
| Fuel filter — Renew .....                         | 19.25.02      | 19—21    |
| Fuel pressure regulator — Description .....       | —             | 19—10    |
| Fuel pressure regulator — Renew .....             | 19.45.11      | 19—19    |
| Fuel pump — Description .....                     | —             | 19—10    |
| Fuel pump — Renew .....                           | 19.45.08      | 19—21    |
| Fuel rail — Renew .....                           | 19.60.04      | 19—19    |
| Fuel supply system — Description .....            | —             | 19—9     |
| Fuel system — Pressure test .....                 | 19.50.13      | 19—23    |
| Fuel tank — Renew .....                           | 19.55.01      | 19—21    |
| Fuel tank cabriolet — Renew .....                 | 19.55.01      | 19—22    |
| Idle speed — Adjust .....                         | 19.20.18      | 19—19    |
| Injector — Test and renew .....                   | 19.60.01      | 19—19    |
| Ignition system — Description .....               | —             | 19—11    |
| Main relay — Description .....                    | —             | 19—20    |
| Main relay — Test and renew .....                 | 19.22.38      | 19—20    |

## FUEL SYSTEM

---

| Operation                                | Operation No. | Page No. |
|--|---------------|----------|
| Oxygen (lambda) sensor — Renew .....     | 19.22.16      | 19—17    |
| Oxygen (lambda) sensor — Test .....      | —             | 19—20    |
| Power resistor — Test and renew .....    | 19.22.44      | 19—19    |
| Pump relay — Test and renew .....        | 19.22.39      | 19—20    |
| Thermotime switch — Test and renew ..... | 19.22.20      | 19—18    |
| Throttle cable — Renew .....             | 19.22.06      | 19—17    |
| Throttle linkage — Renew .....           | 19.20.04      | 19—17    |
| Throttle pedestal — Renew .....          | 19.20.02      | 19—17    |
| Throttle potentiometer — Adjust .....    | 19.22.35      | 19—19    |
| Throttle potentiometer — Renew .....     | 19.22.36      | 19—19    |
| Throttle potentiometer — Test .....      | 19.22.37      | 19—19    |

## TEST EQUIPMENT

1. Epitest
2. Epitest adaptor
3. Fuel pressure gauge
4. EFI Throttle pot adjustment gauge
5. EFI Feedback monitor unit
6. Infra red CO meter
7. Multi test meter
8. Idle mixture adjustment key  
Lucas No. 60730551.

## GOOD PRACTICE

The following instructions must be strictly observed:

1. Always disconnect the battery before removing any components.
2. Always depressurise the fuel system before disconnecting any fuel pipes.
3. When removing fuelling components always clamp fuel pipes approximately 38 mm (1.5 in) from the unit being removed. Do not overtighten clamp.
4. Ensure that rags are available to absorb any spillage that may occur.
5. When reconnecting electrical components always ensure that good contact is made by the connector before fitting the rubber cover. Always ensure that ground connections are made on to clean bare metal, and are tightly fastened using the correct screws and washers.


## WARNING

1. **DO NOT LET THE ENGINE RUN WITHOUT THE BATTERY CONNECTED.**
2. **DO NOT USE A HIGH-SPEED BATTERY CHARGER AS A STARTING AID.**
3. **WHEN USING A HIGH-SPEED CHARGER TO CHARGE THE BATTERY, THE BATTERY MUST BE DISCONNECTED FROM THE REST OF THE VEHICLE'S ELECTRICAL SYSTEM.**
4. **WHEN INSTALLING, ENSURE THAT BATTERY IS CONNECTED WITH CORRECT POLARITY.**
5. **NO BATTERY LARGER THAN 12V MAY BE USED.**
6. **TESTS OR COMPONENT REMOVAL THAT RESULTS IN FUEL VAPOUR BEING PRESENT — IT IS IMPERATIVE THAT ALL PRECAUTIONS ARE TAKEN AGAINST THE RISK OF FIRE AND EXPLOSION.**





## FUEL CONTROL SYSTEM



J19 127

Fig. 1

## KEY TO DIAGRAM

- |                                  |                                 |
|----------------------------------|---------------------------------|
| 1. Fuel tank                     | 11. Coolant temperature sensor  |
| 2. Fuel pump                     | 12. Manifold pressure sensor    |
| 3. Fuel filter                   | 13. Electronic control unit     |
| 4. Fuel pressure regulator       | 14. Thermotime switch           |
| 5. Extra air valve               | 15. Power resistors             |
| 6. Cold start injector           | 16. HT coil                     |
| 7. Injector                      | 17. Starter and ignition switch |
| 8. Air intake temperature sensor | 18. Fuel pump relay             |
| 9. Oxygen sensor (Lambda sensor) | 19. Main relay                  |
| 10. Throttle potentiometer       | 20. Battery                     |

## Fuel injection

The system employed is the Lucas electronically controlled, pulsed, port fuel injection system. The system is shown diagrammatically on (Fig. 1).

FUEL SYSTEM

FUEL CONTROL SYSTEM WIRING DIAGRAMS

NAS




Fig. 2

UK AND EUROPEAN




Fig. 3

## KEY TO DIAGRAMS (Figs. 2 & 3)

|                                  | Main Diagram Nos |
|----------------------------------|------------------|
| 1. Electronic control unit (ECU) | 293              |
| 2. Start relay                   | 194              |
| 3. Main relay                    | 312              |
| 4. Pump relay                    | 314              |
| 5. Cold start injector           | 400              |
| 6. Fuel pump                     | 41               |
| 7. Thermotime switch             | 298              |
| 8. Start inhibit switch          | 75               |
| 9. Power resistor                | 313              |
| 10. Injectors                    |                  |
| 11. Trip computer                |                  |
| 12. Coolant temperature sensor   | 305              |
| 13. Throttle potentiometer       | 310              |

|                             |     |
|-----------------------------|-----|
| 14. Air temperature sensor  | 297 |
| 15. Lambda disable relay    |     |
| 16. Disable socket          | 354 |
| 17. Idle relay              |     |
| 18. Oxygen (lambda) sensor  | 316 |
| 19. Feedback monitor socket | 353 |
| 20. Air injection system    |     |
| 21. Positive battery supply |     |
| 22. Ignition start switch   | 38  |
| 23. Inertia switch          | 250 |
| 24. Starter solenoid        | 4   |
| 25. Ignition amplifier      | 261 |
| 26. Thermal switch          |     |

## KEY TO LOCATIONS (Fig. 4)

|                               |
|-------------------------------|
| 1. Supplementary air valve    |
| 2. Auxiliary air valve        |
| 3. Thermotime switch          |
| 4. Coolant temperature sensor |
| 5. 3-way vacuum valve         |
| 6. Cold start injector        |
| 7. Lambda (oxygen) sensor     |
| 8. Fuel pressure regulator    |
| 9. Throttle potentiometer     |
| 10. Injector                  |
| 11. Air temperature sensor    |




Fig. 4




Fig. 5

## FUEL METERING

Fuel metering is obtained by controlling the length of time for which the injectors are held open during each engine cycle. The pulse duration is varied by the electronic control unit (ECU) (Fig. 5) according to inputs from the engine and chassis mounted sensors.

The control parameters sensed fall into two groups. The primary consists of intake manifold absolute pressure and engine speed.

Information on engine speed received by the ECU is derived from the ignition coil negative terminal. The voltage wave form at this point can reach as much as 400 volts when a spark is generated, and it is desirable to suppress this voltage before allowing it into the fuel injection wiring harness and hence to the ECU. If this is not done, interference may occur with other signals. A resistor serves this purpose and it is located inside the ignition amplifier (Fig. 6).




Fig. 6

The intake manifold absolute pressure is sensed by a transducer located in the ECU and linked to the intake manifold by a pipe. The transducer is an integral part of the ECU and cannot be replaced without recalibrating the electronic circuits.

The fuelling information for the engine is stored in a preprogrammed memory so that for any combination of manifold absolute pressure and engine speed the memory gives out a number which is proportional to the amount of fuel required by the engine. The injector will be energised for a time proportional to the number computed, plus the constant of proportionality which is varied according to the secondary control parameters.

The secondary control parameters consist of engine coolant temperature, inlet air temperature, throttle movement, and position, closed loop correction and battery voltage.

## AIR TEMPERATURE SENSOR

The quantity of fuel supplied per cycle is adjusted according to the air intake temperature, such that it varies approximately with the density of the air aspirated. At low ambient temperatures, the density, and thus the weight of air drawn into the engine is higher, therefore the air/fuel ratio would become leaner. In order to compensate for this, an air intake




Fig. 7

temperature sensor (Fig. 7) is incorporated in the air intake system. The electrical resistance of the device alters with the changes of air temperature. This signal is monitored by the ECU and used to ensure the air/fuel ratio stays correct.

## BATTERY VOLTAGE

The electrical system voltages change with the battery state of charge, electrical load etc., and this in turn affects the amount of fuel delivered. The ECU compensates for this by constantly monitoring the system voltage and generating a correction factor to ensure the pulse sent to the injectors is independent of the system voltage.

## COOLANT TEMPERATURE SENSOR

The coolant temperature sensor (Fig. 8) located in the coolant thermostat housing controls the warm-up enrichment delivered by the ECU. In addition to the enrichment generated during warm-up, further enrichment is required during engine cranking. The signal to the ECU comes via a connection from the starter relay. When the engine fires and the starter is released, the start enrichment decays slowly to the normal fuelling level as determined by the engine coolant temperature. This over fuelling function is known as the 'after start enrichment'. The 'normal' fuelling level is determined by the engine coolant temperature, such that the fuelling level increases as the temperature decreases.




Fig. 8

## THROTTLE POTENTIOMETER

To ensure the vehicle road performance is satisfactory, with good throttle response, acceleration enrichment is necessary. Signals are provided by the throttle potentiometer (Fig. 9) which is mounted on the throttle spindle and indicates the throttle position to the ECU. When the throttle is opened the fuelling is richened and when closed the fuelling is weakened. When the throttle is opened very quickly, all the injectors are simultaneously energised for one pulse. This ensures that there is enough fuel available at the inlet ports for the air admitted by the sudden opening of the throttle. The duration of this extra pulse is controlled by the engine temperature signal, and is longer with a cold engine.




Fig. 9

Lengthening the normal injection pulses is done in proportion to the rate at which the throttle is moved, and it takes a short time to decay when the throttle movement stops. Enrichment in this way is also varied according to the engine temperature. The fuel cut-off function is controlled by the throttle potentiometer and the conditions under which it occurs are programmed into the electronic control unit memory.




Fig. 10

## INJECTORS

The injectors (Fig. 10) consist of a solenoid operated valve. The moveable plunger is rigidly attached to the nozzle needle. In the closed position a helical compression spring holds the nozzle against the valve seat. The electrical pulses from the electronic control unit are passed through the injector solenoid winding creating a magnetic field. As a result the plunger is attracted away from the nozzle seat allowing fuel to enter the inlet port. The injectors are operated in two stages, initially they are operated via a pull-in circuit with current limiting resistors, then when the injectors are open a change to hold on circuit is made via current limiting resistors (Fig. 11) for the remainder of the injector period as determined by the electronic control unit. In this way the heating effect on the output transistors of the electronic control unit is reduced. It also ensures a rapid response from the injectors. To open the injectors at the speeds required by the engine fairly high current is needed. The ECU has an output stage to deliver this current, but to protect the output transistors of the ECU from injector faults and short-circuits a power resistor is wired in series with each three injectors. These resistors will limit fault current to a safe value, thus protecting the ECU. The power resistors (one for each group of injectors) are housed in a single unit secured to the right side of the engine valance by two screws.




Fig. 11

## AUXILIARY AIR VALVE

In order to maintain idling speed during cold start, and warm-up, more air than that supplied by the normal idle bypass is required. This extra air is supplied by the extra air valve (Fig. 12) which is temperature sensitive so that the idle speed can be controlled throughout the warm-up phase. The extra air valve consists of a variable orifice, controlled by an expansion element. It is mounted on the engine cylinder head, where it is responsive to coolant temperatures. By adjusting the profile of the variable orifice according to coolant temperature the engine idling speed can be controlled.




Fig. 12

## SUPPLEMENTARY AIR VALVE

An additional throttle bypass device is used to supplement the air necessary to support the engine idle speed when the air conditioning system is in use. This device is a solenoid operated valve (Fig. 13) which supplies supplementary air to the engine.




Fig. 13

## LAMBDA SENSOR — CARS TO USA

### Oxygen sensor

The oxygen sensors (Fig. 14) measure the free oxygen concentration in the exhaust system. Excessive free oxygen over a certain proportion indicates a weak mixture, whereas insufficient free oxygen indicates a rich mixture. A signal is fed to the ECU to compensate for these variations by revising the applied injector pulse width.

A service interval counter in conjunction with a warning lamp indicate when the oxygen sensors must be replaced.





Fig. 14

## FUEL SUPPLY SYSTEM

A recirculatory fuel system is used (Fig. 15). The fuel tank (7, Fig. 15) is mounted across the car behind the rear passenger seats. The electric pump (5, Fig. 15) draws fuel from a small sealed sump tank (6, Fig. 15) located at a lower level than the main tank and delivers it to a pressure regulator on the engine (3, Fig. 15). The pressure regulator controls the fuel line pressure so that a constant pressure drop is maintained across the injectors (1 & 2, Fig. 15). This is accomplished by applying the intake manifold pressure to the diaphragm of the pressure regulator. Excess fuel is returned to the main fuel tank. The fuel pump is energised only when the electronic control unit senses the engine cranking signal from the starter relay, or the ignition pulses from the ignition amplifier. This will prevent the engine being flooded with fuel in the event of an injector being held open by a foreign body or control unit fault. The fuel pump is protected by a nylon strainer fitted to the suction line inside the fuel tank. A paper element disposable filter (4, Fig. 15) is fitted in the line between the pump and the pressure regulator to protect the pressure regulator and injectors.



J19 125

Fig. 15

## KEY TO FUEL SYSTEM CONFIGURATION

1. Injectors
2. Cold start injector
3. Fuel pressure regulator
4. Fuel filter
5. Fuel pump
6. Sump tank
7. Fuel tank

## FUEL PUMP

The fuel pump (Fig. 16) has a roller type cell driven by a permanent magnet electric motor. A small rotor is mounted on the armature shaft and rotates in an eccentric housing. The rotor contains five metal rollers each one housed in a pocket or cutaway on the circumference of the rotor. When the armature rotates centrifugal forces press them against the metal housing forming a seal. The trapped fuel is then forced to the pressure scale of the system. The pump is designed as a wet pump which means the motor is full of fuel. However, the motor never contains an ignitable mixture even when the tank empties.

For safety reasons the fuel pump is energised via a relay whose earth connection is complete through the electronic control unit. This ensures that when the ignition is switched on a timing circuit located within the electronic control unit will only allow the pump to operate for approximately one second and then switch the relay earth connection off, thus switching the pump off. The fuel pump relay

will remain switched off until the engine is cranked and a signal is received by the electronic control unit from the starter relay, or when the engine is running and the electronic control unit receives a speed signal from the ignition amplifier. Also, as an additional safety measure an inertia switch is fitted to de-energise the pump and the entire fuel system.

## FUEL PRESSURE REGULATOR

The pressure regulator (Fig. 16) is connected to the fuel rail and has an overflow return to the fuel tank. There is also a vacuum pipe connected between the regulator and the inlet manifold via a three-way vacuum valve.

Inside the steel body of the regulator a spring loaded diaphragm is held against the outlet ducts, sealing it off. When the fuel pressure acting on the diaphragm is sufficient to overcome the spring pressure, the diaphragm distorts compressing the spring and allowing the excess fuel to escape through the outlet duct, which is now exposed, causing a reduction in pressure. The reduced fuel pressure allows the diaphragm to return to its original position closing the fuel return outlet. This sequence is repeated as long as the pump is


operating. The continuous movement of the diaphragm which rapidly opens and closes the fuel return valve maintains the fuel rail pressure at 3.1 Bar (43.5 lbf in<sup>2</sup>).

It is necessary that the fuel pressure is maintained at a constant amount above manifold pressure which varies with the engine load and it is for this reason that the spring side of the diaphragm is connected to the manifold to keep the pressure constant across the injectors.

The three-way vacuum valve is fitted to the fuel rail to prevent weak fueling after a hot start.

## COLD START SYSTEM


In addition to the functions of the Electronic Control Unit which provides extra fuel during starting and the warm-up period, additional fuel is injected into the inlet manifold by a cold start injector (Fig. 18).



J19 136


Fig. 18

This injector is controlled by a thermotime switch (Fig. 19). The thermotime switch senses the coolant temperature and depending on that temperature makes or breaks the earth circuit of the cold start injector. When the starter switch is operated the cold start injector is energised with its earth circuit completed via the thermotime



J19 141

Fig. 16



J19 143

Fig. 17



switch, which also limits the time for which the injector is energised to a maximum of 12 seconds under extreme cold conditions. If the temperature is above the rated value of 35°C (95°F) of the thermotime switch the earth circuit of the cold start injector will be open and the cold start injector will not operate as no start enrichment will be required.




Fig. 19

### COLD START CIRCUIT




Fig. 20

- KEY TO DIAGRAM**
1. Thermotime switch
  2. Cold start injector

### IGNITION SYSTEM

The ignition system is operated electronically and is known as the Constant Energy System. In this system the distributor (Fig. 21) incorporates a standard automatic advance system, rotor arm, cover, anti-flash shield, reluctor and pick-up assembly. The reluctor is a gear-like component and is mounted on the distributor shaft in the place of the cam. The pick-up consists of a winding around a pole piece attached to a permanent magnet. The pick-up is prewired with two leads terminating in a moulded two-pin block connector.

When the reluctor passes across the pick-up limb the magnetic field strength is intensified creating a voltage in the winding. This voltage signal created by the reluctor and the pick-up assembly is sensed by the amplifier causing the amplifier to switch the current flowing in the primary winding of the HT coil on and off.

The constant energy electronic ignition system employs output current limiting and variable dwell for optimum performance. A long dwell is provided at high speeds for adequate energy storage in the coil and a dwell is provided at low speeds for minimum power dissipation. The output current limiting function of the amplifier maintains the storage energy for spark, and the system open circuit voltage constant over a wide engine speed range. It eliminates the need for ballast resistor whilst ensuring correct current flows at all times even when the engine is cranking. No current flows through the HT coil when the ignition is switched on and the engine is stationary.

The amplifier assembly (Fig. 22) consists of a solid state electronic amplifier module, a zenor diode to protect the amplifier in the event of a current surge, a suppression capacitor, and a moulding containing two resistors.

**WARNING: THE AMPLIFIER IS A SEALED UNIT CONTAINING BERYLIA. THIS SUBSTANCE IS EXTREMELY DANGEROUS IF HANDLED. DO NOT ATTEMPT TO OPEN THE AMPLIFIER MODULE.**




Fig. 21

- KEY TO DISTRIBUTOR**
1. HT cover
  2. Rotor
  3. Flash shield
  4. Reluctor
  5. Pick-up assembly
  6. Vacuum module




Fig. 22

- KEY TO DIAGRAM**
1. Distributor
  2. Amplifier
  3. HT coil
  4. To tachometer
  5. To ECU
  6. Ignition switch

## RELAYS

Four relays are used in the electrical control system. They are the main, fuel pump, idle speed relay, and the Lambda disable relay. Details of the wiring connections are shown in the circuit diagram.





Fig. 23

## TEST EQUIPMENT

The Epitest (Fig. 24) and the Epitest Adaptor have been developed to enable quick location of faults to be carried out on the vehicle. It is supplied complete with the necessary multiplugs, fuel pressure gauge and the operating instructions.



J19 119

Fig. 24

FAULT FINDING

| SYMPTOM               | CAUSE  | CURE  |
|-----------------------|--|---|
| Engine will not start | <ol style="list-style-type: none"> <li>1. Low battery or poor connections</li> <li>2. Start system malfunction</li> <li>3. Incorrect or dirty fuel</li> <li>4. Fuel starvation</li> <li>5. Fuel injection equipment electrical connections</li> <li>6. Auxiliary air valve inoperative</li> <li>7. Cold start system inoperative</li> <li>8. Pressure sensor (part of the ECU)</li> <li>9. Temperature sensors</li> <li>10. HT circuit faults</li> <li>11. Power faults</li> <li>12. LT switching fault</li> <li>13. Ignition timing incorrect</li> <li>14. ECU/amplifier</li> </ol> | <ol style="list-style-type: none"> <li>1. a) Check battery, recharge. Clean and secure terminals.<br/>b) Check for low charge from alternator.<br/>c) Check for short circuit.</li> <li>2. Clean and check main starter circuit and connections.</li> <li>3. Check grade of fuel. If contamination suspected, drain and flush fuel tank, flush through system, renew fuel filter.</li> <li>4. Check fuel pressure. If not satisfactory, check feed pipes for leaks or blockage. Renew connectors if damaged or deteriorated.</li> <li>5. Ensure that all connector plugs are securely attached. Pull back rubber boot and ensure that plug is fully home. While replacing boot, press cable towards socket. Ensure ECU multi-pin connector is fully made. Check that all ground connections are clean and tight.</li> <li>6. Remove valve and test.</li> <li>7. Check function of cold start system.</li> <li>8. Ensure manifold pressure pipe is attached to sensor, and is not twisted, kinked or disconnected anywhere.</li> <li>9. Check sensor for open and short circuit.</li> <li>10. Check for sparking. See electrical book 10.</li> <li>11. Carry out ignition checks. See electrical book 10.</li> <li>12. Check pick-up module. See electrical book 10.</li> <li>13. Check and adjust as necessary.</li> <li>14. As a last resort check by substitution.</li> </ol> |
| Poor or erratic idle  | <ol style="list-style-type: none"> <li>15. Check items 3, 4, 5 and 12 above</li> <li>16. Throttle potentiometer</li> <li>17. Incorrect idle speed</li> <li>18. Check items 8 and 12 above</li> <li>19. Ignition system deterioration</li> </ol>  | <ol style="list-style-type: none"> <li>15. If trouble persists, proceed with item 18.</li> <li>16. Check function of idle and full load switches.</li> <li>17. Adjust auxiliary air valve by-pass bleed screw.</li> <li>18. If trouble still persists, proceed with item 21.</li> <li>19. Check ignition wiring for fraying, chafing and security. Inspect distributor cap for cracks and tracking and rotor condition. See electrical book 10.</li> </ol>  |

| SYMPTOM                 | CAUSE   | CURE   |
|-------------------------|---|--|
| Poor or erratic idle    | <p>20. Spark plug faults</p> <p>21. Check item 14</p> <p>22. Vacuum system faults</p> <p>23. Advance or retard mechanism faults</p> <p>24. Throttle by-pass valves</p> <p>25. Exhaust system leaking or blocked</p> <p>26. Incorrect idle mixture</p> <p>27. Poor compressions</p> <p>28. Air leaks at inlet manifold</p> <p>29. Check item 6</p> <p>30. Engine oil filler cap loose or leaking</p> <p>31. Engine breather pipe restrictors missing or blocked</p> <p>32. Engine breather hoses blocked or leaking</p> <p>33. Charcoal canister restricted or blocked</p> <p>34. Check items 15, 10 and 9</p> | <p>20. Clean, reset and test plugs; renew as necessary.</p> <p>21. If trouble still persists, proceed with item 24.</p> <p>22. Check operation of vacuum unit and condition of vacuum pipes. Renew as necessary.</p> <p>23. Check operation of advance/retard mechanism. Lubricate or renew as necessary.</p> <p>24. Check and adjust as necessary.</p> <p>25. Check and rectify as necessary.</p> <p>26. Check CO level. Remove the blanking plug from ECU and with special tool No. 60730551 adjust to 1 to 2% max CO at 750 rpm level. Air injection system (where fitted) should be disconnected for this operation.</p> <p>27. Check compressions, and rectify as necessary.</p> <p>28. Check inlet manifold to cylinder head joint. Remake with new gasket if necessary. Check manifold tappings for leaks.</p> <p>29. If trouble still persists, proceed with item 32.</p> <p>30. Check cap for security. Renew seal if damaged.</p> <p>31. Check and clear, or renew as necessary.</p> <p>32. Check and clear, or renew as necessary.</p> <p>33. Inspect, and renew as necessary.</p> <p>34. Check in order shown.</p> |
| Hesitation or flat spot | <p>35. Check items 3, 4 and 5</p> <p>36. Check item 7 with engine cold</p> <p>37. Throttle butterfly</p> <p>38. Check item 8</p> <p>39. Brakes</p> <p>40. Check items, 12, 19, 20, 13, 22, and 23</p> <p>41. Air cleaner blocked</p> <p>42. Check items 25, 27, 28, 30, 31, 32, 33, 9 and 14.</p>   | <p>35. If trouble still persists, proceed with item 38.</p> <p>36. If trouble still persists, proceed with item 39.</p> <p>37. Adjust as necessary.</p> <p>38. If trouble still persists, proceed with item 41.</p> <p>39. Check for binding brakes.</p> <p>40. If trouble still persists, proceed with item 43.</p> <p>41. Inspect element, and renew as necessary.</p> <p>42. Check in the order shown.</p>  |

| SYMPTOM                                   | CAUSE  | CURE   |
|---|--|--|
| Excessive fuel consumption                | <p>43. Leaking fuel</p> <p>44. Check items 18, 7, 8, 41, 27, 29 and 30.</p> <p>45. Cylinder head gasket leaking</p> <p>46. Cooling system blocked or leaking</p> <p>47. Check items 28, 30, 31, 32, 33, and 14</p> | <p>43. Check fuel system for leaks, rectify and renew connectors as necessary.</p> <p>44. If trouble still persists, proceed with item 47.</p> <p>45. Check cylinder head to block joint for signs of leakage. Renew gasket as necessary.</p> <p>46. Flush system, check for blockage. Check hoses and connections for security and leaks; renew as necessary. Check functions of thermostats; renew if necessary.</p> <p>47. Check in the order shown.</p>  |
| Lack of engine braking or high idle speed | <p>48. Air leaks</p> <p>49. Throttle sticking</p> <p>50. Check items 6, 22, 24, 13, 26 and 39</p> <p>51. Throttle spindle leaks</p> <p>52. Check item 28</p>   | <p>48. Any air leak into the manifold will appear as an equivalent throttle opening; correct fuel will then be supplied for that apparent degree of throttle and the engine will run faster. Ensure that all hose and pipe connections are secure. Check all joints for leakage, and remake as necessary.</p> <p>49. Lubricate, check for wear and reset.</p> <p>50. If trouble still persists, proceed with item 53.</p> <p>51. Check seals, bearings and spindles for wear; renew as necessary.</p> <p>52.</p> |
| Lack of engine power                      | <p>53. Check items 3, 4, 5 and 7</p> <p>54. Throttle inhibited</p> <p>56. Check items 39, 41, 8, 12, 19, 20, 13, 23, 25, 27, 28, 22, 30, 31, 32, 33, 37 and 14</p>   | <p>53. If trouble still persists, proceed with item 56.</p> <p>54. Check throttle operation, free off and reset as necessary.</p> <p>56. Check in order shown.</p>   |
| Engine overheating                        | 57. Check items 46, 45, 13 and 22  | 57. Check in order shown.  |
| Engine cuts out or stalls                 | 58. Check items 3, 4, 5, 9, 17, 7, 43, 8, 25, 12, 19, 20, 13, 23, 26, 16, 28, 22, 30, 31, 32, 33, 27 and 14  | 58. Check in order shown.  |
| Engine misfires                           | 59. Check items 3, 4, 5, 7, 8, 12, 19, 20, 13, 23, 41, 25, 26, 27, 28, 22, 30, 31, 32 and 33   | 59. Check in order shown.  |

## FUEL SYSTEM

| SYMPTOM                    | CAUSE  | CURE  |
|----------------------------|--|---|
| Fuel smells                | 60. Check items 43, 7 and 32<br>61. Fuel filler cap defective<br>62. Check items 31, 33, 26, 41 and 14   | 60. If trouble still persists, proceed with item 61.<br>61. Check seal and cap for deterioration; renew as necessary.<br>62. Check in the order shown.  |
| Engine runs on             | 63. Check items 3, 17, 49, 24, 32, 31, 46, 45, 13, 24, 25 and 15   | 63. Check in the order shown.   |
| Engine knocking or pinking | 64. Check items 3, 13, 23, 22, 46 and 45.  | 64. Check in the order shown.   |
| Arcing at plugs            | 65. Check items 19 and 20  | 65.   |
| Lean running (low CO)      | 66. Check items 5, 51, 16, 9, 3, 4, 28, 22, 30, 31, 32 and 33  | 66. Check in the order shown.   |
| Rich running (excess CO)   | 67. Check items 7, 26, 33 and 14   | 67. Check in the order shown.   |
| Backfiring in exhaust      | 68. Check items 3, 4, 5, 41, 25, 28, 22, 46 and 30<br>69. Check item 14  | 65. If trouble persists, proceed with item 71.<br>69.   |
| Noisy air injection        | 70. Incorrectly tensioned air pump drive belt<br>71. Check valve faulty or low pump pressure<br>72. Check valve sticking (Japan and Australia) | 70. Check and adjust drive belt tension; renew belt if necessary.<br>71. Check that the valve operates. If pump fails to produce enough pressure to lift the valve, check item 70. If satisfactory, renew the pump.<br>72. Check valve operation and hoses for security or blockage. Rectify or renew as necessary. |



## AIR CLEANER ASSEMBLY

## Renew

Disconnect the battery earth lead  
Unclip the air cleaner cover and displace the cover from the element (1, Fig. 25).

Remove the air cleaner element (2, Fig. 25) and the cover.

Disconnect the air temperature sensor lead (3, Fig. 25).

Disconnect the air cleaner to oil filler hose (3, Fig. 25) from the air cleaner.

Remove the four bolts securing the air cleaner to the throttle butterfly housing and displace the air cleaner.

Remove the air cleaner from the air solenoid valve and remove the air cleaner.

Remove the air temperature sensor.

Remove the ten bolts securing the backplate to the housing and remove the back plate.

On refitting, ensure all mating surfaces are clean and smeared with arbrasil sealant.




Fig. 25

## THROTTLE PEDESTAL HOUSING

## Renew

Disconnect the battery earth lead.

Release the throttle cable securing clip and disconnect the throttle cable from the linkage (1, Fig. 26).

Disconnect the throttle linkage return spring (2, Fig. 26).




Fig. 26

Remove the throttle linkage retaining spire clip and remove the linkage assembly from the pedestal (3, Fig. 26). Remove the nylon guide from the pedestal.

Remove the pedestal assembly securing bolts (4, Fig. 26) and displace the pedestal assembly.

Remove the pedestal housing securing bolts and remove the pedestal housing.

## THROTTLE CABLE (NAS)

## Renew

Disconnect the battery earth lead.

Remove the throttle pedal link retaining split pin, pedal link washer and the pedal link clevis pin.

Remove the nuts and bolts securing the brake reservoir and displace the reservoir for access.

Displace the speed control actuator cable bracket.

Remove the throttle transfer plate securing nuts and bolts, displace the plate for access and discard the gasket.

Remove the split pin and washer securing the cable.

Displace the cable from the transfer anchor pipe.

Remove the cable from the transfer plate.

Release the cable retaining clip and disconnect the cable from the throttle linkage.

Loosen the cable adjusting nuts and remove.

Remove the cable support bracket from the grommet and remove the cable assembly.

## THROTTLE CABLE (UK AND EUROPEAN)

## Renew

Release the throttle cable retaining clip and disconnect the cable from the throttle linkage.

Remove the cable adjusting nut and displace the cable from the support bracket. Disconnect the cable from the bulkhead retaining clip.

Remove the cotter pin and the cable retaining collar from the throttle pedal. Slide the collar forwards to expose the cable end and disconnect the cable from the pedal arm.

Remove the cable from the engine bay.

## THROTTLE LINKAGE

## Renew

Release the throttle cable securing clip and disconnect the throttle cable from the linkage.

Disconnect the throttle linkage return spring.

Remove the throttle linkage retaining spire clip and remove the linkage assembly from the pedestal.

## AUXILIARY AIR VALVE

## Renew

**CAUTION: The auxiliary air valve must ONLY be removed with a cold or cool engine.**

Carefully remove the pressure cap from the remote header tank to release any cooling system residual pressure.

Drain the coolant into a suitable container.

Loosen the auxiliary air valve hose clips and disconnect the hoses from the air valve (1, Fig. 27).

Remove the bolts securing the air valve to the thermostat housing (2, Fig. 27) and remove the auxiliary air valve (3, Fig. 27).

On refitting, clean the thermostat housing and fit new gasket.

Refill with coolant.

Start and run the engine until the normal operating temperature is attained.

Adjust the idle speed adjustment screw on the auxiliary air valve (4, Fig. 27) to give the required idle speed.




Fig. 27

## OXYGEN SENSOR (LAMBDA SENSOR)

## Renew

Disconnect the battery earth lead.

Disconnect the oxygen sensor cable connector and remove the sensor.

On refitting new sensor, smear the sensor threads with anti-seize compound.

## COOLANT TEMPERATURE SENSOR

## Test

Disconnect the coolant temperature sensor. Check the temperature of the coolant.

Connect an ohmmeter between the terminals of the coolant temperature sensor. The ohmmeter should closely approximate to the relevant resistance value given in the table.

Disconnect the ohmmeter.

Temperature (C) Resistance K ohms

|         |      |        |
|---------|------|--------|
| -10 ± 1 | 7    | — 11.6 |
| +20 ± 1 | 2.1  | — 2.9  |
| +80 ± 1 | 0.27 | — 0.39 |

## FUEL SYSTEM

Connect the ohmmeter to the body of the sensor and each terminal in turn. The ohmmeter should register infinity (open circuit). If the ohmmeter indicates a resistance, the sensor is breaking down to earth and should be replaced.

### Renew

**CAUTION:** This operation must **ONLY** be carried out on a cold or cool engine.

Disconnect the battery earth lead. Carefully remove the pressure cap from the remote header tank to release any cooling system residual pressure.

Disconnect the coolant temperature sensor electrical connector. (1, Fig. 28).

**NOTE:** The replacement component should be ready so that the transfer can be made as quickly as possible. Ensure that the sealing washer is located on the replacement sensor and a coat of a suitable sealing compound is smeared on the threads. Unscrew the temperature sensor from the thermostat housing (2, Fig. 28).

On refitting, check the coolant level and top up if necessary.




Fig. 28

## THERMOTIME SWITCH

### Test

**NOTE:** Check the coolant temperature with a thermometer and note the reading before carrying out the tests detailed below. Check the rated value of the thermotime switch (stamped on the body).

Disconnect the battery earth lead.

Disconnect the electrical connector from the thermotime switch.

'A' coolant temperature higher than the switch rated value.

Connect the ohmmeter between the terminal 'W' and earth (Fig. 29). The ohmmeter should indicate an open circuit reading. Replace the switch if a low reading (short circuit) is obtained.

'B' coolant temperature lower than the switch rated value.

Connect an ohmmeter between terminal 'W' and earth. A very low resistance reading (closed circuit) should be indicated.

Connect a 12 V supply to the terminal 'G' and earth (Fig. 30) of the thermotime switch.




Fig. 29




Fig. 30

Using a stop watch, check the time delay of the reading indicated on the ohmmeter change from a low resistance to a high resistance.

The delay period should closely follow the times given in the table:

| Coolant Temperature | Delay Period |
|---------------------|--------------|
| -20°C               | 12 seconds   |
| 0°C                 | 8 seconds    |
| +35°C               | 0 seconds    |

### Renew

**CAUTION:** This operation must **ONLY** be carried out on a cold or cool engine.

Disconnect the battery earth lead.

Carefully remove the pressure cap from the remote header tank to release any residual pressure in the cooling system.




Fig. 31

Ensure that the new component threads are smeared with a suitable sealing compound and that the sealing washer is fitted correctly.

Disconnect the electrical connector from the thermotime switch (1, Fig. 31) and remove the switch (2, Fig. 31).

On refitting, check the coolant level and top up if necessary.

## AIR TEMPERATURE SENSOR

### Test

Disconnect the battery earth lead.

Disconnect the cable connector from the sensor.

Connect a suitable ohmmeter between the terminals of the sensor. Note the resistance indicated on the ohmmeter. The resistance of the sensor is subject to change according to the temperature, and should closely follow the relevant resistance value given in the table below:

| Temperature | Resistance K ohms |
|-------------|-------------------|
| -10°C       | 8.26 — 10.56      |
| +20°C       | 2.28 — 2.72       |
| +50°C       | 0.76 — 0.91       |

### Renew

Disconnect the battery earth lead.

Disconnect the sensor cable connector.

Remove the air temperature sensor from the air cleaner housing.

## THROTTLE POTENTIOMETER

### Renew

Disconnect the battery earth lead.  
Remove the air cleaner element.  
Remove the throttle potentiometer securing screws.  
Disconnect the multi-pin cable connector.  
Remove the throttle potentiometer.  
On refitting, do not tighten the securing screws.

### Adjust

Connect the throttle potentiometer adjustment gauge to the potentiometer multiplug (1, Fig. 32).  
Connect the adjustment gauge crocodile clips to a 12 volt supply and earth (2, Fig. 32).  
Move the toggle switch on top of the adjustment gauge to position 'T' (3, Fig. 32).  
Adjust by rotating the potentiometer to the right or left until the CORRECT is illuminated (4, Fig. 32).  
Tighten the fixing screws.  
Refit the air cleaner element.

### Test

Remove the air cleaner element.  
Disconnect the throttle potentiometer multiplug connector.  
Connect an ohmmeter between the yellow and the green leads in the throttle potentiometer multiplug.  
The ohmmeter should indicate approximately 5Kohms. Operate the throttle control and the resistance should remain constant.

Remove the ohmmeter leads from the multiplug and reconnect the ohmmeter between the red lead and the green lead of the multiplug. The ohmmeter should indicate approximately 5K ohms.  
When the throttle is opened, the resistance should drop to approximately 125 ohms.

## PRESSURE REGULATOR

### Renew

Remove the luggage compartment RH side panel.  
Remove the pump relay from its bracket and remove the relay from the multiplug connector.  
Crank the engine to depressurise the fuel system.  
Remove the vacuum pipe from pressure regulator (1, Fig. 33).  
Clamp the fuel hose and remove the hose from the regulator (2, Fig. 33).  
Slacken the pressure regulator securing nut (3, Fig. 33).  
Undo the pressure regulator to fuel rail union nut and remove the regulator (4, Fig. 33).




Fig. 33

## FUEL INJECTORS FUEL RAIL

### Renew

Depressurise the fuel system.  
Disconnect the battery earth lead.  
Clamp and disconnect the fuel hose from the pressure regulator.  
Clamp and disconnect the fuel hose from the fuel rail.  
Disconnect the vacuum pipe from the pressure regulator.  
Disconnect the injector electrical block connectors.  
Remove the fuel rail securing bolts and lift the fuel rail complete with the injectors from the engine compartment.  
Remove the injector retaining clip and remove the injector.

### Test

Disconnect the injector electrical block connector.  
Connect an ohmmeter between the injector terminals and the ohmmeter should indicate a reading of approximately 3 ohms.  
Connect the ohmmeter to each of the injector terminals in turn and to the body of the injector. The ohmmeter should indicate an open circuit.

## COLD START INJECTOR

### Test


**WARNING: THIS TEST RESULTS IN FUEL VAPOUR BEING PRESENT IN THE ENGINE COMPARTMENT. IT IS THEREFORE IMPERATIVE THAT ALL DUE PRECAUTIONS ARE TAKEN AGAINST FIRE AND EXPLOSION.**

Remove the bolts securing the cold start injector and place the injector over a suitable container to collect sprayed fuel.  
Disconnect the block connector from the thermotime switch.  
Connect a jumper lead from the white and green lead in the block connector to earth.  
Disconnect the leads from the negative terminal of the ignition coil.  
Crank the engine one or two revolutions. The injector should spray while the engine cranks.  
If the injector does not spray fuel, check the white and red lead to the start relay. If satisfactory, check the white and green lead to the thermotime switch block connector; if satisfactory, replace the injector.

## POWER RESISTORS

### Renew

Disconnect the battery earth lead.  
Remove the bolts securing the power resistor.



J98 005

Fig. 32

## FUEL SYSTEM

Remove the multi-pin block connector from beneath the resistor and remove the resistor.

On refitting, ensure the connector is firmly connected.

### Test

Connect an ohmmeter between terminals 10 and 4 of the power resistor. The ohmmeter should indicate a reading of approximately 6 ohms. The same reading should be indicated with the ohmmeter connected between terminals 8 and 6 of the power resistor.

**NOTE:** The power resistors are fitted to protect the ECU against the high current required to operate the injectors. The resistors will limit the current to a safe value, thus protecting the ECU during the pull-in stage. It is most important to check the resistors before renewing the ECU.

## ELECTRICAL CONTROL UNIT (ECU)

### Renew

Disconnect the battery earth lead.

Remove the RH luggage compartment trim pad.

Withdraw the harness plug from the ECU. Remove the two securing bolts and washers.

Withdraw the ECU clear of the mounting bracket.

Disconnect the vacuum signal hose and remove the ECU.

### Refitting

Ensure the connectors are secure and good contacts are made.

Check the idle CO level using a suitable infra-red CO meter.

When using the CO meter, do not use an exhaust extractor fan.



Fig. 34

## OXYGEN (LAMBDA) SENSOR

### Test

Check the ignition timing and idle speed.

Remove the blanking plug from the ECU to expose the idling fuel setting adjuster.

Run the engine until it reaches operating temperature (at least 8 minutes from cold or 2 minutes if hot).




Fig. 35

Disconnect the Lambda diable plug from the harness socket (1, Fig. 35), otherwise the Lambda sensors will not function whilst in neutral or park.

Connect EFI Feedback monitor to the Fuel Setting Diagnostic socket (2, Fig. 35).

Position switch to LOW (3, Fig. 35).

Slowly turn the idling Fuel Setting Adjuster in the ECU with Special Tool No. 607 30551 until LAMP 2 in ROW A or B is lit and LAMP 2 or 3 in other ROW is lit.

Fit a new blanking plug to cover the idling fuel setting adjuster.

Disconnect the pressure regulator vacuum pipe and temporarily seal off the vacuum take off on the manifold pipe.

The Feedback Monitor unit indicators should move towards 'RICH' i.e. LAMP 2 to LAMP 1 and LAMP 3 to LAMP 2 or 1.

If the indicators do not change, Lambda sensors and associated circuit are suspect.

Reconnect the pressure regulator vacuum pipe.

## MAIN RELAY

### Description

The main relay is mounted on the RH side of the luggage compartment.

The relay coil is energised when the ignition is switched on, which when operated closes the relay contacts and supplies battery voltage to the ECU and the pump relay.

## PUMP RELAY

### Description

The pump relay is mounted in the luggage compartment adjacent to the main relay.

Battery voltage is supplied to the relay coil by the main relay. The earth circuit is via an electronic delay circuit in the ECU. The relay contacts supply battery voltage to the fuel pump. Should the ignition switch be turned 'on' but not to 'start', the delay circuit in the ECU will allow the pump to operate for one or two seconds, then the earth circuit of the relay will be broken, thus switching the pump off. When the ignition switch is turned to the start position, and the engine is cranked, the delay circuit is by-passed. The fuel pump will then operate continuously until such time as the ignition is switched off, or the engine speed signal pulses cease, indicating that the engine has stopped. This provides a safety back up to the inertia switch should the engine stop and the ignition be left in the 'on' position due to an accident situation.

### Renew

Disconnect the battery earth lead.

Remove the relay from the retaining bracket. Disconnect the multiplug connector from the relay.

## MAIN RELAY AND PUMP RELAY

### Test

Switch on the ignition. The pump should run for one or two seconds, then stop.

**NOTE:** If the pump does not run, or does not stop, check systematically as follows:

Check that the inertia switch cut-out button is pressed in.

Remove the screws, detach the inertia switch cover, and ensure that both cables are secure.



Pull the connectors from the switch and check continuity across the terminals.

Pull the button out and check for open circuit.

Remove the ohmmeter, replace the connectors, reset the button and refit the cover.

If the inertia switch is satisfactory, ground the pump relay terminal 85, switch on the ignition and check the circuit systematically as detailed below:

A Check for battery voltage at terminal 86 of the main relay.

If yes: Proceed to Test B.

If no: Check the battery supply from the ignition switch via the inertia switch.

B Check for battery voltage at Terminal 87 of the main relay.

If yes: Proceed to Test C.

If no: Check for battery voltage at the earth lead and connection from terminal 85 of the main relay. If satisfactory, renew the main relay.

C Check for battery voltage at terminal 86 of the pump relay.

If yes: Proceed to Test D.

If no: Open circuit between terminals 87 of the main relay and 86 of the pump relay. If satisfactory, proceed to Test D.

D Check for battery voltage at terminal 87 of the pump relay.

If yes: Proceed to Test E.

If no: Check for battery voltage at earth lead and connections from terminal 85 of the pump relay. If satisfactory, remove the pump relay.

E Check for battery voltage at supply lead (NS) and connections to the fuel pump.

If yes: Faulty pump or earth connections.

If no: Open circuit between terminal 87 of the pump relay and supply lead connection to the fuel pump.

## INERTIA SWITCH

### Renew

Disconnect the battery.

Remove the trip reset cable rubber knob and trim panel securing screws.

Disconnect the trip reset cable from the bracket and carefully displace the driver's side dash liner.

Remove the switch cover.

Disconnect the switch block connector.

Remove the two screws securing the switch and remove the switch.

On refitting the switch, ensure that it is correctly reset.

## FUEL MAIN FILTER

### Renew

Depressurise the fuel system.

Disconnect the battery.

Remove the spare wheel cover and the spare wheel.

Fit pipe clamps to the outlet and inlet hoses.

Disconnect the filter hoses (1, Fig. 36).

Fit plugs to the disconnected hoses and to the filter.

Slacken the filter clamp screw (2, Fig. 36) and remove the filter (3, Fig. 36).

On refitting, ensure the hose connections are secure.




Fig. 36

## FUEL PUMP

### Renew

Depressurise the fuel system.

Disconnect the battery earth lead.

Remove the spare wheel.

Remove the two screws securing the fuel pump cover to the battery tray.

Peel back the floor carpet, release the fuel pump cover from the floor clips.

Fit clamps to the inlet and outlet hoses.




Fig. 37

Remove the nuts and washers securing the fuel pump retaining band to the mounting, retrieve the spacer washers and remove the fuel pump assembly.

Remove the electrical block connector from the fuel pump.

**NOTE:** Place a suitable container beneath the car to collect spilled fuel. Release the clips securing the hoses and disconnect the hoses. Separate and remove the two halves of the fuel pump retainer band. Remove the foam rubber insulation bands.

## FUEL TANK

### Renew

**WARNING: FUEL IS EXTREMELY FLAMMABLE. GREAT CARE SHOULD BE TAKEN WHEN DRAINING THE FUEL TANK AND THE FOLLOWING PROCEDURES SHOULD BE STRICTLY ADHERED TO:**

**NO SMOKING ALLOWED NEAR THE AREA,**

**'NO SMOKING' WARNING SIGN POSTED ROUND THE AREA,**

**DISCONNECT THE BATTERY LEADS,**

**A CO<sup>2</sup> FIRE EXTINGUISHER IS CLOSE AT HAND,**

**DRY SAND IS AVAILABLE TO SOAK UP ANY SPILLAGE,**

**THE WORKING AREA IS WELL VENTILATED,**

**FUEL IS DRAINED INTO AN AUTHORISED EXPLOSION PROOF CONTAINER,**

**DISCARDED TANK NOT TO BE DISPOSED OF UNTIL RENDERED SAFE FROM EXPLOSION.**

Remove the spare wheel.

Depressurise the fuel system and then

## FUEL SYSTEM

disconnect the battery.

Remove the two screws securing the fuel pump cover to the battery tray.

Peel back the floor carpet, release the fuel pump cover from the floor clips.

Clamp the inlet hose to the fuel pump.

Loosen the hose clip securing the inlet hose to the fuel pump and disconnect the hose from the pump.

Remove the grommet from the vent hole in the luggage compartment floor, insert a suitable pump into the pump inlet hose, secure with a hose clip and push the pipe through the vent hole in the luggage compartment floor.

Place a suitable container beneath the car and the protruding pipe to collect the fuel.

Remove the fuel filter cap, release the clamp from the fuel pump inlet hose and drain the tank.

Remove the battery.

Clamp the fuel return hose and disconnect the union nut at the fuel tank (1, Fig. 37).

Release the hose clip securing the expansion tank supply hose to pipe and disconnect the hose (2, Fig. 37).

Release the union nut securing the expansion tank return pipe to fuel tank (3, Fig. 37).

Release the three hose clips securing the vent hoses to the fuel tank vent pipes.

Note the position of and disconnect the hoses (4, Fig. 37).

Note the position of and disconnect the electrical connectors from the fuel gauge tank unit (5, Fig. 37).

Release the hose clips securing the fuel filler assembly to the body and remove the fuel filler assembly (6, Fig. 37).

Remove the two bolts and release the fuel tank securing straps (7, Fig. 37).

Remove the LH and RH luggage compartment trim pads.

Remove the seven screws, plain washers and four fibre washers securing the LH side luggage compartment side panel to body lower panel.

Remove the seven screws, plain washers and four fibre washers securing the RH side panel to body, disconnect the earth leads from the relay bracket and lower the panel.

Remove the fuel tank.

Remove the expansion tank supply pipe (8, Fig. 37) and remove the fuel gauge tank unit (9, Fig. 37).

### Refitting

Reverse the above procedure ensuring that all earth and electrical connections are secure and tight.

Check for fuel leaks.

## CABRIOLET FUEL TANK

### Renew

#### Fuel filler cap and gasket

### Renew

Special Tool No 18G 1001

**WARNING: FUEL IS EXTREMELY FLAMMABLE. GREAT CARE SHOULD BE**

**TAKEN WHEN DRAINING THE FUEL TANK AND THE FOLLOWING PROCEDURES SHOULD BE STRICTLY ADHERED TO:**

**NO SMOKING ALLOWED NEAR THE AREA,**

**'NO SMOKING' WARNING SIGN POSTED ROUND THE AREA,**

**DISCONNECT THE BATTERY LEADS,**

**A CO<sup>2</sup> FIRE EXTINGUISHER IS CLOSE AT HAND,**

**DRY SAND IS AVAILABLE TO SOAK UP ANY SPILLAGE,**

**THE WORKING AREA IS WELL VENTILATED,**

**FUEL IS DRAINED INTO AN AUTHORISED EXPLOSION PROOF CONTAINER,**

**DISCARDED TANK NOT TO BE DISPOSED OF UNTIL RENDERED SAFE FROM EXPLOSION.**

Remove the spare wheel.

Disconnect the battery leads.

Remove the fuel pump cover securing screws, release the cover from the floor clips and remove cover.

Remove the grommet from below the auxilliary fuel tank drain plug.

Fit a drain tube to the auxilliary fuel tank drain plug.

Place a suitable container beneath the drain tube.

Open the filler cap.

Open the drain plug and drain fuel from the fuel tank.

Remove the filler cap securing screws and the fuel type label.

Loosen the filler neck upper securing clip (1, Fig. 38).

Loosen the filler cap breather pipe securing clip (2, Fig. 38).

Carefully displace and remove the filler cap assembly complete with gasket.

Clean the filler cap sealing area.

Remove the boot side trim panels.

Remove the LH upper panel securing screws and displace the panel for access.

Remove the screws securing the service interval counter and displace the interval counter from the panel.

Note and disconnect the boot lamp switch cables.

Remove the nut and bolt securing the bulb failure unit.

Displace the unit from the panel.

Unclip the cable harness from the panel cable clips and remove the panel.

Remove the relays and the interface unit from the RH side panel mounting lugs.

Remove the screws securing the RH upper panel and displace the panel for access.

Note and disconnect the boot lamp cables.

Remove the nut and bolt securing the bulb failure unit.

Displace the unit from the panel.


Remove the cable harness from the panel cable clips and remove the panel.

Remove the battery.

Remove the auxilliary fuel tank cover securing screws, displace and remove the cover.

Remove the auxilliary fuel tank securing bolts.

Remove the fuel pump bracket securing bolts.



J19 155

Displace the auxilliary fuel tank and the fuel pump assembly for access.

Remove the nuts and bolts securing the battery carrier.

Remove the carrier drain hose from the boot floor, displace and remove the battery carrier.

Remove the screws securing the fuel hose clamp plate and remove the plate.

Note and disconnect the fuel tank unit electrical cables using tool No. 18G 1001, rotate the locking ring anti-clockwise to clear the lugs in the tank (3, Fig. 38).

Remove the locking ring and withdraw the tank unit.

Clamp the fuel tank to auxilliary tank hose, release the union nut at the fuel tank, disconnect and displace the hose (4, Fig. 38).

Clamp the fuel tank return hose, release the union nut and displace the hose from the tank (5, Fig. 38).

Remove the fuel tank retaining bracket securing bolts (6, Fig. 38).

Loosen the retaining bracket aligning plate securing bolts.

Displace and remove the retaining bracket assembly (7, Fig. 38).

Remove the aligning plate packing strips.

Remove the nuts securing the vapour separator to the rear bulkhead, displace the separator and disconnect the hoses (8, Fig. 38).

Displace and carefully manoeuvre the fuel tank from its location.

Remove the breather hose (9, Fig. 38), vapour separator hose (10, Fig. 38), and the filler neck hose (11, Fig. 38) from the fuel tank.

Refitting is the reversal of the above operations.

Ensure the foam pads are glued to the side of the tank.

Fit new gaskets to the fuel tank unit and the filler cap assembly.

Ensure all electrical components operate satisfactory.

Reconnect the fuel hose to the cold start injector.

Switch the ignition on and check for leaks.

Remove the jumper lead from the terminal 85 of the pump relay.

Reconnect the leads to the negative terminal of the ignition coil.

## FUEL SYSTEM

### Pressure Test

Depressurise the fuel system.

Slacken the clip on the cold start injector fuel hose and disconnect the hose.

Connect the pressure gauge to the disconnected hose.

Disconnect the leads from the negative terminal of the ignition coil.

Connect a jumper lead from terminal 85 of the pump relay to earth.

Switch on the ignition and check the pressure gauge reading. The reading should be between 2.0 — 2.2 kgf/cm<sup>2</sup> (28.5 — 30.8 lbf/in<sup>2</sup>).

Should the reading be high, check the fuel return pipe for blockage. If the reading is low, check the fuel pump for correct operation, blockage in the supply fuel line or the pump suction pipes, or a choke filter.

Switch the ignition off.

Depressurise the fuel system and remove the pressure gauge.




## CONTENTS

| Operation   | Operation No. | Page No. |
|---|---------------|----------|
| Atmospheric catchment tank — Renew .....                          | 26.15.03      | 26—7     |
| Coolant level probe — Renew .....                                 | 26.40.11      | 26—7     |
| Cooling system — Drain and refill .....                           | 26.10.01      | 26—5     |
| Cooling system flow charts .....                                  | —             | 26—3     |
| Cooling system — Pressure test .....                              | 26.10.07      | 26—5     |
| Description .....   | —             | 26—4     |
| Expansion tank — Renew .....                                      | 26.15.01      | 26—7     |
| Pressure cap — Renew .....  | 26.40.03      | 26—7     |
| Fan electrical — Renew .....                                      | 26.52.22      | 86—30    |
| Fault diagnosis .....   | —             | 26—4     |
| Hose — Expansion tank to atmospheric catchment tank — Renew ..... | 26.30.62      | 26—7     |
| Hose — Set — Renew .....  | 26.30.41      | 26—9     |
| Hose — Cylinder head to water valve — Renew .....                 | 26.30.39      | 26—9     |
| Hose — Expansion tank to radiator — Renew .....                   | 26.30.54      | 26—9     |
| Hose — Expansion tank to thermostat housing — Renew .....         | 26.30.61      | 26—9     |
| Hose — Expansion tank to water pump — Renew .....                 | 26.30.72      | 26—9     |
| Hose — Heater return pipe to water pump — Renew .....             | 26.30.43      | 26—9     |
| Hose — Heater to return pipe — Renew .....                        | 26.30.44      | 26—9     |
| Hose — Heater valve to heater — Renew .....                       | 26.30.40      | 26—9     |
| Hose — Water pipe to water pump — Renew .....                     | 26.30.73      | 26—9     |
| Hose — Water pump to thermostat housing — Renew .....             | 26.30.20      | 26—9     |
| Pressure cap — Test .....   | 25.40.13      | 26—5     |
| Radiator — Renew .....  | 26.40.04      | 26—8     |
| Radiator bottom hose — Renew .....                                | 26.30.07      | 26—8     |
| Radiator drain tap — Renew .....                                  | 26.40.01      | 26—8     |
| Radiator top hose — Renew .....                                   | 26.30.01      | 26—8     |
| Seal coolant level — Renew .....                                  | 26.40.12      | 26—8     |
| Thermostat — Renew .....  | 26.45.01      | 26—6     |
| Thermostat cover — Renew .....                                    | 26.45.12      | 26—6     |
| Thermostat cover gasket — Renew .....                             | 26.45.14      | 26—6     |
| Thermostat housing — Renew .....                                  | 26.45.10      | 26—6     |
| Thermostat housing gasket — Renew .....                           | 26.45.06      | 26—6     |
| Thermostat housing rear outlet gasket — Renew .....               | 26.45.16      | 26—6     |
| Thermostat housing rear outlet — Renew .....                      | 26.45.17      | 26—6     |
| Thermostat — Test .....   | 26.45.09      | 26—5     |
| Thermostatic switch — Renew .....                                 | 26.25.35      | 26—6     |
| Torquatrol unit — Renew .....                                     | 26.25.19      | 26—9     |
| Fan blades — Renew .....  | 26.25.06      | 26—9     |

COOLING SYSTEM

| Operation                        | Operation No. | Page No. |
|----------------------------------|---------------|----------|
| Water pipe gaskets — Renew ..... | 26.30.75      | 26—9     |
| Water pipe — Renew .....         | 26.30.74      | 26—9     |
| Water pump gasket — Renew .....  | 26.50.02      | 26—7     |
| Water pump — Renew .....         | 26.50.01      | 26—7     |
| Water pump housing — Renew ..... | 26.50.07      | 26—6     |


Thermostat closed



J26 054A

Fig. 1

Thermostat open



J26 055A

Fig. 2

KEY

- 1. Radiator
- 2. Top hose
- 3. Engine

- 4. Thermostat housing
- 5. Water pump
- 6. Heater

- 7. Atmospheric catchment tank
- 8. Header tank
- 9. Bottom hose

COOLING SYSTEM FLOW

## COOLING SYSTEM

### DESCRIPTION

The cooling system consists of a crossflow radiator matrix, a water pump belt driven by the engine crankshaft, a header tank and an expansion tank located in the near side wing, and a thermostatic valve to ensure rapid warm up. The radiator is cooled by a viscous coupled fan and also an electric driven fan, this fan is thermostatically controlled and it is possible under very hot conditions for it to operate after the engine is switched off. The fan will switch off automatically when the coolant drops below 90°C.

Under cold start condition coolant is forced by the water pump through the cylinder block and cylinder head to the thermostat housing. The valve is closed and the coolant is therefore returned to the water pump suction inlet.

Cars fitted with automatic transmission have a cooling tube included in the centre section of the radiator matrix.

We use and recommend BP Type H21 or Union Carbide UT184 or Unipart Universal anti-freeze which should be used at the specified concentration whenever the cooling system is refilled. For topping-up purposes, only reputable brands of anti-freeze, formulated and approved for 'mixed metal' engines should be used.

**IMPORTANT NOTE: THE CONCENTRATION OF ANTI-FREEZE MUST NOT BE ALLOWED TO FALL BELOW THE RECOMMENDED STRENGTH AS SEDIMENT MAY BE FORMED IN THE COOLING SYSTEM BY CERTAIN TYPES OF ANTI-FREEZE AT LOW CONCENTRATES.**

A 40% solution by volume in the United Kingdom (55%, U.S.A./Canada and all other countries) must be used at all times, either by topping-up or replenishing the cooling system. For maximum corrosion protection, the concentration should never be allowed to fall below 25%. Always top-up with recommended strength of anti-freeze, NEVER WITH WATER ONLY.

In countries where it is unnecessary to use anti-freeze, Marston SQ35 Corrosion Inhibitor must be used in the cooling system in the proportion of 1 part SQ36 to 24 parts water. CHANGE COOLANT EVERY TWO YEARS. The system should be drained, flushed and refilled with fresh anti-freeze (or Corrosion Inhibitor), mixed with 1 sachet of 'Barrs Leaks'.

An alternative coolant known as CARBUROL FORLIFE is recommended where temperatures below 10°C (14°F) are not encountered. Before Carburol Forlife is used, the coolant already present in the system must be drained out and the system flushed before filling with Carburol Forlife. Once in use the system should be topped-up with Carburol Forlife only, and a label giving this information should be affixed in an appropriate and prominent position.

### Fault diagnosis

| Symptom               | Reason  | Remedy  |
|-----------------------|---|---|
| Overheating           | Insufficient water in cooling system<br>Fan belt slipping<br><br>Radiator core blocked or radiator grille obstructed<br>Thermostat not opening properly<br>Ignition advance and retard incorrectly set (accompanied by loss of power and perhaps misfiring)<br>Incorrect fuel/air mixture<br>Exhaust system partially blocked<br>Oil level in sump too low<br>Blown cylinder head gasket (water/steam being forced down the radiator overflow pipe under pressure)<br>Engine not yet 'run-in'<br>Brakes binding | Top up radiator<br>Tighten fan belt to recommended tension or replace if worn.<br>Reverse flush the radiator, remove obstruction from grille<br>Remove and fit new thermostat.<br><br>Check and reset ignition timing.<br>Check CO/HC level.<br>Check exhaust pipe for obstruction.<br>Top up to correct level.<br><br>Remove cylinder head and fit new gasket.<br>Run-in slowly and carefully.<br>Check brake calipers for sticking pistons and seized brake pad pins. |
| Engine running 'cold' | Thermostat jammed open<br>Incorrect grade of thermostat fitted<br><br>Thermostat missing  | Remove and renew thermostat.<br>Remove and replace with correct type of thermostat.<br>Check and fit correct thermostat.  |
| Leaks in system       | Loose clips on water hoses.<br>Top or bottom water hoses perished<br>Radiator leaking<br>Thermostat gasket leaking<br>Pressure cap spring worn or seal ineffective<br>Cylinder wall or head cracked   | Check and tighten clips.<br>Check and replace any faulty hoses.<br>Remove radiator and repair.<br>Inspect and renew gasket.<br>Renew pressure cap<br>Replace either cylinder block or cylinder head.  |

## COOLING SYSTEM

## Pressure Test

Ensure that the engine is warm from recent operation. Carefully remove the pressure cap from the expansion tank and check that it is the correct type for the vehicle.

Select the correct adaptors for the neck of the header tank (1, Fig. 3) and the Tester (2, Fig. 3) and fit it to the header tank.

Pump up the pressure to a pressure equal to the pressure cap poundage. Watch the gauge for ten seconds and if the pressure drops check the water pump and external connections for leaks. If the pressure remains constant for ten seconds, maintain the pressure and visually check for pin point leaks. Tighten all connections and replace worn or leaky hoses, internal leaks may be cured by torquing the cylinder head bolts.

A more severe test may be carried out by using the above procedure with the engine running. Absence of external leaks accompanied by fluctuations in pressure usually indicates a 'blown' cylinder head gasket, however, under no circumstances should the pressure be allowed to exceed the upper limit of the cap.

## COOLING SYSTEM

## Drain and Refill

Place a drain tray in position under the radiator drain tap (1, Fig. 4). Remove the expansion tank filler cap, open the radiator drain tap (2, Fig. 4) and drain the coolant. Remove the transmission cooler pipes bracket from the drain plug. Remove the rear drain block plug and drain the coolant. Refit the cylinder block drain plug and close the radiator drain tap, reposition the cooler pipes and refit clamp. Fill the cooling system with a solution of anti-freeze and water, move the heater valve control lever to the hot position, refit the expansion tank cap and run the engine until the thermostat is open. Switch off engine, remove expansion tank cap and refill with water.

## PRESSURE CAP

## Test

Ensure that the cooling system is cold before removing the cap. Determine the correct adaptors for the cap to be checked and attach the adaptors to the tester, check and examine the rubbers (1, Fig. 5) for cracks and wear. Rinse the cap in water to remove any sediment and apply the cap (2, Fig. 5) to the tester in the wet condition. Pump up the tester until the gauge pointer stops rising. This pressure should read between 93,15 - 120,75 kPa. Reject the cap if it does not reach or exceeds this pressure. Reject the cap which will not hold the rated pressure for 10 seconds without additional pumping.

**NOTE:** When renewing a defective pressure cap with a new unit, never fit a cap of a higher pressure than of the original fitment.




Fig. 3




Fig. 4




Fig. 5

## THERMOSTAT

## Test

The thermostat may be checked by suspending it, with the thermostat heat control unit facing down, in a small pan or dish (1, Fig. 6) containing a solution of ethylene glycol coolant containing a thermometer (2, Fig. 6). Neither the thermostat or the thermometer should rest on the bottom of the pan because of the uneven concentration of heat at this point when the pan is heated. The thermostat (3, Fig. 6) should open when a temperature of 82°C is attained. When the coolant reaches 97°C the valve should be fully open.




Fig. 6

## THERMOSTAT

### Renew

Drain the coolant.

Remove the thermostat cover securing bolts (1, Fig. 7) and remove the cover (2, Fig. 7). Remove the thermostat (3, Fig. 7) and sealing ring (4, Fig. 7) from the housing (5, Fig. 7), remove the gasket and clean the mating faces.

Fit a new sealing ring and place the new thermostat into the housing ensuring that the face marked 'to RAD' is facing out, and the position marked 'TOP' is at the top.

Smear the gasket face with 'Hylosyl 101', fit the thermostat cover, tighten the securing bolts and refill the cooling system.




Fig. 7

## THERMOSTATIC SWITCH

### Renew

Drain the coolant, note the position of the switch wires (1, Fig. 8) before disconnecting, remove the switch (2, Fig. 8).

Fit and tighten the new switch and refit the connections. Fill the system with coolant.




Fig. 8

## THERMOSTAT HOUSING REAR OUTLET GASKET

### Renew

Drain the coolant. Remove the water pump to thermostat housing hose. Remove the rear outlet cover securing bolts (1, Fig. 9) and remove the cover (2, Fig. 9). Clean the rear outlet gasket faces. Smear the faces with 'Hylosyl 101', fit the rear outlet cover secured with two bolts. Refit the water pump to thermostat housing hose and refill the system with coolant.




Fig. 9

## THERMOSTAT HOUSING GASKET

### Renew

Drain the coolant, disconnect the temperature transmitter, water temperature sensor and the thermotime switch feed wires (1, Fig. 10). Disconnect the hoses from the thermostat housing.

Remove the thermostat housing securing bolts (2, Fig. 10) and remove the housing (3, Fig. 10). Clean the thermostat housing gasket faces.

Coat the faces with 'Hylosyl 101' and refit the thermostat housing and secure with bolts ensuring that the earth lead is attached to the top bolt. Refit the hoses to the housing and tighten the clips. Reconnect the water temperature transmitter, water temperature sensor and thermotime switch wires and refill the cooling system.




Fig. 10

## THERMOSTAT HOUSING

### Renew

Remove the thermostat housing cover (1, Fig. 11), thermostat (2, Fig. 11) and 'O' ring (3, Fig. 11). Remove the auxiliary air valve (4, Fig. 11) and discard the gasket. Remove the rear elbow (2, Fig. 9), the water temperature switch (6, Fig. 11), thermotime switch (7, Fig. 11), the thermostatic switch (8, Fig. 11) and discard the sealing washers.

Clean the gasket and mating faces and fit the sensors and switches with new sealing washers. Smear the rear elbow gasket face with 'Hylosyl 101' and fit the elbow. Fit the auxiliary air valve with a new gasket. Fit the thermostat and cover.

Fit the thermostat housing as instructions in 'Thermostat housing gasket renew'.




Fig. 11

## WATER PUMP HOUSING

### Renew

Drain the coolant: Remove the air cleaner element, the torquatrol unit and the fan. Remove all the hoses from the housing. Remove the water pump housing securing bolts (1, Fig. 12) and remove the housing (2, Fig. 12). Clean the water pump and gasket faces. Smear the gasket face with 'Hylosyl 101', align and fit the pump to the housing and tighten the securing bolts. Fit the housing and pump assembly back to the engine and secure with the mounting bolts. Refit all the hoses and tighten clips. Refit the fan belt and retension by moving the alternator. Refit the fan, the torquatrol unit and the air cleaner element. Refill the system with coolant.




Fig. 12



## WATER PUMP GASKET

### Renew

Drain the coolant, remove the air cleaner element, remove the torquatrol unit. Pivot the alternator towards the engine and remove the fan belt.

Remove the bolts (1, Fig. 13) securing the water pump (2, Fig. 13) to the housing and pull the pump clear of the housing. Remove the gasket and clean the faces (3, Fig. 13).

Smear the pump gasket face with 'Hylosyl 101', fit and align the pump to the housing and secure with the bolts. Refit the fan belt and retension by moving the alternator. Fit the torquatrol unit and air cleaner element. Refill the system with coolant.




Fig. 13

## EXPANSION TANK

### Renew

Remove the air cleaner and box, disconnect the low coolant probe sensor. Place a suitable container below the tank lower outlet (1, Fig. 14) and remove all the hoses (2, Fig. 14) from the tank. Drain the expansion tank, remove the securing bolts (3, Fig. 14) and remove the tank (4, Fig. 14) from the vehicle. Remove the pressure cap, retaining ring, coolant probe, coolant probe grommet and anti-vibration rubber, from the tank.

Assemble all fittings to replacement tank and refit tank to inner wing bracket. Refit hoses and refill with correct anti-freeze/water solution.

Refit air cleaner element and box.




Fig. 14




Fig. 15

## COOLANT LEVEL PROBE

### Renew

Release the pressure cap (1, Fig. 15) from the expansion tank (2, Fig. 15), disconnect the probe feed wire (3, Fig. 15), place a suitable water container in position and remove probe (4, Fig. 15) and sealing washer.

Lubricate probe seal and seat it on the expansion tank, fit and seat the probe to the seal, connect the feed wire, top-up the coolant as required and refit the pressure cap.

## ATMOSPHERIC CATCHMENT TANK

### Renew

Jack up and place the front of the vehicle on stands.

Remove the front left-hand road wheel.

Remove the screws securing the wheel arch rear panel and remove the panel.

Unclip the catchment tank (1, Fig. 16).

Unclip the overflow pipe (2, Fig. 16) from the body and displace the tank from its mounting position.

Disconnect and remove the catchment tank from the joining hose.

On refitting apply new body sealant to the wheel arch panel seal.




Fig. 16

## HOSE EXPANSION TANK TO ATMOSPHERIC CATCHMENT TANK

### Renew

Jack up and place the front of the vehicle on stands.

Remove the left-hand front wheel.

Remove the screws securing the wheel arch rear panel and remove the panel.

Unclip the catchment tank and overflow pipe from the body.

Displace the tank from its mounting position.

Slacken the hose clip and remove the catchment tank complete with the joining hose from the vehicle.

Remove the hose clip from the hose.

Displace the hose from its mounting position and remove the hose from the header tank.

On refitting apply new body sealant to the wheel arch seal.

## RADIATOR

### Renew

Drain the cooling system, remove the torquatrol unit and fan. Disconnect the expansion tank to radiator hose (1 Fig. 17), disconnect the thermostatic switch feed wires (2, Fig. 17) and move the fan cowl away from the top rail. Remove the receiver drier securing nuts (3, Fig. 17) and bolts, move drier (4, Fig. 17) clear of top rail. Release the earth leads, 2 left-hand side (5, Fig. 17), 1 right hand side (6, Fig. 17).

Disconnect the amplifier leads, the distributor harness, the amplifier to coil harness and remove the top rail/amplifier assembly (7, Fig. 17).

Disconnect the top hose (8, Fig. 17) from the radiator.

Disconnect the bottom hose (9, Fig. 17) and lift the radiator (10, Fig. 17) from its lower mounting, remove the fan cowl (11, Fig. 17) and remove the radiator (11, Fig. 17).

Carefully remove the radiator sealing rubbers, the thermostatic switch and the drain tap.

Fit the drain tap, the thermostatic switch and the sealing rubbers to the new radiator and reverse the removal procedure noting to refill the cooling system.




Fig. 17

**TORQUATROL UNIT****Renew**

Slacken the fan blade to torquatrol unit securing nuts (1, Fig. 18) and bolts (2, Fig. 18). Pull the torquatrol unit (3, Fig. 18) clear of fan pulley face and remove the securing nuts, remove the fan and torquatrol unit clear of pulley and remove the fan (4, Fig. 18) from the torquatrol unit.

Refit the fan to the torquatrol unit and bolt the assembly to the fan pulley face. Fill the system with coolant and fit filler cap.




Fig. 18

**CYLINDER BLOCK WATER TRANSFER PIPE GASKETS****Renew**

Drain the coolant and depressurise the fuel system. Remove the air box and element. Remove the induction manifold. Slacken the hose securing clip (1, Fig. 19), cut and remove the harness to water pipe securing clip. Remove the water pipe securing bolts (2, Fig. 19) and remove the pipe (3, Fig. 19). Clean the gasket faces (4, Fig. 19) and then coat them with 'Hylosyl 101', fit a new pipe, fit a new harness securing clip, refit the induction manifold and the air cleaner element. Refill the cooling system.




Fig. 19


**HOSE SET****Renew**

Drain the cooling system, slacken hose clips as required and carefully remove the hoses. To ease assembly of the hoses to attachment points, a liberal application of soft soap may be applied to the inside of the hoses. Position and tighten the securing clips and refill the system with coolant.

CONTENTS

| Operation                                    | Operation No. | Page No. |
|--|---------------|----------|
| Air Cleaner — Renew .....                    | 19.10.08      | 30—3     |
| Exhaust manifold — pair — Renew .....        | 30.15.22      | 30—3     |
| Exhaust manifold — front — Renew .....       | 30.15.28      | 30—3     |
| Exhaust manifold gaskets — Renew .....       | 30.15.19      | 30—3     |
| Front exhaust manifold gasket — Renew .....  | 30.15.20      | 30—3     |
| Exhaust manifold — rear — Renew .....        | 30.15.11      | 30—3     |
| Rear exhaust manifold gasket — Renew .....   | 30.15.21      | 30—3     |
| Exhaust system and mountings — Renew .....   | 30.10.08      | 30—4     |
| Branch pipe — Renew .....                    | 30.10.06      | 30—4     |
| Exhaust trim — Renew .....                   | 30.10.23      | 30—4     |
| Front pipe — Renew .....                     | 30.10.09      | 30—4     |
| Left hand silencer — Renew .....             | 30.10.15      | 30—4     |
| Mounting rubber — front — Renew .....        | 30.20.02      | 30—4     |
| Mounting rubber — front — pair — Renew ..... | 30.20.05      | 30—4     |
| Rear intermediate pipe — LH — Renew .....    | 30.10.25      | 30—4     |
| Rear intermediate pipe — RH — Renew .....    | 30.10.24      | 30—4     |
| RH silencer — Renew .....                    | 30.10.16      | 30—4     |
| Induction manifold gaskets — Renew .....     | 30.15.08      | 30—5     |
| Intake tubes — set — Renew .....             | 30.15.32      | 30—3     |
| Gaskets intake tubes — set — Renew .....     | 30.15.33      | 30—3     |
| Gaskets intake tube — single — Renew .....   | 30.15.31      | 30—3     |
| Intake tube — single — Renew .....           | 30.15.30      | 30—3     |

# MANIFOLD AND EXHAUST SYSTEM



J30-038

Fig. 1

- |                |                         |                                   |
|----------------|-------------------------|-----------------------------------|
| 1. Down pipe   | 7. Clamp                | 13. LH Rear silencer              |
| 2. Clamp       | 8. RH Silencer          | 14. LH Intermediate pipe          |
| 3. Olive       | 9. RH Intermediate pipe | 15. LH Silencer                   |
| 4. Front pipe  | 10. RH Rear silencer    | 16. Branch pipe/catalyst assembly |
| 5. Clamp       | 11. RH Tail pipe/trim   | 17. Down pipe/catalyst assembly   |
| 6. Branch pipe | 12. LH Tail pipe/trim   |                                   |

Note: Items 16 and 17 are only used on USA Federal market vehicles only.

## TORQUE WRENCH SETTINGS

| ITEM                              | SPANNER SIZE     | DESCRIPTION | TIGHTENING TORQUE |              |          |
|-----------------------------------|------------------|-------------|-------------------|--------------|----------|
|                                   |                  |             | Nm                | kgf/cm       | lbf/ft   |
| Intake tube — inlet manifold      | 3 mm (Allen key) | 6 mm bolt   | 9.5 to 12.2       | 0.98 to 1.26 | 7 to 9   |
| Inlet manifold to cylinder head   | 10 mm            | 8 mm bolt   | 23 to 27          | 3.21 to 3.76 | 17 to 19 |
| Inlet manifold to cylinder head   | 13 mm            | 8 mm nut    | 12 to 16          | 1.26 to 1.66 | 9 to 12  |
| Exhaust manifold to cylinder head | 13 mm            | 10 mm nut   | 49 to 54          | 6.82 to 7.52 | 36 to 40 |

## AIR CLEANER

### Renew

Release the outer air box clips (1, Fig. 2) and remove the air cleaner together with the air box (2, Fig. 2).

Hold the new air cleaner and the box together and feed them into the bottom air box flange, pivot air box towards engine and secure with the 'over centre' clips (1, Fig. 2).




Fig. 2

J30-037




Fig. 3

J30-035

## RAM PIPES

### Renew Set

Release the four securing screws per ram pipe (1, Fig. 3) and remove pipes No. 1 and 6.

Remove the air cleaner backplate (2, Fig. 3) for ram pipes 2, 3, 4 and 5 (3, Fig. 3).

Note for No. 4 ram pipe the throttle pedestal (4, Fig. 3) will have to be removed.

Refit replacement pipes and secure with screws.




Fig. 4

J30-036

## EXHAUST MANIFOLDS

### Renew

Disconnect the spark plug leads, release the two manifold to down pipe flanges (1, Fig. 4). Remove the manifold securing nuts (2, Fig. 4) and remove the manifolds (3, Fig. 4).

Fit new exhaust manifold gaskets, position the manifolds and secure with the nuts. Reposition the manifold flanges and secure with the nuts and refit the spark plug leads.

## MANIFOLD AND EXHAUST SYSTEM

## EXHAUST SYSTEM AND MOUNTINGS

**NOTE:** For federal vehicles disregard any reference to the front pipe and refer to Fig. 6.

## Renew

Open the boot and lift the carpet to expose the rear exhaust mounting securing nuts. Remove the rear exhaust mounting nuts and mountings. Remove the mounting spacer washers.

Slacken the tail pipe and silencer to rear intermediate pipe clamp nut (1, Fig. 5) and bolt. Split the rear silencer assembly (2, Fig. 5) from the rear intermediate pipe (3, Fig. 5). Remove the exhaust pipe trim (4, Fig. 5).

Remove the intermediate pipe to silencer clamp nuts (5, Fig. 5) and bolts and support the rear silencers (6, Fig. 5). Remove the front pipe to manifold securing nuts (7, Fig. 5). Carefully disconnect the front pipe (8, Fig. 5) from the manifold and support the

system. Remove the clamps (9, Fig. 5) from the rear joints and separate the silencer (6, Fig. 5) from the branch (10, Fig. 5) and front pipe (11, Fig. 5). Remove clamp (12, Fig. 5) and separate the front pipe (11, Fig. 5) (where fitted) and the branch pipe (10, Fig. 5). Separate the silencers (6, Fig. 5) from the intermediate pipes (3, Fig. 5) and remove the intermediate pipes (3, Fig. 5).

Remove the intermediate pipe mounting bar, spacers and securing nuts, repeat for second pipe and remove the front sealing rings.

Remove the rear mounting to rear suspension securing nuts and bolts, remove the mounting and repeat for the second rear mounting.

Fit new exhaust system brackets to vehicle ensuring that the tail pipes and rear intermediate pipes are fitted to the vehicle first.

Assemble complete system loosely and align to clear of all other fittings ensure that all joints are smeared with exhaust sealant prior to assembly and finally tighten all mountings and clamps.




Fig. 5

J30-032




Fig. 6

J30-033



## INDUCTION MANIFOLD GASKETS

### Renew

Depressurise the fuel system, by disconnecting the relay and cranking the engine over, disconnect the auxiliary air valve hoses, identify and disconnect the air valve feed wires and disconnect the throttle potentiometer block connector.

Disconnect the return hose (1, Fig. 7) from the pressure regulator (2, Fig. 7) and fit blanking plugs to the hose and the regulator.

Disconnect the fuel rail feed hose (3, Fig. 7) from the rail.

Disconnect the kickdown cable (4, Fig. 7) from the throttle linkage and remove the securing bracket (5, Fig. 7).

Disconnect the brake servo hose from the inlet manifold (6, Fig. 7), the air conditioning econocruise pipes (7, Fig. 7) and the ECU vacuum pipe from the manifold (8, Fig. 7).

Disconnect the solenoid air switch vacuum pipe and distributor advance/retard pipe (9, Fig. 7), the ambient air temperature sensor (10, Fig. 7) and injector block connectors (11, Fig. 7).

Remove the breather hose (12, Fig. 7) from the cam cover and the hoses from the air cleaner back plate and manifold.

Release the securing bolt and pull the oil filler pipe (13, Fig. 7) clear of its lower housing.

Remove the dipstick tube securing bolt and tube, the manifold securing nuts and bolts, lifting eyes and filler pipe bracket.

Release the engine earth lead from the rear of the manifold.

Disconnect the solenoid air switching valve and remove.

Remove the manifold (14, Fig. 7) and at the same time feed the injector harnesses and connectors through the manifold. Remove the manifold gaskets (15 Fig. 7) and discard the oil filler tube lower seal.

Clean the filler tube seal and gasket faces and fit new gaskets and seal.

Position the injector, sensor, switch wires and distributor advance/retard pipes through the relevant apertures in the inlet manifold.

Position the manifold onto the cylinder head studs. Refit the filler tube bracket and lifting eyes and reconnect the air solenoid switch to the manifold.

Fit and tighten the manifold securing nuts and bolts ensuring that the earth lead is connected to its correct bolt hole.

Reposition the dipstick tube and secure with the bolt and 'P' Clip.

Fit the filler tube into the lower housing and tighten the tube upper securing bolt. Fit the

breather hose to the filler tube and cam cover. Connect the hoses to the manifold and air cleaner back plate and the injector and air sensor block connectors.

Connect the distributor advance/retard pipes, the air solenoid vacuum pipe, the ECU vacuum pipe, the air conditioning and econocruise vacuum pipes and the brake servo hose to the manifold.

Fit the throttle kickdown cable bracket, the throttle cable and position the clip over the nipple and reconnect the kickdown cable to the linkage.

Remove the plugs from the fuel rail feed hose and refit the hose.

Remove the plugs from the pressure regulator valve return hose and reconnect the hose. Connect the throttle potentiometer block connector and the air switching valve feed wires.

Connect the auxiliary air valve hoses and tighten the clips.

Refit the air cleaner element and box.







Fig. 7

J30-034



**XJ-S 3·6  
XJ-SC 3·6  
SERVICE  
MANUAL**





## **BOOK 4**

**Containing  
Sections**

**33 CLUTCH  
37 MANUAL GEARBOX**

**XJ-S 3·6  
XJ-SC 3·6**

**SERVICE MANUAL**

---

## INTRODUCTION

This Service Manual covers the Jaguar XJ-S 3.6 and XJ-SC 3.6. It is primarily designed to assist skilled technicians in the efficient repair and maintenance of this range of Jaguar cars.

Using the appropriate service tools and carrying out the procedures as detailed will enable the operations to be completed within the time stated in the 'Repair Operation Times'.

The Service Manual has been produced in 9 separate books; this allows the information to be distributed throughout the specialist areas of the modern service facility.

A table of contents in Book 1 lists the major components and systems together with the section and book numbers. The cover of each book depicts graphically and numerically the sections contained within that book.

The title page of each book carries the part numbers required to order replacement books, binders or complete Service Manuals. This can be done through the normal channels.

The contents section of each book lists the repair operations in the section or sections contained within that book. Each operation is given an operation number that corresponds with those listed in the Repair Operation Times.

The method described on the page number listed against the operation will be the one we consider will meet the requirements of safety and enable the operation to be carried out in the time specified in the Repair Operation Times.

Where no page number is given against an operation, we feel that the method is so obvious as to warrant no explanation. It is, however, included so that a warranty time can be given in the Repair Operation Times.

Extensive research has gone into the diagnosis of faults and where appropriate this is covered in the various areas of the manual. By following the sequence of the diagnosis charts, speedy isolation of faults may be expected, and consequent correction will reduce the vehicle off-the-road time to the minimum.

### Service Tools

Where performance of an operation requires the use of a service tool the tool number is quoted under the operation heading and is repeated in, or following, the instruction involving its use. A list of all necessary tools is included in Book 1, Section 99.

### References

References to the LH or RH side in the manual are made when viewing from the rear. With the engine and gearbox assembly removed the timing cover end of the engine is referred to as the front. A key to abbreviations and symbols is given in Book 1, Section 01.

## REPAIRS AND REPLACEMENTS

When service parts are required it is essential that only genuine Jaguar or Unipart replacements are used.

Attention is particularly drawn to the following points concerning repairs and the fitting of replacement parts and accessories.

1. Safety features embodied in the vehicle may be impaired if other than genuine parts are fitted. In certain territories, legislation prohibits the fitting of parts not to the vehicle manufacturer's specification.
2. Torque wrench setting figures given in this Service Manual must be strictly adhered to.
3. Locking devices, where specified, must be fitted. If the efficiency of a locking device is impaired during removal it must be replaced.
4. Owners purchasing accessories while travelling abroad should ensure that the accessory and its fitted location on the vehicle conform to mandatory requirements existing in their country of origin.
5. The vehicle warranty may be invalidated by the fitting of other than genuine Jaguar or Unipart parts. All Jaguar and Unipart replacements have the full backing of the factory warranty.
6. Jaguar Distributors and Dealers are obliged to supply only genuine service parts.

## SPECIFICATION

Purchasers are advised that the specification details set out in this Manual apply to a range of vehicles and not to any one. For the specification of a particular vehicle, purchasers should consult their Distributor or Dealer.

The Manufacturers reserve the right to vary their specifications with or without notice, and at such times and in such manner as they think fit. Major as well as minor changes may be involved in accordance with the Manufacturer's policy of constant product improvement.

Whilst every effort is made to ensure the accuracy of the particulars contained in this Manual, neither the Manufacturer nor the Distributor or Dealer, by whom this Manual is supplied, shall in any circumstances be held liable for any inaccuracy or the consequences thereof.

## COPYRIGHT

© Jaguar Cars Ltd. 1983

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, electronic, mechanical, photocopying, recording or other means without prior written permission of Jaguar Cars Ltd., Service Department, Radford, Coventry CV6 3GB.

## CONTENTS

| Operation                                   | Operation No. | Page No. |
|---|---------------|----------|
| Clutch assembly — Remove and refit .....    | 33.10.01      | 33—5     |
| Clutch pedal — Overhaul .....               | 33.10.07      | 33—6     |
| — Remove and refit .....                    | 33.30.02      | 33—6     |
| Clutch pipe damper — Remove and refit ..... | 33.15.05      | 33—7     |
| Fluid pipe(s) — Remove and refit .....      | 33.15.09      | 33—5     |
| Fluid hose — Remove and refit .....         | 33.15.13      | 33—5     |
| Hydraulic system — Bleed .....              | 33.15.01      | 33—7     |
| Master cylinder — Overhaul .....            | 33.20.07      | 33—6     |
| — Remove and refit .....                    | 33.20.01      | 33—6     |
| Release assembly — Overhaul .....           | 33.25.17      | 33—5     |
| — Remove and refit .....                    | 33.25.12      | 33—5     |
| Slave cylinder — Overhaul .....             | 33.35.07      | 33—5     |
| — Remove and refit .....                    | 33.35.01      | 33—5     |

CLUTCH

TORQUE WRENCH SETTINGS

| ITEM  | DESCRIPTION                                   | SPANNER SIZE             | TIGHTENING TORQUE |            |              |
|---|---|--------------------------|-------------------|------------|--------------|
|   |   |                          | Nm                | kgf/cm     | lbf/ft       |
| Clutch cover to flywheel . . . . .          | W/F* Setscrew M8                              | 10mm                     | 33 to 27          | 2,4 to 2,8 | 17 to 20     |
| Slave cylinder to bellhousing . . . . .     | Nut M8  | 13mm                     | 23 to 27          | 2,4 to 2,8 | 17 to 20     |
| Hydraulic pipe to slave cylinder . . . . .  | Hex End Fitting M12                           | 17mm                     | 34 to 40          | 3,5 to 5,6 | 25 to 30     |
| Damper to bracket . . . . .                 | W/F* Setscrew M6                              | 8mm                      | 9 to 10           | 0,9 to 1,0 | 6.5 to 7.5   |
| Damper bracket to bulkhead . . . . .        | Setscrew $\frac{5}{16}$ in UNF                | $\frac{1}{2}$ in AF      | 15 to 17,5        | 1,5 to 1,8 | 11 to 13     |
| Hydraulic pipe to damper . . . . .          | Male tube nut M12                             | 13mm                     | 20 to 24          | 2 to 2,5   | 14.5 to 17.5 |
| Hydraulic pipe to master cylinder . . . . . | Male tube nut M12                             | 13mm                     | 20 to 24          | 2 to 2,5   | 14.5 to 17.5 |
| Master cylinder to bulkhead . . . . .       | Socket head<br>Setscrew $\frac{5}{16}$ in UNC | $\frac{7}{32}$ Allen key | 15 to 17,5        | 1,5 to 1,8 | 11 to 13     |


\*Washer faced

CLUTCH

Description

The clutch is a single plate, diaphragm type, and is operated hydraulically by a slave cylinder mounted to the gearbox bell housing. This is in turn operated by a clutch master cylinder through a series of hydraulic pipes and a damper. The piston in the master cylinder is moved via a push rod by the clutch pedal, which is mounted to the bulkhead and is positioned to the left of the brake pedal.

**CAUTION:** The hydraulic fluid used in the clutch hydraulic system is injurious to car paintwork. Utmost precautions **MUST** at all times be taken to prevent spillage of fluid. Should fluid be accidentally spilled onto the paintwork, wipe fluid off immediately with a cloth moistened with denatured alcohol (methylated spirits).



## CLUTCH FAULT DIAGNOSIS

| SYMPTOM  | POSSIBLE CAUSE              | CHECK  | REMEDY  |
|--|-----------------------------|--|---|
| Grabbing clutch.<br>(Harsh engagement from standing start, often followed by clutch judder).   | Operating mechanism faulty. | Check operating for wear and binding which usually indicates a binding withdrawal race thrust bearing.   | Free off bearing.<br>Replace as necessary.  |
|  |                             | Check pedal for sticking.  | Free off pedal and check for damaged and distorted parts including return spring. Replace as necessary.             |
|  | Clutch unit faults.         | Check for oil on friction faces.   | Clean off cover. Replace driven plate. Rectify oil leak.  |
|  |                             | Check clutch plate and flywheel for wear. Check flywheel run-out. Check also for glazing on driven plate linings.  | Reclaim or replace as applicable.   |
|  |                             | Check for driven plate hub splines sticking on pinion shaft.   | Free driven plate and check for wear and distortion. Check pinion shaft for wear.                                   |
|  |                             | Check for broken or weak pressure springs. Check torque damper springs in clutch driven plate.   | Replace as necessary.   |
|  | Engine mountings faults.    | Check for damaged or deteriorated engine mountings. Check fixings for looseness.   | Replace or tighten as applicable.   |
|  |                             |  |   |
| Slipping clutch<br>(Indicated by vehicle road speed not responding to engine speed increases). | Faulty driving technique.   | Ensure that none of the Remedy conditions prevail.   | Do not increase engine speed with clutch partially engaged.<br>Do not drive with left foot resting on clutch pedal. |
|  | Operating mechanism faulty. | Check for binding withdrawal lever.  | Free lever and check for wear and distortion.   |
|  |                             | Check for binding of clutch pedal moving components.   | Free off seized or binding components.  |
|  | Clutch unit faults.         | Check for oil on friction faces.   | Clean off metal faces. Replace driven plate. Rectify oil leak.  |
|  |                             | Check for broken or weak pressure springs.   | Replace cover as necessary.   |
|  |                             | Check clutch plates and flywheel for wear and distortion.  | Reclaim or replace as applicable clutch plate flywheel.   |
|  |                             | Check clutch driven plate for fractures and distortion. Damage may be caused by accidental loading during assembly of gearbox to engine. Always support gearbox weight during refitting. | Replace driven plate and check mating components for damage.  |
|  |                             |  |   |
| Dragging or spinning clutch  | Clutch unit faults.         | Check for primary pinion bearing seized.   | Rectify or replace as necessary.  |
|  |                             | Check clutch driven plate hub for binding on primary pinion splines. Check for too thick friction linings. Ensure linings are good.  | Replace as necessary.   |
|  |                             | Check for distorted clutch pressure plate and clutch cover.  | Replace as necessary.   |
|  |                             | Check for foreign matter in clutch unit.   | Clean and replace components as necessary.  |



**CLUTCH FAULT DIAGNOSIS**

| SYMPTOM   | POSSIBLE CAUSE                                  | CHECK  | REMEDY   |
|---|---|--|--|
|   | Hydraulic system defects.                       | Check fluid level in reservoir.  | Replenish as necessary and bleed system if necessary.      |
|   |   | Check for air in the system.   | Bleed the system.  |
| Rattling clutch.  | Operating mechanism faults.                     | Check for defective pedal return spring.   | Replace as necessary.                                      |
|   | Clutch unit faults.                             | Check for damaged pressure plate.  | Replace pressure plate.                                    |
|   |   | Check splines on clutch driven plate and primary pinion shaft for wear.                                  | Replace as necessary clutch plate, or primary pinion.      |
|   |   | Check clutch driven plate for loose or broken springs and for warping.                                   | Replace driven plate.                                      |
|   |   | Check for wear in the clutch withdrawal mechanism.   | Replace as necessary.                                      |
|   |   | Check for worn primary pinion bearing.   | Replace as necessary.                                      |
| Squeaking clutch  | Primary pinion bearing fault.                   | Check for seizing on primary shaft or in flywheel.   | Lubricate or replace as necessary.                         |
| Vibrating clutch or clutch judder (often preceded by clutch grab) | Clutch unit faults.                             | Check the clutch driven plate for distortion and damage and for loose or broken torque springs.          | Replace driven plate.                                      |
|   |   | Check for oil and other foreign matter on the clutch friction linings.                                   | Replace driven plate and clean related parts.              |
|   |   | Check for incorrectly fitted clutch pressure plate.  | Dismantle from clutch and refit, where applicable.         |
|   |   | Check that contact witness on friction linings is evenly distributed.                                    | Replace driven plate as necessary.                         |
|   | Defects other than in clutch unit.              | Check for loose flywheel fixings.  | Tighten to correct torque loading. Check flywheel run-out. |
|   |   | Check for loose engine mountings   | Tighten mounting nuts and bolts.                           |
|   |   | Check for worn propeller shaft universal joints.   | Replace as necessary.                                      |
|   |   | Check for bent primary pinion shaft.   | Replace as necessary.                                      |
| Stiff clutch operation.   | Operating linkage fault.                        | Check for damaged moving parts in operating linkage.   | Replace as necessary.                                      |
|   |   | Check for seized linkage.  | Lubricate linkage and recheck operation.                   |
| Clutch knocks   | Clutch unit fault.                              | Check for worn clutch driven plate hub splines.  | Replace driven plate.                                      |
|   | Primary pinion bearing.                         | Check for wear in bearing.   | Replace as necessary.                                      |
| Fractured clutch plate  | Incorrect fitting method.                       | Damage may be caused by accidental loading during fitting. Always support gearbox weight during fitting. | Replace driven plate. Check mating components for damage.  |
| Excessive lining wear   | Overloading vehicle.                            | Refer to Owner's handbook for permissible load details.  | Fit replacement clutch assembly.                           |
|   | Driving with left foot resting on clutch pedal. | Check as described under 'slipping clutch'.  | Fit replacement clutch assembly.                           |

## HYDRAULIC PIPES

## Renew

Remove the pipes or hoses as required and replace with new units, bleed the hydraulic system as necessary with the recommended brake fluid.

## SLAVE CYLINDER

## Overhaul

Remove the slave cylinder from the vehicle, dismantle the cylinder, and unscrew the bleedscrew.

The new parts in the kit will indicate which used parts should be discarded. Clean the remaining parts and the cylinder thoroughly with unused brake fluid of the recommended type and place the cleaned parts onto a clean sheet of paper.

Examine the cylinder bore and the pistons for signs of corrosion, ridges or score marks. Provided the working surfaces are in perfect condition, new seals from the kit can be fitted, but if there is any doubt as to the condition of the parts then a new cylinder must be fitted.

Fit the new seal to the piston with the flat back of the seal against the shoulder (see inset Fig. 1).

Lubricate the seal and the cylinder bore with unused brake fluid of the recommended type and reassemble the cylinder (Fig. 1). Before fitting the dust cover, smear the sealing areas with rubber grease. Squeeze the remainder of the grease from the sachet into the cover to help protect the internal parts.

Refit the slave cylinder to the vehicle and bleed the system.




Fig. 1

## KEY TO DIAGRAM

1. Body
2. Spring
3. Seal
4. Piston
5. Operating rod
6. Rubber boot

## CLUTCH SLAVE CYLINDER

## Renew

Disconnect the pipe from the slave cylinder; plug or tape the pipe to prevent the ingress of any dirt.

Remove the nuts (1, Fig. 2) and spring washers securing the slave cylinder to the gearbox.

Slide the slave cylinder (1, Fig. 3) off the mounting studs; slide the rubber boot along the push rod, withdraw the cylinder from the push rod (2, Fig. 3).

To reassemble, reverse the removal operations and bleed the clutch hydraulic system.




Fig. 2




Fig. 3

## CLUTCH RELEASE BEARING

## Renew

Remove the gearbox from the vehicle and remove the bell housing. Remove the withdrawal mechanism from the bell housing.

Press off the bearings and refit the new bearings to the housing.

Grease all the release arm pivots with Molykote FB 180 Grease, fit the assembly to the release arm and grease the withdrawal assembly.

Refit the bell housing and gearbox, check the oil level and road test the vehicle.

## CLUTCH WITHDRAWAL LEVER

## Renew

Remove the gearbox and the bell housing. Remove the clutch release bearing assembly (1, Fig. 4) and remove the withdrawal lever assembly pivot nut and remove the lever (2, Fig. 4).

Remove the spire clip (3, Fig. 4) securing the pivot to the withdrawal lever and separate the pivot from the lever.

Fit a new withdrawal lever to the pivot and secure with the spire clip.

Fit the assembly to the bell housing, fit and tighten the securing nut.

Refit the release bearing assembly (after applying Molykote FB 180 Grease) to the bell housing.

Refit the bell housing to the engine and the gearbox to the bell housing.




Fig. 4

## CLUTCH ASSEMBLY

## Renew

Remove the gearbox from the vehicle and remove the bell housing from the rear of the engine.

Lock the flywheel and remove the clutch cover securing bolts (1, Fig. 5), remove the clutch cover (2, Fig. 5) and drive plate.

Clean the flywheel face and dowels, fit a new plate and cover the flywheel, align the drive plate with a dummy input shaft and torque up the cover securing bolts.

Remove the dummy input shaft, refit the bell housing and gearbox assembly, carry out road test.




Fig. 5

# CLUTCH

## CLUTCH PEDAL

### Renew

Remove the pedal box, see 33.10.07.

Using a large screwdriver to disengage the return spring (1, Fig. 6) from the pedal (2, Fig. 6). Remove the spring clip (3, Fig. 6), washer (4, Fig. 6), and clevis pin (5, Fig. 6) securing the pedal arm to the master cylinder push rod. Remove the locating pin. Tap the clutch shaft (6, Fig. 6) from the pedal box casting and recover the pedal return spring and washers.

Locate the return spring on the pedal boss.

Smear the clutch shaft with suitable grease. Tap the clutch shaft through the casting, locating the groove to the outside edge, positioning a washer at either side of the pedal boss.

Fit the pedal arm to the master cylinder push rod and secure using a clevis pin, plain washer and new split pin.

Fit the pedal box and bleed the hydraulic system, see 33.15.01.




Fig. 6

J33 032

## CLUTCH PEDAL

### Overhaul

Remove the clutch pedal.

Using a suitable mandrel, press the bush (1, Fig. 7) from the pedal boss (2, Fig. 7).

Using a suitable mandrel, press the new bearing bushes in from each side. Press until the bush is flush with the sides of the pedal.

Lightly ream the bush to the size using the pedal shaft to check fit.

Smear bushes with a suitable grease.

Fit the clutch pedal and fit a new rubber (3, Fig. 7).




Fig. 7

J33 033

## MASTER CYLINDER

### Renew

Remove the pedal, see 33.30.02.

Note the fitted position of the return spring; disconnect the spring from the pedal.

Remove and discard the split pin.

Withdraw the clevis pin, recover the plain washer.

Remove nuts and spring washers securing the master cylinder to pedal box.

RH drive cars only.

Remove the setscrew nut (1, Fig. 8) and washers securing the master cylinder (2, Fig. 8) to the pillar.

Withdraw the brake fluid reservoir bracket, lift off the master cylinder and shims (if fitted).

To refit the new cylinder, reverse the removal procedure and bleed the hydraulic system.

**CAUTION: The hydraulic fluid used in the clutch hydraulic system is injurious to car paintwork. Utmost precautions MUST be taken at all times to prevent spillage of fluid. Should fluid be accidentally spilled on paintwork, wipe fluid off immediately with a cloth moistened with denatured alcohol (methylated spirits).**




Fig. 8

J33 034

## MASTER CYLINDER

### Overhaul

**WARNING: USE ONLY CLEAN BRAKE FLUID OR DENATURED ALCOHOL (METHYLATED SPIRITS) FOR CLEANING. ALL TRACES OF CLEANING FLUID MUST BE REMOVED BEFORE REASSEMBLY. ALL COMPONENTS SHOULD BE LUBRICATED WITH CLEAN BRAKE FLUID AND ASSEMBLED USING THE FINGERS ONLY.**

### Dismantling

Remove the master cylinder, see 33.20.01.

Detach the rubber boot (1, Fig. 9) from the end of the barrel and move the boot along the push rod (2, Fig. 9).

Depress the push rod and remove the circlip (3, Fig. 9).

Withdraw the push rod, piston (4, Fig. 9), piston washer (5, Fig. 9), main cup (6, Fig. 9), spring retainer (7, Fig. 9), and spring (8, Fig. 9).

Remove the secondary cup (9, Fig. 9) from the piston.

### Inspection

Examine the cylinder bore for scoring.

Thoroughly wash out the reservoir and ensure the by-pass hole in the cylinder bore is clear. Dry using compressed air or a lint-free cloth.

Lubricate the replacement seals with clean brake fluid.

### Reassembling

If necessary, fit end plug on the new gasket.

Fit the spring retainer to the small end of the spring, if necessary, bend over the retainer ears to secure.

Insert the spring, large end leading, into the cylinder bore; follow with the main cup, lip foremost. Ensure the lip is not damaged on the circlip groove. Using the fingers only, stretch the secondary cup on to the piston with the small end towards the drilled end and groove engaging the ridge. Gently work round the cup with the fingers to ensure correct bedding.

Insert the piston washer into the bore, curved edge towards main cup.

Insert the piston in the bore, drilled end foremost.

Fit rubber boot to the push rod.

Offer the push rod to the piston and press into the bore until the circlip can be fitted behind the push rod stop ring.

**CAUTION: It is important to ensure that the circlip is fitted correctly into the groove.**

Locate the rubber boot in the groove.




Fig. 9

J33 035

## CLUTCH HYDRAULIC SYSTEM

### Bleed

**CAUTION:** Only use Castrol-Girling brake fluid in the hydraulic system.

Remove reservoir filler cap. Top up the reservoir to the correct level with hydraulic fluid.

Attach one end of a bleed tube (1, Fig. 10) to the slave cylinder bleed nipple (2, Fig. 10).

Partially fill a clean container with hydraulic fluid. Immerse the other end of the bleed tube in the fluid.

Slacken the slave cylinder bleed nipple.

Pump the clutch pedal slowly up and down, pausing between each stroke.

Top up the reservoir with fresh hydraulic fluid after every three pedal strokes.

**CAUTION:** Do not use fluid bled from the system for topping up purposes as this will contain air. If the fluid has been in use for some time it should be discarded. Fresh fluid bled from the system may be used after allowing it to stand for a few hours to all the air bubbles to disperse.

Pump the clutch pedal until the pedal becomes firm, tighten the bleed nipple.

Top up the reservoir, refit the filler cap.

Apply the working pressure to the clutch pedal for two to three minutes and examine the system for leaks.




Fig. 11



Fig. 10

## CLUTCH PIPE DAMPER

### Renew

Disconnect the hydraulic pipes (1, Fig. 11).

Remove the securing bolts (2, Fig. 11) and remove the damper (3, Fig. 11).

Refit the new damper and secure with the bolts (2, Fig. 11), reconnect the hydraulic pipes (1, Fig. 11) and bleed the system.

## CONTENTS

| Operation  | Operation No. | Page No. |
|--|---------------|----------|
| Bell housing — Renew .....                           | 37.12.02      | 37—3     |
| Front oil seal — Renew .....                         | 37.23.06      | 37—3     |
| Gearbox assembly — Renew .....                       | 37.20.07      | 37—5     |
| Gear change remote control assembly — Overhaul ..... | 37.16.20      | 37—4     |
| Gear change remote control mountings — Renew .....   | 37.16.25      | 37—4     |
| Gear lever — Renew .....                             | 37.16.04      | 37—4     |
| Gear lever draught excluder — Renew .....            | 37.16.05      | 37—3     |
| Gear lever knob — Renew .....                        | 37.16.11      | 37—3     |
| Gear selector shaft rear — Overhaul .....            | 37.16.41      | 37—3     |
| Rear oil seal — Renew .....                          | 37.23.01      | 37—3     |
| Speedometer drive gear pinion — Renew .....          | 37.25.05      | 37—4     |




Fig. 1

## 5 SPEED GETRAG MANUAL GEARBOX

The 5-speed transmission fitted to this vehicle incorporates a synchromesh on all gears. Gear selection is by a centrally mounted lever, connected to the transmission selector shaft via a pivoting joint.

All the gears are engaged by a single selector shaft operating three rods which move the selector forks.

The drive pinion is supported at the rear by a duplex ball bearing situated in the front casing, and at the front a spigot engages in a needle roller bearing fitted in the flywheel.

The mainshaft is supported at the front by a caged roller bearing situated in the drive pinion counterbore in the centre by a roller bearing supported by the intermediate casing and at the rear by a duplex bearing in the transmission rear casing.

Each of the forward speed mainshaft gears incorporates an integral synchromesh mechanism with the clutch hubs splined to the mainshaft and situated between each pair of gears.

The countershaft is supported at the front by a roller bearing situated in the front casing in the centre by a roller bearing in the intermediate casing and at the rear by a roller bearing situated in the tail housing.

The reverse idler gear is supported by two caged roller bearings and is in constant mesh and is situated on a stationary shaft. Longitudinal location of the idler gear is controlled by a spacer abutting on the shaft.

### RATIOS

|   |         |
|---|---------|
| 1 | 3.573:1 |
| 2 | 2.056:1 |
| 3 | 1.391:1 |
| 4 | 1.000:1 |
| 5 | 0.76 :1 |
| R | 3.463:1 |

## TORQUE WRENCH SETTINGS

| ITEM   | DESCRIPTION      | SPANNER SIZE | TIGHTENING TORQUE |            |          |
|--|------------------|--------------|-------------------|------------|----------|
|  |                  |              | Nm                | kgf/cm     | lbf/ft   |
| Bell housing to adaptor plate . . . . .                  | W/F* Bolt M10    | 13mm         | 49 to 54          | 5,0 to 5,5 | 36 to 40 |
| Front cover to gearbox — top three bolts . . . . .       | Setscrew M8      | 13mm         | 23 to 27          | 2,4 to 2,8 | 17 to 20 |
| Front cover to gearbox — lower four bolts only . . . . . | Setscrew M8      | 13mm         | 16 to 20          | 1,6 to 2,1 | 12 to 15 |
| Gearbox to bell housing . . . . .                        | Nut M12          | 19mm         | 70 to 80          | 7,2 to 8,2 | 52 to 59 |
| Gear lever housing to pedestal . . . . .                 | Bolt M8          | 13mm         | 23 to 27          | 2,4 to 2,8 | 17 to 20 |
| Gear lever pivot bolt . . . . .                          | Nyloc Nut M8     | 13mm         | 23 to 27          | 2,4 to 2,8 | 17 to 20 |
| Speed transducer to gearbox . . . . .                    | W/F* Setscrew M6 | 8mm          | 9,5 to 12         | 1,3 to 1,6 | 7 to 9   |
| Pedestal to gearbox . . . . .                            | W/F* Bolt M8     | 10mm         | 23 to 27          | 2,4 to 2,8 | 17 to 20 |
| Pedestal to gearbox . . . . .                            | Bolt M8          | 13mm         | 23 to 27          | 2,4 to 2,8 | 17 to 20 |

\*Washer faced

## BELL HOUSING

### Renew

Remove the gearbox from the vehicle and remove the sound deadening pad, remove the exhaust bracket from the bell housing (1, Fig. 2) and remove the clutch slave cylinder (2, Fig. 2).

Remove the bell housing/starter motor securing bolts (3, Fig. 2) and nuts and remove the bell housing (4, Fig. 2).

Remove the release arm securing nut and remove the arm, remove the slave cylinder securing studs.

Fit the slave cylinder studs to the replacement bell housing, the clutch release arm and securing nut.

Fit the bell housing to the adaptor plate and the exhaust bracket to the bell housing.

Refit the starter motor.

Reposition the sound deadening pad and refit the gearbox to the vehicle.




Fig. 2

## OIL SEAL — REAR

### Renew

Remove the propellor shaft and remove the rear oil seal (1, Fig. 3) from the rear of the gearbox, taking care not to damage the output shaft on the gearbox case.

Carefully position a new seal at the rear of the gearbox and carefully tap the seal into the gearcase, ensuring that the seal is square and flush with the housing.

Lubricate the output shaft and carefully fit the propellor shaft and secure the rear flange to the differential drive flange.

Top up the gearbox and road test the vehicle.




Fig. 3

## FRONT OIL SEAL

### Renew

Remove the gearbox from the vehicle and drain the oil, remove the seven bolts (1, Fig. 4) securing the thrust plate (2, Fig. 4) to the gearbox and remove the plate.

Prise the seal (3, Fig. 4) from the housing.

Clean the thrust plate and remove the spiral spring from the seal prior to installing the seal in the housing, press the seal into the plate and refit the spiral spring to the seal.

Coat the lip of the seal with grease and the transmission case cover with roller bearing grease and fit the plate to the gearbox ensuring that any shims removed are replaced.

Fit the four lower bolts first followed by the top three.

Prior to fitting, coat all the bolts with Loctite 573.




Fig. 4

## GEAR SELECTOR SHAFT

### Overhaul

Remove the remote control assembly and slide the selector shaft universal joint cover back (1, Fig. 5), remove the selector shaft retaining pin (2, Fig. 5) and collect the shaft (3, Fig. 5).

Remove the pin securing the universal joint and remove the joint.

Clean all components, examine for wear or damage and replace as necessary.

Lubricate all new or components to be re-used and fit the universal joint to the rear selector shaft, secure with the retaining pin, assemble to the gearbox and secure with the retaining pin. Reposition the retaining cover and refit the remote control assembly.




Fig. 5

## GEAR LEVER DRAUGHT EXCLUDER

### Renew

Remove the gear lever knob (1, Fig. 6) remove the gear lever gaiter, remove the draught excluder securing screws (2, Fig. 6) and ring (3, Fig. 6) and remove the draught excluder (4, Fig. 6).

Renew the draught excluder and fit over the gear lever, secure with the ring and screws, refit the gear lever gaiter and refit the knob.



Fig. 6



## GEAR LEVER

### Renew

Remove the remote control assembly (1, Fig. 7) lever securing snap ring (2, Fig. 7), collar (3, Fig. 7), spring (4, Fig. 7) and the lever (5, Fig. 7). Remove the spacer from the lever, remove the lower nylon cup (6, Fig. 7) and the upper nylon spacer (7, Fig. 7).

Clean the gear lever and all other component parts, check for wear and distortion and replace as necessary.

Fit the nylon cup to the mounting and grease the new gear lever ball, fit the lower spacer, spring and collar, compress the spring and secure with the snap ring.




Fig. 7

### GEAR CHANGE REMOTE CONTROL ASSEMBLY

#### Overhaul

Slacken the torquatrol to water pump securing nuts, turn the torquatrol assembly and remove the torquatrol from the pulley. Fit Service Tool MS 53 (1, Fig. 8) across the wing channels, and fit to the rear lifting eye and take the engine weight.




Fig. 8

Remove the front pipe clamp nut/bolt. Disconnect exhaust from the front pipe and remove the sealing olive.

Remove intermediate heat shield.

Remove rear mounting centre securing nut (1, Fig. 9), the crash bracket to gearbox securing nuts/bolts (2, Fig. 9) and remove the bracket (3, Fig. 9).

Take the weight of the rear mounting with a jack.

Remove the rear mounting to body securing bolts (4, Fig. 9), lower the jack and remove the mounting assembly (5, Fig. 9).




Fig. 9

Remove the spacers from the rear mounting assembly, remove the rear heat shield securing screws, carefully ease the exhaust down and remove the heat shield.

Slacken MS 53 hook nut and slacken, the gear lever to rear shaft securing nut/bolt (1, Fig. 10). Also remove the control mounting securing bolts (2, Fig. 10) and remove the gear lever bolt (1, Fig. 10).




Fig. 10

Pull the gear change lever (1, Fig. 11) from the selector shaft (2, Fig. 11) and remove the remote control/gear lever assembly. Ensure that the draught excluder (3, Fig. 11) is not moved from its position. Once moved, invert the assembly (gear lever down) to aid removal.

Remove the mounting rubbers and washers. Remove the snap ring (4, Fig. 11) and the gear change lever assembly.

Remove the collar (5, Fig. 11) and spring (6, Fig. 11) from the lever, remove the gear lever lower nylon cup from the control.




Fig. 11

Clean all the component parts and inspect for wear or damage, and replace as necessary.

Fit the lower nylon cup.

Grease the gear lever ball.

Fit the spring and collar to the lever.

Compressing the spring with the gear lever assembly, secure the snap ring.

Lubricate the gear lever to ease fitment to the draught excluder.

Lubricate the lower spacer and position the assembly into the mounting.

Enter the lever into the gaiter and position the lever into the yoke, ensure the lever is fitted correctly.

Fit but do not tighten the gear lever securing nut and bolt.

Fit the lower LH mounting rubber and washer. Align mounting bracket and fit the remaining spacer and rubber.

Fit but do not tighten the mounting securing bolt.

Repeat the above procedure for the remaining rubbers and finally tighten the securing bolts.

Finally tighten the gear lever securing nut and bolt.

Tighten MS 53 hook nut to raise the gearbox into position.

Fit the gearbox mounting to the body.

Ensure that the spring is fully seated in the gearbox spring pan and fit but do not fully tighten the mounting bolts.

Align the mounting assembly, finally tighten the securing bolts, remove the engine retaining Service Tool MS 53 and fit the rear mounting spacers.

Fit the crash bracket and tighten the securing nuts and bolts.

Fit the rear heat shield.

Fit the intermediate heat shield.

Clean the exhaust sealing olive and smear the olive with sealant. Fit the sealing olive to the intermediate pipe.

Connect the exhaust system to the front pipe, position the clamp over the union and tighten the clamp bolt.

Reposition the fan/torquatrol assembly, fit but do not tighten torquatrol securing nuts, fully seat the assembly onto the studs and finally tighten the assembly securing nuts.

### SPEEDOMETER DRIVE PINION

#### Renew

Release the speed transducer knurled ring (1, Fig. 12) and remove the transducer (2, Fig. 12).

Remove the drive gear locking clamp (3, Fig. 12) and remove the drive gear from the gearbox and remove the 'O' ring.

Fit and 'O' ring to the drive, lubricate, fit the assembly to the gearbox and secure with a clamp.

Refit the transducer and secure with the knurled ring.



Fig. 12

## GEARBOX ASSEMBLY

### Renew

Select third gear.

Remove the torquatrol unit from the front pulley. Fit Service Tool MS 53 (1, Fig. 13) to the rear engine lifting eye and take the weight of the engine.




Fig. 13

Release the clamp (1, Fig. 14) securing the front pipe from the intermediate pipe and collect the olive.




Fig. 14

Remove the intermediate heat shield. Remove the gearbox rear mounting nut (1, Fig. 15) and the crash bracket (2, Fig. 15). Take the weight of the gearbox and remove the rear mounting complete (3, Fig. 15) and lower the gearbox.




Fig. 15

Remove the rear heat shield and the propeller shaft and fit a blanking plug to the rear of the gearbox.

Disconnect the speed transducer block connector (1, Fig. 16), remove the clutch slave cylinder securing nuts and pull the cylinder clear of the bell housing; disconnect the reverse light feed wires from the switch (2, Fig. 19).




Fig. 16

Remove the selector bracket securing bolts (1, Fig. 17), and collect the mounting rubbers and washers (2, Fig. 17).

Remove the selector lever to yoke securing bolt and nut (3, Fig. 17) and disconnect the lever.




Fig. 17

Take the weight of the gearbox, remove the bell housing securing bolts (1, Fig. 18 & 19) and remove the gearbox from the vehicle.




Fig. 18




Fig. 19

Check the alignment of the clutch plate. Select third gear on the new gearbox, fit the reverse light switch, lift the gearbox into position and secure with the bell housing bolts.

Fit a new 'O' ring to the speed transducer, fit the transducer and secure with the clamp.

Fit the rear mounting assembly to the gearbox, lift the gearbox into position at the rear and secure with the mounting nuts and washers.

Grease the selector universal joint and align and fit the selector assembly to the shaft, secure with the pin and reposition the universal joint cover.

Fit the securing rubbers to the selector lever mounting bracket and fit the lever to yoke securing bolt.

Fit the selector mounting washers to the rubbers, align the mounting holes and fit the bracket securing bolts.

Reconnect the reverse light switch and speed transducer feed wires.


Fit the crash bracket to the rear mounting and secure with the bolts.

Fit and tighten the slave cylinder securing nuts.

MANUAL GEARBOX

Fit the intermediate heat shield.  
Remove the blank from the rear of the gearbox, grease the spline, refit the propellor shaft and secure the rear flange to the differential with the bolts and nuts.  
Fit the rear heat shield.  
Fill the gearbox with oil.  
Clean and smear the exhaust front olive with sealant, reposition the clamp and secure the intermediate pipe to the front pipe.  
Remove Service Tool MS 53.  
Refit the fan and torquatrol assembly and road test the vehicle.


J37-041








**XJ-S 3·6  
XJ-SC 3·6  
SERVICE  
MANUAL**





## BOOK 5

Containing  
Sections

47 PROPELLOR & DRIVE SHAFTS  
51 FINAL DRIVE

XJ-S 3·6  
XJ-SC 3·6

SERVICE MANUAL



---

## INTRODUCTION

This Service Manual covers the Jaguar XJ-S 3.6 and XJ-SC 3.6. It is primarily designed to assist skilled technicians in the efficient repair and maintenance of this range of Jaguar cars.

Using the appropriate service tools and carrying out the procedures as detailed will enable the operations to be completed within the time stated in the 'Repair Operation Times'.

The Service Manual has been produced in 9 separate books; this allows the information to be distributed throughout the specialist areas of the modern service facility.

A table of contents in Book 1 lists the major components and systems together with the section and book numbers. The cover of each book depicts graphically and numerically the sections contained within that book.

The title page of each book carries the part numbers required to order replacement books, binders or complete Service Manuals. This can be done through the normal channels.

The contents section of each book lists the repair operations in the section or sections contained within that book. Each operation is given an operation number that corresponds with those listed in the Repair Operation Times.

The method described on the page number listed against the operation will be the one we consider will meet the requirements of safety and enable the operation to be carried out in the time specified in the Repair Operation Times.

Where no page number is given against an operation, we feel that the method is so obvious as to warrant no explanation. It is, however, included so that a warranty time can be given in the Repair Operation Times.

Extensive research has gone into the diagnosis of faults and where appropriate this is covered in the various areas of the manual. By following the sequence of the diagnosis charts, speedy isolation of faults may be expected, and consequent correction will reduce the vehicle off-the-road time to the minimum.

### Service Tools

Where performance of an operation requires the use of a service tool the tool number is quoted under the operation heading and is repeated in, or following, the instruction involving its use. A list of all necessary tools is included in Book 1, Section 99.

### References

References to the LH or RH side in the manual are made when viewing from the rear. With the engine and gearbox assembly removed the timing cover end of the engine is referred to as the front. A key to abbreviations and symbols is given in Book 1, Section 01.

## REPAIRS AND REPLACEMENTS

When service parts are required it is essential that only genuine Jaguar or Unipart replacements are used.

Attention is particularly drawn to the following points concerning repairs and the fitting of replacement parts and accessories.

1. Safety features embodied in the vehicle may be impaired if other than genuine parts are fitted. In certain territories, legislation prohibits the fitting of parts not to the vehicle manufacturer's specification.
2. Torque wrench setting figures given in this Service Manual must be strictly adhered to.
3. Locking devices, where specified, must be fitted. If the efficiency of a locking device is impaired during removal it must be replaced.
4. Owners purchasing accessories while travelling abroad should ensure that the accessory and its fitted location on the vehicle conform to mandatory requirements existing in their country of origin.
5. The vehicle warranty may be invalidated by the fitting of other than genuine Jaguar or Unipart parts. All Jaguar and Unipart replacements have the full backing of the factory warranty.
6. Jaguar Distributors and Dealers are obliged to supply only genuine service parts.

## SPECIFICATION

Purchasers are advised that the specification details set out in this Manual apply to a range of vehicles and not to any one. For the specification of a particular vehicle, purchasers should consult their Distributor or Dealer.

The Manufacturers reserve the right to vary their specifications with or without notice, and at such times and in such manner as they think fit. Major as well as minor changes may be involved in accordance with the Manufacturer's policy of constant product improvement.

Whilst every effort is made to ensure the accuracy of the particulars contained in this Manual, neither the Manufacturer nor the Distributor or Dealer, by whom this Manual is supplied, shall in any circumstances be held liable for any inaccuracy or the consequences thereof.

## COPYRIGHT

© Jaguar Cars Ltd. 1983

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, electronic, mechanical, photocopying, recording or other means without prior written permission of Jaguar Cars Ltd., Service Department, Radford, Coventry CV6 3GB.

CONTENTS

| Operation                                | Operation No. | Page No. |
|--|---------------|----------|
| Description .....                        | —             | 47—2     |
| Drive shaft — Overhaul .....             | 47.10.08      | 47—2     |
| Drive shaft — Remove and refit .....     | 47.10.01      | 47—2     |
| Propeller shaft — Overhaul .....         | 47.15.10      | 47—3     |
| Propeller shaft — Remove and refit ..... | 47.15.01      | 47—3     |
| Torque wrench settings .....             | —             | 47—2     |

## TORQUE WRENCH SETTINGS

| Item                                 | Spanner Size          | Description                         | Tightening Torque |              |            |
|--------------------------------------|-----------------------|-------------------------------------|-------------------|--------------|------------|
|                                      |                       |                                     | Nm                | kgf/m        | lbf/ft     |
| Drive shaft to drive unit (Cleveloc) | $\frac{11}{16}$ in AF | $\frac{7}{16}$ in UNF nut           | 66,4 to 74,5      | 6,78 to 7,6  | 49 to 55   |
| Drive shaft to hub carrier           | $\frac{11}{8}$ in AF  | $\frac{3}{4}$ in UNF nut            | 136 to 163        | 13,8 to 16,6 | 100 to 120 |
| Propeller shaft flange bolts         | $\frac{9}{16}$ in AF  | $\frac{3}{8}$ in UNF bolts and nuts | 36,7 to 43,4      | 3,74 to 4,42 | 27 to 32   |

## SERVICE TOOLS

| Tool No. | Description |
|----------|-------------|
| JD1D     | Hub remover |

## DRIVE SHAFTS AND PROPELLER SHAFT

### Description

The drive shafts replace the half shafts of a conventional rear axle, and in addition serve as upper transverse members to locate the rear wheels; their inner universal joints are attached to the final drive unit by bolts which also carry the brake discs, but the brakes are not disturbed in drive shaft removal. The outer joints are integral with the hub driving shafts, and the hubs must therefore be separated from the drive shafts before they can be removed.

The propeller shaft is a two universal joint type, at the front end of which is a reverse spline fitting coupled to the gearbox and at the rear a flange bolted to the input drive flange of the final drive unit.

When fitting a propeller shaft it is essential to ensure that the universal joints operate freely; any stiffness, even in a single joint, will initiate propeller shaft vibration.

## DRIVE SHAFT

### Renew

Service tool: Hub remover JD 1D.

To remove a drive shaft it is necessary to detach the hub and to swing one suspension unit aside to clear the inner joint.

Ensure that car is securely supported on stands before removing the wheel. Release clips (1, Fig. 1) and before removing nut from drive shaft in hub, slide inner shroud along shaft.




Fig. 1

Remove grease nipple from hub carrier, and using tool JD 1D (2, Fig. 1), withdraw hub from shaft. Allow the hub carrier to pivot about wishbone pin. Before detaching inner joint, release lower end of rear spring/damper unit (3, Fig. 1) and swing aside to clear joint. Collect and retain any camber setting shims fitted between inner joint and brake disc.

### Refitting

Replacement drive shafts are supplied without shrouds, oil seal track or spacer; remove these items and transfer them to the new shaft. Seal shroud joints with underseal. Ensure that chamfer on oil seal track clears radius on shaft, and apply Loctite to spline before refitting hub. Tighten all nuts and bolts to the correct torque. Check and if necessary adjust hub bearing end-float and ensure that camber angles of the wheels are correct.

## DRIVE SHAFT

### Overhaul

#### Dismantling

Remove drive shaft.

Remove grease nipples (1, Fig. 2), place shaft in vice and remove two opposed circlips (2, Fig. 2).

**NOTE:** Tap bearings slightly inwards to assist removal of circlips.




Fig. 2

Tap one bearing inwards to displace opposite bearing (3, Fig. 2).

Trap displaced bearing in vice and remove shaft and joint from bearing.

Replace shaft in vice, displace second bearing by tapping joint spider across and extract second bearing.

Remove two grease seals (4, Fig. 2).

Detach spider, with end section of shaft, from centre section of shaft.

Place end section of shaft in vice and repeat above operations.

Remove spider from end section of shaft.

Repeat above operations on opposite end of shaft.

### Inspection

Wash all parts in petrol.

Check splined yoke for wear of splines.

Examine bearing races and spider journals for signs of looseness, load markings, scoring or distortion.

**NOTE:** Spider or bearings should not be renewed separately, as this will cause premature failure of the replacement.

It is essential that bearing races are a light drive fit in yoke trunnion.

## Reassembling

Remove bearing assemblies from one replacement spider; if necessary, retain rollers in housings with petroleum jelly. Leave grease shields in position.

Fit spider to one end section of shaft.

Fit two bearings and circlips in end section trunnions. Use a soft round drift against bearing housings.

Insert spider in trunnions of centre section of shaft.

Fit two bearings and circlips in centre section trunnions.

Fit grease nipple to spider.

Repeat above operations on opposite end of drive shaft.

Grease joints with hand grease gun.

Refit drive shaft.

## PROPELLER SHAFT

### Renew

Slacken the front to intermediate exhaust pipe clamp  $\frac{7}{16}$  in AF nut and bolt, (1, Fig. 3) spread the clamp (2, Fig. 3) and push it clear along the pipe. Pull the intermediate pipe down and remove the olive (3, Fig. 3). Remove the four self-tappers and washers (1, Fig. 4) and pull the heat shield (2, Fig. 4) forward and down and remove from the vehicle.

Mark the propshaft flange relative to the differential flange, remove the four  $\frac{9}{16}$  in AF flange securing bolts and nuts and remove the propshaft from the vehicle.




Fig. 3

Refit the propshaft in the opposite procedure to the removal noting that the propshaft flange nuts are torqued to 27 - 32 lbf/ft (3,7 - 4 kgf/m) and the propshaft alignment marks are observed.




Fig. 4

## PROPELLER SHAFT

### Overhaul

To overhaul the propeller shaft universal joints, remove the snap-rings from the grooves (1, Fig. 5).

**NOTE:** If difficulty is encountered, tap the bearing cup (2, Fig. 5) inwards to relieve the pressure on the snap-ring.

Hold the flange yoke and tap the yoke with a soft-faced hammer. The bearing cup should gradually emerge and can be finally removed.

Alternatively, secure the propeller shaft in a vice. Using a suitable soft metal drift, drift down on a bearing cup to displace the opposite cup. Remove the propeller shaft from the vice, hold the displaced cup in the vice and separate from the propeller shaft by pulling and twisting.

Repeat the above operations for the opposite bearing cup, and the remaining bearing cups at each end of the shaft.

### Reassembling

Using new universal joint assemblies if necessary, insert the spider into the flange, tilting it to engage in the yoke bores.

Ensure that all the needle rollers are in position; fill each bearing cup one-third full of grease of the recommended type.

Fit one of the bearing cups (2, Fig. 5) in the yoke bore, and using a suitable soft metal drift, tap the bearing cup fully home.

Fit a new snap-ring (1, Fig. 5) ensuring it is correctly located in the groove.

Assemble the other spiders and bearing cups, and fit new snap-rings, to retain the bearing cups.





Fig. 5

## CONTENTS

| Operation                                      | Operation No. | Page No. |
|--|---------------|----------|
| Description .....                              | —             | 51—3     |
| Drive flange — Renew .....                     | 51.15.36      | 51—6     |
| Drive pinion shaft oil seal — Renew .....      | 51.20.01      | 51—6     |
| Final drive unit — Overhaul .....              | 51.25.19      | 51—11    |
| Final drive unit — Renew .....                 | 51.25.13      | 51—10    |
| Hypoid casing rear cover gasket — Renew .....  | 51.20.08      | 51—6     |
| Output shaft assembly (one side) — Renew ..... | 51.10.20      | 51—7     |
| Output shaft bearings — Renew .....            | 51.10.22      | 51—7     |
| Output shaft oil seal — Renew .....            | 51.20.04      | 51—9     |
| Pinion bearings — Renew .....                  | 51.15.19      | 51—11    |
| Torque wrench settings .....                   | —             | 51—3     |



J51-048

CROSS-SECTION OF THE REAR AXLE

## TORQUE WRENCH SETTINGS

| Item                                    | Spanner Size          | Description                    | Tightening Torque |                |            |
|---|-----------------------|--------------------------------|-------------------|----------------|------------|
|   |                       |                                | Nm                | kgf/m          | lbf/ft     |
| Caliper mounting bracket to unit .....  | $\frac{5}{8}$ in AF   | $\frac{7}{16}$ in UNC setbolts | 81,3 to 93        | 8,3 to 9,54    | 60 to 69   |
| Differential bearing caps .....         | $\frac{3}{4}$ in AF   | $\frac{1}{2}$ in UNC setbolts  | 85,4 to 97        | 8,71 to 9,95   | 63 to 72   |
| Drive pinion nut .....                  | $1\frac{1}{8}$ in AF  | $\frac{3}{4}$ in UNF nut       | 244 to 256        | 24,92 to 26,34 | 180 to 190 |
| Drive gear to differential flange ..... | $\frac{5}{8}$ in AF   | $\frac{7}{16}$ in UNF setbolts | 102 to 118        | 10,78 to 12,16 | 77 to 88   |
| Powr-Lok differential case .....        | $\frac{9}{16}$ in AF  | $\frac{3}{8}$ in UNC setbolts  | 58,3 to 67        | 5,95 to 6,9    | 43 to 50   |
| Rear cover attachment .....             | $\frac{1}{2}$ in AF   | $\frac{5}{16}$ in UNC setbolts | 20,5 to 27        | 2,1 to 2,76    | 15 to 20   |
| Ring gear attachment .....              | $1\frac{1}{16}$ in AF | $\frac{7}{16}$ in UNF Rippbolt | 136 to 151        | 13,8 to 15,46  | 100 to 111 |

## SERVICE TOOLS

| Tool No.                      | Description                              |
|-------------------------------|--|
| 18G 120 5                     | Flange Holder                            |
| 18G 134 (MS 550, 550, SL 550) | Adaptor Handle                           |
| SL 550-1                      | Outer Pinion Cup Remover                 |
| 47 (MS 47, SL 14)             | Hand Press                               |
| { SL14-3/2                    | Differential Side Bearing Remover        |
| { SL14-3/1                    | Differential Side Bearing Remover Button |
| { SL 3                        | Clock Gauge Tool                         |
| { 4 HA                        | Pinion Height Setting Gauge              |
| SL 550-9                      | Pinion Inner Bearing Cup Replacer        |
| SL 550-8/1                    | Pinion Outer Bearing Cup Replacer        |
| { SL 47-1/1                   | Pinion Head Bearing Remover              |
| { SL 47-1/2                   | Pinion Head Bearing Replacer             |
| 18G 1428                      | Rear Oil Seal Replacer                   |
| SL 15A                        | Spanner                                  |
| 18G 681 CBW 548               | Torque Driver                            |
| { SL 47-3/1                   | Output Shaft Outer Bearing Remover       |
| { SL 47-3/2                   | Output Shaft Outer Bearing Replacer      |
| JD 14                         | Dummy Shaft                              |

{ Items marked thus are sold as sets.

## DESCRIPTION

The standard transmission unit is a Salisbury 4HU final drive, incorporating a 'Powr-Lok' differential when specified; this is identified by the letters 'PL' on a tab under a cover bolt. A Powr-Lok differential differs from a conventional bevel gear unit by the addition of plate clutches loaded by input torque to oppose rotations of the output shafts relative to the differential cage. Clutch plates are splined to the cage, and their mating discs to the output bevels; the loading between plates and disc increases with input torque due partly to the separating forces of bevels and also to the bevel pinion cross-shafts being carried on ramps instead of being positively located in the cage. Increase in output torque causes

the cross-shafts to move 'up' the ramps and, by pressing plates and discs together, to 'lock' the differential; this gives the effect of a differential-less axle at maximum torque without increasing the disadvantages of this type of axle in low-torque conditions. Some low-torque stiffness, to reduce one-wheel spin on ice, is provided by forming the outer plates as Belleville washers to produce compression between plates and discs; if one wheel is held and the propeller shaft is disconnected, a torque of between 5,6 and 9,6 kgf/m (40 to 70 lbf/ft) is required to turn the other wheel.

The final drive unit is rigidly attached to a fabricated sheet steel cross-beam which is flexibly mounted to the body structure by

four rubber and metal sandwich mountings. Noises coming from the vicinity of the final drive unit usually originate from incorrect meshing of drive gear and pinion, or from bearings on differential or pinion shafts developing play. Operation procedures for the correction of these noise sources are fully covered in operation 51.25.19, but a noise occurring at low speeds only, under braking, could be caused by loss of pre-load in the output shaft bearings. Bearing inspection involves the removal and renewal of an oil seal before resetting pre-load, and is covered in operation 51.20.04, while if inspection indicates that bearing renewal is advisable this is detailed in operation 51.10.22.



## TO CHECK THE TOOTH CONTACT PATTERN

Sparingly paint eight or ten of the drive gear teeth with a stiff mixture of marking raddle or engineers blue. Move the painted gear teeth in mesh with the pinion until a good impression of the total contact is obtained. The result should conform with the ideal tooth contact pattern (Fig. 1).




Fig. 1 Ideal tooth contact pattern.




Fig. 2 High tooth contact pattern.




Fig. 3 Low tooth contact pattern.




Fig. 4 Toe contact pattern.





Fig. 5 Heel contact pattern.

- A The HEEL is the larger outer end of the tooth.
- B The TOE is the small or inner end of the tooth.
- C The DRIVE side of the drive gear tooth is convex.
- D The COAST side of the drive gear tooth is concave.

## FAULT DIAGNOSIS

| TOOTH PATTERN   | REMEDY   |
|---|--|
| <p>The ideal tooth bearing impression on the drive and coast sides of the gear teeth is evenly distributed over the working depth of the tooth profile and is located nearer to the toe (small end) than the heel (large end). This type of contact permits the tooth bearing to spread towards the heel under operating conditions when allowance must be made for deflection.</p>                                     |   |
| <p>In High Tooth Contact it will be observed that the tooth contact is heavy on the drive gear face or addendum. To rectify this condition, move the pinion deeper into mesh, that is, reduce the pinion cone setting distance, by adding shims between the pinion inner bearing cup and the housing and fitting a new collapsible spacer.</p>  | <p>Move the drive pinion deeper into mesh, i.e. reduce the pinion cone setting.</p>  |
| <p>In Low Tooth Contact it will be observed that the tooth contact is heavy on the drive gear flank or dedendum. This is the opposite condition from that shown in High Tooth Contact and is therefore corrected by moving the pinion out of mesh, that is, increase the pinion cone setting distance by removing shims from between the pinion inner bearing cup and housing and fitting a new collapsible spacer.</p> | <p>Move the drive pinion out of mesh, i.e. increase the pinion cone setting</p>  |
| <p>Toe Contact occurs when the bearing is concentrated at the small end of the tooth.</p>   | <p>Move the drive gear out of mesh, that is, increase backlash, by transferring shims from the drive gear side of the differential to the opposite side.</p>   |
| <p>Heel Contact is indicated by the concentration of the bearing at the large end of the tooth.</p>   | <p>Move the drive gear closer into mesh, that is, reduce backlash, by adding shims to the drive gear side of the differential and removing an equal thickness of shims from the opposite side.</p> <p><b>NOTE:</b> It is most important to remember when making this adjustment to correct a heel contact that sufficient backlash for satisfactory operation must be maintained. If there is insufficient backlash the gears will at least be noisy and have a greatly reduced life, whilst scoring of the tooth profile and breakage may result. Therefore, always maintain a minimum backlash requirement of 0,10 mm. (0.004 in).</p> |

## DRIVE PINION SHAFT OIL SEAL

### Renew

Service tools: Torque screwdriver 18G 681, Oil seal replacer 18G 1428.

Detach the four bolts (1, Fig. 6) securing propeller shaft to final drive flange; support propeller shaft rear end and clean flange and nose of final drive.




Fig. 6

Accurately measure torque required to turn flange through backlash, using torque screwdriver 18G 681 (2, Fig. 6) with a suitable adaptor and socket.

**NOTE:** Set screwdriver initially to 0,057 kgf/m (5 lbf/in) and increase setting progressively until torque figure is reached at which flange commences to move. Flange **MUST** be turned fully anti-clockwise through backlash between each check.

Mark nut and pinion shaft so that in refitting, nut may be returned to its original position on shaft (3, Fig. 6).

Unscrew nut and remove washer and place both washer and nut aside for refitting.

Draw flange (4, Fig. 6) off pinion shaft using extractor.

Prise oil seal (5, Fig. 6) out of final drive casing.

### Refitting (using original bearings)

Thoroughly clean splines on pinion shaft and flange. Clean oil seal recess and coat internally with Welseal liquid sealant. Using tool No. 18G1428 tap new oil seal squarely into position with sealing lip facing to rear (1, Fig. 7).




Fig. 7

Smear sealing lip with grease.

Apply grease lightly to outer two thirds of pinion shaft splines.

Lightly tap flange back on pinion shaft, using wooden mallet.

Refit washer and nut and tighten nut until it exactly reaches position previously marked.

Re-check turning torque. Torque required to turn pinion shaft through backlash should exceed by 0,7 to 1,4 kgf/m (5 to 10 lbf/in) the torque recorded earlier. If, however, torque required to turn pinion shaft exceeds 0,52 kgf/m (45 lbf/in), final drive overhaul, operation 51.25.19 **MUST** be carried out.

Lift propeller shaft into position, replace bolts, fit and tighten nuts to correct torque.

Check oil level in final drive unit and top up if necessary.

Remove car from ramp and road test.

If final drive is noisy, an overhaul must be carried out.

## FINAL DRIVE REAR COVER GASKET

### Renew

Remove the fourteen  $\frac{1}{2}$  in AF bolts and setscrews (1, Fig. 8) securing the bottom tie-plate to the cross-beam and inner fulcrum brackets.

Drain the oil from the final drive.

Remove the ten  $\frac{1}{2}$  in AF setscrews (1, Fig. 9) and remove the rear cover (2, Fig. 9) noting the position of the identification tabs.

Clean off any gasket or sealant from the rear cover and the hypoid housing.

Smear the rear cover flange with Wellseal jointing compound and place the gasket on the casing.

Refit the rear cover and secure with the ten setscrews, prior to fitting coat the threads of the bolts with Loctite.

Refill with new oil.

**NOTE:** The vehicle must be on level ground before checking the oil level.

Replace the bottom tie-plate and tighten the bolts and setscrews to the correct torque.




Fig. 8




Fig. 9

### OUTPUT SHAFT ASSEMBLY (One Side)

#### Renew

To remove an output shaft it is necessary to detach the inboard end of the drive shaft, the forward attachment of the radius rod, and to remove the brake caliper and disc (1, Fig. 10).

These operations are detailed in Section 70, the Brake System.




Fig. 10

Cut locking wire and remove five set bolts (2, Fig. 10) securing caliper mounting flange to final drive. Withdraw complete output shaft assembly and discard 'O' ring (3, Fig. 10).

Before fitting, ensure that four bolts (4, Fig. 10) are in position, and that new 'O' ring (3, Fig. 10) is fitted. Lightly oil splines and outside of bearing with final drive oil, insert assembly; fit bolts with spring washers, tighten to 8,4 to 9,66 kgf/m (60 to 69 lbf/ft), tightening the bolt nearest to the input flange first, and wire lock bolt heads together so that wire tension is tending to tighten bolts.

Replace brake caliper and disc as described in Brake System section; check camber angle of rear wheels, and adjust if necessary, refer to Section 64 for the correct procedure.

### OUTPUT SHAFT BEARINGS

#### Renew

Service tools: 47 Press, Torque screwdriver 18G 681, Adaptor, Spanner SL 15A or 15, Output shaft bearing remover/replacer SL 47-3/1, SL 47-3/2.

Remove output shaft assembly incorporating bearing to be removed.

Clean assembly and clamp caliper mounting bracket between suitably protected jaws of vice.

Turn down tabs of lock washer and remove nut (1, Fig. 11) from shaft, using spanner SL 15A (Fig. 12).

Remove and discard lock washer.




Fig. 11

J51 003A




Fig. 12

Withdraw output shaft (1, Fig. 13) from caliper mounting bracket (2, Fig. 13). Collect inner bearing (3, Fig. 13) and cone. Discard collapsed spacer (4, Fig. 13).

**NOTE:** If outer bearing remains on shaft and pushes oil seal out of caliper mounting bracket on withdrawal, remove it from shaft using tool SL 47-3/1, 47 (1, Fig. 14).




Fig. 14

Prise oil seal from caliper mounting bracket. Collect outer bearing and cone. Discard oil seal.

Using a suitable drift, gently tap bearing cups (5, Fig. 13) out of housing. Remove caliper mounting bracket from vice and carefully clean internally.




Fig. 13

**NOTE:** When bearings are to be renewed, always replace complete bearings. Never fit new cone and roller assemblies into used cups.

Before fitting, bearings should be lightly greased, but it is most important that at least 4 cc of hypoid oil is added to the cavity between the bearings during assembly, and that the oil seal is lubricated by packing the annular space between its sealing edges with grease. This prevents premature seal or bearing wear before oil flow begins from the axle centre.

## Refitting

Press cups of replacement bearings into housing, using suitable press and adaptors to ensure that cups are pressed fully home in housing.

Place roller and cone assembly of outer bearing (already greased) in position.

Press replacement oil seal into position (1, Fig. 15) ensuring that spring-loaded sealing edge is adjacent to bearing. Load seal with grease between sealing edges.




Fig. 15

Clamp caliper mounting bracket between protected jaws of vice.

Check that four special bolts for brake disc are in position in output shaft flange and enter shaft through seal and outer bearing.

Fit new collapsible spacer and fill the space between bearings with Hypoid EP 90 oil before replacing rollers and cone of inner bearing and fitting new lock washer on shaft.

Place nut on shaft, grease face next to washer and tighten finger-tight only.

Using spanner SL15A and a tommy-bar at disc attachment bolts to oppose torque, tighten nut on shaft just sufficiently to almost eliminate play from bearings. Torque required to turn shaft should be 0,14 to 0,28 kgf/m (10 to 20 lbf/in).

Further tighten nut, very slightly (not more than a thirty-second of a turn — about 5 mm ( $\frac{3}{16}$  in) at perimeter of nut) and re-check torque required to turn shaft. Continue to tighten nut in very small increments, turning shaft to seat bearings and measuring torque after each increment, until correct figure is reached.

**CAUTION:** If torque required to turn shaft exceeds by more than 0,28 kgf/m (20 lbf/in) torque recorded in first check, it is necessary to dismantle assembly, discard collapsed spacer and rebuild with new collapsible spacer. It is not permissible to slacken back nut after collapsing spacer as bearing cones are then no longer rigidly clamped.

Turn down tab washers in two places to lock nut and remove assembly from vice. Refit output shaft assembly to final drive unit, see operation 51.10.20.

## OUTPUT SHAFT OIL SEAL

### Renew

Service tools: 47 Press, torque screwdriver 18G 681, Adaptor, Spanner SL 15A or 15 Output shaft bearing remover/replacer SL 47-3/1, SL 47-3/2.

Remove output shaft assembly.

Clean assembly and clamp caliper mounting bracket between suitably protected jaws of vice.

Turn down tabs of lock washer (1, Fig. 16) and remove nut from shaft, using spanner SL15A (1, Fig. 17).




Fig. 16




Fig. 17

Remove and discard lock washer.

Withdraw output shaft from caliper mounting bracket. Collect inner bearing and cone and mark for correct reassembly. Discard collapsed spacer.

Prise oil seal from caliper mounting bracket and discard. Collect outer bearing and cone. Remove caliper mounting bracket from vice and thoroughly clean internally.

If outer bearing remains on shaft and pushes oil seal out of caliper mounting bracket on withdrawal, remove it from shaft using tool SL47-3/1, 47 (1, Fig. 18).




Fig. 18

**NOTE:** Carefully inspect taper roller bearing components before refitting. If any fault is found in either bearing, replace both complete bearings. Refer to operation 51.10.22, for full details. Never fit new cone and roller assemblies into used cups.

Before fitting, bearings should be lightly greased, but it is most important that at least 4 cc of hypoid oil is added to the cavity between the bearings during assembly, and that the oil seal (2, Fig. 16) is lubricated by packing the annular space between its sealing edges with grease. This prevents premature seal or bearing wear before oil flow begins from the axle centre.

### Refitting (using original bearings)

Place roller and cone assembly of outer bearing (already greased) in position.

Press replacement oil seal into position, ensuring that spring-loaded sealing edge is adjacent to bearing. Load seal with grease between sealing edges.

Clamp caliper mounting bracket (3, Fig. 16) between protected jaws of vice.

Check that four special bolts (4, Fig. 16) for brake disc are in position in output shaft flange and enter shaft through seal and fit the outer bearing using tools SL47 3/1, SL47-3/2 (1, Fig. 19).




Fig. 19

Smear oil on portion of shaft in contact with seal.

Fit new collapsible spacer (5, Fig. 16) and fill the space between bearings with Hypoid EP 90 oil before replacing rollers and cone of inner bearing and fitting new lock washer on shaft.

Place nut (6, Fig. 16) on shaft, grease face next to washer and tighten finger-tight only.

Using torque screwdriver 18G 681 and adaptor check torque required to turn shaft in caliper mounting bracket against resistance of the oil seal. Record the torque.

## FINAL DRIVE

**NOTE:** Set screwdriver initially to 0.05 kgf/m (4 lbf/in). Setting should then be progressively increased until torque figure is established at the point when shaft commences to turn.

Using spanner SL15A and a tommy-bar at disc attachment bolts to oppose torque, tighten nut on shaft just sufficiently to almost eliminate play from bearings. Repeat torque check. Torque required to turn shaft should be unchanged, if it has increased, slacken nut very slightly and re-check.

Further tighten nut, very slightly (not more than a thirty-second of a turn — about 5 mm ( $\frac{3}{16}$  in) at perimeter of nut — and re-check torque required to turn shaft. If this torque exceeds by 0.05 to 0.10 kgf/m (4 to 8 lbf/in) the torque recorded earlier, correct bearing pre-load has been achieved, otherwise continue to tighten nut in very small increments, turning shaft to seat bearings and measuring torque after each increment, until correct figure is reached.

**CAUTION:** If torque required to turn shaft exceeds by more than 0.10 kgf/m (8 lbf/in) torque recorded initially, it is necessary to dismantle assembly, discard collapsed spacer and rebuild with new collapsible spacer. It is not permissible to slacken back nut after collapsing spacer as bearing cones are then no longer rigidly clamped.

Turn down tab washer in two places to lock nut and remove assembly from vice.

Refit output shaft assembly to final drive unit, refer to operation 51.10.20 for full details.




Fig. 20

Remove the fourteen  $\frac{1}{2}$  in AF bolts, nuts and setscrews (1, Fig. 20) securing the bottom tie-plate to cross-beam and inner fulcrum brackets.




Fig. 21




Fig. 22

Remove the  $\frac{1}{16}$  in AF nuts and washers (1, Fig. 21) securing the dampers to the wishbone and drift out the retaining pins (1, Fig. 22) recover the spacers and tie-down brackets.




Fig. 23

Slacken the clips (2, Fig. 21) securing the inner universal joint shrouds and slide the shrouds outwards.

Remove the four  $\frac{11}{16}$  in AF self locking nuts (1, Fig. 23) either side securing the drive shaft inner universal joint to the brake disc and output flange.

Remove the  $\frac{3}{4}$  in AF nut (3, Fig. 21) from the inner wishbone fulcrum shaft and drift out the shaft (1, Fig. 24) collecting the spacers, seals and bearings from the wishbone pivots (2, Fig. 23).




Fig. 24

Remove the drive shaft, hub and wishbone assembly from the rear suspension assembly.

Remove the camber shims from the drive shaft flange studs at the brake disc on both sides.

Remove the spacer tubes from between the lugs of the fulcrum brackets and turn the suspension assembly over on the bench.

Disconnect the brake feed pipes from the calipers, seal the ends of the pipes and the ports in the calipers. Release the brake return springs from the operating levers.

Cut the locking wire and remove the four  $\frac{3}{4}$  in AF bolts (1, Fig. 25) securing the final drive to the cross-beam and lift the cross-beam off the unit (Fig. 26).




Fig. 25

## FINAL DRIVE UNIT

Service tool: Dummy shaft JD14.

### Renew

The final drive unit cannot be removed from the vehicle unless it is detached as part of the rear suspension unit, removal of this item is detailed in the rear suspension section.

Drain the oil from the unit to prevent any leakage from the breather, and invert the whole assembly onto a workbench.






Fig. 26

Invert the unit and remove the locking wires and the  $\frac{11}{16}$  in AF setscrews securing the fulcrum brackets to the final drive unit (1, Fig. 27).




Fig. 27

Remove the brackets, noting the position and number of shims at each attachment point.

Cut the wires from the  $\frac{5}{8}$  in AF caliper mounting bolts, remove the bolts and calipers (1, Fig. 28). Remove the brake discs, noting the number of shims between the discs and the flanges.




Fig. 28

Replace the shims and disc on one output shaft flange and secure with two nuts. Replace the caliper, tighten the mounting bolts and check the centering and the run out of the disc. The centering tolerance is  $\pm 0.25$  mm (0.010 in), this can be rectified by transferring shims from one side of the disc to another. The disc run out should not exceed 0.15 mm (0.006 in).

Tighten the caliper bolts to a torque of 6.78 - 7.60 kgf/m 66.4 - 74.5 Nm (49 - 55 lb/ft).

Repeat the above operations on the opposite side. Remove the nuts from both discs.

Place the cross-beam over the final drive, align and replace the bolts and tighten to the correct torque and wire lock 10.4 kgf/m, 101.68 Nm (75 lb/ft). Slacken the brake feed pipes at the centre union, unseal the brake pipes and the ports in the caliper, align and fit the pipes and tighten the unions.

Replace the handbrake lever return springs and invert the assembly on the bench. Position the fulcrum brackets against the final drive unit and locate each bracket loosely with two setscrews. Replace the shims between the fulcrum brackets and the final drive unit.

Tighten the setscrews and wire lock. Refit the camber shims to the drive shaft studs on one side. Fit the drive shaft on to the studs and loosely fit the nuts, and then tighten fully. Replace the spacer tube between the lugs of the fulcrum bracket.

Clean, inspect and grease the lower wishbone bearings, thrust washer etc. Fit new seals and offer up the wishbone fulcrum bracket lugs and locate with dummy shafts.

Tool No. JD14 (1, Fig. 29).




Fig. 29

Take great care not to displace any component during this operation. Drift the dummy shafts from the fulcrum bracket with the fulcrum shaft. Restrain the dummy shafts to prevent spacers or thrust washers dropping out of position. Tighten the fulcrum shaft nuts to a torque of:

Inner 61.0 - 67.8 Nm, 6.23 - 6.91 kgf/m (45 - 50 lb/ft).

Outer 131 - 145 Nm, 13.4 - 14.8 kgf/m (97 - 107 lb/ft).

Reposition the drive shaft shroud and secure it with the clip. Line up the damper lugs with the wishbone bosses and replace the damper shaft, including the spacer and tie down bracket and tighten the nuts to a torque of 43.4 - 48.8 Nm, 4.43 - 4.97 kgf/m (32 - 36 lb/ft).

Replace the wishbone, drive shaft and damper shaft on the opposite side. Replace the bottom tie-plate and tighten the bolts and setscrews.

Replace the rear suspension unit.

Check the rear wheel camber. Bleed the brakes and fill the final drive with oil as necessary.

**NOTE:** Use Shell Super Spirax 90 or BP Gear Oil 1453 if new gears have been fitted; otherwise use a recommended refill or top up oil as specified in Section 09.

## FINAL DRIVE UNIT

### Overhaul

Service tools: 18G 1205, 47, SL 47-1/1, 18G 134, SL 550/1, SL 14-3/1, SL 14-3/2, SL 550-1, SL 3, 4HA, SL 550-9, SL 550-8-1, SL 47-1/1, SL 47-1/2, 18G 1428.

### Dismantling

Ensure that all lubricant is drained from the unit and support the unit in a vice.




Fig. 30

## FINAL DRIVE

Remove the ten  $\frac{1}{2}$  in AF rear cover securing bolts (1, Fig. 30), the cover and the gasket. Remove the locking wire and five  $\frac{3}{8}$  in AF bolts securing the caliper mounting bracket on one side and withdraw the output shaft assembly.

Repeat for the shaft on the other side.

Remove the two  $\frac{3}{4}$  in AF bolts (1, Fig. 31) securing the differential bearing cap, lift out the cap from the differential housing, repeat for the other side.




Fig. 31

Using two suitably padded levers, prise out the differential unit.

Using tool 18G 1205 (1, Fig. 32) to hold the drive flange, remove the pinion nut and washer and withdraw the flange (2, Fig. 32).




Fig. 32

Using a suitable press extract the pinion from the housing.

Using tool 18G 134 remove the oil seal, oil thrower and outer bearing cone.

Examine the inner and outer bearing cups for wear, if replacement is required extract the outer cup using tools 18G 134 and SL550/1 for inner bearing removal, carefully tap the bearing cone out with a brass punch in the cut-outs provided in the differential casing and carefully collect the shims.

Remove the pinion head bearing using tools 47 (1, Fig. 33), SL 47-1/1 (2, Fig. 33).




Fig. 33

Remove the differential side bearings using tool Nos. 47 (1, Fig. 34), SL 14-3/2 (2, Fig. 34) and SL 14-3/1 (3, Fig. 34), and collect the shims.




Fig. 34




Fig. 35

In the absence of any alignment marks (1, Fig. 35), scribe a line across both halves of differential casing to facilitate reassembly. Remove the ten  $\frac{11}{16}$  in AF crown wheel bolts (1, Fig. 36) and remove the crown wheel (2, Fig. 36).

Remove the eight  $\frac{9}{16}$  in AF bolts (1, Fig. 37), securing both halves of the differential casing (2, Fig. 37).

Remove differential side ring (3, Fig. 37).

Remove pinion side gear and pinion cross-shafts complete with gears (4, Fig. 37).

Separate cross-shafts (5, Fig. 37).

Remove remaining side gear (6, Fig. 37) and ring (7, Fig. 37).

Extract the remaining clutch discs (8, Fig. 37) and plates (9, Fig. 37).




Fig. 36




Fig. 37

## Reassembling

**NOTE:** Before commencing assembly, check from reference numbers and letters that pinion and drive gear are a matched pair.

The same serial number must be marked on the pinion end and the outer periphery of the crown wheel (1, Fig. 38), (e.g. 7029). If these requirements are not met the unit must be exchanged.




Fig. 38

Prior to reassembly coat all plates and discs with Powr-lok oil.

Refit two Belleville clutch plates (2, Fig. 39) so that convex sides are against differential casing.

Refit clutch plates (4, Fig. 39) and discs (3, Fig. 39) as shown into each half of the casing.

Fit side ring (5, Fig. 39).

Position one side gear into ring recess (6, Fig. 39).

Fit cross-shafts.

Refit pinion mating cross-shafts complete with pinion gears ensuring that ramps on the shafts coincide with the mating ramps in the differential case (7, Fig. 39).

Assemble remaining side gear (6, Fig. 39) and ring (7, Fig. 39).

Offer up right-hand half of differential case (8, Fig. 39) to flange half in accordance with identification marks and position clutch

friction plate tongues so that they align with grooves in differential case.

Assemble right-hand half to flange half of differential case using eight bolts but do not tighten at this stage (9, Fig. 39).

Tighten eight bolts to a torque of 6,05 to 6,9 kg/m (43 to 50 lb/ft) while drive shafts are in position (1, Fig. 40, 1, Fig. 41). With one drive shaft locked, the torque to turn the other (2, Fig. 41) should be between 40 lb/ft and 70 lb/ft.

e.g. hold one shaft in vice soft jaws whilst turning the other.




Fig. 40

**NOTE:** Ensure that prior to assembly the crown wheel mounting face is free from damage or burrs, particularly on the edge; should any burrs be left on the carrier they must be removed with an oil stone prior to fitment of the crown wheel.

Fit the crown wheel to the carrier diametrically using the ten bolts and tab washers, torque up the bolts to 10,78 to 12,4 kgf/m (77 to 88 lb/ft).

Thickness of shims required in the installation of the differential side bearings is determined as follows:

Fit the differential side bearings (1, Fig. 42) using tools 18G 134 (2, Fig. 42) and SL 550-1 (3, Fig. 42) without the shims onto the differential case, making sure that




Fig. 41

the bearings and housing are perfectly clean.




Fig. 42

Place the differential assembly with the bearings in their housing into the differential case without the pinion in position.




Fig. 43




Fig. 39


## FINAL DRIVE

Install a dial indicator gauge setting the button against the back face of the crown wheel (1, Fig. 43).

Inserting two levers between housing and the bearing cups, move the differential assembly to one side of the carrier.


Set the dial indicator to zero.

Move the assembly to the other side and record indicator reading, giving total clearance between bearings, as now assembled, and abutment faces of the gear carrier housing.



J51-028

Fig. 44




J51-012

Fig. 45

Remove differential assembly from the gear carrier.

Re-install the pinion outer bearing cup using tools 18G 134 (1, Fig. 44 & 45) and SL 550-8 (2, Fig. 44 & 45).


Fit the inner bearing cup (1, Fig. 46) and shims using tools 18G 134 and SL 550-9 (2, Fig. 46).



J51-026

Fig. 46

Press the inner bearing cone onto the pinion using tools 47 (1, Fig. 47), SL 47-1/1 (2, Fig. 47) and SL 47-1/2 (3, Fig. 47).




J51-027

Fig. 47

**NOTE:** The hypoid drive pinion must be correctly adjusted before attempting further assembly, the greatest care being taken to ensure accuracy.

The correct pinion setting is marked on the ground end of the pinion. The matched assembly serial number is also marked on the periphery of the crown wheel, and care should be taken to keep similarly marked gears and pinions in their matched sets as each pair is lapped together before despatch from the factory. The letter on the left is a production code letter and has no significance relative to assembly or servicing of any axle. The letter and figure on the right refer to the tolerance on offset or pinion drop dimension, which is stamped on the cover facing of the gear carrier housing. The number at the bottom gives the cone setting distance of the pinion and may be Zero (0), Plus (+) or Minus (-). (Fig. 48).



J51 013

Fig. 48


When correctly adjusted a pinion marked Zero will be at the zero cone setting distance dimension which is 66,67 mm (2.625 in) (i.e. from the centre line of the gear to the face on the small end of the pinion. A pinion marked Plus two (+2) should be adjusted to the nominal (or Zero) cone setting plus 0,0508 mm (0.002 in) and a pinion marked Minus two (-2) to the cone setting distance minus 0,0508 mm (0.002 in). Thus for a pinion marked Minus two (-2) the distance from the centre of the drive gear to the face of the pinion should be 66,619 mm i.e. 66,67 - 0,0508 mm (2.623 in i.e. 2.625 - 0.002 in) and for a pinion marked Plus three (+3) the cone setting distance should be 66,746 mm (2.628 in). Place pinion, together with inner bearing cone, into gear carrier.

A Pinion drop 38,1 mm (1.5 in)

B Zero cone setting 66,67 mm (2.625 in)

C Mounting distance 108,52 mm (4.312 in)

D Centre line to bearing housing 139,57 mm (5.495 in) to 139,83 mm (5.505 in).



J51 014

Fig. 49

Turn carrier over and support pinion with a suitable block of wood for convenience before attempting further assembly.

Fit pinion outer bearing cone, companion flange, washer and nut only, omitting the collapsible spacer, oil thrower and oil seal, and tighten nut to remove all backlash.

Check pinion setting distance by means of gauge tool SL3 (1, Fig. 50).




Fig. 50

Adjust bracket carrying dial indicator using 4HA setting block (2, Fig. 50) and set dial face to zero.

Check pinion setting by taking a dial indicator reading on the differential bearing bore with the assembly firmly seated on the ground face of the pinion (3, Fig. 50). The correct reading will be the minimum obtained; that is, when the indicator spindle is at the bottom of the bore. Slight movement of the assembly will enable the correct reading to be easily ascertained. The dial indicator shows the deviation of the pinion setting from the zero cone setting and it is important to note the direction of any such deviation as well as the magnitude.

If pinion setting is incorrect it is necessary to dismantle the pinion assembly and remove the pinion inner bearing cup. Add or remove shims as required from the pack locating the bearing cup and re-install the shim pack and bearing cup. Adjusting shims are available in thicknesses of 0.076 mm, 0.127 mm and 0.254 mm (0.003 in, 0.005 in and 0.010 in). Repeat setting operations until satisfactory result is obtained.

Extract pinion shaft from gear carrier far enough to enable the outer bearing cone to be removed from the pinion.

Fit the collapsible spacer to the pinion ensuring that it seats firmly on the machined shoulder on the pinion shaft.

Insert pinion into gear carrier.

Refit the outer bearing cone, oil thrower and using tool 18G 1428 (1, Fig. 51) fit the oil seal.

Lightly grease the splines of the pinion shaft and fit the flange. Fit a new washer, convex face outermost. Fit, but DO NOT tighten the flange retaining nut.

Begin tightening the flange nut, stopping at frequent intervals to check the torque required to turn the pinion, using the string and spring balance, until the required torque is obtained.




Fig. 51

The flange nut may have to be tightened to as much as 18 kgf/m (130 lbf/ft).

Torque required to turn pinion bearings and oil seal:

Old bearings — 0.20 to 0.28 kgf/m (20 to 25 lbf/in).

New bearings — 0.35 to 0.46 kgf/m (30 to 40 lbf/in).

Note the actual figure required to turn the pinion.

If the above values are exceeded a new collapsible spacer must be fitted. ON NO account must the nut be slackened off and retightened as the collapsed spacer will not then sufficiently clamp the bearing cones.

Place differential assembly complete with side bearings but less shims, in the housing. Ensure that bearings and housing are perfectly clean.

Using the shim pack previously selected, vary the shim thicknesses between each bearing cup and the carrier face to achieve a backlash of 0.15 to 0.25 mm (0.006 to 0.010 in) measured at the outer edge of the ring gear (Fig. 52).

Add an additional 0.07 mm (0.003 in) shim to each pack and carefully note from which side of the differential case the pack was removed.

Remove the bearing cups and cones from the differential case using SL 14-3/2 and SL 14-3/1.

Fit appropriate shim pack to the differential case and refit the bearing cone.

Ensure that the matching shim pack and cone are fitted to the same side of the differential housing that they were removed from.




Fig. 52

Lower differential assembly into position lightly tapping the bearings home with a hide hammer.

**NOTE:** Ensure that gear teeth are led into mesh with those of the pinion. Careless handling at this stage may result in bruising the gear teeth. Removal of the consequent damage can only be partially successful and will result in inferior performance.

When refitting side bearing caps, ensure that position of the numerals marked on gear carrier housing face and side bearing cap coincide (1, Fig. 53).

Tighten cap bolts to a torque of 8.82 to 10.08 kgf/m (63 to 72 lbf/ft) (2, Fig. 53).




Fig. 53

Mount a dial indicator on gear carrier housing with the button against back face of gear (1, Fig. 54).




Fig. 54

## FINAL DRIVE

Turn pinion by hand and check run out on back face of gear. Run out should not exceed 0,13 mm (0.005 in). If run out excessive, strip the assembly and rectify by cleaning the surfaces locating the drive gear. Any burrs on these surfaces must be removed.

Remount dial indicator on gear carrier housing with button tangentially against one of drive gear teeth (1, Fig. 55).




Fig. 55

Move drive gear by hand to check backlash which should be 0,15 to 0,25 mm (0.006 to 0.010 in). If backlash is not to specification, transfer the necessary shims from one side of the differential case to the other to obtain the desired setting. Check backlash in at least four positions of drive gear, ensuring that backlash is always greater than 0,15 mm (0.006 in).




Fig. 56

Check that the torque to turn the input flange is 1,4 to 2,8 kgf/m (10 to 20 lbf/in) additional to the torque measured previously to turn the pinion (page 51-15).

Smear cover flange only with Welseal jointing compound, place gasket on final drive casing, place cover over gasket and insert two bolts to retain, coating threads with Loctite.

Replace remaining eight bolts, coating threads with Loctite and replace the tabs.

Tighten screws by diagonal selection to correct torque 2,1 to 2,8 kgf/m (15 to 20 lbf/ft).

Refit both output shaft assemblies (1, Fig. 56) and torque the bolts to 8,4 to 9,66 kgf/m (60 to 69 lbf/ft), replace the drain plug and refit the drive unit to the cross-member (1, Fig. 57).




Fig. 57

Secure with bolts (1, Fig. 58) torque and lockwire (2, Fig. 58), ensuring that when lockwired, the wire is tightening the bolts.





Fig. 58


After refitting the unit to the vehicle fill with new oil.

---





**XJ-S 3·6  
XJ-SC 3·6  
SERVICE  
MANUAL**





## **BOOK 6**

**Containing  
Sections**

**57 STEERING  
60 FRONT SUSPENSION  
64 REAR SUSPENSION  
70 BRAKES  
74 WHEELS & TYRES**

**XJ-S 3·6  
XJ-SC 3·6**

**SERVICE MANUAL**

## INTRODUCTION

This Service Manual covers the Jaguar XJ-S 3.6 and XJ-SC 3.6. It is primarily designed to assist skilled technicians in the efficient repair and maintenance of this range of Jaguar cars.

Using the appropriate service tools and carrying out the procedures as detailed will enable the operations to be completed within the time stated in the 'Repair Operation Times'.

The Service Manual has been produced in 9 separate books; this allows the information to be distributed throughout the specialist areas of the modern service facility.

A table of contents in Book 1 lists the major components and systems together with the section and book numbers. The cover of each book depicts graphically and numerically the sections contained within that book.

The title page of each book carries the part numbers required to order replacement books, binders or complete Service Manuals. This can be done through the normal channels.

The contents section of each book lists the repair operations in the section or sections contained within that book. Each operation is given an operation number that corresponds with those listed in the Repair Operation Times.

The method described on the page number listed against the operation will be the one we consider will meet the requirements of safety and enable the operation to be carried out in the time specified in the Repair Operation Times.

Where no page number is given against an operation, we feel that the method is so obvious as to warrant no explanation. It is, however, included so that a warranty time can be given in the Repair Operation Times.

Extensive research has gone into the diagnosis of faults and where appropriate this is covered in the various areas of the manual. By following the sequence of the diagnosis charts, speedy isolation of faults may be expected, and consequent correction will reduce the vehicle off-the-road time to the minimum.

### Service Tools

Where performance of an operation requires the use of a service tool the tool number is quoted under the operation heading and is repeated in, or following, the instruction involving its use. A list of all necessary tools is included in Book 1, Section 99.

### References

References to the LH or RH side in the manual are made when viewing from the rear. With the engine and gearbox assembly removed the timing cover end of the engine is referred to as the front. A key to abbreviations and symbols is given in Book 1, Section 01.

## REPAIRS AND REPLACEMENTS

When service parts are required it is essential that only genuine Jaguar or Unipart replacements are used.

Attention is particularly drawn to the following points concerning repairs and the fitting of replacement parts and accessories.

1. Safety features embodied in the vehicle may be impaired if other than genuine parts are fitted. In certain territories, legislation prohibits the fitting of parts not to the vehicle manufacturer's specification.
2. Torque wrench setting figures given in this Service Manual must be strictly adhered to.
3. Locking devices, where specified, must be fitted. If the efficiency of a locking device is impaired during removal it must be replaced.
4. Owners purchasing accessories while travelling abroad should ensure that the accessory and its fitted location on the vehicle conform to mandatory requirements existing in their country of origin.
5. The vehicle warranty may be invalidated by the fitting of other than genuine Jaguar or Unipart parts. All Jaguar and Unipart replacements have the full backing of the factory warranty.
6. Jaguar Distributors and Dealers are obliged to supply only genuine service parts.

## SPECIFICATION

Purchasers are advised that the specification details set out in this Manual apply to a range of vehicles and not to any one. For the specification of a particular vehicle, purchasers should consult their Distributor or Dealer.

The Manufacturers reserve the right to vary their specifications with or without notice, and at such times and in such manner as they think fit. Major as well as minor changes may be involved in accordance with the Manufacturer's policy of constant product improvement.

Whilst every effort is made to ensure the accuracy of the particulars contained in this Manual, neither the Manufacturer nor the Distributor or Dealer, by whom this Manual is supplied, shall in any circumstances be held liable for any inaccuracy or the consequences thereof.

## COPYRIGHT

© Jaguar Cars Ltd. 1983

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, electronic, mechanical, photocopying, recording or other means without prior written permission of Jaguar Cars Ltd., Service Department, Radford, Coventry CV6 3GB.

## CONTENTS

| Operation  | Operation No. | Page No. |
|--|---------------|----------|
| Camber angle — Check and adjust .....                          | 57.65.04      | 57—5     |
| Castor angle — Check and adjust .....                          | 57.65.05      | 57—5     |
| Control valve and pinion — Renew .....                         | 57.10.19      | 57—7     |
| Control valve and pinion, upper seal — Renew .....             | 57.10.23      | 57—7     |
| Data .....   | —             | 57—3     |
| Description .....  | —             | 57—3     |
| Front wheel alignment — Check and adjust .....                 | 57.65.01      | 57—6     |
| Lower steering column seal — Renew .....                       | 57.40.15      | 57—9     |
| Lower steering column — Renew .....                            | 57.40.05      | 57—9     |
| Universal joint — Renew .....                                  | 57.40.25      | 57—9     |
| Power steering rack — Overhaul .....                           | 57.10.07      | 57—10    |
| Control valve housing, port inserts — Renew .....              | 57.10.24      | 57—11    |
| Power steering rack — Remove and refit .....                   | 57.10.01      | 57—10    |
| Power steering rack, pinion clearance — Check and adjust ..... | 57.10.13      | 57—6     |
| Service tools .....  | —             | 57—2     |
| Steering arm — Renew .....                                     | 57.55.29      | 57—8     |
| Steering pump — Overhaul .....                                 | 57.20.20      | 57—12    |
| Steering pump — Remove and refit .....                         | 57.20.14      | 57—12    |
| Symptom and diagnosis chart .....                              | —             | 57—4     |
| System bleeding .....  | 57.15.02      | 57—5     |
| System testing .....   | 57.15.01      | 57—5     |
| Tie rod ball joints — Renew .....                              | 57.55.01      | 57—7     |
| Tie rod gaiters — Renew .....                                  | 57.10.27      | 57—7     |
| Tie rod inner ball joint — Renew .....                         | 57.55.03      | 57—7     |
| Tie rod outer ball joint — Renew .....                         | 57.55.02      | 57—7     |
| Torque wrench settings .....                                   | —             | 57—2     |
| Upper steering column — Renew .....                            | 57.40.02      | 57—8     |
| Adjusting clamp — Overhaul .....                               | 57.40.07      | 57—8     |
| Steering column lock — Remove and refit .....                  | 57.40.28      | 57—9     |
| Steering wheel — Remove and refit .....                        | 57.60.01      | 57—8     |
| Steering wheel pad — Remove and refit .....                    | 57.60.03      | 57—8     |

## STEERING

### TORQUE WRENCH SETTINGS

| ITEM  | DESCRIPTION                | SPANNER SIZE          | TIGHTENING TORQUE |              |               |
|---|----------------------------|-----------------------|-------------------|--------------|---------------|
|   |                            |                       | Nm                | kgf/cm       | lbf/ft        |
| Collet adaptor pinchbolt  | $\frac{1}{4}$ in UNF       | $\frac{7}{16}$ in AF  | 13,5 to 16,2      | 1,4 to 1,67  | 10 to 12      |
| Collet adaptor retaining screw locknut                              | $\frac{1}{4}$ in UNF nut   | $\frac{7}{16}$ in AF  | 8,1 to 9,5        | 0,8 to 0,98  | 6 to 7        |
| Hydraulic hose to outlet port of steering pump                      | —                          | 16 mm                 | 20 to 35          | 2,1 to 3,6   | 15 to 26      |
| Hydraulic pipe connections to steering rack                         | $\frac{7}{16}$ in UNF      | $\frac{1}{2}$ in AF   | 8 to 15           | 0,83 to 1,55 | 5,9 to 11     |
| Inner balljoint assembly to rack bar                                | —                          | —                     | 60 to 74          | 6,2 to 7,54  | 44,3 to 54,6  |
| Outlet port to steering pump  | M16                        | 26 mm                 | 50 to 70          | 5,3 to 7,24  | 38 to 52      |
| Outer balljoint locknut   | —                          | —                     | 52 to 68          | 5,5 to 6,9   | 38,5 to 50,4  |
| Pinion housing to rack end housing                                  | —                          | 13 mm                 | 7 to 10,5         | 0,75 to 1,1  | 5,2 to 7,7    |
| Steering arm to stub axle carrier                                   | M12                        | —                     | 67,8 to 74,5      | 6,9 to 7,7   | 50 to 55      |
| Steering pump adaptor to engine                                     | M8                         | 10 mm                 | 23 to 27          | 2,4 to 2,8   | 17 to 20      |
| Steering pump to adaptor  | M10 bolt                   | 13 mm                 | 49 to 54          | 5 to 5,6     | 36 to 40      |
| Steering rack mounting to subframe                                  | $\frac{5}{16}$ in UNF      | $\frac{1}{2}$ in AF   | 19 to 24,4        | 1,95 to 2,52 | 14 to 18      |
| Steering rack damper adjuster locknut                               | —                          | —                     | 36 to 67          | 3,7 to 6,85  | 26,5 to 49,4  |
| Steering rack damper plate securing bolts                           | —                          | —                     | 19 to 24,4        | 1,95 to 2,52 | 14 to 18      |
| Universal joint pinch bolts   | $\frac{5}{16}$ in UNF      | $\frac{1}{2}$ in AF   | 19 to 24,4        | 1,95 to 2,52 | 14 to 18      |
| Upper steering column longitudinal strut to vertical strut          | —                          | $\frac{1}{2}$ in AF   | 10,8 to 13,6      | 1,12 to 1,4  | 8 to 10       |
| Upper steering column lower mounting and longitudinal strut to body | $\frac{5}{16}$ in UNF bolt | $\frac{1}{2}$ in AF   | 19 to 24,4        | 1,95 to 2,52 | 14 to 18      |
| Upper steering column to vertical strut                             | $\frac{5}{16}$ in UNF bolt | $\frac{1}{2}$ in AF   | 19 to 24,4        | 1,95 to 2,52 | 14 to 18      |
| Upper steering column transverse strut to vertical strut            | $\frac{5}{16}$ in UNF bolt | $\frac{1}{2}$ in AF   | 19 to 24,4        | 1,95 to 2,52 | 14 to 18      |
| Upper steering column vertical strut to bracket                     | $\frac{5}{16}$ in UNF      | $\frac{1}{2}$ in AF   | 19 to 24,4        | 1,95 to 2,52 | 14 to 18      |
| Upper steering column vertical strut bracket to body                | $\frac{5}{16}$ in UNF      | $\frac{1}{2}$ in AF   | 19 to 24,4        | 1,95 to 2,52 | 14 to 18      |
| Steering rack end housing ring nut                                  | —                          | —                     | 119 to 170        | 12,3 to 17,6 | 87,8 to 125,4 |
| Steering rack end housing locating screw                            | —                          | —                     | 10 to 17          | 1,1 to 1,8   | 7,4 to 12,5   |
| Steering wheel to shaft   | $\frac{5}{8}$ in UNF nut   | $\frac{15}{16}$ in AF | 34 to 43,4        | 3,5 to 4,5   | 25 to 32      |

### SERVICE TOOLS

|                            |                      |
|----------------------------|----------------------|
| Ball joint separator       | JD.24                |
| 'C' nut spanner            | S.355                |
| Camber gauge               |                      |
| Castor gauge               |                      |
| Circlip pliers             |                      |
| Compression sleeve         | 606603               |
| Dial test indicator        |                      |
| Drive dog remover/replacer | 18G 1445             |
| Expansion sleeve           | 606602               |
| Pipe connection plugs      |                      |
| Pressure gauge             | JD.10                |
| Rack centralising tool     | 12297 or<br>18G 1466 |
| Rack checking fixture      |                      |
| Seal saver                 | 18G 1259             |
| Suspension setting links   | JD.25B               |
| Tap                        | JD.10—2              |
| Wheel alignment equipment  |                      |

## DESCRIPTION

A power assisted steering rack and pinion assembly is mounted to the front crossmember with rubber damping bushes.

The power assisted steering rack differs from the un-assisted type of rack; a single piston is fitted to the rack bar, operating in an enclosed cylinder. The pinion housing is replaced by a control valve/pinion assembly with a combined pinion shaft and spool assembly. This directs hydraulic pressure to the appropriate side of the rack piston, thus providing power assistance when the steering wheel is turned.

Oil flow through the control valve is continuous; when the wheels are in the

straight ahead position, low oil pressure is applied to each side of the piston. As the steering wheel is turned, a small torsion bar, within the control valve/pinion assembly allows a few degrees of rotation before actually turning the pinion. This rotation is used to open and close ports in the control valve, to ensure that as the torsion bar is twisted, the hydraulic pressure directed to one side of the piston is also increased, from 2,8 kgf/cm<sup>2</sup> (40 lbf/in<sup>2</sup>) to a maximum of 84,4 kgf/cm<sup>2</sup> (1200 lbf/in<sup>2</sup>), returning to minimum when the load on the torsion bar from the steering wheel is zero. The increase in pressure being proportional to the twist in the torsion bar.

Hydraulic pressure is provided by a vane-type, non-submerged pump, driven directly from the engine auxiliary shaft.

To prevent the hydraulic pressure from exceeding 84,4 kgf/cm<sup>2</sup> (1200 lbf/in<sup>2</sup>) a flow control valve is fitted to the outlet port of the pump.

## DATA


|   |   |
|---|---|
| Castor angle .....  | $3\frac{1}{2}^{\circ} \pm \frac{1}{4}^{\circ}$ positive   |
| Camber angle — Front .....  | $\frac{1}{2}^{\circ} \pm \frac{1}{4}^{\circ}$ negative (both front wheels to be within $\frac{1}{4}^{\circ}$ of each other) |
| Front wheel alignment .....   | 0 to 3,18 mm (0 to $\frac{1}{8}$ in) toe in   |
| Number of turns, lock to lock .....   | 2.75  |
| Total stroke of rack .....  | 146,46 mm (5.77 in)   |
| Rack 'pull through load', with a feed pressure of 2,11 kgf/cm <sup>2</sup> (30 lbf/in <sup>2</sup> ) and a pump flow of 9,45 litres/min (2.08 gal/min) is to be 18,1 kg (40 lb) max, 13,6 kg (30 lb) min. |   |
| Maximum axial lift of inner ball joint .....  | 0,0127 to 0,0762 mm (0.0005 to 0.0030 in)   |
| Rack pinion inclination .....   | 22°   |
| Tie rod articulation, maximum force .....   | 4 Nm (36 lb in)   |
| Rack pinion — inlet ports .....   | 0.500 in — 20 UNF   |
| — outlet ports .....  | 0.625 in — 18 UNF   |
| Quantity of grease from dry .....   |   |
| Specification .....   | Lithium based grease  |
| Rack and pinion tooth area .....  | 42,5 to 57 grammes (1.5 to 2 oz)  |
| Bellows — each .....  | 57 grammes (2 oz)   |

## Power Steering Pump

|                                       |  |
|---------------------------------------|--|
| External diameter of shaft .....      | 19,04 to 19,05 mm (0.7496 to 0.7500 in)                                |
| Internal diameter of drive dog .....  | 18,986 to 19,014 mm (0.7475 to 0.7486 in)                              |
| Relief valve operating pressure ..... | 77,34 to 84,37 kgf/cm <sup>2</sup> (1100 to 1200 lbf/in <sup>2</sup> ) |
| Power steering fluid .....            | S.A.E. Automatic Transmission Fluid Type A or Dexron R                 |

## DIMENSIONAL DATA — STEERING ARM (Fig. 1)

- A. 82,3 to 82,8 mm (3.24 to 3.26 in)
- B. 79,73 to 80,24 mm (3.139 to 3.159 in)
- C. 53,34 to 53,85 mm (2.10 to 2.12 in)
- D. 17,78 to 18,29 mm (0.70 to 0.72 in)
- E. 58,93 to 59,44 mm (2.32 to 2.34 in)
- F. 135,38 to 135,89 mm (5.33 to 5.35 in)



J57-052

Fig. 1

**SYMPTON AND DIAGNOSIS CHART**

| SYMPTOM   | CAUSE  | CURE  |
|---|--|---|
| External oil leaks from steering rack unit.   | Damaged or worn seals.<br>Loose unions.<br>Damaged union sealing washers.  | Replace seals.<br>Tighten unions.<br>Replace sealing washers.   |
| Oil leak at pump shaft.   | Damaged shaft seal.  | Replace shaft seal.   |
| Oil leak at high pressure outlet union.   | Loose or damaged union.<br>Damaged pipe end.   | Tighten union.<br>Replace pipe.   |
| Oil leak at low pressure inlet connection.  | Loose or damaged hose connection.  | Remove and refit or renew hose and clip.  |
| Oil overflowing reservoir cap.  | Reservoir overfull.<br>Sticking flow control valve (closed).   | Reduce level in reservoir.<br>Remove valve, renew and refit.  |
| Noise from hydraulic system.  | Air in system.   | Bleed system.   |
| Noise from pump.  | Worn drive coupling.<br>Internal wear and damage.  | Renew coupling.<br>Overhaul pump.   |
| Noise from rack (rattling).   | Worn rack and pinion gears.<br>Worn inner ball joints.<br>Universal joint loose.   | Adjust rack damper.<br>Replace inner ball joints.<br>Tighten clamping bolts.  |
| Steering veering to left or right.  | Unbalanced tyre pressures.<br>Incorrect tyres fitted.<br>Incorrect geometry.<br>Steering unit out of trim.   | Inflate to correct pressure.<br>Fit tyres of correct specification.<br>Reset geometry to correct specification.<br>Replace valve and pinion assembly. |
| Heavy steering when driving.  | Low tyre pressures.<br>Tightness in steering column.<br>Tightness in steering joints.  | Inflate to correct specification.<br>Grease or replace.<br>Grease or renew joints.  |
| Heavy steering when parking.  | Low tyre pressures.<br>Tightness in steering column.<br>Tightness in steering joints.<br>Restricted hose.<br>Sticking flow control valve (open).<br>Internal leaks in steering unit. | Inflate to correct specification.<br>Grease or replace.<br>Grease or renew joints.<br>Replace hose.<br>Remove and renew valve.<br>Replace seals.      |
| Steering effort too light.  | Valve torsion bar dowel pins worn.<br>Valve torsion bar broken.  | Replace valve assembly.<br>Replace valve assembly.  |
| Momentary increase in effort when the steering wheel is turned quickly in either direction. | Low fluid level.<br>High internal leakage.   | Top up fluid reservoir.<br>Overhaul steering pump.  |
| Jerky steering, especially when parking.  | Low fluid level.<br>Insufficient pump pressure.<br>Sticking flow control valve.  | Top up fluid reservoir.<br>Check flow valve/overhaul pump.<br>Check and rectify.  |



## SYSTEM TESTING

**Service Tools:** Tap JD10-2, Pressure gauge JD 10.

Before commencing the test procedure, ensure that the fluid in the reservoir is free from froth, and that the level is correct.

Fit the pressure gauge (1, Fig. 2) in the pressure line from the pump.

**NOTE:** The gauge must read to 100 kgf/cm<sup>2</sup> (1500 lbf/in<sup>2</sup>).




Fig. 2

Start the engine and allow it to idle. Turn the steering wheel to full lock and continue to increase steering effort, until the pressure recorded on the gauge ceases to increase. Check that the recorded pressure is between 77.55 and 84.4 kgf/cm<sup>2</sup> (1100 and 1200 lbf/in<sup>2</sup>).

**NOTE:** If the pressure is below 77.5 kgf/cm<sup>2</sup> (1100 lbf/in<sup>2</sup>) at idle, but rises to the correct value when the engine speed is increased, then a defective pump control valve, or excessive internal leakage in the rack and pinion unit is indicated.

Carry out the following test to establish the location of the fault.




Fig. 3

Fit the tap JD 10-2 (2, Fig. 3) between the pump and the pressure gauge (1, Fig. 3), arranged as shown so that the pressure gauge will at all times be connected to the pump but the rack unit can be isolated.

With the tap in the 'Open' position, start the engine and allow it to idle. Turn the steering wheel to full lock. Check the reading on the gauge which should be in excess of 77.5 kgf/cm<sup>2</sup> (1100 lbf/in<sup>2</sup>).

If the pressure does not reach this figure, CLOSE THE TAP IMMEDIATELY, noting the reading on the gauge as the tap reaches the 'OFF' position.

**CAUTION:** Do NOT keep the tap closed for any longer than 5 seconds when the engine is running.

If the reading on the gauge increases when the tap is closed to at least 77.5 kgf/cm<sup>2</sup> (1100 lbf/in<sup>2</sup>), then leaks are confined to the steering unit, which requires overhauling.

If the reading on the gauge exceeds 84.4 kgf/cm<sup>2</sup> (1200 lbf/in<sup>2</sup>), remove the pump discharge port and withdraw the spring and control valve assembly.

Inspect the small hemispherical gauge filter located at the inner end of the control valve. If blocked, clean using compressed air. Refit the control valve, spring and discharge port.

## POWER STEERING SYSTEM

### Bleed

The presence of any air in the system will cause the steering to be lumpy and erratic: Air can be removed by the following method:

Fill the fluid reservoir to the full mark, start the engine and turn the steering wheel from lock to lock; avoid the steering lock stops.

Keep a constant check on the fluid level in the reservoir and top up as necessary.

Position the wheels in the straight ahead position and allow the engine to continue to idle for a few minutes.

Switch off the engine, allow the system to settle and recheck the fluid level; add fluid as necessary.

Use only fluid of the correct specification.

## CASTOR ANGLE/CAMBER ANGLE

**Service Tools:** JD 25B Suspension links. Camber and castor angle checking gauges.

**CAUTION:** Before checking, examine all rubber/steel bushes for deterioration or distortion. Check upper and lower wishbone ball joints for excessive play. Check shock absorbers for leaks and mountings for security.

The two operations require the vehicle to be set up in a mid-laden condition. This can be done as follows:

Ensure that the car is standing on level ground and inflate the tyres to the correct pressure; check that the standing heights are equal on both sides of the car, and the front wheels are in the straight-ahead position.

Make up two front suspension tubes to the dimensions shown (Fig. 4).

Compress the front suspension and insert the setting tubes under the upper wishbones, adjacent to the rebound stop rubbers and over the brackets welded to the bottom of the 'turrets'. This locks the front suspension in the mid-laden condition.

Lock the rear suspension in the mid-laden condition using the suspension links, service tool JD 25B.





Fig. 4

For each side, compress the suspension, pass the hooked end of service tool JD 25B through the lower hole in the rear mounting and fit the looped end over the rear pivot nut (Fig. 5).




Fig. 5

### Castor angle — check and adjust

Using the castor angle checking gauge, check the castor angle. Refer to the Data for correct setting.

To adjust, slacken the two bolts, on each side, securing the upper wishbone members to the upper ball joints.

Transpose shims, which can now be lifted out, from front to rear or vice versa, to reduce or increase the castor angle respectively (Fig. 6).




Fig. 6

Transposing one shim 1.6 mm (0.0625 in) thick will alter the castor angle by approximately 1/4°.

## STEERING

After adjusting the castor angle to the correct figure, tighten the bolts to the correct torque. Check the front wheel alignment and adjust if necessary.

### Camber angle — check and adjust

Using the camber angle checking gauge, check the camber angle. Refer to data for the correct settings.

Rotate the road wheels through 180° and re-check.

To adjust, slacken the nuts and bolts securing the upper wishbone inner pivots to the cross member turrets.

Add or remove shims between the pivot shafts and cross member turrets to reduce or increase the camber angle (Fig. 7).




Fig. 7

Shims are available in 0.8 mm ( $\frac{1}{32}$  in), 1.6 mm ( $\frac{1}{16}$  in) and 3.2 mm ( $\frac{1}{8}$  in) thickness. A change of 1.6 mm ( $\frac{1}{16}$  in) in shim thickness will alter the camber angle by approximately  $\frac{1}{4}^\circ$ .

**NOTE:** It is necessary to partly withdraw the bolts to change the shims, so only one bolt of a pair should be shimmed at a time. It is important that an equal thickness of shims should be changed on front and rear bolts, otherwise the castor angle will be affected.

Tighten all the bolts and nuts to the correct torque, and re-check the camber angle. Check the front wheel alignment and adjust if necessary.

## FRONT WHEEL ALIGNMENT

### Check and adjust

Service Tool: Centralising tool 18G 1466 (was Jaguar Parts Issue 12297)

### Check

Inflate the tyres to the correct pressures. Set the front wheels in the straight-ahead position.




Fig. 8

Remove the grease nipple from the rack adjuster pad (1, Fig. 8).

Insert the centralising tool (2, Fig. 8) and adjust the position of the rack until reduced tip of the tool enters the locating hole in the rack.

Check the alignment by using light beam equipment or an approved track setting gauge.

**NOTE:** As a front wheel alignment check is called for in the Option Service of the Maintenance Summary, very little variation from specified figures for the wheel alignment is to be expected; if, however, a discrepancy of as much as 3 mm ( $\frac{1}{8}$  in) from specified limits is recorded, accidental damage to a steering lever may have occurred and the following check must be carried out, on both levers.

Remove the steering levers.

Accurately check the dimensions of each lever against those quoted in the Data and Fig. 1.

Reject for scrap and replace any lever with dimensions outside the limits quoted.

**WARNING: IT IS ABSOLUTELY FORBIDDEN TO ATTEMPT TO STRAIGHTEN A DAMAGED STEERING ARM. IT MUST BE REPLACED.**

If both steering levers are within limits, a discrepancy in alignment figures may be due to the distortion of the upper or lower wishbones, or the end of the stub axle carriers (vertical links.) Dimensioned drawings of these parts for checking purposes, are given in Group 60.

### Adjust

Slacken the locknuts at the outer end of each tie-rod.

Release the clips securing the outer ends of the gaiters to the tie-rods.

Turn the tie-rods by an equal amount until the alignment of the wheels is correct.

Tighten the locknuts to the figure quoted in the torque wrench setting table while holding the track rod end spanner flats.

Re-check the alignment.

Ensure that the gaiters are not twisted and re-tighten the clips.

Remove the centralising tool (2, Fig. 8) and refit the grease nipple.

## STEERING RACK PINION CLEARANCE

### Check and adjust

Service Tools: Ball joint separator JD 24, Dial test indicator.

The correct clearance should allow smooth travel of the rack, without binding.

The maximum clearance between the rack and the pinion should not exceed 0.25 mm (0.010 in).

The clearance is measured from beneath the car.

Detach the outer ball joint on the tie rod nearest to the pinion, from the steering arm, using Service Tool JD 24 (Fig. 9).

**NOTE:** It may be necessary to substitute a 2 in long  $\frac{1}{2}$  in UNF socket headed (grub) screw for the existing bolts of JD 24.




Fig. 9

Remove the grease nipple (1, Fig. 10) from the rack damper threaded plug and insert the stem of a dial test indicator through the grease nipple hole to contact the back of the rack shaft. Secure the gauge to the rack. Zero the gauge.




Fig. 10

Firmly grip the tie rod inner ball joint assembly, nearest to the pinion, and move it away from the pinion, towards the rack damper assembly; note the reading on the gauge.

If the clearance is excessive and adjustment is required, release the locknut (2, Fig. 10), screw in the plug (3, Fig. 10) until firm resistance is felt. Back off  $\frac{1}{8}$ th of a turn and tighten the locknut; re-check the pinion to rack clearance.

Move the rack through its full travel. If binding occurs at any point, slightly increase the clearance and re-check.

When the correct clearance is achieved, fully tighten the locknut and refit the grease nipple.

Connect the tie rod outer ball joint to the steering arm.

Check the front wheel alignment; adjust as necessary.

## CONTROL VALVE AND PINION

### Renew

**Service Tool:** Pinion Housing Seal Saver 18G 1259.

It is possible to remove the control valve and pinion assembly without removing the rack. Extreme care must be taken to prevent contamination from entering the rack housing whilst the pinion is removed. Place the car on a ramp or over a pit.

Mark the relationship of the steering column universal joint to the upper and lower columns, remove the steering column universal joint.

Mark the relationship of the lower column to the rack pinion and remove the lower column.


Thoroughly clean the pinion housing.

Remove the way washer and the dust shield from the pinion.

Disconnect the rack feed hose from the pinion housing and drain the fluid into a suitable container.

### Upper Seal

The upper seal can be renewed without removing the control valve and pinion assembly from the rack.



Remove the circlip (1, Fig. 11) seal retainer (2, Fig. 11) and seal (3, Fig. 11) from the pinion housing.

Position the seal saver, Service Tool 18G 1259, over the serrations on the pinion. Fit a new seal, grooved face downwards. Ensure that the flange fits snugly in the recess. Fit the seal retainer with the rubber side and lip outermost. Fit the circlip, ensure that it is seated fully in the groove. Remove the Service Tool.

### Control Valve and Pinion

Disconnect the hydraulic pipe unions from the pinion valve housing and remove the pipes (1, Fig. 12).

Remove the three self locking nuts (2, Fig. 12) securing the pinion valve housing to the steering rack.

Undo the rack damper pad locknut and slacken the rack damper threaded plug (3, Fig. 12) one turn.

Mark the position of the pinion shaft in relation to the valve housing (4, Fig. 12).

Remove the control valve and pinion assembly.

Do NOT move the front wheels or turn the steering wheel until the pinion assembly is refitted.




Fig. 12

Remove and discard the 'U' section seal and clean the sealing faces.

Fit a new 'U' section seal to the pinion rack housing, ensure that the grooves in the seal face upwards and that the seal flange fits snugly in the groove.

Grease the pinion teeth with the correct specification grease.

Fit the pinion valve housing to the rack, ensure that the pinion shaft is in the correct position in the housing as previously marked.

Fit and tighten the three self locking nuts securing the pinion valve housing to the rack.

Reset the rack damper adjuster plug and tighten the locknut.

### Refitting

Refit the lower steering column to the rack pinion and the universal joint to the upper and lower columns. Note the previously marked positions. Fit and tighten the pinch bolts.

Refit the hydraulic pipes and the rack feed hose.

Fill the system to the correct level with the fluid of the correct specification and bleed the system.

Check for leaks.

## TIE ROD BALL JOINTS

### Renew

**Service Tool:** Ball Joint Separator JD 24.

The inner ball joint is only supplied as a complete assembly. To renew the inner ball joint, it is necessary to remove the outer ball joint and locknut first.

To assist in the initial setting of the front wheel alignment prior to dismantling, measure the distance between the centres of the inner and outer ball joints.

The front wheel alignment must be checked after renewing either ball joint, as it is difficult to ensure that the length between the ball joint centres is not altered.

### Outer Ball Joint

Remove the self locking nut securing the outer ball joint to the steering arm. Use Service Tool JD 24 (Fig. 13) to detach the ball joint.

**NOTE:** It may be necessary to substitute a 2 in long  $\frac{1}{2}$  in UNF socket headed (grub) screw, for the existing bolt of JD 24.




Fig. 13

Release the outer ball joint locknut. Do not run the locknut along the thread. Unscrew the ball joint from the tie rod.

Screw on the replacement ball joint up to the locknut. This gives an approximate setting prior to checking the front wheel alignment.

Refit the ball joint to the steering arm and secure using a new self locking nut.

Check and adjust the front wheel alignment.

### Inner Ball Joint

Release the outer ball joint from the steering arm and remove the ball joint and locknut from the tie rod.

Release the clips (1, Fig. 14) securing the rubber gaiter to the steering rack housing and tie rod. Withdraw the rubber gaiter (2, Fig. 14).

Check for splits or perishing.




Fig. 14

Knock back the tab washer (3, Fig. 14) and unscrew the inner ball joint and tie rod assembly (4, Fig. 14) from the rack bar.

Collect the spring and packing washer (5 & 6, Fig. 14).

Fit the new inner ball joint assembly to the rack bar, with a new tab washer. Bend over the tab washer.

Coat the inner ball joint with 60 g (2 oz) of the recommended grease and refit the gaiter. Secure with the clips.

Refit the outer ball joint and secure to the steering arm.

Check and adjust the front wheel alignment.

## STEERING ARM

### Renew

Service Tool: Ball Joint Separator JD 24.

Jack up the front of the car and support on stands.

Remove the self locking nut (1, Fig. 16) securing the tie rod outer ball joint to the steering arm. Detach the ball joint using Service Tool JD 24 (Fig. 15).





Fig. 15

**NOTE:** It may be necessary to substitute a 2 in long  $\frac{1}{2}$  in UNF socket headed (grub) screw for the existing bolt of JD 24.



Cut and remove the locking wire (2, Fig. 16) securing the steering arm mounting bolts, remove the bolts (3, Fig. 16). Make a record of the number and position of any shims fitted between the steering arm and the brake caliper.

Check the steering arm against the dimensions given in Fig. 16. No attempt should be made to straighten a damaged steering arm. IT MUST BE REPLACED.

Fit the steering arm and secure with the bolts. Tighten to correct torque and wirelock.

**NOTE:** Ensure that any shims between the steering arm and brake caliper are refitted in their original positions.

Check and adjust the front wheel alignment.

## UPPER STEERING COLUMN

### Renew

#### Removing the Steering Wheel Assembly

Disconnect the battery earth cable.

Remove the three screws securing the steering column lower switch cover and remove the cover.

Slacken the locknut (1, Fig. 17) and release the grub screw (2, Fig. 17), in the collet adaptor, two complete turns.




Fig. 17

Centralise the front wheels and mark the relationship of the steering wheel to the steering column upper switch cover.

Remove the clamp bolt and nyloc nut securing the collet adaptor to the steering column.

Withdraw the steering wheel complete with the lock ring collar and adjuster assembly.

#### Dismantling the Steering Column Adjusting Clamp

Unscrew the two self locking screws securing the horn pad to the steering wheel. Unscrew the nylon nut from the top of the steering wheel shaft and remove it, withdrawing the horn contact tube with it. Remove the self locking nut and plain washer securing the steering wheel to the splined shaft.

Carefully remove the steering wheel from the splined shaft. Collect both halves of the split cone.

Remove the three screws securing the 'U' plate (3, Fig. 17) to the collet adaptor (4, Fig. 17).

Unscrew the collet adaptor from the lock ring collar.

Remove the impact rubber (5, Fig. 17) from the steering wheel shaft.

Remove the circlip (6, Fig. 17) securing the lock ring collar (7, Fig. 17) to the splined steering wheel shaft (8, Fig. 17) and remove the lock ring collar.

Slacken the grub screw (9, Fig. 17) securing the split collet (10, Fig. 17) to the steering wheel shaft and remove the collet.

Check the split collet for wear in the splines. There should not be any radial movement between the collet and the splined shaft.

## Removing the Upper Steering Column

To obtain access to the column upper mounting bolts, it is necessary to remove the Instrument Panel (Module) as follows:

Remove the driver's side dash lower casing. Remove the centre securing strip and screw from the instrument module surround (1, Fig. 18).

Remove the screws securing the side pieces of the surround and remove the surround (2, Fig. 19).




Fig. 18

Pry off the covers from the securing screw apertures (3, Fig. 18) and remove the screws (4, Fig. 18) securing the instrument panel module to the fascia.

Ease the module forwards and disconnect the harness block connectors.

Manoeuvre the instrument panel clear of the fascia.

Remove the screws securing the ignition switch surround and remove the surround.

Disconnect the block connectors for the ignition switch and the switchgear harnesses.

Remove the pinch bolts securing the universal joint to the upper and lower steering columns.

Disconnect the horn electrical feed from the column.

Slacken the two setscrews securing the lower end of the column to the mounting struts.

Release the upper mounting bolts and recover distance pieces and washers.

Supporting the column by hand, remove the lower mounting setscrews and withdraw the column.

## Dismantling the Upper Column

Remove the upper switch cover.

Slacken the screw securing the switchgear to the column. Make a note of the position of the switches and slide the assembly from the column.

Using a suitable punch, remove the two shear bolts securing the ignition switch and lock assembly to the column (Fig. 19).

Remove the bolts securing the horn feed contact assembly to the column mounting bracket.

Remove the feed and contact units from the column.

**NOTE:** No further overhaul of the column is possible.




Fig. 19

### Assembling the Upper Column

This operation is the reverse of the dismantling procedure. Ensure that the switch gear is fitted in the correct position. Refit the ignition switch and lock assembly using new shear head bolts. Tighten until the heads shear off.

### Fitting the Upper Column

Position the column in the car. Fit but do not fully tighten the lower mounting bolts.

Fit the upper mounting bolts, spacers and washers; do not fully tighten the bolts.

Adjust the column so that the upper section is in the centre of the cutout in the fascia and the groove on the lower portion of the inner splined shaft aligns with the bolt locating hole of the universal joint.

Tighten the upper and lower mounting bolts to the correct torque.

Refit the pinch bolts securing the universal joint to the upper and lower steering columns.

Reconnect the block connectors for the ignition switch and the switchgear harnesses.

Refit the instrument panel (module) and secure to the fascia. Refit the driver's side dash lower casing.

### Assembling the Steering Column Adjusting Clamp

Slightly smear the splined steering wheel shaft with grease.

Fit the split collet (1, Fig. 20) to the shaft, ensure that the screw locating hole (2, Fig. 20) aligns with the groove (3, Fig. 20) in the shaft.

Fit and tighten the grub screw and back off half a turn. The split collet should slide freely along the shaft splines.

Position the lock ring collar (4, Fig. 20) over the split collet and secure with the circlip (5, Fig. 20).

Refit the collet adaptor (6, Fig. 20) to the locking right collar. Refit the 'U' plate (7, Fig. 20) to the collet adaptor, and secure with the three screws.

Refit the impact rubber (8, Fig. 20) to the steering wheel shaft, refit the steering wheel. Ensure that the split cones (9, Fig. 20) are refitted. Fit the plain washer and fit and tighten the self locking nut.

### Refitting the Steering Wheel Assembly

Centralise the horn slip ring needle (10,

Fig. 20) in the upper column and slide the steering wheel shaft into the column.

Make sure that the front wheels and the steering wheel are set in the straight ahead position. Also ensure that the tongue on the collet adaptor aligns with the groove in the nylon bush.

Tighten the grub screw (11, Fig. 20) in the collet adaptor finger tight only. Tighten the locknut (12, Fig. 20).

Fit and tighten the clamp bolt and nut (13, Fig. 20).

Refit the horn contact rod (14, Fig. 20) to the upper column. Tighten the nylon nut onto the top of the steering wheel shaft. Secure the horn pad to the steering wheel with the two self tapping screws.

Refit the lower switch cover to the column. Reconnect the battery earth cable.




Fig. 20

### LOWER STEERING COLUMN SEAL

#### Renew

#### Removing the Universal Joint

Remove the pinch bolts (1, Fig. 21) securing the steering column universal joint to the upper and lower steering columns.

Set the wheels and the steering wheel in the straight ahead position.

Remove the universal joint, (2, Fig. 21) first from the upper column, then from the lower column.

#### Removing the Lower Steering Column

Cut and remove the 'Oetika' clip (3, Fig. 21) securing the nylon draft (4, Fig. 21) excluder to the lower column and remove the draft excluder.




Fig. 21

J57 057

## STEERING

Remove the pinch bolt (5, Fig. 21) securing the lower universal joint (part of the lower column) to the steering rack pinion shaft. Remove the lower column assembly (6, Fig. 21).

### Renewing the Lower Column Seal and Bush

Remove the three self tapping screws (7, Fig. 21) securing the gaiter retainer (8, Fig. 21) to the bulkhead.

Remove the retainer, gaiter and nylon bush (9, Fig. 21).

Check the bush for wear and the gaiter for splits or perishing, and renew as necessary. Fit the gaiter to the bulkhead, secure in position with the retainer and self tapping screws.

### To Refit the Lower Column and Universal Joint

Reverse the removal procedure. Fit the nylon draft excluder with the flanged end first and secure with a new 'Oetika' clip.

When fitting the universal joint, ensure that the road wheels and the steering wheel are set in the straight ahead position.

Refit and tighten the pinch bolts.

## POWER STEERING RACK

### Overhaul

**Service Tools:** Ball joint separator JD 24 +2 in long  $\frac{1}{2}$  in UNF socket headed (grub) screw. Rack checking fixture JD 36A. Plugs for pipe connections. End housing 'C' nut remover S355. Pinion ring expansion sleeve 606602. Pinion ring compression sleeve 606603 (JD33). Pinion housing seal saver 18G 1259. Rack centralising tool, Jaguar Part No. 12297.

### Steering Rack Remove

Slacken the power steering fluid reservoir filler cap. Raise the car and support; detach both the hoses from the pinion housing. Collect the escaping fluid in a suitable container. Blank off all ports and hoses.




Fig. 22

J57-043A

Separate the ball joints from the steering arms, using Service Tool JD 24 (Fig. 22).

**NOTE:** It may be necessary to substitute a 2 in long  $\frac{1}{2}$  in UNF socket headed (grub) screw, for the existing bolt of JD 24.

Remove the pinch bolt (1, Fig. 23) securing the lower steering column universal joint, to the rack pinion.




Fig. 23

J57-045

Remove the bolt, washer and self locking nut, securing the steering rack top mounting (pinion side of rack assembly) (2, Fig. 23), to the crossmember.

Remove both the rack bottom mounting bolts, washers and nuts, securing the steering rack to the crossmember.

**CAUTION:** Make a careful record of the number and position of the packing washers for refitting.

Release the steering rack from the crossmember and retrieve the packing washers.

### Steering Rack Dismantle

Thoroughly clean the exterior of the steering rack.

Remove the blanking plugs from the pinion housing ports and purge any remaining fluid by turning the pinion gently from lock to lock. Centre the pinion gear and note the location of the pinchbolt groove.

Remove the rack mounting rubbers and sleeves.

Release the nuts securing the feed pipes to the pinion valve housing and the rack body; remove the pipes from the rack assembly.

Remove the sealing washer from the port in the pinion end rack housing.




Fig. 24

J57 070

Make a note of their position and release the two large clips (1, Fig. 24) securing the tie rod gaiters to the pinion and end housings. Pull back the gaiters (2, Fig. 24) to allow access to the inner ball joint assemblies.

**NOTE:** Do not disturb the outer ball joints, unless replacement is necessary.

If the outer ball joints are to be renewed, measure accurately and record the total length of each tie rod, before releasing the locknuts. This will assist when re-tracking the car.

Knock back the tab washers (3, Fig. 24) securing the inner ball joint assembly locknuts to the rack.

**CAUTION:** Do not disturb the tab washers between the locknuts and the ball pin housings.


Hold one inner ball joint assembly (4, Fig. 24) with a suitable spanner and release the opposite one.

Protect the rack teeth and back of the rack; clamp the rack to enable the other inner ball joint to be released.

Unscrew the tie rod assemblies from the rack. Collect the springs and packing pieces (5, Fig. 24).

Release the locknut securing the rack damper; remove the nut, threaded plug, spring and rack damper pad.

**NOTE:** If the rack damper adjustment is satisfactory and the rack damper assembly does not require overhauling then remove the two bolts and lift off the plate; remove the 'O' ring, spring and rack damper pad (Fig. 25).




J57 072

Fig. 25

### Pinion Valve and Housing

Remove the three self locking nuts securing the pinion and valve assembly to the pinion end rack housing. Note the relationship of the ports to the rack and remove the complete pinion and valve assembly (1, Fig. 26).



J57 074

Fig. 26

Remove the sealing ring (2, Fig. 26) the pinion seal (3, Fig. 26) and the backing washer (4, Fig. 26).

Using a suitable mallet gently tap the pinion valve from the pinion valve housing.

Remove the circlip washer and ball bearing race, from the valve assembly, if a replacement is necessary.

**NOTE:** The pinion valve cannot be dismantled further. This item must be replaced as a complete assembly.

### Port Inserts Renew

Tap a suitable thread in the bore of the insert (1, Fig. 27).

Insert a setscrew (2, Fig. 27) with attached nut (3, Fig. 27) and distance piece (4, Fig. 27).




Fig. 27

Tighten the nut and withdraw the insert.

Ensure that all swarf and metal particles are completely removed.

Fit a new insert into each port and tap home squarely using a soft mandrel.

### End Housing

Release the small hexagon socket grub screw (1, Fig. 28) in the end housing.

Using Service Tool S355, unscrew the ring nut from the end housing (2, Fig. 28). Remove the end housing (3, Fig. 28) from the rack tube.

Remove the air transfer pipe and sealing rings (4, Fig. 28), from both the pinion and end housings.




Fig. 28

### Rack and Inner Sleeve

Remove the hexagon socket grub screw (1, Fig. 29) from the pinion end rack housing and collect the sealing washer (2, Fig. 29).

Remove the rack complete with the inner sleeve (3, Fig. 29) from the bore of the rack tube.

**NOTE:** Removal of the inner sleeve over the rack teeth will destroy the seal (6, Fig. 29).

Bend up the retaining tabs on the seal cap (4, Fig. 29) and remove the cap from the inner sleeve.

Remove the seal 'O' ring (5, Fig. 29), seal (6, Fig. 29) and split bearing (7, Fig. 29).

Remove the rubber 'O' ring (8, Fig. 29) and nylon washer (9, Fig. 29) from the bottom of the rack tube.




Fig. 29

The piston cannot be removed from the rack but the piston ring (1, Fig. 30) and the backing ring (2, Fig. 30) can be renewed.




Fig. 30

The rack tube cannot be removed from the plain (pinion end) rack housing, but the ring nut (2, Fig. 28) and circlip (5, Fig. 28) can be renewed. Exercise caution, when removing and replacing the circlip over the ground sealing outer diameter of the rack tube.

### Renewing Seals

Discard all the old seals, and the inner sleeve seal retaining cap.

Thoroughly clean and inspect each item for surface damage and wear.

For efficient sealing it is essential that all seal surfaces, lead chambers etc., are smooth, with no scratches or score marks.

### Re-assembling — Inner Sleeve and Rack Bar

Fit a new backing ring and piston ring to the piston, and ensure that it moves freely in its groove.

Place a new seal retaining cap over the rack teeth, with the three tabs facing away from the piston.

Fit a new split bearing in the recess in the inner sleeve, ensure that it is seated correctly.

To protect the new inner sleeve seal from being damaged by the rack teeth; cover the rack teeth with a piece of suitable plastic adhesive tape, placed lengthways over the teeth.

Carefully slide the seal, with the recessed face towards the piston, over the tape and onto the rack bar.

Remove the tape.

Fit a new 'O' ring in its recess in the inner sleeve, ensure that it seats correctly.

Ensure that the ends of the split bearing are on the opposite side of the rack bar to the teeth and push the inner sleeve along the

rack bar. Carefully push the seal up against the retaining cap and in turn, against the piston.

Ensure that the inner sleeve is square to the piston; continue pushing until the seal is fully home.

Maintain the pressure against the piston and neatly bend the three tangs into the groove on the outside of the inner sleeve, securing the retaining cap.

Apply a smear of silicone to the bore of the new square section sealing ring. Fit the nylon backing washer (9, Fig. 29) and sealing ring (8, Fig. 29) into the bore of the rack tube; slide them all the way down until they contact the pinion end main housing.

Assemble the rack bar, with the inner sleeve still against the piston, into the rack tube bore. Guide the piston ring into the rack tube bore, until the inner sleeve enters the sealing ring and seats firmly against the pinion end rack housing.

Look into the hexagon socket screw hole and ensure that the retaining shoulder has passed the hole. Fit the sealing washer and socket grub screw (1 & 2, Fig. 29). After tightening, it should fit flush to slightly proud, stake in position.

### End Housing

Remove the seal (1, Fig. 31) and 'O' ring (2, Fig. 31) using a suitable sharp instrument.

With a suitable soft metal drift, carefully remove the steel retaining washer (3, Fig. 31).

Fit a new 'O' ring in the recess, pushing a new seal with the groove uppermost, on to the top of the 'O' ring; replace the steel retaining washer with the spigot towards the seal and press home.

Fit a new square section sealing ring (4, Fig. 31) into the end housing; smear the sealing ring bore, with a silicone lubricant, to aid assembly.

Fit new air transfer pipe sealing rings (5, Fig. 31) to the pinion and end housings. Fit the air transfer pipe to the pinion rack housing.

Fit the end housing over the rack bar, taking care to align it, to avoid damaging the end housing seal.

Slide the end housing onto the rack tube with a slightly twisting action. Engage the air transfer pipe in to its port. Align the end housing mounting lug (6, Fig. 31) with the lower cut out of the rack tube. Tighten the 'C' nut using Service Tool S355, to the correct torque.

Refit the hexagon socket grub screw. Tighten and stake in position.




Fig. 31

J57 068



## Pinion Valve and Housing

To remove the seals from the pinion, use a sharp knife and cut diagonally, taking care not to damage the groove ends.

Using Service Tool 606602, to expand the seals, fit one in the groove nearest to the ball bearing race. Repeat the procedure for the other three seals.

The rings can then be compressed to their original size by fitting a sleeve over them. Use 606603. If this tool is not available, then recovery will take place naturally if left for about  $\frac{3}{4}$  hour.

Fit the washer and 'U' section seal, into the pinion main housing, ensure that the grooves in the seal face upwards and that the seal flange fits snugly in the groove.

## Valve Housing

Using suitable circlip pliers remove the circlip (1, Fig. 32). Remove the seal retainer (2, Fig. 32) and the seal (3, Fig. 32).




Fig. 32

Fit a new seal, grooved face downwards. Ensure that the flange sits snugly in the recess. Fit the seal retainer, with the rubber side and lip outermost. Fit the circlip, ensure that it is seated fully in the groove.

Smear the seals with a little clean power steering fluid. Fit the taper seal saver 18G 1259 over the serrations on the pinion valve, and enter the pinion valve into the pinion valve housing. Press the ball bearing race fully home.

Refit the rack damper assembly. Ensure that the threaded plug is slack. Remove the grease nipple from the plug, and centralise the rack using Service Tool 18G 1466 or Jaguar part number 12297 (Fig. 33).

Refit the pinion valve assembly to the pinion rack housing, ensure that the coupling groove in the pinion is in the correct position. Fit and tighten the three self locking nuts.




Fig. 33

Adjust the rack damper pad assembly to obtain the correct end float. Tighten the locknut and refit the grease nipple.

Fit a new sealing washer to the port in the pinion end rack housing. Fit and tighten the feed pipes to the pinion valve housing and rack body. Do not overtighten the pipe nuts as irreversible damage could be caused to the pipes.

## Tie Rods

Refit the new tab washers to the rack, dished face outermost. Screw on the tie rods. Holding one ball joint and tighten the opposite ball joint (one joint should react against the other). Do not restrain the rack assembly. Secure the tab washers in four places against the spanner flats.

Regrease the ball joint areas and replace any lost from the gaiters. Each gaiter should contain 57 gms (2 oz) of grease.

Fit the gaiters and secure with the clips, ensuring that the clips are in their correct position.

## Refitting the Steering Rack

Ensure that the steering wheel is set to the straight ahead position and refit the rack.

Fit the lower coupling to the pinion. Ensure that the single rack mounting lug is shimmed so that it is central between the cross-beam brackets. This is achieved by fitting shims between the faces of the steel/rubber washers and the bracket. Check that a gap of 2.5 to 3.0 mm (0.10 to 0.12 in) exists between the face of the rubber thrust washers and the single lug of the rack.

Insert the mounting bolts, fit but do not fully tighten the nuts.

Slacken the clips securing the rubber gaiters to the rack housing, pull the gaiters (1, Fig. 34) clear of the inner ball joint assemblies.

Locate the two attachment brackets of Service Tool JD 36A on the heads of the lower wishbone fulcrum shaft bolts (2, Fig. 34).




Fig. 34

Release the locking screw (3, Fig. 34) on the forward arm of the tool and position the slide so that the slot engages with the front welded flange of the cross beam. Tighten the lock screw.

Rotate the alignment legs (4, Fig. 34) of the tool until one or both rest on the rack shaft.

Adjust the position of the rack if necessary, until both legs are in contact with the rack shaft.

Tighten the nuts of the mounting bolts to secure the rack in this position. Remove Service Tool JD 36A.

Refit the rubber gaiters and secure with the clips.

Refit the ball joints to the steering arms and secure with the nyloc nuts.

Remove the blanking plugs and connect both fluid hoses to the pinion housing.

Refit the pinch bolt and nut to the lower universal coupling.

Refill the system with the recommended fluid and carry out the bleed procedure.

Check the front wheel alignment.

## NOTE:

(A) It is important that the distance between the rubber faces of the thrust washers and the adjacent rack lug should in no case be less than 2.5 mm (0.1 in). This is to allow adequate 'rack' compliance in either direction.

(B) If a replacement rack unit is to be fitted it may be necessary to detach the lower column from the upper column at the universal joint, to obtain correct centralisation.

## STEERING PUMP

### Overhaul

Service Tools: Drive dog remover/replacer 18G 1445.

### Steering pump removal

Open the bonnet.

Remove the cap from the hydraulic fluid reservoir. Disconnect the inlet hose (1, Fig. 35) from the pump, and drain the fluid into a suitable container.




Fig. 35

Blank off the hose and pump inlet to prevent the ingress of dust and dirt.

**CAUTION: Under no circumstances must the fluid be reused.**

Replace the fluid reservoir cap.

Disconnect the rack feed hose (2, Fig. 35) from the pump outlet, remove and discard the 'O' ring seal.

Remove the three bolts (3, Fig. 35) securing the pump mounting adaptor to the cylinder block and remove the pump assembly.

Blank off the hose and port to prevent the ingress of dust and dirt.

Remove the drive coupling.

Remove the three bolts (4, Fig. 35) securing the steering pump to the pump adaptor and remove the pump.

## Steering Pump Dismantle

**NOTE:** Absolute cleanliness and extreme care are essential when overhauling the pump. This operation should not be entrusted to inexperienced mechanics.

If any doubt exists as to the necessity of the replacement of partly worn items, they should be replaced, as pump overhaul is not specified in the routine maintenance schedule.

Thoroughly clean the exterior of the pump. Remove the plugs, drain and discard the fluid.




Fig. 37

Using Service Tool 18G 1445 remove the drive dog from the pump shaft (see Fig. 37).




Fig. 38

Insert a suitable punch (1, Fig. 38) in the hole in the rear of the pump body and dislodge the spring ring.

Extract the ring with a screwdriver (as shown 2, Fig. 38).

If the endplate is not ejected by the spring pressure, a light tap on the casing should free it.

Extract the endplate 'O' ring seal (13, Fig. 36) from the pump body and discard.

**NOTE:** Examine the exposed portion of the driveshaft. If it is corroded, thoroughly clean it with crocus cloth. This will prevent damage being caused to the shaft bushing when tapping the shaft through.

If the shaft bushing is damaged, then replacement of the entire pump housing will be necessary.

Lightly tap the shaft (1, Fig. 36) through the pump body, carrying the pump rotor assembly with it.


Extract the other 'O' ring seal (12, Fig. 36) from the pump body and discard.

Carefully separate the pump rotor components.

Remove the circlip (8, Fig. 36) and withdraw

the rotor (6, Fig. 36) and thrust plate (5, Fig. 36) from the shaft.

Extract the drive shaft oil seal (2, Fig. 36) using a suitable drift.



J57 075

Fig. 36

### KEY TO FIG. 36

- |                     |                             |
|---------------------|-----------------------------|
| 1. Drive shaft      | 10. Pressure plate          |
| 2. Drive shaft seal | 11. Pressure plate spring   |
| 3. Pump body        | 12. Pump ring 'O' ring seal |
| 4. Dowel pins       | 13. End plate 'O' ring seal |
| 5. Thrust plate     | 14. End plate               |
| 6. Pump rotor       | 15. End plate spring ring   |
| 7. Pump rotor vanes | 16. Outlet connector        |
| 8. Circlip          | 17. 'O' ring seal           |
| 9. Pump ring        | 18. Control valve           |
|                     | 19. Control valve spring    |

## Inspection

Clean all the components; carefully inspect for any signs of wear and damage.

Light scoring of the thrust and pressure plates can be removed by lapping.

If the pump ring or vanes show signs of chattering or grooving, then they must be renewed.

Scuff marks and light universal wear are acceptable.

Check the control valve for free movement; remove any burrs and renew the valve if it is at all faulty.


Check the shaft in the bush; it should run freely and no excessive sideways movement should be evident.

Measure the external diameter of the shaft and the internal diameter of drive dog. There **MUST** be an interference fit of 0.025 to 0.066 mm (0.001 to 0.0026 in) between the drive dog and the shaft.

## Steering Pump Assemble

Fit a new shaft seal to the pump housing, lightly smear with petroleum jelly and insert the shaft, splined end first.

Fit the dowel pins (1, Fig. 39). Fit the thrust plate, ensure that the port face is facing outwards (2, Fig. 39) over the dowel pins.



J57 063

Fig. 39

continued




Fig. 40

Fit the rotor (Fig. 40) counterboard face first, to the shaft splines and secure with a new circlip. Do not overstretch the circlip.




Fig. 41

Slide the pump ring (1, Fig. 41) over the dowel pins; ensure that the rotation arrow is visible (arrowed Fig. 41).




Fig. 42

Fit the vanes in the slots in the rotor with their radiused edges outermost (Fig. 42). Lightly smear the new pressure plate 'O' ring seal with petroleum jelly and insert in the groove of the pump housing. Fit the pressure plate (1, Fig. 43) with the spring recessed face outermost and press firmly in to the 'O' ring seal.

Lightly smear the other new 'O' ring seal with petroleum jelly and insert into the outer groove of the pump housing.




Fig. 43

Refit the spring and place the end plate in position. Place the spring ring (1, Fig. 44) with the gap away from the extractor hole in the pump body.

Place the assembly under a press (2, Fig. 44) and carefully depress the end plate until the spring ring can be sprung into the groove.




Fig. 44

Reassemble the control valve (Fig. 45) and refit to the outlet port.




Fig. 45

Using Service Tool 18G 1445 refit the drive dog to the shaft (see Fig. 46).




Fig. 46

## Steering Pump Refitting

Refit the steering pump mounting adaptor to the pump and secure with the three bolts. Clean the drive coupling faces, check for wear or damage and renew as necessary. Locate the coupling in the drive dog and refit the pump assembly to the engine. Ensure that the drive coupling engages with the distributor drive shaft.

Secure the pump mounting adaptor to the cylinder block with the three bolts.

Fit a new 'O' ring seal to the pump outlet port, remove the blanking plug from the rack feed hose and secure the hose union to the pump. Tighten to the correct torque.

Remove the blanking plug from the pump inlet hose, refit the hose to the pump inlet and secure with the hose clip.

Refill the fluid reservoir with fluid of the correct specification.

Bleed the system and carry out a system check.


## KEY TO EXPLODED VIEW OF STEERING RACK

1. Wavy washer
2. Dust shield
3. Circlip
4. Seal retainer
5. Pinion upper seal
6. Pinion valve housing
7. Locknut
8. Studs
9. Pinion valve
10. Valve housing 'U' seal
11. Ball bearing race
12. Washer
13. Circlip
14. Pinion lower seal
15. Washer
16. Bush
17. Gaiter clip, small
18. Rubber gaiters
19. Gaiter clip, large
20. Sealing washer
21. End housing fluid feed pipe
22. Outer ball joint locknut

23. Outer ball joints
24. Self locking nut
25. Tie rod
26. Inner ball joint
27. Packing washer
28. Thrust spring
29. Inner ball joint tab washer
30. Rack bar
31. Backing ring
32. Piston ring
33. Piston
34. Fluid feed and return pipes
35. Thrust spring
36. Rack damper retainer plate
37. Spring washers
38. Set bolts
39. Threaded plug
40. Locknut
41. Grease nipple
42. 'O' ring seal
43. Rack damper
44. Grub screw
45. Sealing washer
46. Rack housing — pinion end
47. Sealing washer

48. 'C' nut
49. Retaining circlip
50. Backing washer
51. Seal
52. Inner sleeve
53. Split bearing
54. Seal
55. 'O' ring
56. Retaining cap
57. End housing 'U' seal
58. Retaining washer
59. Seal
60. 'O' ring
61. Grub screw
62. Rack tube alignment set bolt
63. Sealing washer
64. End housing
65. Air transfer pipe

Fig. 47



CONTENTS

| Operation  | Operation No. | Page No. |
|--|---------------|----------|
| Anti-roll bar — Renew .....                            | 60.10.01      | 60—5     |
| Anti-roll bar mounting rubbers — Renew .....           | 60.10.05      | 60—5     |
| Anti-roll link and bushes — Renew .....                | 60.10.02      | 60—5     |
| Ball-joint, lower — Overhaul .....                     | 60.15.13      | 60—7     |
| Ball-joint, lower — Adjust .....                       | 60.15.04      | 60—7     |
| Ball-joint, upper — Renew .....                        | 60.15.02      | 60—8     |
| Bump stop — Renew .....                                | 60.30.10      | 60—9     |
| Description .....                                      | —             | 60—2     |
| Dimensional data .....                                 | —             | 60—3     |
| Exploded view of the front suspension components ..... | —             | 60—11    |
| Front dampers — Renew .....                            | 60.30.02      | 60—5     |
| Front hub bearings — Renew .....                       | 60.25.14      | 60—6     |
| Front hub assembly — Remove and refit .....            | 60.25.01      | 60—6     |
| Front hub bearings, endfloat — Check/adjust .....      | 60.25.13      | 60—6     |
| Front hub grease seal — Renew .....                    | 60.25.15      | 60—6     |
| Front wheel studs — Renew .....                        | 60.25.29      | 60—6     |
| Front stub axle carrier — Renew .....                  | 60.25.23      | 60—6     |
| Front stub axle — Renew .....                          | 60.25.22      | 60—6     |
| Rebound stops — Renew .....                            | 60.30.14      | 60—8     |
| Suspension unit, mounting bushes — Renew .....         | 60.35.06      | 60—9     |
| Suspension unit, rear mounting — Renew .....           | 60.35.07      | 60—9     |
| Torque wrench settings .....                           | —             | 60—2     |
| Wishbone, lower — Overhaul .....                       | 60.35.09      | 60—9     |
| Wishbone, lower — Remove and refit .....               | 60.35.02      | 60—9     |
| Wishbone, upper — Overhaul .....                       | 60.35.08      | 60—10    |
| Wishbone, upper — Remove and refit .....               | 60.35.01      | 60—10    |

## FRONT SUSPENSION

### TORQUE WRENCH SETTINGS

| ITEM                                  | DESCRIPTION                | SPANNER SIZE           | TIGHTENING TORQUE |                |           |
|---------------------------------------|----------------------------|------------------------|-------------------|----------------|-----------|
|                                       |                            |                        | Nm                | kgf/cm         | lbf/ft    |
| Anti-roll bar bracket to body         | $\frac{3}{8}$ in UNF nut   | $\frac{9}{16}$ in AF   | 37 to 43          | 3,74 to 4,42   | 27 to 32  |
| Anti-roll bar to link                 | $\frac{3}{8}$ in UNF nut   | $\frac{9}{16}$ in AF   | 19 to 24          | 1,94 to 2,48   | 14 to 18  |
| Anti-roll bar link to lower wishbone  | $\frac{3}{8}$ in UNF nut   | $\frac{9}{16}$ in AF   | 19 to 24          | 1,94 to 2,48   | 14 to 18  |
| Brake caliper to stub axle carrier    | M12 bolt                   | 19 mm                  | 68 to 81          | 6,91 to 8,29   | 50 to 60  |
| Brake disc to hub                     | $\frac{7}{16}$ in UNF bolt | $\frac{5}{8}$ in AF    | 41 to 54          | 4,2 to 5,54    | 30 to 40  |
| Bump stop to spring pan               | $\frac{5}{16}$ in UNF nut  | $\frac{1}{2}$ in AF    | 11 to 14          | 1,11 to 1,38   | 8 to 10   |
| Clamp and shield to stub axle carrier | $\frac{1}{4}$ in UNF nut   | $\frac{7}{16}$ in AF   | 6 to 8            | 0,69 to 0,83   | 5 to 6    |
| Clamp, crossbeam front mounting       | $\frac{1}{2}$ in UNF nut   | $\frac{3}{4}$ in AF    | 34 to 41          | 3,46 to 4,14   | 25 to 30  |
| Damper mounting bracket to wishbone   | $\frac{3}{8}$ in UNF nut   | $\frac{9}{16}$ in AF   | 37 to 43          | 3,74 to 4,42   | 27 to 32  |
| Damper mounting, lower                | $\frac{7}{16}$ in UNF nut  | $\frac{11}{16}$ in AF  | 61 to 68          | 6,23 to 6,91   | 45 to 50  |
| Damper mounting, upper                | $\frac{3}{8}$ in UNF nut   | $\frac{9}{16}$ in AF   | 37 to 43          | 3,74 to 4,42   | 27 to 32  |
| Front mounting bolt                   | $\frac{3}{4}$ in UNF nut   | $1\frac{1}{8}$ in AF   | 129 to 156        | 13,14 to 15,91 | 95 to 115 |
| Fulcrum shaft, lower                  | $\frac{9}{16}$ in UNF nut  | $\frac{7}{8}$ in AF    | 43 to 68          | 4,43 to 6,91   | 32 to 50  |
| Fulcrum shaft, upper                  | $\frac{1}{2}$ in UNF nut   | $\frac{3}{4}$ in AF    | 61 to 75          | 6,23 to 7,60   | 45 to 55  |
| Lower ball joint to lower wishbone    | $\frac{9}{16}$ in UNF nut  | $\frac{7}{8}$ in AF    | 75                | 7,60           | 55        |
| Lower ball joint to stub axle carrier | $\frac{5}{16}$ in UNF bolt | $\frac{1}{2}$ in AF    | 20 to 27          | 2,08 to 2,76   | 15 to 20  |
| Rear mounting to body                 | $\frac{3}{8}$ in UNF bolt  | $\frac{9}{16}$ in AF   | 30 to 35          | 3,05 to 3,59   | 22 to 26  |
| Rear mounting to crossbeam            | $\frac{3}{8}$ in UNF nut   | $\frac{9}{16}$ in AF   | 19 to 24          | 1,94 to 2,48   | 14 to 18  |
| Rebound stops to upper wishbone       | $\frac{5}{16}$ in UNF bolt | $\frac{5}{8}$ in AF    | 11 to 14          | 1,11 to 1,38   | 8 to 10   |
| Spring pan to lower wishbone          | $\frac{3}{8}$ in UNF bolt  | $\frac{9}{16}$ in AF   | 37 to 43          | 3,74 to 4,42   | 27 to 32  |
| Steering arm to stub axle carrier     | M12 bolt                   | 19 mm                  | 108 to 122        | 6,91 to 7,60   | 50 to 55  |
| Stub axle to carrier                  | $\frac{5}{8}$ in UNF nut   | $1\frac{15}{16}$ in AF | 37 to 43          | 11,1 to 12,4   | 80 to 90  |
| Upper ball joint to stub axle carrier | $\frac{1}{2}$ in UNF nut   | $\frac{3}{4}$ in AF    | 47 to 68          | 4,84 to 6,91   | 35 to 50  |
| Upper ball joint to wishbone          | $\frac{3}{8}$ in UNF bolt  | $\frac{9}{16}$ in AF   | 35 to 43          | 3,60 to 4,42   | 26 to 32  |
| Upper fulcrum shaft to spring turret  | $\frac{7}{16}$ in UNF nut  | $\frac{11}{16}$ in AF  | 66 to 75          | 6,78 to 7,60   | 49 to 55  |
| Wheel nuts                            | $\frac{1}{2}$ in UNF stud  | $\frac{7}{8}$ in AF    | 89 to 99          | 9,1 to 10,4    | 65 to 75  |

### DESCRIPTION

The front suspension is fitted to the car as a complete unit. It comprises a fabricated sheet steel crossmember, mounted to the Body/Chassis structure at four points.

The two longitudinal members are attached to brackets at the front end of the chassis side member with rubber/steel mountings.

The crossmember has a turret welded at each end, which houses a coil spring. The spring is retained at its lower end by a seat pan, bolted to a lower wishbone.

The lower wishbone is a one piece forging, attached at the inner end to the crossmember, by rubber/steel bonded bushes, and at the outer end by a lower ball

joint assembly, attached to a stub axle carrier.

Upper wishbone levers, steel forged, are mounted at their inner ends to a fulcrum shaft on rubber/steel bonded bushes. The fulcrum shaft is bolted to the spring turret. The outer ends of the wishbone are attached to the stub axle carrier by an upper ball joint.

The wheel hub is supported on two taper roller bearings, the inner races of which fit on the stub axle shaft, located in a tapered hole bored in the stub axle carrier.

An anti roll bar, fitted between the two lower wishbones, is attached to the chassis side members by rubber insulated brackets.

## DIMENSIONAL DATA


The following dimensional drawings are provided to assist in assessing accidental damage. A component suspected of being damaged should be removed from the car, cleaned off and the dimensions checked and compared with those given in the appropriate illustration.

Components found to be dimensionally inaccurate, or damaged in any way MUST be scrapped and NO ATTEMPT made to straighten and re-use.

### Dimension — Lower Wishbone

- A. 225,30 to 225,81 mm (8.87 to 8.89 in)
- B. 244,35 to 244,60 mm (9.62 to 9.63 in)
- C. 177,67 to 177,93 mm (6.995 to 7.005 in)
- D. 5,84 to 6,35 mm (0.23 to 0.25 in)
- E. 60,20 to 60,45 mm (2.37 to 2.38 in)
- F. 34,67 to 35,18 mm (1.365 to 1.385 in)
- G. 353,82 to 354,33 mm (13.93 to 13.95 in)
- H.  $6^\circ \pm 0^\circ 30'$
- J. 23,11 to 23,37 mm (0.91 to 0.92 in)
- K. 26,67 to 27,18 mm (1.05 to 1.07 in)
- L. 21,08 to 21,59 mm (0.83 to 0.85 in)
- M. 33,20 to 33,45 mm (1.307 to 1.317 in)

Fig. 1




J57-039

### Dimension — Stub Axle Carrier

- A. 81,28 to 81,78 mm (3.26 to 3.22 in)
- B. 42,68 to 43,18 mm (1.68 to 1.70 in)
- C. 0,8 to 1,0 mm (0.03 to 0.04 in)
- D. 19,02 to 19,07 mm (0.749 to 0.751 in)
- E.  $70 \pm 0^\circ 30'$  Total taper.
- F. 25,4 mm (1.0 in)
- G. 100,09 to 100,59 mm (3.94 to 3.96 in)
- H.  $5^\circ \pm 0^\circ 30'$
- I.  $88^\circ \pm 0^\circ 30'$
- J. 148,91 to 149,41 mm (5.86 to 5.88 in)
- K. 31,76 to 32,26 mm (1.25 to 1.27 in)
- L. 88,65 to 89,15 mm (3.49 to 3.51 in)
- M. 112,3 to 115,3 mm (4.42 to 4.54 in)
- N. 70,85 to 71,35 mm (2.79 to 2.81 in)
- P. 58,93 to 59,43 mm (2.32 to 2.34 in)

Fig. 2




J57-040

## FRONT SUSPENSION

### Dimension — Upper Wishbone Arm — Front

- A. 60,20 to 60,71 mm (2.37 to 2.39 in)
- B. 161,44 to 161,95 mm (6.356 to 6.376 in)
- C. 44,2 to 44,7 mm (1.74 to 1.76 in)
- D. 31,50 to 31,75 mm (1.24 to 1.25 in)

Fig. 3





J57-041

### Dimension — Upper Wishbone Arm — Rear

- A. 44,2 to 44,7 mm (1.74 to 1.76 in)
- B. 161,44 to 161,95 mm (6.356 to 6.376 in)
- C. 44,2 to 44,7 mm (1.74 to 1.76 in)
- D. 31,50 to 31,75 mm (1.24 to 1.25 in)

Fig. 4



J57-045



## ANTI-ROLL BAR LINK BUSHES

### Renew

Jack up the front of the car and place on stands.

Remove the upper self locking nut (1, Fig. 5), special washer and rubber bush, securing each end of the anti-roll bar to the anti-roll bar links. Remove the lower self locking nut (2, Fig. 5) special washer and rubber bush, securing each end of the anti-roll bar link to the anti-roll bar support brackets.




Fig. 5

Remove each link in turn, recover two spacer tubes, rubber bushes and special washers from each link.

Inspect the rubber bushes, renew if any wear or damage is evident.

Reverse the above procedure, but do not fully tighten the fixings until the car is resting on its wheels.

## ANTI-ROLL BAR

### Renew

**Service Tools:** JD24 Steering Joint Separator, and  $\frac{1}{2}$ in UNF socket headed (grub) screw 2in long.

Jack up the front of the car and place on stands. Leave the jack in position under the front suspension crossmember.

Remove both front wheels.

Remove the plastic drive fasteners securing the wheel arch front dust shields, and




Fig. 6

screws and plastic drive fasteners securing the spoiler undertray to the body and spoiler.

Remove the nut securing the LH steering tie rod to the steering arm, and using service tool JD24 detach the tie rod from the steering arm (Fig. 6).

**NOTE:** When using JD24 Steering Joint Separator, substitute a 2in long  $\frac{1}{2}$ in UNF socket headed (grub) screw for the existing bolt.

Remove the self locking nuts, special washers and rubber bushes securing each end of the anti-roll bar, to the anti-roll bar links (1, Fig. 7). Ensure that the jack is supporting the front suspension crossmember, and remove the front suspension crossmember front mounting bolts.




Fig. 7

Lower the jack; collect the washers, spacers and bush sleeves.

Remove the nuts and bolts securing the anti-roll bar brackets to the front crossmember (2, Fig. 7) and detach the keeper plates.

Remove the rubbers from the anti-roll bar. Lift the anti-roll bar off the links and manoeuvre out through the LH wheel arch.

**NOTE:** The fitting of the rubber bushes will be greatly assisted if a proprietary rubber lubricant, or a liquid soap and water solution is used.

Manoeuvre the anti-roll bar into position across the car.

Lubricate the rubber bushes and position them on the anti-roll bar adjacent to the keeper plate locations, with the splits towards the rear of the car.

Fit the keeper plates and brackets, loosely secure to the front suspension cross frame.

Fit the anti-roll bar to the anti-roll bar links and fit the rubbers, special washers and self locking nuts.

Refit the steering tie rod to the LH steering arm and tighten the nut.

Raise the jack to locate the front suspension crossmember front mountings with the body. Fit bolts, washers, spacers and bush sleeves.

Tighten the nuts.

Refit the spoiler undertray using new plastic drive fasteners. Refit the two setscrews.

Refit the wheel arch front dust shields using new plastic drive fasteners.

Refit the front road wheels.

Lower the car and fully tighten the anti-roll bar links and mounting nuts.

**CAUTION:** All anti-roll bar fixings must only be tightened with the full weight of the car resting on the wheels. Premature failure of the rubber bushes could occur if this precaution is not taken.

## FRONT DAMPERS

### Renew

**NOTE:** In the event of a damper being unserviceable a replacement unit must be fitted.

Remove the locknut, nut, outer washer, rubber buffer and inner washer from the damper top mountings (1, Fig. 8), accessible from the engine compartment.




Fig. 8

To remove the LH side front damper, it is necessary to remove the air cleaner cover and element, to gain access to the top mounting.

Jack up the front of the car and place on stands.

Remove the self locking nut and bolt from the bottom mounting (2, Fig. 8). Telescope the damper and withdraw from the car.

Before fitting new dampers it is advisable to 'bleed' any air which may have accumulated in the pressure chamber due to the damper having been stored in a horizontal position. To do this, hold the damper vertically and make several strokes (not exceeding more than halfway) until there is no lost motion. Then extend the damper to its full length once or twice. Keep upright until fitted.

To fit the new dampers, reverse the above procedure, ensuring that the lower washers and rubber buffer are in position on the damper stem, before inserting through the hole in the wheel arch.

Tighten all fixings to the correct torque.

## FRONT HUB BEARINGS

### Renew

Jack up the front of the car, place on stands and remove the road wheel. Remove the bolts and washers securing the hub assembly to the brake disc. Access is gained through the aperture in the disc shield (1, Fig. 9). Remove the hub grease cap, extract the split pin; remove the nut retaining cap, nut and washer from the stub axle. (2, Fig. 9). Withdraw the hub by hand.




Fig. 9

The front hub wheel studs can be replaced using a power press and suitable mandrel, once the hub assembly has been removed from the stub axle.

Remove the grease seal (1, Fig. 10). Withdraw the inner and outer bearing races (2, Fig. 10). Taking the appropriate safety precautions, use a suitable punch to drift out the inner and outer bearing races (3, Fig. 10). Cut-outs are provided in the hub assembly abutment shoulders for this purpose.




Fig. 10

Tap replacement cups into position, ensuring that they seat squarely in the abutments.

Lubricate and fit the inner bearing. Fit a new grease seal, ensuring that it is seated squarely in position.

Pack the hub with the specified grease and fit to the stub axle.

Fit the outer bearing, washer and nut.

Adjust the bearing endfloat to 0,03 — 0,08 mm (0.001 in — 0.003 in), this is measured with a dial indicator gauge mounted with the plunger against the end of the hub.

If a gauge is not available, tighten the hub nut until there is no endfloat, i.e. when rotation of the hub is slightly restricted. (A torque of 0,691 kg/fm, (5 lb/ft), must not be exceeded or damage may be caused to the bearings and bearing tracks). Slacken the nut one flat and fit the nut retaining cap.

Fit a new split pin and bend over. Refit the grease cap, ensure that the vent hole is clear.

Refit the road wheel and lower the car.

## FRONT STUB AXLE CARRIER

### Renew

**Service Tool:** JD6G Road Spring Compressor.

Jack-up the front of the car, place on stands and remove the road wheel. Remove the brake pad retaining pin spring clips, remove the upper pin, anti-rattle springs and lower pin.

Withdraw the brake pads. Note their position for refitting.

Break the lock wire and remove the the two bolts and spring washers securing the steering arm and brake caliper to the stub axle carrier (1, Fig. 11).




Fig. 11

Move aside caliper and secure with wire or strong cord to prevent damaging the brake hose.

Remove the remaining bolt and spring washer (2, Fig. 11) securing the steering arm to the stub axle carrier.

**NOTE:** Record the number of shims fitted between the steering arm and the brake caliper.

Remove the front hub grease cap, extract the split pin, remove the nut retaining cap, and washer from the stub axle.

Withdraw the front hub and disc assembly. Using JD6G Spring Compressor, relieve the stub axle carrier of spring tension (Fig. 12).




Fig. 12

Undo and remove the nyloc nut and washer securing the upper ball joint to the stub axle carrier (3, Fig. 11), release the taper.

Undo and remove the nyloc nut and washer securing the lower ball joint to the lower wishbone (4, Fig. 11). Release the taper and remove the stub axle carrier assembly from the vehicle.

Remove the two nyloc nuts securing the clamps at the bottom of the disc shields (5, Fig. 11). Remove the attachment plate and the front and rear disc shields.

The stub axle can now be removed. Undo and remove the nyloc nut (6, Fig. 11) and washer, support the stub axle carrier, and using a suitable punch, drift out the stub axle.

If the carrier is to be renewed it is necessary to remove the lower ball joint. Bend back the tab washers and remove the four bolts securing the ball pin cap to the stub axle carrier. Discard the tab washers.




Fig. 13

### Key to Fig. 13.

1. Self-locking nut
2. Washer
3. Gaiter
4. Flexible gaiter retaining ring
5. Moulded gaiter retainer
6. Ball socket — upper
7. Ball pin
8. Ball socket — lower
9. Shim
10. Ball pin cap
11. Grease nipple
12. Washer
13. Tab washer
14. Bolts

Detach the lower ball pin cap and lower socket, remove the shims, retain for refitting, and lift out the ball pin.

Remove the gaiter flexible plastic retaining ring, and remove the gaiter.

Release the moulded plastic gaiter retainer from the upper socket. Tap the upper socket out of the stub axle carrier.

Fit the stub axle to the carrier. Secure with a new nyloc nut tightened to the correct torque.

Fit the lower ball joint upper socket to the stub axle carrier.

Fit the moulded plastic gaiter retainer, lip first, to the ball joint upper socket. Lip of the retainer must engage with the slot in the upper socket.

Fit the gaiter over the gaiter retainer and secure with the flexible plastic ring.

Fit the ball pin through the gaiter and locate in the ball joint upper socket.

Replace the shims, previously removed, fit the lower socket and ball pin cap.

Fit the four bolts and new tab washers, tighten to the correct torque. Check the adjustment of the ball pin, it should be slightly stiff in the socket when the bolts are tightened to their correct torque.

Correct adjustment of the ball pin is achieved by limiting the vertical lift of the ball pin, without lubrication, to 0,025 — 0,203 mm (0,001 — 0,008 in). When grease is added the torque required to move the ball pin must not exceed 1 Nm (9 lbf/in). This is achieved by adding or subtracting shims which are available in 0,5 mm (0,002 in) and 0,10 mm (0,004 in) thicknesses.

When this adjustment is obtained bend over the locking tabs.

Refit the disc shields and attachment plate to the stub axle assembly and refit the stub axle carrier to the vehicle.

Refit the front hub and disc assembly, ensure that the hub bearing end float is properly adjusted.

Refit the brake caliper and steering arm to the stub axle carrier, ensuring that if any shims were removed, they are refitted in their previously noted positions.

Refit the brake pads, pins, and spring clips. Remove the service tool JD6G, refit the road wheel and lower the car.

Depress the brake pedal several times to centralise the brake pads.

Carry out a front suspension geometry check.

## FRONT SUSPENSION RIDE HEIGHT

### Check and Adjust

Service tools: JD6G Spring Compressor. Slip Plates.

Ensure that the car is in its kerb weight condition i.e. full tank of fuel; engine oil and water at correct levels.

Check that the tyres are at the correct pressure.

Position the front wheels on slip plates.

Press downwards on the front bumper to depress the suspension and slowly release.

Measure the distance between the lower face of the crossbeam and the ground on both sides of the car.

Obtain values for dimension 'A' (Fig. 14), left and right hand.




Fig. 14

J76-063

The correct height is 152 mm (6 in) minimum, plus the thickness of the slip plates. If necessary, add or remove packing plates from either end of the spring to obtain this dimension.

The packing rings are 3,18 mm (0.125 in) thick, and vary the ride height by 7.93 mm (0.3125 in).

To add or remove packing rings the front road springs must be removed.




Fig. 15

J60-011

Jack up the front of the car and place on stands. Remove the appropriate road wheel. Fit Spring Compressor tool JD6G, as shown in Fig. 15. Compress the spring sufficiently to relieve the load on the spring pan fixings, and remove the fixings.

Slacken the spring compressor tool and remove with the spring pan, spring and packers.

**NOTE:** Record the quantity and position of the packers. Add or remove packers to obtain the correct ride height.

**WARNING: THE MAXIMUM NUMBER OF PACKERS THAT CAN BE FITTED TO EACH SPRING MUST NOT EXCEED FIVE, COMPRISING, THREE BELOW THE SPRING IN THE SPRING PAN AND TWO ABOVE IN THE CROSSMEMBER SPRING TURRETS.**

Assemble the spring, packers and spring pan; lift up into position in the spring turret. Retain in this position using the Spring Compressor tool JD6G.

Align the spring pan fixing holes with the tapped holes in the lower wishbone using the pilot studs.

Wind up the handle of the spring compressor tool sufficiently to compress the spring, locating the spring pan on the pilot studs, until the setscrews, nuts, bolts and washers can be fitted. Remove the pilot studs and fit the setscrews and washers.

Remove the spring compressor.

Refit the road wheel, and lower the car.

Recheck the suspension ride height as previously detailed.

## LOWER BALL JOINT

### Overhaul

Service Tools: JD6G Road Spring Compressor, JD24 Steering Joint Taper Separator, and  $\frac{1}{2}$  in socket headed (grub) screw 2 in long.

Jack up the front of the car, place on stands and remove the road wheel.

Using service tool JD6G (as shown in Fig. 15), compress the road spring sufficiently to relieve the stub axle carrier of spring pressure.

Remove the self locking nut and washer securing the tie-rod ball joint to the steering arm, and separate using service tool JD24.

**NOTE:** When using JD24 Steering Joint Separator, substitute a 2 in long  $\frac{1}{2}$  in UNF socket headed (grub) screw for the existing bolt.




Fig. 16

J57-043

continued




Fig. 17

## Key to Fig. 17.

1. Self-locking nut
2. Washer
3. Gaiter
4. Flexible gaiter retaining ring
5. Moulded gaiter retainer
6. Ball socket — upper
7. Ball pin
8. Ball socket — lower
9. Shim
10. Ball pin cap
11. Grease nipple
12. Washer
13. Tab washer
14. Bolts

Undo and remove the upper ball joint inner nut and bolt; slacken but do not remove the outer nut and bolt.

Undo and remove the nyloc nut and washer securing the lower ball joint to the lower wishbone.

Support the hub/disc assembly and release the lower ball joint taper. Swing the assembly outwards.

Knock back the tab washers securing the ball pin cap to the stub axle carrier. Remove the four bolts and tab washers, discard the tab washers. Detach the lower ball pin cap and lower socket, remove the shims, retain for refitting, and lift out the ball pin.

Remove the gaiter flexible plastic retaining ring, and remove the gaiter.

Release the moulded plastic gaiter retainer from the upper socket.

Tap the socket out of the stub axle carrier.

**NOTE:** Excessive wear in the ball pin and sockets cannot be adjusted by shims, worn parts must be renewed.

Inspect all the components for wear or damage.

The lower socket has to be broken up to remove it from the ball pin cap.

Renew parts as necessary. The lower socket is a press fit in the ball pin cap.

Fit the lower ball joint upper socket to the

stub axle carrier.

Fit the moulded plastic gaiter retainer, lip first, to the ball joint upper socket. Lip of the retainer must engage with the slot in the upper socket.

Fit the gaiter over the gaiter retainer and secure with the flexible plastic ring.

Fit the ball pin through the gaiter and locate in the ball joint upper socket.

Replace the shims, previously removed, fit the lower socket and ball pin cap.

Fit the four bolts and new tab washers, tighten to the correct torque.

Check the adjustment of the ball pin, it should be slightly stiff in the socket when the bolts are tightened to their correct torque.

To obtain the correct adjustment of the ball pin, after assembling the ball joint, remove shims one by one until the ball pin is tight in its socket when the bolts are tightened to their correct torque. Remove the ball pin and add shims to the value of 0,10 — 0,15 mm (0.004 — 0.006 in).

**NOTE:** The correct adjustment of the ball pin is achieved by limiting the vertical lift of the ball pin, without lubrication, to 0,025 — 0,203 mm (0.001 — 0.008 in). When grease is added the torque required to move the ball pin must not exceed 1 Nm (9 lbf/in). Achieved by adding or subtracting shims, which are available in 0,05 mm (0.002 in) and 0,10 mm (0.004 in) thicknesses.

When the correct adjustment has been obtained, bend over the locking tabs; reverse the dismantling procedure.

**CAUTION:** The bolts securing the upper ball joint to the upper wishbone **MUST** be fitted from the front of the car.

Tighten all nuts and bolts to the correct torque.

Carry out a front suspension geometry check.

## UPPER BALL JOINT

### Renew

Service Tool: JD6G Spring Compressor.

**NOTE:** The upper wishbone ball joint cannot be dismantled and if worn, the complete assembly must be replaced.

Jack up the front of the car, place on stands, and remove the front road wheel. Fit service tool JD6G Spring Compressor (see Fig. 18), and relieve stub axle carrier of spring tension.

Using strong cord or wire, tie the stub axle carrier to the cross member spring turret, to prevent straining the front brake caliper hose.

Remove the two nuts bolts and plain washers securing the ball joint to the upper wishbone arms (1, Fig. 19).

**CAUTION:** Make a careful note of the number and position of packing and shims as these control the caster angle.




Fig. 18

Remove the self locking nut and plain washer securing the ball joint to the stub axle carrier (2, Fig. 19), release taper and remove the ball joint.




Fig. 19

To fit a new ball joint, reverse the above procedure, ensuring that the packing and shims are repositioned as previously noted. Fit the ball joint to the stub axle carrier before securing it to the wishbone arms.

**CAUTION:** The bolts securing the upper ball joints to the upper wishbone, must be fitted from the front of the car.

Remove the support wire or cord. Remove service tool JD6G.

Refit the road wheel and lower the car.

Carry out a front suspension geometry check.

## REBOUND STOPS

### Renew

**NOTE:** Rebound stops must only be replaced as a pair; uneven loads will be placed on the upper wishbone arms if this is not done.

Jack up the front of the car, place on stands and remove the road wheel.

Unscrew the rebound stops from the upper wishbone arms.

To fit new rebound stops, reverse the above procedure; tighten to the correct torque.

## BUMP STOP

### Renew

Jack up the front of the car, place on stands and remove the road wheel.

Remove the two plain nuts and spring washers (1, Fig. 20) securing the bump stop to the spring pan seat.




Fig. 20

Manoeuvre the bump stop clear, through the coils of the spring. It may be necessary to carefully prise apart the coils, to enable the bump stop to be removed.

To fit a new bump stop, reverse the above procedure.

Tighten nuts to the correct torque.

## SUSPENSION UNIT — MOUNTING BUSHES

### Renew

**NOTE:** A worn or damaged bush infers that undue strain has been placed upon the apparently satisfactory bush on the opposite side of the car. Bushes must therefore be renewed as a pair.

Jack up the front of the car, using a trolley jack under the front suspension crossmember (1, Fig. 21). Position axle stands under the jacking spigots (2, Fig. 21), and lower the car onto them.




Fig. 21

Adjust the jack to release the load from the bushes, but to still remain in contact with the crossmember.

Remove the wheel arch front dust shields.

Remove the self locking nut securing one of the mounting bolts and drift the bolt clear of the bush (3, Fig. 21).

**NOTE:** Record the position of the plain and special washers, and if fitted the securing bracket.

Slacken the clamping nut and bolt, securing the relevant mounting bush eye.

Lower the jack SLIGHTLY to improve access to the bush, and tap the bush clear of the eye.

Repeat this procedure for the other side.

To fit new bushes, reverse the above procedure, tightening the nuts to their correct torque.

## SUSPENSION UNIT — REAR MOUNTINGS

### Renew

**NOTE:** A worn or damaged mounting infers that undue strain has been placed upon the apparently satisfactory mounting on the opposite side of the car. Mountings must therefore be renewed as a pair.

Jack up the front of the car, using a trolley jack under the front suspension crossmember (1, Fig. 22). Position axle stands under the jacking spigots (2, Fig. 22), and lower the car onto them.

Remove the nuts securing the engine front mountings.




Fig. 22

Ensure that the trolley jack is supporting the crossmember, remove the self locking nut and washer (3, Fig. 22) securing each mounting to the crossmember. Carefully lower the rear of the crossmember unit, sufficiently to enable the two special setscrews and washers (4, Fig. 22) securing each mounting to the body, to be removed. Carefully lever one side of the suspension crossmember down, to facilitate the removal of the mounting. Repeat for the other side.

To fit new mountings reverse the above procedure. Tighten all fixings to their correct torque.

**NOTE:** Mountings are offset and only fit one way.

## LOWER WISHBONE

### Overhaul

Service tool: JD6G Spring Compressor.

Jack up the front of the car, place on stands and remove the road wheel.

Remove the pinch bolt (1, Fig. 23) securing the lower steering column to the rack pinion.

Remove the bolt, washer and self locking nut, securing the rack top mounting (pinion side of rack assembly) (2, Fig. 23) to the crossmember.




Fig. 23

Remove both the rack bottom mounting bolts, washers and nuts, securing the steering rack to the crossmember.

**CAUTION:** Make a careful record of the number and position of the packing washers for reassembly.

Release the steering rack from the crossmember, and retrieve the packing washers.

**NOTE:** Removal of the RH side lower wishbone requires the removal of the exhaust downpipe from the exhaust manifold.

Fit the Spring Compressor JD6G as shown, (Fig. 24), and compress the spring sufficiently to relieve the load on the spring seat pan fixings. Remove the bolts and nuts securing the spring seat pan to the lower wishbone.




Fig. 24

Slacken the spring compressor tool and remove the spring seat pan, spring and packers.

**NOTE:** Record the quantity and position of the packer for reassembly.

*continued*

Remove the split pin, castellated nut and washer from the end of the lower wishbone fulcrum shaft; drift out the shaft.

Remove the inner bolt, nut and washer, securing the upper ball joint to the upper wishbone, and slacken the outer nut and bolt.

**NOTE:** Record the position of the castor shims and packing pieces **BEFORE** removing them.

Pull the top of the hub and stub axle carrier outwards and swivel to gain access to the self locking nut, securing the lower ball joint to the stub axle carrier.

Remove the self locking nut and plain washer; release the taper.

Remove the two bolts and nuts securing the front damper and anti-roll bar brackets to the lower wishbone.

Telescope the shock absorber and move clear.

Remove the lower wishbone and spacer washers.

Drift or press out the bush from the wishbone eye. Press a new bush into the eye, ensure that the bush projects from each side by an equal amount. Fitting the bush will be made easier by using a recommended rubber lubricant or a liquid soap solution.

The refitting procedure of the lower wishbone is the reverse of the above procedure.

**CAUTION:** The lower fulcrum shaft securing nut **MUST NOT** be fully tightened until the full weight of the car is resting on the suspension. Failure to carry out this procedure will result in undue torsional loading of the rubber bushes with possible premature failure.

## UPPER WISHBONE

### Overhaul

Service tool: JD6G Spring Compressor.

Jack up the front of the car, place on stands and remove the road wheel. Fit service tool JD6G, Spring Compressor, and tighten to relieve the stub axle carrier of spring tension (Fig. 25).




Fig. 25

Remove the two bolts, nuts and plain washers (1, Fig. 26), securing the ball joint to the upper wishbone levers. Note the relative positions of the packing pieces and shims, as these control the castor angle. Alternatively, remove the self locking nut (2, Fig. 26) securing the ball joint to the stub axle carrier, and release the taper. Tie up the stub axle carrier to the suspension crossmember, so that the flexible brake hose is not damaged.




Fig. 26

Remove the two bolts which secure the upper wishbone fulcrum shaft to the suspension crossmember turret. Note the relative positions of the shims as these control the camber angle.

The upper wishbone assembly can now be removed.

Remove the self locking nuts and plain washers and withdraw the wishbone levers from the fulcrum shaft.

Release the locknuts and unscrew the rebound rubbers from the levers.

Drift out or press out the bush from the wishbone eye.


Press a new bush into the eye, ensuring that the bush projects from each side by an equal amount. Fitting of the bush will be made easier if a recommended rubber lubricant or a liquid soap solution is used.

The reassembly and refitting of the wishbone assembly, is a reversal of the above procedure.

**CAUTION:** The nuts securing the wishbone levers to the fulcrum shaft must not be fully tightened until the upper wishbone assembly has been fitted to the car and the full weight of the car is resting on the suspension. Failure to carry out this procedure will result in undue torsional loading of the rubber bushes with possible premature failure.

# KEY TO EXPLODED VIEW OF THE FRONT SUSPENSION COMPONENTS

- |  |                                     |   |
|--|-------------------------------------|---|
| 1. Crossmember                             | 36. Upper wishbone mounting rubbers | 72. Rubber bush                         |
| 2. Rear mounting plate                     | 37. Upper wishbone — front          | 73. Cup washers                         |
| 3. Rear mounting fixings                   | 38. Grease nipple                   | 74. Rubber bush                         |
| 4. Rear mounting                           | 39. Plain washer                    | 75. Plain washer                        |
| 5. Bolt                                    | 40. Fulcrum shaft — upper           | 76. Front damper                        |
| 6. Anti-roll bar                           | 41. Plain washer                    | 77. Damper mounting bracket             |
| 7. Rubber bush                             | 42. Self locking nut                | 78. Anti-roll bar link mounting bracket |
| 8. Keeper plate                            | 43. Camber shims                    | 79. Nut and bolt                        |
| 9. Self locking nut                        | 44. Bolt                            | 80. Self locking nut                    |
| 10. Anti-roll bar                          | 45. Upper wishbone — rear           | 81. Plain washer                        |
| 11. Cup wash-outer                         | 46. Top ball joint — inner bolt     | 82. Lower ball joint gaiter             |
| 12. Anti-roll bar to link — outer bush     | 47. Top ball joint — outer bolt     | 83. Gaiter retaining ring               |
| 13. Anti-roll bar to link — inner bush     | 48. Rebound rubber                  | 84. Gaiter retainer                     |
| 14. Anti-roll bar link                     | 49. Locking washer                  | 85. Upper socket                        |
| 15. Cup washers — inner                    | 50. Grease cap                      | 86. Ball pin                            |
| 16. Lower bushes                           | 51. Nut retainer                    | 87. Lower socket                        |
| 17. Cup washer                             | 52. Hub nut                         | 88. Shims                               |
| 18. Self locking nut                       | 53. Split pin                       | 89. Ball pin cap                        |
| 19. Bolt                                   | 54. Plain washer                    | 90. Tab washers                         |
| 20. Plain washer                           | 55. Outer bearing cone              | 91. Bolts                               |
| 21. Steel bush                             | 56. Outer bearing track             | 92. Grease nipple                       |
| 22. Clamping bolt                          | 57. Front hub                       | 93. Plain washer                        |
| 23. Crossmember front mounting rubber bush | 58. Inner bearing track             | 94. Bolts                               |
| 24. Plain washer                           | 59. Inner bearing cone              | 95. Spring washer                       |
| 25. Self locking nut                       | 60. Grease seal                     | 96. Nut                                 |
| 26. Self locking nut                       | 61. Stub axle                       | 97. Spring pan                          |
| 27. Plain washer                           | 62. Water deflector                 | 98. Lower wishbone                      |
| 28. Gaiter retaining ring                  | 63. Stub axle carrier               | 99. Lower fulcrum shaft                 |
| 29. Top ball joint gaiter                  | 64. Plain washer                    | 100. Bush                               |
| 30. Gaiter retainer                        | 65. Self locking nut                | 101. Washer serrated                    |
| 31. Top ball joint                         | 66. Steering arm                    | 102. Washer plain                       |
| 32. Castor shims                           | 67. Road spring                     | 103. Castellated nut                    |
| 33. Self locking nut                       | 68. Spring packer                   | 104. Split pin                          |
| 34. Self locking nut                       | 69. Locknut                         | 105. Bump stop rubber                   |
| 35. Plain washer                           | 70. Nut                             | 106. Shims                              |
|  | 71. Plain washer                    |   |



**CONTENTS**

| <b>Operation</b>   | <b>Operation No.</b> | <b>Page No.</b> |
|--|----------------------|-----------------|
| Bump stop — Renew .....                                  | 64.30.15             | 64—7            |
| Camber angle — Check and adjust .....                    | 64.25.18             | 64—3            |
| Description .....  | —                    | 64—2            |
| Dimensional data .....                                   | —                    | 64—2            |
| Exploded view of the rear suspension assembly .....      | —                    | 64—9            |
| Hub and carrier assembly — Overhaul .....                | 64.15.07             | 64—4            |
| Hub and carrier assembly — Remove and refit .....        | 64.15.01             | 64—4            |
| Hub oil seals — Renew .....                              | 64.15.15             | 64—4            |
| Hub bearing end-float — Check and adjust .....           | 64.15.13             | 64—3            |
| Mountings — Inspect .....                                | 64.25.00             | 64—7            |
| Radius arm — Renew .....                                 | 64.35.28             | 64—6            |
| Radius arm bushes — Renew .....                          | 64.35.29             | 64—6            |
| Rear suspension height — Check .....                     | 64.25.12             | 64—3            |
| Rear suspension unit — Remove and refit .....            | 64.25.01             | 64—7            |
| Road spring — Renew .....                                | 64.20.01             | 64—6            |
| Damper units — Renew .....                               | 64.30.01             | 64—6            |
| Torque wrench settings .....                             | —                    | 64—2            |
| Wishbone/Inner fulcrum mounting bracket — Overhaul ..... |                      | 64—6            |
| Inner fulcrum mounting bracket — Renew .....             | 64.35.21             | 64—6            |
| Wishbone — Remove and refit .....                        | 64.35.15             | 64—6            |
| Wishbone bearings — Renew .....                          | 64.35.16             | 64—6            |
| Wishbone oil seals — Renew .....                         | 64.35.17             | 64—6            |



## REAR SUSPENSION

### TORQUE WRENCH SETTINGS

| ITEM   | DESCRIPTION                        | SPANNER SIZE          | TIGHTENING TORQUE |              |            |
|--|------------------------------------|-----------------------|-------------------|--------------|------------|
|  |                                    |                       | Nm                | kgf/cm       | lbf/ft     |
| Bumpstop rubbers to body . . . . .               | $\frac{5}{16}$ in UNF nut          | $\frac{1}{2}$ in AF   | 10,8 to 13,6      | 1,12 to 1,4  | 8 to 10    |
| Drive shaft to rear hub . . . . .                | $\frac{3}{4}$ in UNF nut           | $1\frac{1}{8}$ in AF  | 136 to 163        | 13,8 to 16,6 | 100 to 120 |
| Inner fulcrum mounting attachment . . . . .      | $\frac{7}{16}$ in UNC bolt         | $\frac{11}{16}$ in AF | 81,3 to 88        | 8,4 to 9,1   | 60 to 65   |
| Inner fulcrum shaft nuts . . . . .               | $\frac{1}{2}$ in UNF nuts          | $\frac{3}{4}$ in AF   | 61 to 68          | 6,23 to 6,9  | 45 to 50   |
| Outer fulcrum shaft nuts . . . . .               | $\frac{5}{8}$ in UNF nuts          | $\frac{15}{16}$ in AF | 131 to 145        | 13,5 to 15   | 97 to 107  |
| Radius arm and safety strap to body . . . . .    | $\frac{7}{16}$ in UNF bolt         | $\frac{5}{8}$ in AF   | 61 to 68          | 6,23 to 6,9  | 45 to 50   |
| Radius arm to lower wishbone . . . . .           | $\frac{1}{2}$ in UNF bolt          | $\frac{3}{4}$ in AF   | 88 to 95          | 9,1 to 9,8   | 65 to 70   |
| Rear damper attachment . . . . .                 | $\frac{7}{16}$ in UNF nut          | $\frac{11}{16}$ in AF | 43 to 49          | 4,5 to 5,04  | 32 to 36   |
| Safety strap to floor panel . . . . .            | $\frac{3}{8}$ in UNF nut           | $\frac{9}{16}$ in AF  | 37 to 43          | 3,8 to 4,5   | 27 to 32   |
| Tie plate to crossbeam & inner fulcrum . . . . . | $\frac{5}{16}$ in UNF nuts & bolts | $\frac{1}{2}$ in AF   | 19 to 24          | 1,95 to 2,52 | 14 to 18   |
| 'Vee' mountings to body . . . . .                | $\frac{3}{8}$ in UNF nut           | $\frac{9}{16}$ in AF  | 37 to 43          | 3,8 to 4,5   | 27 to 32   |
| 'Vee' mountings to crossbeam . . . . .           | $\frac{5}{16}$ in UNF nut          | $\frac{1}{2}$ in AF   | 19 to 24          | 1,95 to 2,52 | 14 to 18   |
| Wheel studs to rear hub . . . . .                | $\frac{1}{2}$ in UNF               | —                     | 75 to 81,3        | 7,66 to 8,4  | 55 to 60   |

## REAR SUSPENSION

### Description

The complete independent rear suspension system is mounted to a pressed steel crossbeam, which is attached to the body/chassis structure via four 'Vee' rubber mountings.

The system is geometrically similar to that of a double wishbone set-up, but a drive shaft takes the place of a conventional upper wishbone, and the lower wishbone is replaced by a lower link.

One end of the link pivots at the crossmember, and the other end at a hub carrier. The lower link is strengthened torsionally to resist dive and braking loads, which are partially transmitted to the body structure via radius rods.

The aluminium alloy hub carrier houses a rear hub, which is splined to the drive shaft and runs in taper roller bearings.

Two gas filled shock absorber and spring assemblies are mounted between each lower link, and the crossbeam to regulate bump and rebound forces.

Plates are attached between the lower rear pick up points of the dampers and the hub carriers to provide lash-down points when transporting the vehicle.

**WARNING: ON CARS FITTED WITH A 'POWER-LOK' LIMITED SLIP DIFFERENTIAL UNIT; UNDER NO CIRCUMSTANCES MUST THE ENGINE BE RUN WITH THE CAR IN GEAR AND ONLY ONE WHEEL OFF THE GROUND. IF IT IS FOUND NECESSARY TO TURN THE TRANSMISSION WITH THE CAR IN GEAR, THEN BOTH REAR WHEELS MUST BE RAISED CLEAR OF THE GROUND.**

### DIMENSIONAL DATA

The dimensional drawings below (Fig. 1) are provided to assist in assessing accidental damage. A component suspected of being damaged should be removed from the car and cleaned off, the dimensions should then be checked and compared with those given in the appropriate illustration.

### Dimension

- A. 15,75 to 16,26 mm (0.62 to 0.64 in)
- B. 519,43 to 519,94 mm (20.45 to 20.47 in)
- C. 150,62 to 151,13 mm (5.93 to 5.95 in)
- D. 270,05 to 270,31 mm (10.632 to 10.642 in)
- E. 155,45 to 155,70 mm (6.12 to 6.13 in)




Fig. 1

34718

## REAR SUSPENSION RIDE HEIGHT

### Check

Ensure that the car is in its kerb weight condition i.e. full tank of fuel, engine oil and water at correct levels.

Check that the tyres are at the correct pressure.

Roll the car forward three lengths on a perfectly level surface, and measure the distance between the lower surface of the rear crossbeam and the ground on both sides of the car.




Fig. 2

Dimension A (Fig. 2) must be  $190.6 \pm 6.4$  mm,  $7.55 \pm 0.25$  in.

If this dimension is not correct, check all bushes and bearing points of the rear suspension. If the cause is not found, then the rear road springs must be changed; all four must be replaced as a complete set.

## REAR SUSPENSION CAMBER ANGLE

### Check and Adjust

**Service Tools:** Setting Links JD25B, Camber Gauge.

Check that the tyre pressures are correct. Position the car on a level surface.

Fit the Setting Links JD25B as shown in Fig. 3. Engage the hook end of JD25B in the lower hole of the rear mounting and depress the body until the other end can be slid over the outer fulcrum nut. Repeat on the other side of the car.




Fig. 3

Position the camber gauge (Fig. 4) against each rear wheel in turn, and make a note of the camber angle reading.

The correct reading should be  $\frac{3}{4}^\circ \pm \frac{1}{4}^\circ$  negative. If these limits are not met, then the camber angle must be adjusted.




Fig. 4

### To adjust the camber angle

Remove the setting links, jack up the rear of the car and place on stands. Remove the appropriate road wheel.

Remove the lower wishbone outer fulcrum grease nipple (to prevent damaging the nipple).

Slacken the clip (1, Fig. 5) securing the universal joint cover in position, and slide the cover clear of the joint.




Fig. 5

Remove the four self-locking nuts (2, Fig. 5) securing the drive shaft flange to the brake discs (3, Fig. 5).

Remove the drive shaft flange from the disc to enable the number of shims to be altered.

**NOTE:** Each shim is 0.5 mm (0.020 in) thick and will alter the camber angle by  $\frac{1}{4}^\circ$ .

Add or remove the necessary number of shims to obtain the correct camber angle.

Refit the drive shaft flange to the brake disc and secure with the four self-locking nuts. Position and secure the drive shaft flange cover.

Refit the outer fulcrum grease nipple.

Refit the road wheel and lower the car.

Carry out the camber angle checking procedure as previously described.

## REAR HUB BEARING END-FLOAT

### Check and Adjust

**Service Tools:** Backlash Gauge JD13A, Hub Remover JD1D.

The hub bearing end-float is controlled by a spacer located next to the universal joint on the drive shaft.

Spacers are available in thickness from 2.77 to 3.84 mm (0.109 to 0.151 in) in 0.076 mm (0.003 in) increments.

End-float should be between 0.025 to 0.076 mm (0.001 to 0.003 in) and **MUST** be rectified if it exceeds 0.102 mm (0.004 in) by changing the spacer for a thicker one.

### Checking

Jack up the rear of the car and place on stands. Remove the road wheel and gently tap the hub inwards.

Clamp the Backlash gauge JD13A to the hub carrier as shown (1, Fig. 6) so that the stylus of the dial gauge (2, Fig. 6) contacts the hub flange.

Make a note of the reading of the dial gauge.




Fig. 6

Using two screwdrivers (3, Fig. 6), or similar levers, move the hub outwards to its fullest extent. Take care not to damage the water thrower.

Make a note of the new readings on the dial gauge.

**NOTE:** The difference between the dial gauge readings represents the end-float of the hub bearings. If this exceeds 0.102 mm (0.004 in) then carry out the adjusting procedure.

### Adjusting

Remove the split pin, nut and washer from the end of the drive shaft.

Remove the fulcrum shaft grease nipple from the hub carrier.

Fit the Hub Puller JD1D to the hub (Fig. 7) and secure using the road wheel nuts.

Withdraw the hub and carrier from the drive shaft and remove the hub puller.

Remove the spacer from the drive shaft and measure the thickness using a micrometer.




Fig. 7

## REAR SUSPENSION

Determine the thickness of the spacer required to remove end-float to the specified amount 0,025 to 0,076 mm (0.001 to 0.003 in) i.e. if the end-float measurement was 0,203 mm (0.007 in), the replacement spacer would need to be 0,127 mm (0.005 in) thicker than the one removed. This will give an end-float of 0,051 mm (0.002 in).

As the spacers are only supplied in 0,075 mm (0.003 in) increments, then a spacer 0,152 mm (0.006 in) must be used, thus reducing the end-float to 0,025 mm (0.001 in).

Clean any dried Loctite from the drive shaft splines.

Place the selected spacer on the drive shaft. Apply Loctite grade AAV to the outer two-thirds of the drive shaft splines, using a small brush.

Introduce the half shaft into the hub, and engage the splines.

Drift the hub onto the shaft, fit the washer and tighten the nut to the correct torque. Fit a new split pin.

Re-check the end-float.

Refit the fulcrum shaft grease nipple to the hub carrier.

Remove the service tool JD13A, and refit the road wheel.

## REAR HUB AND CARRIER ASSEMBLY

### Overhaul

**Service Tools:** Hub Remover JD1D, Dummy Shaft JD14, Hand Press 47 or Hydraulic/Workshop Press and Adaptor Plate MS370, Press Tools Adaptors JD16C, Press Tool JD20A and Adaptors JD20A-1, Dial Gauge JD13A, Master Spacer JD15.

Jack up the rear of the car and place on stands. Remove the road wheel.

Remove the fulcrum shaft grease nipple (1, Fig. 8) from the hub carrier; this is to avoid damaging the grease nipple when the hub is pulled off.

Remove the split pin, nut and washer (2, Fig. 8) from the end of the drive shaft.




Fig. 8

Fit the Hub Puller JD1D to the hub (Fig. 9) and secure using the wheel nuts.

Using the service tool, withdraw the hub and carrier assembly (5, Fig. 8) from the drive shaft.

Remove the hub puller.




Fig. 9

Remove the spacer (3, Fig. 8) from the drive shaft and retain.

Remove one of the self-locking nuts securing the hub carrier assembly fulcrum shaft to the wishbone. Drift out the fulcrum shaft (4, Fig. 8) using a suitable drift.

Remove the hub and carrier assembly from the car; make a note of any shims and spacers that may be disturbed.




Fig. 10

### Key to Fig. 10

1. Bearing spacer ring
2. Dummy shaft (JD14)
3. Seal tracks
4. Felt seal
5. Seal retaining ring

Remove the oil seal retainers from the fulcrum shaft housing.

Remove seals, bearings, spacers, distance tube and shims (Fig. 10) from the fulcrum shaft housing.

Transfer the hub carrier to a suitable press; press out the hub assembly from the carrier (Fig. 11) and place to one side.




Fig. 11

Secure the hub carrier in a soft jawed vice. Using a suitable brass drift and observing the proper safety precautions, drift the bearing tracks out of the fulcrum shaft housing.

Drift out the hub inner bearing track, together with the seal and bearing from the hub carrier.

Drift out the hub outer bearing track from the hub carrier.

Fit Adaptors JD16C-1 to the hub outer bearing, position the assembly in the Hand Press 47 (Fig. 12) or Hydraulic Press Adaptor MS370, and remove the bearing.




Fig. 12

Examine all the bearing cones, rollers and tracks for wear or damage, and renew as necessary. Inspect the oil seal track on the hub for damage; a minute score can considerably shorten oil seal life.

Press the outer bearing cone into position on the hub shaft and liberally grease the bearing with Retinax 'A'.

Press the hub bearing outer races into the hub carrier using service tool JD20-A and Adaptors JD20A-1 (Fig. 13).




Fig. 13

Fit a new outer oil seal to the hub carrier; lower the carrier onto the hub shaft and outer bearing assembly.




Fig. 14

Place the inner bearing into position, position the Master Spacer, service tool JD15 (as shown in Fig. 14), and press the inner bearing into position until the Master Spacer contacts the hub. This will ensure a certain amount of end-float.

Remove the hub and carrier from the press and secure in a vice, in order to measure the end-float.

## Hub Bearing End-Float

With the inner end of the hub uppermost and the Master Spacer JD15 in position, fit the Dual Gauge JD13A to the hub as shown in Fig. 15. Tap the hub carrier downwards and set the dial gauge to zero. Using two screwdrivers or similar levers between the hub and the hub carrier, lift the hub carrier to its fullest extent. Note the reading on the dial gauge.




Fig. 15

## CAUTION: Take care not to damage the water thrower with the levers.

Having determined the measured end-float, a spacer washer must be fitted in place of the Master Spacer tool JD15 to give an end-float of 0,025 to 0,076 mm (0,001 to 0,003 in).

The Master Spacer tool has a diameter of length 'A' equivalent to a spacer of 3,81 mm (0.15 in).

Spacers are supplied in thicknesses of 2,75 to 3,84 mm (0.109 to 0.151 in) in increments of 0,076 mm (0.003 in) and are lettered A to R (less letters I, N and O).

See table below.

| SPACER LETTER | THICKNESS |        |
|---------------|-----------|--------|
|               | mm        | inches |
| A             | 2,77      | 0.109  |
| B             | 2,85      | 0.112  |
| C             | 2,92      | 0.115  |
| D             | 3,00      | 0.118  |
| E             | 3,07      | 0.121  |
| F             | 3,15      | 0.124  |
| G             | 3,23      | 0.127  |
| H             | 3,30      | 0.130  |
| J             | 3,38      | 0.133  |
| K             | 3,45      | 0.136  |
| L             | 3,53      | 0.139  |
| M             | 3,61      | 0.142  |
| P             | 3,68      | 0.145  |
| Q             | 3,76      | 0.148  |
| R             | 3,84      | 0.151  |

Example: Assume the end-float measured was 0,66 mm (0.026 in). Subtract the required nominal end-float of 0,050 mm (0.002 in) from the measured end-float i.e. 0,66 mm (0.026 in) minus 0,050 mm

(0.002 in) equals 0,61 mm (0.024 in). Since the Master Spacer JD15 represents a thickness of 3,81 mm (0.150 in) then the thickness of the spacer to be fitted will be 3,81 mm (0.150 in) minus 0,61 mm (0.024 in) which equals 3,20 mm (0.126 in). The nearest spacer is 3,23 mm (0.127 in) — letter G. This spacer must be fitted to obtain the correct end-float.

Make a note and place to one side.

Remove the Master Spacer and fit a new inner bearing oil seal to the hub carrier.

## Fulcrum Shaft Bearings

Fit the fulcrum shaft bearing outer tracks to the hub carrier.

The fulcrum shaft bearing pre-load adjustment is effected by shims fitted between the fulcrum shaft spacer tube and bearings. The correct bearing adjustment is 0,025 mm (0.001 in) nominal pre-load.

A simple jig should be made out of a piece of plate steel approximately 18 cm x 10 cm x 9,5 mm (7 x 4 x 0.375 in).

Drill and tap a hole suitable to receive the outer fulcrum shaft.

Secure the steel plate in a vice and screw in the fulcrum shaft. Slide an oil seal track onto the shaft.

Place the hub carrier assembly into position on the fulcrum shaft.

Omit the felt grease seals, but add an excess number of shims between the spacer tube and one of the bearings.

Place an inner wishbone fork, outer thrust washer onto the fulcrum shaft, so that it abuts the other oil seal track.

Fill the remaining spacer on the shaft with washers and secure with a nut, tightened to the correct torque.

Press the hub carrier assembly towards the steel plate using a slight twisting motion to settle the taper rollers.

Maintain a steady pressure against the hub carrier, and use feeler gauges to measure the amount of clearance between the large diameter washer and the hub carrier (Fig. 16). Make a note of this reading 'A'.

Pull the hub carrier towards the large diameter washer, twisting it to settle the taper rollers. Maintain a steady pressure on the carrier, and use feeler gauges to again measure the clearance between the washer and the hub carrier. Make a note of this reading 'B'.




Fig. 16

By subtracting clearance 'A' from clearance 'B' an end-float measurement is obtained for the fulcrum shaft bearing assemblies.

Dismantle the hub carrier assembly from the jig plate, and remove sufficient shims to obtain a pre-load reading of 0,05 mm (0.002 in).

Example: Assume the end-float found by the above method was 0,25 mm (0.010 in). Shims to the value of 0,25 mm (0.010 in) + 0,05 mm (0.002 in) = 0,030 mm (0.012 in) must be removed to give the correct pre-load.

Pack the fulcrum bearing housing with the specified grease and reassemble the components. Ensure that a spacer ring is fitted between each taper roller bearing track and the grease seal retainer. (See Fig. 17).




Fig. 17

## Key to Fig. 17

1. Bearing spacer ring
2. Dummy shaft (JD14)
3. Seal tracks
4. Felt seal
5. Seal retaining ring

Insert Dummy Shaft JD14, fit the grease seal tracks and new felt grease seals.

Locate the fulcrum shaft boss of the hub carrier, between the jaws of the lower wishbone. Press the hub carrier against one of the jaws of the wishbone and using feeler gauges, measure the distance between the other jaw and the oil seal track. (See Fig. 18).




Fig. 18

Select shims to this value and divide into two; fit these either side of the hub carrier to centralise the carrier between the jaws of the wishbone.

These also prevent the jaws of the wishbone from closing inwards.

*continued*

## REAR SUSPENSION

Shims are available in 0.75 mm (0.003 in) and 0.179 mm (0.007 in) thicknesses and 22.2 mm (0.875 in) diameter.

Fit a seal retaining ring and selected shims to each side of the fulcrum bearing assembly. Position the hub carrier assembly to the lower wishbone and chase dummy shaft, JD14, through the wishbone, with the fulcrum shaft.

Fit and tighten the nuts to the correct torque.

Thoroughly clean and degrease the splines of the drive shaft and hub. Fit the selected spacer washer to the drive shaft.

Using a small brush, sparingly apply Loctite grade AAV to the outer two-thirds of the drive shaft splines.

Assemble the hub carrier to the drive shaft, fit the washer and nut. Tighten to the correct torque and fit a new split pin.

Refit the fulcrum shaft grease nipple.

Refit the road wheel and lower the car.

### RADIUS ARM BUSHES

#### Renew

**Service Tool:** Press Mandrel JD21.

Jack up the rear of the car; support the body on stands forward of the radius arm anchorage points.

Remove the appropriate road wheel.




Fig. 19

Remove the special bolt and spring washer, securing the safety strap to the body (1, Fig. 19).

Remove the locking wire and bolt securing the radius arm to the body (2, Fig. 19); remove the safety strap.

Remove the self-locking nut and plain washer (1, Fig. 20) securing the front damper assembly to the damper lower mounting pin.

Drift the damper mounting pin (2, Fig. 20) far enough through the wishbone to clear the front damper and spacer (3, Fig. 20). Recover the spacer.

Knock back the tabs of the lockwasher (4, Fig. 20) and remove the bolt securing the




Fig. 20

radius arm to the wishbone. Remove the radius arm.

Using service tool JD21 and a suitable press, press the front and rear bushes from the radius arm (Fig. 21).

Press a new bush into the rear bush housing, centralising the bush in the radius arm.




Fig. 21

Press a new bush into the front bush housing; ensure that the holes in the bush rubber are in line with the centre line of the radius arm and the ring of the bush is flush with the housing.

When pressing in the bushes, ensure that the small hole in the bush is uppermost.

To refit the radius arm, reverse the above procedure.

Renew the locking wire and tab washer.

Tighten all the bolts to their correct torques.

### ROAD SPRING AND DAMPER

#### Renew

**Service Tools:** Hand Press 47, Adaptors JD11B.

**NOTE:** The roadspring and hydraulic damper assemblies can be removed from the car with the rear suspension assembly in position.

Jack up the rear of the car; place the body on stands and remove the road wheel.

Position a trolley jack to support the lower wishbone.




Fig. 22

Remove the bolt and self-locking nut (1, Fig. 22), securing the top of each damper assembly to the crossbeam.

Remove the nuts and washers (2, Fig. 22) securing the damper assemblies to the lower wishbone.

Drift out the damper mounting pin (3, Fig. 22).

Recover the spanner from the forward end of the damper mounting pin.




Fig. 23

Withdraw the spring and damper assemblies from the car.

Using Hand Press 47 and Adaptors JD11B, as illustrated in Fig. 23, compress the road spring sufficiently to allow the collets and spring seat to be removed.

Release the spring and separate the damper from the spring.

**NOTE:** In some cases, a spring packer may be fitted. Note position for refitting.

To refit, compress the road spring, using service tools JD11B and 47, sufficiently to allow the damper to be passed through the road spring. Fit the packing ring, spring seat and split collets.

Ensure that the spring and collets are fully seated before releasing the pressure on the road spring.

Fit the road spring and damper assemblies to the car by reversing the removal procedure.

### WISHBONE/INNER FULCRUM MOUNTING BRACKET

#### Overhaul

**Service Tool:** Dummy Shafts JD14.

#### Dismantling

Jack up the rear of the car; support the body on stands and remove the appropriate road wheel.

Remove the self-locking nut from one end of the outer fulcrum shaft (1, Fig. 24) and drift out the shaft.




Fig. 24

Fit the Dummy Shaft JD14 to the hub carrier assembly.

Retain the shims and oil seal retaining washers on each side of the hub carrier with adhesive tape.

**NOTE:** Make a record of the number and position of any shims fitted between the wishbone and the hub carrier assembly. (This is to ensure that they are reassembled in their correct positions.)

*continued*

Raise the hub carrier and drive shaft clear of the wishbone; secure to the crossbeam using wire or strong cord.

Remove the six bolts and nuts (1, Fig. 25), securing the tie-plate to the crossbeam. Remove the bolt securing the radius arm safety strap to the body. Remove the locking wire and unscrew the radius arm retaining bolt from the body. Remove the safety strap and detach the forward end of the radius arm from the mounting on the body. Remove the eight setscrews (2, Fig. 25) securing the tie-plate to the inner fulcrum brackets.




Fig. 25

Remove the nuts and washers (1, Fig. 26) securing the spring and damper assemblies to the wishbone.

Drift out the damper mounting pin (2, Fig. 26) and recover the spacer (3, Fig. 26) from the front damper.

Remove the rear nut from the inner fulcrum shaft and drive the shaft clear of the inner fulcrum mounting bracket and wishbone.

Withdraw the wishbone and radius arm assembly from the car. Collect the four outer thrust washers (1, Fig. 27) and inner thrust washers (2, Fig. 27); grease seals (3, Fig. 27) and retainers (4, Fig. 27).




Fig. 26

Bend back the tab washer (4, Fig. 26) and remove the bolt securing the radius arm to the wishbone.

Remove the two bearing tubes (5, Fig. 27).




Fig. 27

Use a suitable drift to carefully tap the needle roller cages (6, Fig. 27) from the wishbone.

If the inner fulcrum mounting bracket is to be removed, tap the spacing tube (1, Fig. 28) from between the lugs of the mounting bracket.

Remove the locking wire from the setscrews (2, Fig. 28) securing the mounting bracket to the final drive unit.

Remove the setscrews and withdraw the fulcrum bracket.




Fig. 28

**NOTE:** Make a record of the number and position of the shims (3, Fig. 28) at each attachment point.

Examine all the components for wear and damage; renew as necessary.

## Assembly

Press the needle roller cages into position in the wishbone arms. The engraved edge of each bearing needle cage facing outwards. Position the inner fulcrum mounting bracket against the final drive unit and loosely secure with the two setscrews.

Pass the inner fulcrum shaft through the crossbeam and mounting bracket.

Position the shims previously removed between the final drive unit and mounting bracket.

Using feeler gauges, as shown in Fig. 29, determine whether the shimming is sufficient to remove the clearance. Adjust the shim pack as necessary. Shims are available in thicknesses of 0,127 mm (0,005 in) and 0,178 mm (0,007 in).




Fig. 29

Remove the fulcrum shaft; position the selected shims and tighten the setscrews to the correct torque.

Wirelock the setscrews to tension in a clockwise direction.

Tap the spacing tube into position between the mounting bracket lugs.

Fit new grease seals to the wishbone inner fulcrum arms; relocate the seal retainers and thrust washers with grease.

Offer up the wishbone to the inner fulcrum mounting bracket complete with bearing tubes, needle roller bearings, inner and outer thrust washers, grease seals and grease seal retainers. Ensure that the radius arm mounting bracket is towards the front of the car.

Align the holes and spacers, press a Dummy Shaft JD14 (1, Fig. 30) through each side of the crossbeam and wishbone.




Fig. 30

The dummy shafts locate the wishbone, spacers, crossbeam and inner fulcrum mounting bracket, and facilitate the refitting of the inner fulcrum shaft.

Smear the inner fulcrum shaft with grease and gently tap the shaft through the crossbeam, wishbone and inner fulcrum mounting bracket. As the fulcrum shaft is tapped into position, the short dummy shafts will be displaced from the opposite side. It will be found advantageous to keep a slight amount of pressure exerted on the dummy shafts as they emerge from the crossbeam. This will reduce the possibility of the dummy shafts being knocked out of position and allowing a spacer or thrust washer to become displaced.

If a washer or spacer does become displaced, it will be necessary to remove the inner fulcrum shaft, dummy shafts and wishbone, and repeat the operation.

When the fulcrum shaft is in position, fit and tighten the self-locking nuts to the correct torque.

Locate the radius arm to the wishbone, fit the bolt and new tabwasher. Tighten to the correct torque and bend over the tabwasher. Raise the wishbone, refit the damper mounting pin, spacer and tie-down bracket; tighten the nuts to the correct torque.

Raise the radius arm; clean and lightly grease the spigot. Fit the safety strap. Fit the radius arm securing bolt; tighten to the correct torque and wirelock.

Fit and tighten the bolt securing the safety strap to the body.

Release the wire or strong cord suspending the hub assembly to the crossbeam.

Remove the adhesive tape attaching the shims and washers to the hub carrier.

Fit new grease seals. Refit the grease seal retainers and shims.

Align the hub carrier with the wishbone outer fulcrum and chase out the Dummy Shaft JD14 with the outer fulcrum shaft. Fit and tighten the self-locking nuts to the correct torque.

*continued*

## REAR SUSPENSION

Refit the tie-plate and insert the eight setscrews (2, Fig. 31).

Refit the six bolts and nuts (1, Fig. 31). Tighten all tie-plate fixings to the correct torque.




Fig. 31

Refit the road wheel and lower the car. Carry out a rear suspension camber-angle check and adjust as required.

## REAR SUSPENSION MOUNTINGS

### Inspect

Drive the vehicle onto a ramp. Raise the ramp and position a ramp jack under the jacking point, in front of the rear radius arm body mounting.

Lower the ramp sufficiently to allow either the rear wheel to clear the ramp, or until the distance between the lower edge of the rear quarter valance and the ramp is 34 cm (13.5 in) DO NOT exceed this distance.

Visually inspect the condition of the rubber and the rubber/metal bonding. If the rubber shows signs of cracking, or there is unbonding of the rubber to a depth greater than 3,175 mm (0.125 in), then the mounting must be replaced.

If a visual inspection is not conclusive, insert a lever between the two 'V's' of the mounting and apply pressure.

Check the rubber for cracking and the rubber/metal bonding.

Repeat this procedure for the other side.

## BUMP STOP

### Renew

Jack up the car support the body on stands and remove the appropriate road wheel.

Remove the two self-locking nuts and washers securing the bump stop to the body, and remove the bump stop. (1, Fig. 32).




Fig. 32

To fit a new bump stop, reverse the above procedure.

Tighten all fixings to their correct torque.

## REAR SUSPENSION UNIT

### Remove and Refit

Jack up the rear of the car and support on stands forward of the radius arm anchorage points.

Remove the clamps securing the left and right hand intermediate exhaust pipes to the tail pipes and main silencers.

Disengage each intermediate pipe mounting pin from the rubber mounting and manoeuvre the pipes clear of the rear suspension unit.

Position suitable packing between each exhaust tail pipe and the rear bumper to support the silencer and tail pipe assemblies in their fitted positions.

Remove the special bolt and spring washer (1, Fig. 33) securing each radius arm safety strap to the body.

Remove the locking wire and bolt (2, Fig. 33) securing each radius arm to the body; remove both the safety straps.




Fig. 33

Disconnect the brake pipe hose at the body mounting bracket. Plug the ends to prevent the ingress of dirt.

Remove the bolts and self-locking nuts securing the propeller shaft flange to the differential unit pinion flange.

Ensure that the handbrake is in the fully 'OFF' position. Lift the carpet adjacent to the handbrake mounting for access to the cable adjusting nuts, slacken the cable lock and adjusting nuts.

Release the springs (1, Fig. 34) from the caliper operating arms. Move the right-hand arm (2, Fig. 34) (when viewed from the front of the car) towards the centre line of the car, to enable the end of the handbrake operating cable (3, Fig. 34) to be detached from the arm.




Fig. 34

Position the handbrake cable clear of the suspension unit.

Position a jack underneath the tie-plate and raise sufficiently to take the weight.

Remove the eight bolts and self-locking nuts, and the four nuts, securing the mounting brackets to the crossbeam. Carefully lower the jack and suspension unit. To refit reverse the above procedure.

Bleed the hydraulic brake system and re-adjust the handbrake cable.

## REAR SUSPENSION

Key to the Exploded View of the Rear Suspension (Fig. 35)

1. Crossmember
2. Rubber mounting
3. Inner fulcrum mounting
4. Shims
5. Tie-plate
6. Inner fulcrum shaft
7. Distance piece
8. RH wishbone
9. Bearing tube
10. Needle roller bearing
11. Thrust washer
12. Grease seal
13. Seal retaining ring
14. Thrust washer
15. Grease nipple
16. Spacer tube
17. Shims
18. Taper roller bearing
19. Grease seal track
20. Bearing spacer
21. Grease seal retainer
22. Grease seal
23. Grease seal retaining washer
24. Shims
25. Outer fulcrum shaft
26. Lashdown bracket
27. Self locking nut
28. Hub carrier
29. Grease nipple
30. Grease retaining cap
31. Hub outer bearing
32. Outer grease seal
33. Grease seal track
34. Rear hub
35. Hub inner bearing
36. Spacer
37. Inner grease seal
38. Seating ring
39. Drive shaft
40. Camber shims
41. Inner joint cover
42. Outer joint cover
43. Coil spring
44. Spring packing ring
45. Shock absorber (Damper)
46. Dust shield
47. Rubber bush
48. Spring seat
49. Split collars
50. Damper mounting pin
51. Radius arm
52. Rubber bush
53. Safety strap
54. Rubber bush




Fig. 35

J64-045



## CONTENTS

| Operation                                     | Operation No. | Page No. |
|---|---------------|----------|
| Brake caliper, front — Overhaul .....         | 70.55.13      | 70—8     |
| Brake caliper, front — Remove and refit ..... | 70.55.02      | 70—8     |
| Brake pads, rear — Renew .....                | 70.40.02      | 70—8     |
| Brake caliper, rear — Overhaul .....          | 70.55.14      | 70—8     |
| Brake fluid .....                             | —             | 70—2     |
| Brake system — Bleed .....                    | 70.25.02      | 70—5     |
| Brake system — Drain and flush .....          | 70.25.17      | 70—5     |
| Cleaning solvents .....                       | —             | 70—2     |
| Data .....                                    | —             | 70—2     |
| Description .....                             | —             | 70—3     |
| Disc, front — Renew .....                     | 70.10.10      | 70—6     |
| Disc, rear — Renew .....                      | 70.10.11      | 70—6     |
| Brake caliper, rear — Remove and refit .....  | 70.10.11      | 70—7     |
| Brake pads, handbrake — Renew .....           | 70.40.04      | 70—7     |
| Brake pads, rear — Renew .....                | 70.40.03      | 70—7     |
| Handbrake mechanism — Renew .....             | 70.55.04      | 70—6     |
| Disc shield, front — Renew .....              | 70.10.18      | 70—5     |
| Fault finding and diagnosis .....             | —             | 70—4     |
| Handbrake cable — Renew .....                 | 70.35.16      | 70—9     |
| Handbrake cable — Adjust .....                | 70.35.10      | 70—9     |
| Handbrake lever assembly — Renew .....        | 70.35.08      | 70—9     |
| Hoses — General instructions .....            | —             | 70—4     |
| Master cylinder — Overhaul .....              | 70.30.09      | 70—9     |
| Master cylinder — Renew .....                 | 70.30.08      | 70—10    |
| Fluid reservoir — Renew .....                 | 70.30.16      | 70—10    |
| Pipes — General instructions .....            | —             | 70—4     |
| Reservac tank — Renew .....                   | 70.50.04      | 70—10    |
| Servo assembly — Overhaul .....               | 70.50.06      | 70—5     |
| Servo assembly — Test and check .....         | 70.50.05      | 70—5     |
| Torque wrench settings .....                  | —             | 70—2     |

**BRAKES**

**TORQUE WRENCH SETTINGS**

| ITEM   | DESCRIPTION   | SPANNER SIZE         | Nm         | TIGHTENING TORQUE |          |
|--|---|----------------------|------------|-------------------|----------|
|  |   |                      |            | kgf/cm            | lbf/ft   |
| Brake fluid reservoir to bracket                 | $\frac{1}{4}$ in UNF nut                                | $\frac{7}{16}$ in AF | 27 to 34   | 0,28 to 0,34      | 2 to 2,5 |
| Brake pedal pivot pin                            | $\frac{3}{8}$ in UNF nut                                | $\frac{9}{16}$ in AF | 19 to 24   | 1,95 to 2,49      | 14 to 18 |
| Hydraulic connections for $\frac{3}{16}$ in pipe | UNF   |                      | 8 to 9,5   | 0,83 to 0,97      | 6 to 7   |
|  | M 12  |                      | 16 to 19   | 1,66 to 1,95      | 12 to 14 |
|  | M 10 male   |                      | 8 to 11    | 0,83 to 1,12      | 6 to 8   |
|  | M 10 female   |                      | 11 to 13   | 1,12 to 1,4       | 8 to 10  |
| Handbrake to body                                | $\frac{5}{16}$ in UNF bolt                              | $\frac{1}{2}$ in AF  | 19 to 24   | 1,95 to 2,52      | 14 to 18 |
| Handbrake lever pivot to body                    | $\frac{5}{16}$ in UNF bolt                              | $\frac{5}{8}$ in AF  | 19 to 24   | 1,95 to 2,52      | 14 to 18 |
| Hose bracket to rear X-beam                      | $\frac{5}{16}$ in UNF nut                               | $\frac{1}{2}$ in AF  | 19 to 24   | 1,95 to 2,52      | 14 to 18 |
| Hoses to bracket & body                          | M 10 nut  | 15 mm                | 13 to 16   | 1,4 to 1,66       | 10 to 12 |
| Master cylinder to servo                         | M 10 nut  | 15 mm                | 22 to 27   | 2,24 to 2,8       | 16 to 20 |
| Pedal to body                                    | $\frac{5}{16}$ in UNF nut<br>$\frac{5}{16}$ in UNF bolt | $\frac{1}{2}$ in AF  | 15 to 17,5 | 1,55 to 1,81      | 11 to 13 |
| Servo to pedal box                               | M 8 nut   | 13 mm                | 11 to 13   | 1,12 to 1,4       | 8 to 10  |
| Vacuum pipe clips to wing stays                  | No 10 UNF nut   | $\frac{5}{16}$ in AF | 5,5 to 6   | 0,56 to 0,62      | 4 to 4,5 |
| Vacuum tank bracket to body                      | $\frac{5}{16}$ in UNF nut                               | $\frac{1}{2}$ in AF  | 11 to 13   | 1,12 to 1,4       | 8 to 10  |

**DATA**

|                                       |                                       |
|---------------------------------------|---------------------------------------|
| Front brakes—make and type            | Girling, ventilated disc              |
| Rear brakes—make and type             | Girling, inboard disc                 |
| Handbrake—type                        | Mechanical, operating on rear disc    |
| Disc diameter—front                   | 283,8 mm (11.175 in)                  |
| —rear                                 | 263,8 mm (10.385 in)                  |
| Disc thickness—front                  | 24,0 mm (0.945 in)                    |
| —rear                                 | Normal 12,7 mm (0.5 in)               |
|                                       | Min. permissible 11,43 mm (0.45 in)   |
| Master cylinder bore diameter         | 23,8 mm (0.937 in)                    |
| Hydraulic fluid specification         | Castrol Girling Code 1735 (SAE J1703) |
| Main brake friction pad specification | Ferodo 3401                           |
| Handbrake friction pad specification  | Mintex M68/1                          |
| Servo unit make                       | Girling                               |

**CLEANING SOLVENTS**

**WARNING: NEVER USE METHYLATED SPIRIT (DENATURED ALCOHOL) FOR CLEANING PURPOSES. USE ONLY CASTROL/GIRLING BRAKE CLEANING FLUID.**

THROUGHOUT THE FOLLOWING OPERATIONS ABSOLUTE CLEANLINESS MUST BE OBSERVED TO PREVENT GRIT OR OTHER FOREIGN MATTER CONTAMINATING THE BRAKE SYSTEM. IF THE SYSTEM IS TO BE FLUSHED OR CLEANED THROUGH, ONLY GIRLING BRAKE CLEANER MUST BE USED. BRAKE SYSTEM COMPONENTS MUST BE WASHED AND ALL TRACES OF CLEANER REMOVED BEFORE REASSEMBLY.

ALL BRAKE SYSTEM RUBBER COMPONENTS MUST BE DIPPED IN CLEAN BRAKE FLUID AND ASSEMBLED USING THE FINGERS ONLY.

**BRAKE FLUID**

**WARNING: DURING OPERATIONS WHICH NECESSITATE THE HANDLING OF BRAKE FLUID, EXTREME CARE MUST BE OBSERVED; BRAKE FLUID MUST NOT BE ALLOWED TO CONTACT THE CAR PAINTWORK. IN INSTANCES WHERE THIS HAS OCCURRED THE CONTAMINATED AREA MUST IMMEDIATELY BE CLEANED, USING A CLEAN CLOTH AND WHITE SPIRIT. THIS SHOULD BE FOLLOWED BY WASHING**

THE AREA WITH CLEAN WATER. METHYLATED SPIRIT (DENATURED ALCOHOL) MUST NOT BE USED TO CLEAN THE CONTAMINATED AREA.

## DESCRIPTION

The brake system comprises the following main components:

- Pedal box
- Servo unit
- Tandem master cylinder
- Remote fluid reservoir
- Four disc brake assemblies
- Two handbrake calipers

The above components provide the car with a dual braking system in which the front and rear caliper assemblies are totally independent of each other. In the event of a brake line fracture, or partial loss of fluid, one pair of brake calipers will remain operative.

## Operation (Fig. 1)

When the brake pedal is depressed, the servo unit, which is directly coupled to the master cylinder, transfers increased pedal pressure to the master cylinder primary piston 'A', causing this piston to move forward past the by-pass port 'B', and establish a rear brake line pressure in chamber 'C'. Pressure from the primary piston return spring 'D', combined with the rear brake line pressure in chamber 'C', forces the secondary piston 'E' forward past the by-pass port 'F' to establish front brake line pressure in chamber 'G'.

Brake pressure entering the caliper 'H' forces the pistons 'J' (four on each front disc, two on each rear) out to act on the friction pads 'K', clamping the brake disc 'L'. When the brake pedal is released, brake line pressure collapses, allowing the piston seals 'N' to retract the pistons into the calipers sufficiently for the friction pads to be in a relaxed position away from the disc. This provides automatic adjustment for brake pad lining wear.

If the brake servo unit becomes inoperative, front and rear braking systems will still operate, but at a greatly reduced brake line pressure.

A divided brake fluid reservoir ensures that in the event of fluid loss to front or rear brake systems, one pair of calipers will remain operative.


The fluid reservoir contains a float/switch assembly 'P' which, when actuated, illuminates a warning light on the fascia, should the level of fluid in the reservoir fail to an unsatisfactory level.

## Metrication

The examples shown in Fig. 2, Fig. 3 and Fig. 4 are intended as an aid to identification of brake components in metric form.

All metric pipe nuts, hose ends, unions and bleed screws are coloured black. The hexagon area of pipe nuts are indented with the letter 'M'.


Metric and UNF pipe nuts are different in shape and the female nut is always used with a trumpet flared pipe, the male nut always having a convex flared pipe.



J70-002

A = Metric B = UNF  
Fig. 2


Hose ends differ slightly between metric and UNF.



J70-004

A = Metric B = UNF  
Fig. 3

Copper gaskets are not used with metric hose and a gap exists between the hose end and cylinder.






J70-003

A = Metric B = UNF  
Fig. 4

Metrication does not apply to the following brake components.

1. Rear calipers.
2. Handbrake calipers.
3. Feed pipes from rear three-way connector to rear calipers.
4. Three-way connector.



J70-048

Fig. 1

## SYMPTOM AND DIAGNOSIS CHART FOR HYDRAULIC BRAKE SYSTEM

| SYMPTOM                         | DIAGNOSIS  | ACTION  |
|---------------------------------|--|---|
| Fade                            | Incorrect pads.<br>Overloaded vehicle.<br>Excessive braking. Old hydraulic fluid.  | Replace the pads, decrease vehicle load or renew hydraulic fluid as necessary.  |
| Spongy pedal                    | Air in system. Badly lined pads. Weak master cylinder mounting.  | Check for air in the system, and bleed if necessary. Check the master cylinder mounting, pads and discs and replace as necessary.   |
| Long pedal                      | Discs running out pushing pads back. Distorted damping shims. Misplaced dust covers.   | Check that the disc run out does not exceed 0.101 mm (0.004 in). Rotate the disc on the hub.<br>Check the disc/hub mounting faces.  |
| Brakes binding                  | Handbrake incorrectly adjusted.<br>Seals swollen. Seized pistons. Servo faulty.  | Check and adjust handbrake linkage. Check for seized pistons. Repair or replace as necessary. Carry out servo test procedure.<br>Replace servo if faulty.   |
| Hard pedal—poor braking         | Incorrect pads. Glazed pads. Pads wet, greasy or not bedded correctly.<br>Servo unit inoperative. Seized caliper pistons. Worn shock absorbers causing wheel bounce. | Replace the pads or if glazed, lightly rub down with rough sandpaper. Carry out servo test procedure.<br>Replace servo if faulty.<br>Check caliper for damage and repair as necessary. Fit new shock absorbers. |
| Brake pulling                   | Seized pistons. Variation in pads. Unsuitable tyres or pressures. Worn shock absorbers. Loose brakes. Greasy pads. Faulty discs, suspension or steering.             | Check tyre pressures, seized pistons, greasy pads or loose brakes; then check suspension, steering and repair or replace as necessary.<br>Fit new shock absorbers.  |
| Fall in fluid level             | Worn disc pads. External leak. Leak in servo unit.   | Check the pads for wear and for hydraulic fluid leakage. Carry out servo test procedure.<br>Replace servo if faulty.  |
| Disc brake squeal—pad rattle    | Worn retaining pins. Worn discs. Worn pads. Broken anti-chatter spring.  | Renew the retaining pins, or discs. Fit new pads, or anti-chatter spring.   |
| Uneven or excessive pad wear    | Disc corroded.<br>Disc badly scored.<br>Incorrect friction pads.   | Check the disc for corrosion, or scoring and replace if necessary. Fit new pads with correct friction material.   |
| Brake warning light illuminated | Fluid level low.<br>Short in electrical warning circuit.   | Top up reservoir. Check for leaks in system and pads for wear. Check electrical circuit.  |

## GENERAL FITTING INSTRUCTIONS

### Hoses

Thoroughly clean the unions of the hose to be removed.  
Ensure the pipe sealing plugs are at hand.  
Fully release the unions (1, Fig. 5) securing each end of the hose to the fluid pipes.




Fig. 5

Withdraw the pipe unions (2, Fig. 5) from the hose ends. Plug the ends of the pipes to prevent the loss of fluid and the ingress of dirt.  
Remove the locknut (3, Fig. 5) securing the hose to the mounting bracket and remove the hose.  
Thoroughly clean the hose and examine it for any signs of deterioration or damage. Renew the hose if there is any doubt about its condition.  
Using compressed air, thoroughly clean the bore of the hose.  
To refit the hose, reverse the above procedure. Before fully tightening the locknut (3, Fig. 5) ensure that the hose is neither kinked nor twisted.  
Carry out the brake bleeding procedure.

### Pipes

Clean the unions of the pipe to be removed.  
Ensure that sealing plugs are at hand. Fully release the pipe unions.  
Withdraw the pipe from the car. Plug the open end of the pipe remaining on the car, to prevent the loss of fluid or the ingress of dirt.  
Thoroughly clean and examine the pipe for any signs of damage or deterioration. Renew the pipe if there is any doubt about its condition.  
Using compressed air, thoroughly clean the bore of the pipe.  
To refit, reverse the above procedure and carry out the brake bleed procedure.

## BRAKE SERVO TEST PROCEDURE

**NOTE:** The following tests on the vacuum system should only be carried out if it is known that the hydraulic brake system is in a satisfactory condition.

Jack up the front of the car and check that one wheel will rotate freely. Start the engine, allow the vacuum to build up, and apply the brake pedal several times. Check that the wheel is free to rotate immediately the pedal is released. If the brakes bind, then the servo is faulty.

With the engine running, apply the brake pedal several times, and check the operation of the pedal. If the response is sluggish, check the condition of the vacuum hoses and the servo unit air filter.

Allow the vacuum to build up, and then switch off the engine and operate the brake pedal. The pedal should be vacuum assisted for approximately three applications; any less indicates a leaking vacuum system or an inoperative non-return valve.

With the engine switched off, operate the brake pedal several times to evacuate any vacuum left in the system.

Whilst maintaining light pressure on the footbrake pedal, start the engine. If the servo unit is operating correctly, the pedal will fall under the existing foot pressure. If the pedal remains stationary, then there is a leak in the vacuum system.

## BLEEDING THE BRAKE SYSTEM

Bleeding the brake system (expelling the air) is not a routine maintenance operation and should only be necessary when part of the system has been disconnected, or air has contaminated the fluid. The presence of air in the system will cause the brake pedal to feel 'spongy' when applied.

During the bleeding operation, it is **important** that the level of the fluid in the fluid reservoir is kept topped up, to avoid drawing more air into the system.

Attach a bleed tube to the left hand rear bleed screw, immerse the open end of the tube in a small jar, partially filled with clean, fresh brake fluid.

Position the gear selector lever in neutral; start the engine and allow it to idle.

Slacken the left-hand rear bleed screw.

An assistant is required to slowly operate the brake pedal through its full stroke. Continue to do this, until the fluid pumped into the jar is free from air bubbles. When this is achieved, keep the pedal depressed and close the bleed screw. Release the pedal.

Repeat the operation for the right-hand rear brake caliper and the two front brake calipers.

Check the tightness of all the bleed screws and fit protective caps.

Top up the reservoir as necessary.

**CAUTION:** DO NOT 'top up' the fluid reservoir with fluid which has been bled through the system, as it will have become aerated. Always use fresh, clean fluid from a new tin.

Apply a normal 'working' load to the brake pedal, for several minutes. If the pedal moves or feels spongy, then further bleeding of the system is required. Also check the entire system for any signs of fluid leakage.

## DRAINING AND FLUSHING THE BRAKE SYSTEM

Service Tool: Brake piston retractor, Girling Part No. 64932392

### Draining

Place the car on stands and remove all the road wheels.

Attach a bleed tube to the rear left-hand caliper bleed screw with the open end in a suitable container. Slacken the bleed screw and slowly operate the brake pedal through its full stroke, until the rear brake section of the fluid reservoir is empty and fluid ceases to come out of the bleed tube.

Remove the rear left-hand caliper friction pads.

**WARNING: DO NOT OPERATE THE BRAKE PEDAL WHILE THE FRICTION PADS ARE REMOVED.**

Using Service Tool 64932392, as shown in Fig. 6 A and B, lever the pistons into their bores, expelling any remaining fluid.

Replace the friction pads.





Fig. 6 J70-046



J70-047

**NOTE:** It is not necessary to replace the retaining pins and spring clips at this time, as the friction pads will have to be removed again.

Close the bleed screw.

Discard the expelled fluid.

Repeat the draining procedure for the rear right-hand and front brake calipers.

## FLUSHING

Fill the fluid reservoir with Castrol/Girling Flushing Fluid.

Attach a bleed tube to the rear left-hand caliper bleed screw with the open end in a suitable container.

Slacken the bleed screw and slowly operate the brake pedal, through its full stroke; continue until clear flushing fluid is expelled from the tube.

**NOTE:** The fluid reservoir must be kept 'topped-up' with fresh flushing fluid.

Close the bleed screw and operate the brake pedal two or three times.

Repeat the flushing procedure on the remaining brake calipers.

Carry out the draining procedure to expell all the flushing fluid from the rear brake calipers. Secure the friction pads with the retaining pins and spring clips. Do not forget to fit the anti-rattle springs to the front calipers.

Close all the bleed screws.

Discard the expelled flushing fluid.

Fill the brake fluid reservoir with new brake fluid of the correct specification.

Carry out the brake bleeding procedure.

Ensure that the brake fluid expelled through the bleed tube is completely free of flushing fluid.

Refit the road wheels and remove the car from the stands.

## SERVO ASSEMBLY

### Overhaul

The servo assembly is a sealed unit and cannot be overhauled. Should the operation of the servo unit deteriorate to an extent where braking efficiency is affected, or a fault develops in the unit, then a replacement servo assembly must be fitted. Servo unit replacement is covered in the pedal box overhaul procedure.

## DISC SHIELDS — FRONT

### Renew

Jack up the front of the car, place on stands and remove the road wheel.

Slacken the upper bolt securing the steering arm to the stub axle carrier.

Remove the locking wire securing the caliper mounting bolts and remove the upper mounting bolt.

Remove the self locking nuts which retain the disc shield securing brackets (1, Fig. 7) to the lower portion of the stub axle carrier.




Fig. 7

J70-009

Withdraw the front and lower disc shields (2, Fig. 7).

Disconnect the brake caliper feed pipe from the flexible hose. Remove the locknut securing the flexible hose union to the bracket (3, Fig. 7) on the rear disc shield. Remove the rear disc shield (4, Fig. 7).

Plug the ends of the brake pipes to prevent the loss of fluid and the ingress of dirt. To refit the disc shields, reverse the above procedure.

Ensure that the flexible hose is not twisted or kinked when secured to the rear disc shield.

Tighten all fixings to their correct torque figures.

Wirelock the caliper mounting bolts.

Refit the road wheel.

Bleed the brakes.

## DISC — FRONT

### Renew

**Service Tool:** Brake piston retractor, Girling Part No. 64932392

Jack up the front of the car, place on stands and remove the road wheel.

Remove the spring clips (1, Fig. 8), securing the brake pad retaining pins (2, Fig. 8) and withdraw the retaining pins.




Fig. 8

Recover the anti-rattle springs (3, Fig. 8), and withdraw the brake pads (4, Fig. 8).




Fig. 9

Break the lock wire (1, Fig. 9) and remove the two bolts and spring washers (2, Fig. 9), securing the brake caliper to the stub axle carrier.

Slacken the bolt and washer (3, Fig. 9) securing the steering arm to the stub axle carrier.

**NOTE:** Make a careful record of the shim(s) fitted between the steering arm and the brake caliper.

Gently ease the caliper aside and secure with wire or strong cord, to prevent damaging the brake hose.




Fig. 10

Remove the front hub grease cap (1, Fig. 10), extract the split pin (2, Fig. 10), remove the hub retaining cap (3, Fig. 10), nut and washer (4, Fig. 10) from the stub axle. Withdraw the front hub and disc assembly.

Remove the five bolts and spring washers securing the brake disc to the front hub assembly, and withdraw the brake disc.

Inspect the disc for cracks and heavy scoring; light scratches are not detrimental. If any doubt exists, a new disc must be fitted.

Fit a new disc to the hub assembly, secure with five bolts and spring washers, tightened to the correct torque.

Refit the hub and disc assembly to the stub axle; adjust the hub bearing endfloat to 0.03 - 0.08 mm (0.001 - 0.003 in). This is measured using a dial test indicator gauge, mounted with the plunger against the hub. Tighten the nut until the correct endfloat is obtained, refit retainer, split pin and hub cap.

If a gauge is not available, the following procedure can be used:

Tighten the nut until there is no endfloat i.e. when the rotation of the hub is slightly restricted.

**CAUTION:** A torque of 0.691 Kg/m (5 lbf/ft) must not be exceeded or damage may be caused to the bearings and bearing tracks.

Slacken the nut one flat and fit the nut retaining cap. Fit a new split pin and bend over. Refit the grease cap, ensure that the vent hole is clear.

Refit the caliper to the stub axle carrier; ensure that the correct number of shims are fitted between the steering arm and the brake caliper. Tighten and wire lock the two caliper securing bolts. Tighten the steering arm securing bolt.

When a new disc has been fitted, it is recommended that new brake pads are also fitted. If the thickness of the pad material is less than 4 mm (0.16 in), then NEW pads MUST be fitted.

**NOTE:** It is advisable to reduce the level of brake fluid in the reservoir before fitting the new brake pads.

Lever the caliper pistons into the cylinder bores using Girling tool 64932392.




Fig. 11




Fig. 12

Fit the new brake pads to the caliper, fit the new anti-rattle springs. Secure in position with the retaining pins. Fit the spring clips. Refit the road wheel and lower the car. Run the engine and apply the brake pedal several times until the pedal feels solid.

## DISC — REAR

### Renew

**Service Tool:** Brake piston retractor, Girling Part No. 64932392

### Handbrake Mechanism

Jack up the rear of the car and place on stands.

Remove the nuts and bolts securing the tie-plate to the rear suspension unit; remove the tie-plate.

Ensure that the handbrake lever is in the fully 'OFF' position. Lift the carpet adjacent to the handbrake lever mounting for access to the cable adjusting nuts (1, Fig. 13); Slacken the cable lock and adjusting nuts.




Fig. 13




Fig. 14

J70-038

Release the springs (1, Fig. 14) from the handbrake caliper arms. Move the right-hand arm on RHD vehicles, or the left-hand arm on LHD vehicles (when viewed from the front of the car), to the centre line of the car, enabling the end of the inner (operating) cable (2, Fig. 14) to be detached from the operating arm. Slide the rubber cover from the outer cable (3, Fig. 14) and release the outer cable from the other handbrake operating arm.

Position the handbrake cable clear of the caliper.

Bend back the locking tabs (4, Fig. 14), securing the handbrake caliper mounting bolts. Remove the two mounting bolts, tab washer and retraction plate.

Slide the handbrake caliper around the brake disc, and withdraw through the gap exposed by the removal of the tie-plate.

### Rear Caliper

Remove the brake pads from the caliper.

Slacken the caliper feed pipe union at the three way connector, and disconnect the feed pipe from the caliper.

Plug the ports to prevent the loss of fluid and ingress of dirt.

Break the locking wire and remove the caliper mounting bolts.

**CAUTION: DO NOT under any circumstances remove the bolts securing the halves of the caliper together.**

Slide the caliper around the brake disc and withdraw through the gap exposed by the removal of the tie-plate.

### Rear Disc

Remove the road wheel, adjacent to the brake disc to be renewed.

Remove the hub carrier fulcrum shaft grease nipple (1, Fig. 16) to prevent damaging the nipple.

Remove the locking wire securing the radius arm bolt (1, Fig. 15) and remove the bolt. Lever the radius arm from the spigot anchor on the body.

Position a jack, or support blocks, under the hub carrier assembly.

Remove the nuts and washers securing the rear dampers to the lower wishbone.

Drift out the damper mounting pin (2, Fig. 16); recover the front damper spacer collar.

Slacken the clip (3, Fig. 16) securing the drive shaft inner universal joint cover and slide the cover along the drive shaft clear of the joint.




Fig. 16

J70-011

Remove the nuts (4, Fig. 16) securing the driveshaft flange to the brake disc.

Carefully separate the drive shaft flange from the brake disc; collect the camber angle shims located on the disc mounting bolts.

**NOTE: Record the number and value of the camber shims.**

Remove the brake disc from the mounting bolts.

**NOTE: Do NOT disturb the shims mounted between the final drive flange and the brake disc.**

Inspect the disc for cracks and heavy scoring; light scratching is not detrimental. If any doubt exists, a new disc MUST be fitted.

Fit the new disc on to the mounting bolts.

Replace the camber angle shims.

Fit the drive shaft flange over the shims on to the mounting bolts.

Fit and tighten the nuts to secure the drive shaft flange to the brake disc.

Check the disc for run-out. Clamp a dial test indicator to the suspension unit cross-member, position the indicator button against the brake disc face and zero the dial. Run-out must not exceed 0.10 mm (0.004 in).

Offer the brake caliper to its mountings and secure with the mounting bolts.

Check that the brake disc is central in the caliper by measuring the gap between the caliper abutments and the disc faces.

The gap on opposite sides of the disc may differ by up to 0.25 mm (0.010 in), but the gap between the upper abutment face and the disc, and the lower abutment face and the disc, on the same side should be equal.

To adjust, remove the caliper and disc, add or remove shims from between the axle unit output shaft flange and the brake disc. Make a note of the thickness of the shims added or removed.

On completion of the centralisation operation, add or withdraw camber shims to the same value as those used in the above adjustment operation.

e.g. If a 2.15 mm (0.06 in) shim was ADDED between the axle unit output flange and the brake disc, to centralise the disc, then REMOVE the same value of the shims from the camber angle shim pack, fitted between the brake disc and the drive shaft collar.

If shims were removed to centralise the disc, then ADD the same value of shims to the camber angle shim pack. This ensures that the camber angle, prior to the renewal of the disc, is retained.

When the disc is central in the caliper, tighten the caliper mounting bolts to the correct torque and wire lock.

Reposition the radius arm to the body spigot, refit the bolt, tighten to the correct torque and wire lock.

**NOTE: Prior to fitting the radius arm, wire brush the spigot and smear with grease.**

Slide the inner universal joint cover into place and secure with the clip.

Examine the brake pads for wear and damage. If the lining thickness is less than 4 mm (0.16 in), then new brake pads must be fitted.

Refit the brake pads to the caliper. Locate the retaining pins and fit the spring pins.

Examine the handbrake pads for wear. If the lining thickness is less than 4 mm (0.16 in) then new pads must be fitted.

If new handbrake pads are fitted, adjust the handbrake caliper.

Hold one pad carrier and unwind the other one until the distance between the pad faces is 19 mm (0.75 in).

Position the handbrake caliper, retraction plate and new tab washer. Secure with the mounting bolts and bend up the tab washer. Operate the actuating lever until the adjuster ratchet ceases to click. The handbrake pads are now adjusted to the correct clearance. Refit the springs to the operating arms.

Fit the brake feed pipe to the caliper and the three-way connector.

Refit the handbrake cable and adjust so that with the handbrake fully 'OFF' there is a slight amount of slack within the cable.

**NOTE: If the cable is adjusted so that all the slack is removed, binding of the handbrake caliper may result.**

Tighten the locknut and replace the sill carpet.

Refit the tie-plate to the suspension unit.

Bleed the brakes.

Refit the road wheel and lower the car.

Check and, if necessary, adjust the camber angle.




Fig. 15

J70-012

## BRAKE CALIPER — FRONT

### Overhaul

Jack up the front of the car, place on stands and remove the road wheel.




Fig. 17

J70-007

Remove the spring clips (1, Fig. 17) securing the brake pad retaining pins (2, Fig. 17) and withdraw the retaining pins. Recover the anti-rattle springs (3, Fig. 17) and withdraw the brake pads (4, Fig. 17).




Fig. 18

J70-022

Slacken the caliper feed pipe union (1, Fig. 18) at the support bracket and disconnect the feed pipe from the caliper, plug the pipe to prevent the loss of fluid and ingress of dirt.

Break the lock wire (2, Fig. 18) and remove the two bolts and spring washers (3, Fig. 18) securing the brake caliper and the stub axle carrier.

**NOTE:** Make a careful record of the shim(s) fitted between the steering arm and the brake caliper.

Withdraw the caliper (4, Fig. 18) from the car.

Thoroughly clean the caliper using ONLY Castrol/Girling Brake Cleaning Fluid.

**CAUTION:** DO NOT under any circumstances remove, or attempt to remove, the bolts securing the halves of the caliper together.

Remove the spring clips (1, Fig. 19) retaining the piston dust covers (2, Fig. 19) and remove the dust covers from the pistons (3, Fig. 19).




Fig. 19

J70-031

To expel the pistons, carefully feed compressed air into the caliper fluid inlet port; remove the pistons from the caliper.

**WARNING:** EXTREME CARE MUST BE TAKEN NOT TO DAMAGE THE CYLINDER BORES WHEN EXTRACTING THE SEALS.

Carefully prise each seal (4, Fig. 19) from the recess in each piston cylinder bore.

Using only Castrol/Girling Brake Cleaning Fluid, thoroughly clean all the components. Examine the pistons and cylinder bores for signs of abrasion, 'scuffing', scratches or corrosion. If any doubt exists as to the condition of a component then a new one must be fitted.

Coat the new seals in Castrol/Girling Brake Lubricant, or new, clean brake fluid. Fit the new seals into the recesses in the cylinder bores (1, Fig. 20) using ONLY finger pressure.




Fig. 20

J70-032

Lubricate the pistons (2, Fig. 20) with brake lubricant, or new, clean brake fluid, and enter them into the cylinder bores.

Fit new dust covers (3, Fig. 20) over the pistons and locate in the outer groove of the piston. Push the pistons fully home and locate the dust cover in the outer grooves of the cylinder bores.

Secure the dust covers with the spring clips (4, Fig. 20).

Refit the caliper to the stub axle carrier; ensure that the correct value of shim(s) is fitted between the brake caliper and the steering arm. Tighten the bolts to the correct torque and wire lock.

Reconnect the caliper feed pipe to the support bracket and tighten the pipe union to the support bracket.

**NOTE:** Examine the brake pads for wear and damage. If the lining thickness is less than 4 mm (0.16 in), then new brake pads must be fitted.

Refit the brake pads. Bleed the brakes. Refit the road wheel and lower the car.

## BRAKE CALIPER — REAR

### Overhaul

Service Tool: Piston Clamp 18G672

Jack up the rear of the car and remove the handbrake and rear brake calipers as described on page 70—6 in the rear disc renewal procedure.

Thoroughly clean the caliper using ONLY Castrol/Girling Brake Cleaning Fluid.

**CAUTION:** DO NOT under any circumstances remove or attempt to remove the bolts securing the caliper halves together.

Fit the piston clamp, Tool No. 18G672, to one half of the caliper, to retain one piston in position, whilst carefully feeding compressed air into the caliper inlet port, to expel the other piston (3, Fig. 21).




Fig. 21

J70-033

Remove the dust seal (2, Fig. 21) from the piston and cylinder bore.

**WARNING:** EXTREME CARE MUST BE TAKEN NOT TO DAMAGE THE CYLINDER BORE WHEN EXTRACTING THE SEAL.

Carefully prise the seal (1, Fig. 21) from the recess in the cylinder bore.

Using only Castrol/Girling Brake Cleaning Fluid, thoroughly clean the cylinder bore and piston.

Examine the components for signs of abrasion, 'scuffing', scratches or corrosion. If any doubt exists as to the condition of a component, then a new one MUST be fitted. Coat the new seal (1, Fig. 21) in Castrol/Girling Brake Lubricant, or in new clean brake fluid, and enter it onto the cylinder bore.

Fit a new dust cover (2, Fig. 21) over the piston and locate it in the outer groove of the piston. Push the piston (3, Fig. 21) fully home and locate the dust cover in the outer groove of the cylinder bore.



Release the piston clamp tool and fit it to the other half of the caliper.  
Repeat the applicable operations on the other piston.  
Refit the caliper assembly to the car.

## HANDBRAKE LEVER ASSEMBLY

### Renew

Disconnect the battery.  
Remove the driver's seat assembly. This operation is fully covered in the Body Section of this Manual Book 8, Section 76, page




Fig. 22

J70-063

Remove the setbolt (1, Fig. 22) securing the handbrake lever mechanism cover. Raise the handbrake lever and slide off the cover. Disconnect the electrical lead (1, Fig. 24) from the brake warning light switch.




Fig. 23

J70-064

Lift the carpet adjacent to the handbrake lever mounting for access to the cable adjusting nuts (1, Fig. 23); slacken the cable, lock and adjusting nuts.




Fig. 24

J70-064

Remove the adjustable nipple (2, Fig. 24) from the end of the handbrake cable. Remove the pivot bolt (3, Fig. 24) and the bolts (4, Fig. 24) securing the handbrake assembly to the inner sill.

Detach the earth lead (5, Fig. 24). Recover the distance pieces (6, Fig. 24) fitted between the handbrake assembly and the inner sill.

Disengage the handbrake assembly and remove from the car.

Remove the warning light switch.

Fit the warning light switch to the new handbrake lever assembly; reverse the above procedure to fit the handbrake lever assembly to the car.

Reconnect the battery. Adjust the handbrake warning light switch so that when the handbrake is in the 'OFF' position the warning light just goes out. Tighten the securing bolts.

Check that the warning light comes 'on' when the handbrake is applied and goes 'off' when the handbrake is released. Re-adjust as necessary.

Adjust the handbrake cable; a slight amount of slack should be evident with the handbrake in the 'OFF' position.

Refit the handbrake cover. Refit the driver's seat assembly.

## HANDBRAKE CABLE

### Renew

Remove the driver's seat. This operation is fully covered in the Body Section of this Service Manual, Book 8, Section 76, page

Remove the setbolt securing the handbrake lever mechanism cover. Raise the handbrake lever and slide off the cover.




Fig. 25

J70-064

Lift the carpet adjacent to the handbrake lever mounting for access to the cable adjusting nuts (1, Fig. 25). Slacken the cable lock and adjusting nuts.

Remove the adjustable nipple (1, Fig. 26) from the end of the handbrake cable.

Disconnect the nipple and inner cable from the operating arm of the handbrake caliper (2, Fig. 26).

Disconnect the outer cable from the other handbrake operating arm (3, Fig. 26).

Cut the clips securing the protective sleeve (4, Fig. 26) to the outer cable; slide the sleeve off the cable.





Fig. 26

Remove the protective cover (5, Fig. 26) from the point where the outer cable goes through the body.

From inside the car, pull the cable assembly free from the body guide tube (6, Fig. 26); remove the cable from the car.

Remove the adjusting nut, locknut and guide tube from the cable.

To refit the cable assembly, reverse the above procedure.

Adjust the cable so that with the handbrake fully 'OFF' there is a slight amount of slack within the cable.

**NOTE:** If the cable is adjusted so that all the slack is removed, the handbrake calipers may bind on the discs.

Tighten the locknut and replace the sill carpet.

## MASTER CYLINDER

### Overhaul

Peel back the rubber cover (1, Fig. 27) from the top of the brake fluid reservoir and disconnect the wires from the fluid level indicator switch.

Remove the reservoir cap and filter.

Using a suitable syringe, remove the brake fluid from the reservoir.




Fig. 27

J70-065A

### To remove the fluid reservoir:

Slacken the clips securing the master cylinder feed pipe hoses to the fluid reservoir and disconnect the hoses from the reservoir. Use a piece of rag, or a suitable container, to collect any remaining fluid.

## BRAKES

Remove the nuts, bolts and plain washers securing the fluid reservoir to the mounting bracket; remove the reservoir.

Plug all the hose and pipe ends to prevent any further loss of fluid and the ingress of dirt.

### To remove the master cylinder

Slacken the clips securing the feed pipe hoses (2, Fig. 27) to the master cylinder, and disconnect the hoses from the master cylinder. Use a piece of rag, or a suitable container, to collect any remaining fluid.

Plug all the hose and pipe ends to prevent any further loss of fluid or ingress of dirt.

**CAUTION:** Before removing the master cylinder, it is imperative that the brake pedal is operated at least ten times to ensure that there is no vacuum left to operate the servo.

**Operation of the servo, when the master cylinder is not fitted, can cause the servo mechanism to travel beyond its normal limit, making the servo unit irreparable.**

Remove the nuts and washers (3, Fig. 27) securing the master cylinder to the servo unit; remove the master cylinder.

**NOTE:** The overhaul of the master cylinder should be carried out with the work area, tools and hands in a clean condition.

### To dismantle the master cylinder:

Carefully prise out the master cylinder inlet pipe adaptors (1, Fig. 28) from the sealing grommets.




Fig. 28

Using a suitable screwdriver, lever out the sealing grommets (2, Fig. 28) from the master cylinder.

Press in the primary piston to relieve the pressure on the secondary piston stop pin (3, Fig. 28); remove the stop pin from the front grommet sealing housing. Maintain the pressure on the primary piston; remove the circlip (4, Fig. 28).

Tap the flange (open) end of the master cylinder on a wooden block to remove the primary and second pistons and spring assemblies (5, Fig. 28). It may be necessary to feed compressed air into the master cylinder front delivery port.

**NOTE:** Once the piston assemblies have been withdrawn, it is important that the appropriate piston and spring are kept together. In the event of the springs being mixed, then the secondary piston spring is slightly thicker and longer than the primary spring.




Fig. 29

Remove the spring, spring seat and seal from the front end of the secondary piston (1, Fig. 29).

Carefully prise the seal (2, Fig. 29) from the rear of the secondary piston.

Remove the spring, spring seat and seal from the front end of the primary piston (3, Fig. 29).

Carefully prise the seal (4, Fig. 29) from the rear of the primary piston.

Discard all the old seals and associated items, which will be replaced by those contained within the service kit.

Clean all the components with Castrol/Girling Cleaning Fluid and dry with a lint free cloth.

Examine the piston and bore of the master cylinder for visible signs of scoring, ridges and corrosion. If any doubt exists as to the condition of a component, then it must be renewed.

**CAUTION:** To help prevent damage, it is essential that generous amounts of clean brake fluid are used at all stages of the seal fitting.

Carefully fit the rear seal in its groove in the secondary piston; ensure that the lip of the seal faces towards the primary piston.

Fit the front seal, spring seat and spring to the front end of the secondary piston; ensure that the lip of the seal faces away from the primary piston.

Carefully fit the rear seal in its groove in the primary piston; ensure that the lip of the seal faces forwards i.e. away from the circlip groove.

Fit the seal, spring seat and spring to the front end of the primary piston, with the lip of the seal facing forwards i.e. away from the circlip grooves.

**CAUTION:** Adherence to the following instructions is vitally important. Failure to comply will result in damaged piston seals.

Carefully secure the master cylinder in a vice and generously lubricate the piston seals with new, clean brake fluid. Offer the secondary piston assembly to the master cylinder until the front seal rests centrally in the mouth of the cylinder. Ensure that the seal is not trapped; slowly rotate and rock the piston assembly whilst GENTLY introducing the piston into the cylinder bore. Once the front seal has entered the bore of the cylinder, SLOWLY push home the piston in one continuous movement.

Repeat this method for the primary piston assembly.

Press the primary piston into the bore and fit the circlip.

Fully push home the primary piston and fit the secondary piston stop pin.

Fit the sealing grommets to the master cylinder. Lubricate and press the hose adaptors into the sealing grommets.

Refit the master cylinder to the servo.

Reconnect the fluid feed pipe hoses to the master cylinder.

Fill the reservoir with new fluid of the correct specification and carry out the brake system bleed procedure as detailed on page 70—5.

## RESERVAC TANK

### Renew

The reservac tank is situated behind the front right-hand wheel arch front dust shield. The dust shield must be removed to gain access to the tank.

The dust shield is secured to the wheel arch with plastic drive fasteners.

CONTENTS

| Operation                                  | Operation No. | Page No. |
|--|---------------|----------|
| Data .....                                 |               | 74—2     |
| Description .....                          |               | 74—2     |
| Tyres .....                                |               | 74—2     |
| Damage .....                               |               | 74—3     |
| General .....                              |               | 74—2     |
| Heat .....                                 |               | 74—3     |
| Pressure .....                             |               | 74—2     |
| Repairs .....                              |               | 74—3     |
| USA gradings .....                         |               | 74—3     |
| Valves .....                               |               | 74—3     |
| Wear .....                                 |               | 74—3     |
| Tyre and wheel balance .....               |               | 74—4     |
| Dynamic balance .....                      |               | 74—4     |
| Static balance .....                       |               | 74—4     |
| Wheels .....                               |               | 74—3     |
| Alignment Precautions .....                |               | 74—4     |
| Misalignment and road camber effects ..... |               | 74—3     |

### DESCRIPTION

## TYRES

Tyres of the correct type, dimensions and at the correct cold inflation pressures are an integral part of the vehicle's design. Regular maintenance of tyres, therefore, not only contributes to safety but retains road-holding, steering and braking qualities. Tyres of the same type and size have widely

## Pressure

## DATA

|   |                         |
|---|-------------------------|
| Type — All countries excluding USA/Canada ..... | 6 x 15 perforated alloy |
| — USA/Canada only .....                         | 6.5 x 15 starfish alloy |
| Fixing .....                                    | Five studs and nuts     |

Make ..... Pirelli or Dunlop  
 Type — Pirelli ..... 215/70 VR15 P5 Cinturato  
       — Dunlop ..... 215/70 VR15 SP Sport Super D7

| Pressure               | Front                   | Rear                    |
|------------------------|-------------------------|-------------------------|
| Speeds above 160 km/hr | 2.20 bars               | 2.20 bars               |
| (100 mph) under all    | 2.25 kg/cm <sup>2</sup> | 2.25 kg/cm <sup>2</sup> |
| load conditions .....  | 32 lb/in <sup>2</sup>   | 32lb/in <sup>2</sup>    |

## Valves

|              |                                   |
|--------------|-----------------------------------|
| Make .....   | Bridgeport                        |
| Type .....   | Screw in                          |
| Torque ..... | 3.39 to 4.52 Nm (30 to 40 lbs/in) |

|               |   |
|---------------|---|
| Make .....    | Dunlop  |
| Type .....    | Weathermaster 185 SR15 SP<br>M & S (Mud and Slush)    |
| Fitting ..... | Complete set with 'Weathermaster only'<br>inner tubes |

| Pressure  | Front   | Rear  |
|---|---|---|
| Speeds up to 137 km/hr<br>(85 mph) under all<br>load conditions | 1.79 bars<br>1.83 kg/cm <sup>2</sup><br>26 lb/in <sup>2</sup> | 1.79 bars<br>1.83 kg/cm <sup>2</sup><br>26 lb/in <sup>2</sup> |
| Speeds up to 161 km/h<br>(100 mph) under all<br>load conditions | 2.35 bars<br>2.39 kg/cm <sup>2</sup><br>34 lb/in <sup>2</sup> | 2.35 bars<br>2.39 kg/cm <sup>2</sup><br>34 lb/in <sup>2</sup> |

1. All tyre inflation pressures are applicable to cold tyres only.
2. Snow chains may be fitted over snow tyres of rear wheels only.
3. Studs may be fitted to all snow tyres, but a maximum speed restriction of 121 km/hr (75 mph) is imposed.

Tyre pressures should be checked and, if necessary, adjusted weekly with the tyres cold i.e. not immediately following a run as pressure increases with temperature due to road friction. 'Bleeding' a warm tyre to the recommended pressure will result in under-inflation which can be both dangerous and depreciate tyre life. Pressure loss with time is normal, but investigation should be made if a pressure loss in excess of 0.14 kg/cm<sup>2</sup> (2 lb/in<sup>2</sup>) is encountered during a period of one week.

It is an offence in the UK to use a vehicle on public roads with tyres improperly inflated. Furthermore, incorrect inflation accelerates wear and causes excessive heating which can result in tyre failure due to blow out.

**CAUTION: When inflating a tyre, it is important to ensure that a pressure of 2.8 kg/cm<sup>2</sup> (40 lb/in<sup>2</sup>, 3.1 bars) is not exceeded otherwise serious tyre damage may result.**

### Wear

All tyres fitted as standard have a tread wear indicator (Fig. 1) moulded into their tread pattern to provide indication when the tread depth remaining is 1.5 mm (0.6 in). Each indicator appears on the tread surface as bars which connect the tread pattern across the full width of the tyre. It is illegal in the UK and certain other countries to continue using tyres after the tread has worn to less than 1 mm (0.039 in) over three quarters of the tread width around the entire circumference.

The properties of many tyres alter progressively with wear. In particular, 'wet grip' and aquaplaning resistance properties are gradually, but substantially, reduced. Extra care and speed restriction should therefore be exercised on wet roads as the effective tread depth diminishes.

Should either front or rear tyres only show excessive wear, new tyres must be fitted to replace worn ones. Under no circumstances interchange tyres from front to rear or vice versa as individual tyre wear produces unique characteristics which adversely affect performance.

### Damage

Excessive localised distortion, sometimes caused by severe contact with kerbs or stones, can cause the tyre casing to fracture and may lead to premature tyre failure. Tyres should, therefore, be periodically examined and any tyre having distortion, cracks and/or cuts should be replaced. In addition, all tread imbedded objects, such as stones and glass, should be withdrawn and all contamination, i.e. oil and grease, removed using a suitable solvent.

**CAUTION: Paraffin (kerosene) must not be used as a cleansing agent on tyres.**

### Heat

Tyres should not be subjected to excessive heat such as that inherent of paint drying/baking ovens. It is recommended, therefore, that all wheels be removed or at least the tyres be relieved of vehicle body weight.

### Repairs

All minor tyre and tube repairs must be vulcanised in accordance with the vulcanising equipment manufacturer's operating instructions.

### Valves

When a new tubeless tyre is fitted, the valve should be renewed.

### USA Grading

The following information relates to the tyre grading system developed by the national Highway Traffic Safety Administration which grades tyres by tread wear, traction and temperature performance.

### Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tyre when tested under controlled conditions on a specified government test course. For example, a tyre graded 150 would wear one and a half times less on the government

course than a tyre graded 100. The relative performance of the tyres depends upon the actual conditions of their use, however, and may depart significantly from normal due to variations in driving habits, service practices and differences in road characteristics and climate.

### Traction — A, B, C

The traction grades, from highest to lowest, are A, B and C, and they represent the tyres ability to stop in wet conditions measured on specified government test surfaces of asphalt and concrete.

**WARNING: THE TRACTION GRADE IS BASED ON BRAKING (STRAIGHT AHEAD) TRACTION TESTS AND DOES NOT INCLUDE CORNERING (TURNING) TRACTION.**

### Temperature — A, B, C

The temperature grades are A (the highest), B and C, and they represent the tyre's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tyre to degenerate and reduce tyre life, and excessive temperature can lead to sudden tyre failure. Grade C corresponds to a level of performance which all passenger car tyres must meet under Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

**WARNING: THE TEMPERATURE GRADE IS ESTABLISHED FOR A TYRE THAT IS PROPERLY INFLATED AND NOT OVERLOADED. EXCESSIVE SPEED, UNDERINFLATION, OR EXCESSIVE LOADING, WHETHER SEPARATELY OR IN COMBINATION, CAN CAUSE HEAT BUILD UP AND POSSIBLE TYRE FAILURE.**

## WHEELS

### Misalignment and road camber effects

It is important that correct wheel alignment be maintained. Misalignment causes tyre tread to be scrubbed off laterally because the natural direction of the wheel differs from that of the car.

A sharp 'fin' protrusion on the edge of each pattern rib is a sure sign of misalignment and it is possible to determine from the position of the 'fins' whether the wheels are toeing in or toeing out.

'Fins' on the inside edges of the pattern ribs, particularly on the nearside tyre, indicate toe-in. 'Fins' on the outside edges, particularly on the offside tyre, indicate toe-out.

With minor misalignment, the evidence is less noticeable and sharp pattern edges






Fig. 1


may be caused by road camber even when the wheel alignment is correct. In such cases it is better to make sure by checking with an alignment gauge. Road camber affects the direction of the car by imposing a side thrust and, if left to follow its natural course, the car will drift towards its near-side. This is instinctively corrected by steering towards the road centre and, as a result, the car runs crabwise as illustrated in an exaggerated form in Fig. 2. The diagram shows why nearside tyres are very sensitive to too much toe-in and offside tyres to toe-



(A) Wheels parallel in motion: tyre wear equal



(B) Wheels toed-out in motion: RH front tyre wears faster



(C) Wheels toed-in in motion: LH front tyre wears faster.

Fig. 2 Exaggerated diagram of the way in which road camber affects a car's progress.

out. It also shows why sharp 'fins' appear on one tyre but not on the other, and why the direction of misalignment can be determined by noting the position of the 'fins'. Severe misalignment produces clear evidence on both tyres.

The front wheels on a moving car should be parallel. Tyre wear can be affected noticeably by quite small variations from this condition. It will be noted from the diagram that even with parallel wheels, the car is still out of line with its direction of movement, but there is less tendency for the wear to be concentrated on one tyre.

The near front tyre sometimes persists in wearing faster and more unevenly than the other tyres, even when the mechanical condition of the car and tyre maintenance are satisfactory. The more severe the average road camber, the more marked this tendency will be.

## Alignment Precautions

Wheels and tyres vary laterally within their manufacturing tolerances, or a result of service, and alignment figures obtained without moving the car are unreliable. The following precautions should, therefore, be observed:

1. The car should have come to rest from a forward movement. This ensures, as far as possible, that the wheels are in natural running positions.
2. It is preferable for alignment to be checked with the car laden.
3. With a conventional base bar tyre alignment gauge, measurements should be taken in front of and behind the wheel centres at the same position on the tyre and rim flanges. This is achieved by marking the tyres where the first reading is taken and moving the car forwards approximately half a road wheel revolution before taking the second reading at the same points. With an optical gauge, two or three readings should be taken with the car moved forwards to different positions — 180° road wheel turn for two readings and 120° for three readings. An average figure should then be calculated.

## TYRE AND WHEEL BALANCE

### Static Balance

In the interests of smooth riding, precise steering and the avoidance of high speed 'tramp' or 'wheel hop', all tyres are balance checked to predetermined limits. To ensure the best degree of tyre balance, the covers are marked with white spots on one bead and these indicate the highest part of the cover.

Some tyres are slightly outside standard balance limits and are corrected before issue by attaching special patches to the inside of the covers at the crown. These patches contain no fabric, they do not affect the local stiffness of the tyre and should not

be mistaken for repair patches. They are embossed 'Balance Adjustment Rubber'. The original degree of balance is not necessarily maintained and it may be affected by uneven tread wear, by cover and tube repair, by tyre removal or refitting, or by wheel damage or eccentricity. The car may also become sensitive to unbalance due to normal wear of moving parts. If roughness or high speed steering troubles develop and mechanical investigation fails to disclose a possible cause, wheel and tyre balance should be suspected.

Recommended Tyre Balancing Equipment can be found in the BL STEP programme manual.

**WARNING: IF BALANCING EQUIPMENT IS USED WHICH DYNAMICALLY BALANCES THE ROAD WHEELS ON THE CAR, ALWAYS JACK BOTH REAR WHEELS OFF THE GROUND WHEN REAR WHEEL BALANCING OTHERWISE DAMAGE MAY BE CAUSED TO THE DIFFERENTIAL. THIS IS DOUBLY IMPORTANT IN THE CASE OF CARS FITTED WITH A 'POWR-LOK' DIFFERENTIAL AS, IN ADDITION TO POSSIBLE DAMAGE TO THE DIFFERENTIAL, THE CAR MAY DRIVE ITSELF OFF THE JACK OR STAND.**

### Dynamic Balance

Static unbalance can be measured when the tyre and wheel assembly is stationary. There is another form known as dynamic unbalance which can be detected only when the assembly is revolving.


There may be no heavy spot, that is, there be no natural tendency for the assembly to rotate about its centre due to gravity, but the weight may be unevenly distributed each side of the centre tyre line. Laterally, the eccentric wheels give the same effect. During rotation, the offset weight distribution sets up a rotating couple which tends to steer the wheel to the right and left alternately.

Dynamic unbalance of the tyre and wheel assemblies can be measured on suitable tyre balancing equipment, and corrections made when cars show sensitivity to this form of unbalance. Where it is clear that a damaged wheel is the primary cause of severe unbalance, it is advisable for the wheel to be replaced.





**XJ-S 3.6  
XJ-SC 3.6  
SERVICE  
MANUAL**







## BOOK 7

Containing  
Section

76 BODY

XJ-S 3·6  
XJ-SC 3·6

SERVICE MANUAL

---

## INTRODUCTION

This Service Manual covers the Jaguar XJ-S 3.6 and XJ-SC 3.6. It is primarily designed to assist skilled technicians in the efficient repair and maintenance of this range of Jaguar cars.

Using the appropriate service tools and carrying out the procedures as detailed will enable the operations to be completed within the time stated in the 'Repair Operation Times'.

The Service Manual has been produced in 9 separate books; this allows the information to be distributed throughout the specialist areas of the modern service facility.

A table of contents in Book 1 lists the major components and systems together with the section and book numbers. The cover of each book depicts graphically and numerically the sections contained within that book.

The title page of each book carries the part numbers required to order replacement books, binders or complete Service Manuals. This can be done through the normal channels.

The contents section of each book lists the repair operations in the section or sections contained within that book. Each operation is given an operation number that corresponds with those listed in the Repair Operation Times.

The method described on the page number listed against the operation will be the one we consider will meet the requirements of safety and enable the operation to be carried out in the time specified in the Repair Operation Times.

Where no page number is given against an operation, we feel that the method is so obvious as to warrant no explanation. It is, however, included so that a warranty time can be given in the Repair Operation Times.

Extensive research has gone into the diagnosis of faults and where appropriate this is covered in the various areas of the manual. By following the sequence of the diagnosis charts, speedy isolation of faults may be expected, and consequent correction will reduce the vehicle off-the-road time to the minimum.

### Service Tools

Where performance of an operation requires the use of a service tool the tool number is quoted under the operation heading and is repeated in, or following, the instruction involving its use. A list of all necessary tools is included in Book 1, Section 99.

### References

References to the LH or RH side in the manual are made when viewing from the rear. With the engine and gearbox assembly removed the timing cover end of the engine is referred to as the front. A key to abbreviations and symbols is given in Book 1, Section 01.

## REPAIRS AND REPLACEMENTS

When service parts are required it is essential that only genuine Jaguar or Unipart replacements are used.

Attention is particularly drawn to the following points concerning repairs and the fitting of replacement parts and accessories.

1. Safety features embodied in the vehicle may be impaired if other than genuine parts are fitted. In certain territories, legislation prohibits the fitting of parts not to the vehicle manufacturer's specification.
2. Torque wrench setting figures given in this Service Manual must be strictly adhered to.
3. Locking devices, where specified, must be fitted. If the efficiency of a locking device is impaired during removal it must be replaced.
4. Owners purchasing accessories while travelling abroad should ensure that the accessory and its fitted location on the vehicle conform to mandatory requirements existing in their country of origin.
5. The vehicle warranty may be invalidated by the fitting of other than genuine Jaguar or Unipart parts. All Jaguar and Unipart replacements have the full backing of the factory warranty.
6. Jaguar Distributors and Dealers are obliged to supply only genuine service parts.

## SPECIFICATION

Purchasers are advised that the specification details set out in this Manual apply to a range of vehicles and not to any one. For the specification of a particular vehicle, purchasers should consult their Distributor or Dealer.

The Manufacturers reserve the right to vary their specifications with or without notice, and at such times and in such manner as they think fit. Major as well as minor changes may be involved in accordance with the Manufacturer's policy of constant product improvement.

Whilst every effort is made to ensure the accuracy of the particulars contained in this Manual, neither the Manufacturer nor the Distributor or Dealer, by whom this Manual is supplied, shall in any circumstances be held liable for any inaccuracy or the consequences thereof.

## COPYRIGHT

© Jaguar Cars Ltd. 1983

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, electronic, mechanical, photocopying, recording or other means without prior written permission of Jaguar Cars Ltd., Service Department, Radford, Coventry CV6 3GB.

## CONTENTS

| Operation  | Operation No. | Page No. |
|--|---------------|----------|
| Alignment — Check .....                          | 76.10.01      | 76—3     |
| 'A' post trim pad — Renew .....                  | 76.13.07      | 76—4     |
| Bonnet — Renew .....                             | 76.16.01      | 76—5     |
| Grille — Renew .....                             | 76.55.03      | 76—5     |
| Bonnet hinge — Renew .....                       | 76.16.12      | 76—5     |
| Bonnet lock control cable — Adjust .....         | 76.16.01      | 76—5     |
| Bonnet lock LH — Renew .....                     | 76.16.21      | 76—5     |
| Bonnet lock RH — Renew .....                     | 76.16.26      | 76—5     |
| Bonnet lock trigger release handle — Renew ..... | 76.16.17      | 76—5     |
| Boot lid — Renew .....                           | 76.19.01      | 76—6     |
| Boot lid hinge — Renew .....                     | 76.19.07      | 76—6     |
| Boot lid handle/lock assembly — Renew .....      | 76.19.17      | 76—7     |
| Boot lid lock — Renew .....                      | 76.19.11      | 76—6     |
| Boot lid lock striker — Renew .....              | 76.19.12      | 76—6     |
| Boot lid seal — Renew .....                      | 76.19.06      | 76—6     |
| 'B' post trim pad — Renew .....                  | 76.19.08      | 76—4     |
| Bumper front centre section blade — Renew .....  | 76.22.11      | 76—8     |
| Bumper front quarter — Renew .....               | 76.22.16      | 76—7     |
| Bumper energy absorbing beam front — Renew ..... | 76.22.26      | 76—7     |
| Bumper energy absorbing beam rear — Renew .....  | 76.22.27      | 76—7     |
| Bumper rear centre section — Renew .....         | 76.22.12      | 76—7     |
| Bumper rear quarter section — Renew .....        | 76.22.17      | 76—7     |
| Cabriolet cant rail trim pad — Renew .....       | 76.85.09      | 76—16    |
| Cabriolet front headlining — Renew .....         | 76.85.08      | 76—16    |
| Cabriolet hood canopy — Renew .....              | 76.85.01      | 76—15    |
| Cabriolet hood canopy guides — Renew .....       | 76.85.04      | 76—14    |
| Cabriolet hood canopy latches — Renew .....      | 76.85.02      | 76—15    |
| Cabriolet hood canopy seal — Renew .....         | 76.85.03      | 76—15    |
| Cabriolet rear stowage compartment — Renew ..... | 76.85.07      | 76—14    |
| Cabriolet roll bar trim pad — Renew .....        | 76.85.06      | 76—15    |
| Cabriolet targa top seal — Renew .....           | 76.85.05      | 76—16    |
| Console assembly — Renew .....                   | 76.25.01      | 76—8     |
| Door arm rest — Renew .....                      | 76.34.22      | 76—10    |
| Door glass — Renew .....                         | 76.31.01      | 76—9     |
| Door glass weather strip — Renew .....           | 76.31.50      | 76—10    |
| Door hinge — Renew .....                         | 76.31.42      | 76—9     |

**BODY**

| <b>Operation</b>  | <b>Operation No.</b> | <b>Page No.</b> |
|---|----------------------|-----------------|
| Door inside handle — Renew .....                          | 76.31.18             | 76—11           |
| Door lock — Adjust .....                                  | 76.37.01             | 76—11           |
| Door lock — Renew .....                                   | 76.37.12             | 76—10           |
| Door lock striker plate — Renew .....                     | 76.37.23             | 76—10           |
| Door outside handle — Renew .....                         | 76.58.01             | 76—11           |
| Door quarter light — Renew .....                          | 76.31.29             | 76—10           |
| Door trim pad — Renew .....                               | 76.34.21             | 76—9            |
| Electric door mirror — Renew .....                        | 76.10.52             | 76—4            |
| Fascia — Renew .....                                      | 76.46.01             | 76—11           |
| Fascia glove box lid — veneer panel — Renew .....         | 76.52.12             | 76—11           |
| Fascia switch panel — veneer panel — Renew .....          | 76.46.30             | 76—11           |
| Fascia underscuttle casing — driver's side — Renew .....  | 76.46.11             | 76—11           |
| Fascia underscuttle casing — passenger side — Renew ..... | 76.46.15             | 76—11           |
| Fascia veneer panel — centre — Renew .....                | 76.46.29             | 76—11           |
| Fascia veneer panel — driver's side — Renew .....         | 76.46.26             | 76—11           |
| Fascia veneer panel — passenger side — Renew .....        | 76.46.25             | 76—11           |
| Front ash tray — Renew .....                              | 76.67.13             | 76—13           |
| Front seat — Renew .....                                  | 76.70.01             | 76—14           |
| Front seat belt — Renew .....                             | 76.73.10             | 76—4            |
| Front seat cushion — Renew .....                          | 76.70.03             | 76—14           |
| Front seat runner and adjuster assembly — Renew .....     | 76.70.24             | 76—14           |
| Front spoiler — Renew .....                               | 76.10.46             | 76—4            |
| Fuel filler cap — Renew .....                             | 76.10.25             | 76—4            |
| Headlining — Renew .....                                  | 76.64.01             | 76—             |
| Lower grille — Renew .....                                | 76.55.09             | 76—4            |
| Rear ashtray — Renew .....                                | 76.67.14             | 76—13           |
| Rear quarter light — Renew .....                          | 76.00.00             | 76—10           |
| Rear set parcel shelf — Renew .....                       | 76.67.06             | 76—13           |
| Rear seat cushion — Renew .....                           | 76.70.37             | 76—13           |
| Rear seat squab — Renew .....                             | 76.70.38             | 76—13           |
| Rear seat arm rest — Renew .....                          | 76.70.39             | 76—13           |

| SYMBOL | MEASUREMENT TAKEN FROM   | cm     | in     |
|--------|--|--------|--------|
| A      | Front suspension mounting point to datum line  | 7,70   | 3.05   |
| B      | Inner face of front suspension mounting point to centre line of car                      | 39,50  | 15.56  |
| C      | Rear suspension front lower mounting point to datum line                                 | 11,50  | 4.54   |
| D      | Rear suspension rear lower mounting point to datum line                                  | 11,00  | 4.34   |
| E      | Front suspension, front mounting point to rear suspension front lower mounting point     | 278,23 | 109.54 |
| F      | Rear suspension, front lower mounting point to rear suspension rear lower mounting point | 33,05  | 13.01  |
| G      | Distance between inner faces of front suspension mounting points                         | 79,04  | 31.12  |
| H      | Radius arm mounting to rear suspension front mounting point                              | 26,65  | 10.50  |
| J      | Wheelbase  | 259,10 | 102.00 |
| K      | Track (front)  | 148,30 | 58.40  |
| L      | Track (rear)   | 149,60 | 58.90  |
| M      | Distance between inner faces at rear of front chassis members                            | 34,10  | 13.43  |
| N      | Horizontal datum line  | —      | —      |
| O      | Centre line of car   | —      | —      |
| P      | Overall width of car   | 179,30 | 70.60  |
| Q      | Front bumper mounting to datum line  | 38,23  | 15.05  |
| R      | Distance between front bumper mountings  | 76,46  | 30.10  |
| S      | Front suspension mounting to front cross member mounting                                 | 40,59  | 15.98  |
| T      | Radius arm mounting to rear suspension front mounting                                    | 28,57  | 11.25  |
| U      | Radius arm mounting to datum line  | 56,03  | 22.06  |
| V      | Distance between radius arm mountings  | 112,06 | 44.12  |
| W      | Rear suspension front mounting to datum line   | 49,60  | 19.53  |
| X      | Distance between rear suspension front mounting  | 99,20  | 39.06  |
| Y      | Rear bumper mounting to datum line   | 46,38  | 18.26  |
| Z      | Distance between rear bumper mountings   | 92,76  | 36.52  |




Fig. 1

**ELECTRIC DOOR MIRROR**

**Renew**

Remove the screws securing the door mirror and displace the mirror to gain access to the cable harness block connector.  
Remove the block connector securing strap, and disconnect the block connector.  
Remove the mirror and gasket  
On refitting, ensure the connections are clean and tight.  
Secure the block connector with a new strap.

**FUEL FILLER FLAP**

**Renew**

Open the fuel filler flap.  
Remove the bolts securing the flap and hinge mechanism to the body.  
Remove the flap assembly.  
On refitting adjust the flap to the correct position before tightening the securing bolts.

**FRONT SPOILER AND LOWER GRILLE**

**Renew**

Drive the vehicle on a ramp and raise the ramp.  
Remove the two screws retaining the oil cooler grille and detach the grille (1, Fig. 2).  
Prise out and discard the plastic drive fasteners securing the spoiler undertray to the body and spoiler (2, Fig. 2).  
Remove the screws and detach the spoiler undertray (3, Fig. 2).  
Remove the screws securing the spoiler (4, Fig. 2).




Fig. 2

**Refitting**

Offer the spoiler up and align the holes.  
Replace and tighten the screws securing the spoiler.  
Offer up the spoiler undertray and secure new drive fasteners.  
Replace and tighten the screws securing the spoiler undertray.  
Fit the oil cooler grille and secure with the two screws.

**'A' POST TRIM PAD**

**Renew**

Unclip the section of the crash roll adjacent to the 'A' post trim pad.  
Remove the screws securing the trim pad to the 'A' post (1, Fig. 3).  
Lift the trim pad clear.




Fig. 3

**'B' POST TRIM PAD**

**Renew**

Move the seat forward and tilt the headrest.  
Unclip the cantrail trim pad to clear the 'B' post trim pad.  
Remove the seat belt anchorage cover and remove the anchorage bolt (1, Fig. 4).  
Displace the belt from the 'B' post, the spacers and wavy washers.  
Remove the trim pad (2, Fig. 4).




Fig. 4

**REAR QUARTER TRIM CASING (Lower) FRONT SEAT BELT**

**Renew**

Remove the rear seat cushion and squab (1, Fig. 5).  
Remove the upper 'B' post trim pad.  
Remove the front seat belt lower and upper anchorage bolt, spacing washers and spring (2, Fig. 5).  
Displace the 'Furplex' trim from the door flange at the trim position (3, Fig. 5).  
Carefully displace the trim casing flap from the door flange and remove the casing front securing screws.

Remove the remaining casing securing screws and displace the casing from the mounting position for access to the rear speaker cables.

Disconnect the rear speaker cables.  
Reposition the seat belt through the casing and remove the casing assembly.  
Remove the bolt securing the seat belt rod and remove the reel.  
Remove the screws securing the arm rest and remove the arm rest.  
Remove the companion box lower securing rivets.  
Remove the trim clips and displace the upper securing tabs.  
Remove the companion box assembly.  
Replace the tabs securing the rear seat belt blank or surround (if fitted) and the front seat belt guides.  
Remove the guides.

**Refitting**

On refitting, ensure the speaker cables are reconnected correctly and the trim is securely adhered to the body flange.




Fig. 5

**REAR QUARTER TRIM PAD (Upper)**

**Renew**

Remove the rear seat cushion and squab.  
Remove the blanking screws from the rear parcel shelf, unclip and remove the shelf, (1, Fig. 6).  
Unclip the cantrail crash roll from the trim pad location (2, Fig. 6).  
Remove the trim pad securing screws and unclip the trim pad (3, Fig. 6).




Fig. 6

Note and disconnect the interior lamp cable harness.

Remove the trim pad.

Remove the interior lamp from the trim pad. On refitting, ensure the lamp is connected correctly and the connections are clean.

## COMPANION BOX LINER — REAR QUARTER LOWER

### Renew

Remove the rear seat cushion and squab.  
Remove the 'B' post trim pad.  
Remove the rear quarter lower trim casing assembly and remove the rear speaker.  
Remove the speaker grille by releasing the companion box securing tabs.  
Remove the companion box liner.

## FACING TRIM PAD — COMPANION BOX — REAR QUARTER (Lower)

### Renew

Remove the rear seat cushion and squab.  
Remove the upper 'B' post trim pad.  
Remove the rear quarter lower trim casing assembly.  
Remove the companion box assembly and arm rest.  
Remove the trim pad lower securing rivets and clips.  
Displace the upper securing tabs and remove the trim pad.

## BONNET AND GRILLE

### Renew

Remove the screws securing the stay to the bonnet and wing valance (1, Fig. 7).  
Remove the stay, retaining the back plates and seating blocks.  
Remove the screws securing the radiator grille to the bonnet and remove the grille (2, Fig. 7). Retain the washers and distance pieces.




Fig. 7

Remove the four bolts securing the bonnet to the hinges (3, Fig. 7) and lift the bonnet from the car.

When fitting the bonnet to the hinges, do not fully tighten the securing bolts. Close the bonnet and if necessary, adjust the position to centralise the bonnet between the wing valances.

Open the bonnet and fully tighten the securing bolts.

## BONNET HINGES

### Renew

With the bonnet assembly removed.  
Mark the location of the hinges to the crossmember.

Remove the four bolts securing the hinges to the crossmember (4, Fig. 7) and remove the hinges.

Position the new hinges to the marked location, fit and tighten the securing bolts.

When refitting the bonnet to the hinges, do not fully tighten the securing bolts.

Close the bonnet, adjust the position to centralise the bonnet between the wing valances.

Open the bonnet and tighten the securing bolts.

## BONNET LOCK — LH

### Renew

Slacken the bolt securing the control cable to the bonnet release handle nipple and release the cable (1, Fig. 8).

Slacken the bolt securing the control cable to lock pivot and release the cable (2, Fig. 8).

Remove the four screws securing the lock assembly to the bulkhead (3, Fig. 8).

Remove the lock assembly complete with the lock to release handle cable (4, Fig. 8).

Remove the two bolts securing the lock to the backplate and remove the backplate (5, Fig. 8).

Remove the lock to release the handle control cable.




Fig. 8

## BONNET LOCK — RH

### Renew

Remove the two screws securing the start relay cover to the RH wing valance and remove the cover.

Remove the four screws securing the lock assembly to the bulkhead.

Slacken the bolt securing the control cable to the LH bonnet lock pivot and release the cable.

Remove the lock assembly complete with the control cable then remove the control cable.

Remove the two bolts securing the lock to the backplate and remove the backplate.

When fitting new lock, fit but do not tighten the two screws securing the lock to the backplate.

Raise or lower the lock as required then pinch up the screws to secure the lock.

Close the bonnet, check the adjustment by operating the bonnet release handle. Raise the bonnet, readjust as necessary.

Fully tighten the securing screws.

## BONNET LOCK CONTROL CABLE

### Adjust

Slacken the bolt securing the control cable at the LH bonnet lock (1, Fig. 9).

Adjust the control cable as required by tightening or slackening in the nipple.

Tighten the control cable securing bolt.

Close the bonnet and check the control cable adjustment by operating the release handle.

Readjust if necessary.




Fig. 9

## BONNET LOCK TRIGGER RELEASE HANDLE

### Renew

Remove the driver's footwell side trim pad.  
Move the bonnet release handle to the correct open position.

Slacken the control cable damping screw and release the control cable (1, Fig. 10).

Move the bonnet release handle to the bonnet closed position (2, Fig. 10).

Remove the three bolts and washers securing the release handle mounting bracket to the body (3, Fig. 10).

## BODY

Remove the bonnet release handle assembly.

On refitting, check the bonnet alignment and adjust the control cable.




Fig. 10

### BOOT LID

#### Renew

Disconnect the battery earth lead.

Peel back the boot carpet to gain access to the electrical cable harness (1, Fig. 11).

Disconnect the cable harness block connector (2, Fig. 11) and remove the cable clips securing the harness to the RH boot lid hinge (3, Fig. 11).

Remove the four bolts and washers securing the boot lid to the hinges (4, Fig. 11), then remove the boot lid.




Fig. 11

On fitting new boot lid, fit but do not tighten the four bolts securing the boot lid to the hinges.

Close the boot lid to check the alignment, adjust by moving the boot lid as required on the hinges elongated bolt holes.

Fully tighten the hinge securing bolts.

Clip the cable harness to RH boot lid hinge and ensure the cable harness connector is clean and securely connected.

Check the electrical components for correct operation.

### BOOT LID HINGES

#### Renew

With the boot lid removed.

Remove the rear seat cushion and the rear seat squab.

Carefully prise the rear parcel shelf from the rear parcel shelf panel.

Remove the bolt and washer securing the boot hinges to the rear parcel shelf plate (1, Fig. 12).




Fig. 12

Remove the two bolts and washers securing the hinges to the mounting brackets (2, Fig. 12).

Remove the hinge assemblies.

Refitting is the reversal of the above operations.

Ensure the cable harness connections are clean and secure, and the electrical components operate correctly.

### BOOT LID SEAL

#### Renew

Remove the screws securing the finisher to the boot aperture valance and lift the panel from the boot (1, Fig. 13).

Remove the tape joining the ends of the seal and ease the remainder of the seal from the flange (2, Fig. 13).

On fitting new seal, take care not to stretch the seal and ensure it is correctly bedded down.




Fig. 13

### BOOT LID LOCK

#### Renew

Remove the clip securing the boot lid handle operating lever to the boot lid lock operating rod and disconnect the rod from the lever (1, Fig. 14).

Remove the three bolts and washers securing the lock assembly to the boot lid (2, Fig. 14).

Remove the lock assembly (3, Fig. 14).

Release the spring clip securing the operating rod to the lock operating lever and remove the operating rod.

On fitting the new lock, smear the operating mechanism with a suitable grease.

Fit the operating rod to the lock operating lever using a new spring clip.

Fit the lock assembly to its location but do not overtighten the three securing bolts and washers.

Use a new spring clip to secure the operating rod to the boot lid handle operating lever.

Close the boot lid, check the adjustment of the lock and adjust as necessary before fully tightening the three securing bolts.




Fig. 14

### BOOT LID LOCK STRIKER

#### Renew

Remove the screws securing the finisher panel to the boot aperture valance and lift the panel from the boot (1, Fig. 15).

Mark the striker legs along the top face of the clamp plate for a reference when refitting.

Slacken the bolts securing the striker clamp plate (2, Fig. 15) and slide the striker free from the clamp (3, Fig. 15).

On fitting new striker, align scribe marks to top face of the clamp and tighten the clamp bolts.




Fig. 15



Adjust the position of the striker, should more than a push effort be required to close the boot lid.

Refit the finisher panel to the boot aperture valance.

## BOOT LID HANDLE/LOCK ASSEMBLY

### Renew

Disconnect the battery earth lead.

Disconnect the number plate and reverse lamp cable harness connectors.

Remove the bolts securing the lamp assembly and ease the assembly clear of the boot lid.

Remove the spring clip securing the boot lid handle operating lever to the boot lid lock operating rod and disconnect the rod from the lever (1, Fig. 16).

Remove the two screws and spring washers securing the handle/lock assembly to the boot lid (2, Fig. 16).

Remove the plate from the rear of the assembly (3, Fig. 16) and manoeuvre the handle/lock assembly through the boot lid aperture (4, Fig. 16).

On fitting new assembly, ensure electrical connections are clean and secure.

Check the lamps for correct operation.




Fig. 16

## BUMPER — REAR CENTRE SECTION — BLADE

### Renew

Displace the boot side carpeting for access to quarter bumper securing bolts.

Remove the quarter bumper securing bolts and nuts securing the blade to the body flange (1, Fig. 17).

Remove the blade, quarter bumper and rubber buffer assembly.

**NOTE:** It is advisable to carry out this operation with two men so as to avoid damage to paintwork.

Remove nuts and bolts securing the quarter bumpers to the blade (2, Fig. 17).

Remove the quarter bumpers and rubber joint finishers (3, Fig. 17).




Fig. 17

## ENERGY ABSORBING BEAM — REAR

### Renew

Remove the nuts securing the fog guard lamps to the rear beam and displace the lamps from the mounting position (where fitted).

Slacken the beam bumper blade to body securing nuts (4, Fig. 17).

Remove the beam to the bracket securing nuts (5, Fig. 17).

Carefully remove the beam assembly ensuring the rear fog guard lamps (if fitted) are not damaged.

Remove the clips securing the beam cover (6, Fig. 17) and remove the cover.

## QUARTER BUMPER — REAR — RUBBER BUFFER

### Renew

With the rear bumper centre blade assembly removed.

Remove the nuts securing the rubber buffer (7, Fig. 17) and remove the buffer (8, Fig. 17).

## QUARTER BUMPER — FRONT

### Renew

Remove the quarter bumper trim finisher (1, Fig. 18).

Remove the quarter bumper blade securing nuts (2, Fig. 18).

Remove the quarter bumper blade to the centre blade securing nuts and bolts (3, Fig. 18).

Remove the quarter bumper blade and quarter bumper finisher (4, Fig. 18).

## ENERGY ABSORBING BEAM — FRONT

### Renew

Disconnect the battery.

Disconnect the front flasher lamps.

Remove the nuts securing the beam mounting brackets to body struts (5, Fig. 18).

Remove the beam, cover and lamp assembly (6, Fig. 18).

Remove the nuts securing the brackets to the beam and remove the brackets (7, Fig. 18).

Remove the flasher lamp securing screws and remove the lamps with the sealing rubbers.

Remove the bolts and clips securing the beam cover to the beam and remove the cover (8, Fig. 18).

Remove the flasher lamp securing cage nuts.

On refitting, ensure that the beam assembly is aligned before all the mounting bracket securing nuts are fully tightened.




Fig. 18

## FRONT BUMPER — CENTRE SECTION — BLADE

### Renew

Remove the upper radiator grille.  
Remove the nuts and bolts securing the bumper blade to the quarter bumpers (3, Fig. 18).

Remove the nuts and bolts securing the finisher to the body (9, Fig. 18).

Remove the blade and the finisher assembly (10, Fig. 18).

Drill out the pop rivets securing the finisher to the blade and remove the finisher.

On refitting, ensure the beam is aligned before the mounting nuts are fully tightened. Also align the fog lamps before the securing nuts are fully tightened.

## CONSOLE ASSEMBLY — FRONT

### Renew

Remove the air conditioning switch knobs (1, Fig. 19) and the control panel securing bezel. Displace the panel (2, Fig. 19).

Remove the console side casing securing screws (3, Fig. 19).

Remove the footwell vents and the console side casing.

Remove the console finisher panel.

Remove the screws securing the stop light failure sensor and displace the sensor (7, Fig. 19).

Remove the screws securing the front of the console (8, Fig. 19).

Move the seats fully forward and remove the screws securing the rear of the console. Reposition the seat backrest.

Position the air conditioning control panel through the aperture.

Displace and remove the console assembly. Remove the centre glove box lid, check strap securing screws (1, Fig. 20).

Remove the centre glove box lid hinge screws and remove the glove box lid (2, Fig. 20).

Remove the glove box lid catch and liner.

Remove the rear outlet duct and the ashtray assembly.

Refitting new console assembly is the reversal of the above procedure.

Ensure the electrical connections are clean and tight.

Check stop lamps, window lift motors and the cigar lighter for correct operation.




Fig. 20

Unscrew and remove the gear lever knob (4, Fig. 19).

Remove the screws securing the console finisher panel (5, Fig. 19) and displace the panel over the gear lever (6, Fig. 19).

Note and disconnect the cable connectors from the window lift switches and the cigar lighter.




Fig. 19

## DOOR

## Renew

**NOTE:** The door **MUST** be adequately supported in a half open position during this operation.

Remove and swing the inertia switch aside (driver's door only).

Remove the three screws securing the footwell side trim pad and remove trim pad. Remove the screws securing the door lock solenoid relay and ease the relay to one side (1, Fig. 21).

Note and disconnect the door cable harness connectors and the earth lead from the solenoid relay mounting bracket (2, Fig. 21). Disconnect the radio speaker connectors.




Fig. 21

Remove the six nuts and washers securing the hinge plates to the body and remove the hinge plates (1, Fig. 22).

With assistance, remove the door assembly.




Fig. 22

## Refitting

Locate the door assembly and hinges to the body, secure using one nut and washer on each hinge, do not tighten fully.

Remove the support, close the door, check the alignment and align as required.

Fit the remaining nuts and washers.

Tighten fully.

Ensure all electrical connections are secure and the button on the inertia switch is depressed.

DOOR HINGE  
(DOOR TRIM PAD)

## Renew

**NOTE:** Ensure the door is adequately supported in the half open position.

Remove the door mirror switch bezel.

To avoid damage to the arm rest and the stitching, apply masking tape to the arm rest.

Carefully displace the chrome finisher on to the masking tape (1, Fig. 23).

Remove the arm rest lower securing screw (2, Fig. 23).

Remove the screws securing the door pillar switch plate and remove the plate (3, Fig. 23).

Carefully unclip and raise the door trim pad to release it from the door (4, Fig. 23).

Note and disconnect the puddle light and the radio speaker cables (5, Fig. 23).

Carefully remove the trim pad assembly (6, Fig. 23).




Fig. 23

Remove and swing the inertia switch to one side (driver's door only).

Remove the three screws securing the underscuff casing and remove the casing. Remove the two screws securing the footwell side trim pad and remove the trim pad.

Remove the two screws securing the door lock relay and ease the relay aside (1, Fig. 21).

Remove the three nuts and washers securing the hinge plate to the body. Remove the hinge plate.

Remove the nuts and washers securing the hinge plate to the door (four on the top hinge and three on lower hinge) (1, Fig. 24). Remove the hinge plate and hinge (2, Fig. 24).




Fig. 24

## Refitting

Locate the new hinge and hinge plate to the body, secure with one nut and washer, do not fully tighten.

Remove the support.

Close the door, check the alignment, and readjust the door as required.

Fit the remaining nuts and washers, then fully tighten.

On refitting the door trim ensure the electrical components operate correctly.

## DOOR GLASS

## Renew

With door trim pad removed and the glass in the raised position, remove the two screws and washers securing the window channel to the door (1, Fig. 25).

Ease the rubber clear of the channel (2, Fig. 25) and remove the window channel (3, Fig. 25).

Remove the two bolts, plain and shockproof washers securing the window stop to the base of the door (4, Fig. 25).

Remove the window stop (5, Fig. 25).

Lower the door glass.




Fig. 25

**NOTE:** When lowering the window glass, care should be taken to guide the glass by hand.

Disconnect the window lift remote control mechanism from the window glass by tilting the glass forward (1, Fig. 26).

With the glass still in the tilted position, carefully lift the glass clear of the door (2, Fig. 26).

Refitting is the reversal of the above procedure.




Fig. 26

# **QUARTERLIGHT — FRONT**

## **Renew**

Remove the two screws securing the quarter light from the door panel (1, Fig. 27).  
Lower the door glass, ease the door glass rubber to one side (2, Fig. 27) and remove the two screws securing the quarterlight to the door glass frame (3, Fig. 27).  
Remove the quarterlight assembly.  
Remove the quarterlight glass and rubber from the frame (4, Fig. 27).




Fig. 27

# **QUARTERLIGHT — REAR**

## **Renew**

Remove the rear quarter upper and lower trim pads.  
Using a suitable tool, prise the rear quarter glass and rubber from the body.  
Remove the seal from the glass (1, Fig. 28).

## **Refitting**

Apply sealant into the locating grooves of the new seal and fit the glass into the seal.  
Fit the glass and seal to the quarterlight location.




Fig. 28

# **DOOR GLASS WEATHER STRIP**

## **Renew**

Remove the front quarterlight and the door trim pad.  
With the glass in the raised position (1, Fig. 29), remove the two bolts and washers securing the window stop to the base of the door (2, Fig. 29).  
Remove the window stop and lower the door glass.

Remove the three screws securing the quarterlight channel and remove the channel (3, Fig. 29).  
Release the clip securing the door finisher at the rear edge of the door (4, Fig. 29).  
Remove the eight screws securing the door finisher to the door and remove the door finisher (5, Fig. 29).  
Remove the weather strip from the door finisher (6, Fig. 29).




Fig. 29

# **DOOR ARM REST**

## **Renew**

With the door trim pad removed, remove the two screws securing the arm rest retaining bracket and remove the bracket (1, Fig. 30).  
Remove the split rivets securing the arm rest (2, Fig. 30), unclip and remove the arm rest.  
Unclip and remove the chrome finishers.




Fig. 30

# **DOOR LOCK**

## **Adjust**

**WARNING: IF ANY OF THE FOLLOWING SYMPTOMS BECOME EVIDENT IMMEDIATE REMEDIAL ACTION MUST BE TAKEN AS OUTLINED BELOW:**

- A Door fails to fully close.
- B Door fails to open with the operation of the inside door handle.
- C Door opens upon the initial movement of the inside door handle.




Fig. 31

D Door fails to lock upon operation.

**NOTE: When symptom A, B or C are evident proceed as follows:**

Remove the door trim pad.  
Slacken the link rod adjusting sleeve lock nut (1, Fig. 31). Adjust sleeve (2, Fig. 31) as required until the door opens when the handle is in the halfway position when operated and the door closes fully.  
Re-tighten the lock nut.

**NOTE: If symptom D is evident:**

Slacken the link rod adjusting sleeve lock nut (3, Fig. 31). Adjust the sleeve (4, Fig. 31) as required. close door and check for correct operation of lock lever.

# **DOOR LOCK**

## **Renew**

Remove the door trim pad.  
Disconnect the inner handle to lock connecting rods from the anti-rattle and connecting clips (1, Fig. 32).  
Ease the plastic sheeting to one side.  
Disconnect the outer handle to lock connecting rods (3, Fig. 32).  
Remove the four screws securing the outer lock unit to the door (3, Fig. 32).  
Remove the outer lock unit (4, Fig. 32) and the inner lock unit (Fig. 32).  
Refitting is the reversal of the above procedure.




Fig. 32

# **DOOR LOCK STRIKER PLATE**

## **Renew**

Remove the rear seat cushion and rear seat squab.  
Remove the 'B' post upper trim pad and the rear quarter lower trim casing.  
Remove the screws securing the striker plate (1, Fig. 33) and remove the striker plate halves (2, Fig. 33).  
On refitting, adjust the striker plate until the door closes with the minimum push effort.




Fig. 33

## DOOR — VENEER PANEL

### Renew

Disconnect the battery.  
Remove the door mirror switch mounting panel and the door trim pad assembly.  
Remove the nuts securing the veneer panel to the trim pad and remove the veneer panel.

## DOOR OUTSIDE HANDLE

### Renew

Remove the door trim pad.  
Remove the door glass.  
Remove the three clips securing the control arms to the outside handle.  
Disconnect the control arms from the outside handle (1, Fig. 34).  
Remove the two nuts and washers securing the door handle (2, Fig. 34).  
Remove the securing bracket (3, Fig. 34).  
Remove the outside handle assembly (4, Fig. 34).




Fig. 34

## DOOR INSIDE HANDLE

### Renew

Remove the door trim pad.  
Remove the three screws securing the handle to the door (1, Fig. 35).  
Disconnect the control arms from the anti-rattle clips and lock clips (2, Fig. 35).  
Ease the handle clear of the door panel and release the lock control arm from the plastic clip (3, Fig. 35).  
Remove the interior handle assembly (4, Fig. 35).




Fig. 35

## FASCIA VENEER PANEL — PASSENGER SIDE FASCIA VENEER PANEL — DRIVER'S SIDE FASCIA VENEER PANEL — CENTRE

### Renew

For the centre and passenger side veneer panels, open the glove box for access. By using a suitable long thin bladed instrument, carefully release the veneer panel retaining clips and remove the appropriate panel.

## DRIVER'S UNDERSCUTTLE CASING

### Renew

Remove the screws securing the casing to the fascia and the scuttle (1, Fig. 36).  
Carefully lower the casing sufficiently to give access to the rheostat (2, Fig. 36).  
Disconnect the electrical cable from the rheostat and lift the casing from the car (3, Fig. 36).




Fig. 36

## PASSENGERS' UNDERSCUTTLE CASING

### Renew

Remove the screws securing the casing to the fascia panel and the underscuttle (1, Fig. 37).  
Carefully manoeuvre casing from its location (2, Fig. 37).




Fig. 37

## GLOVE BOX LID — VENEER PANEL

### Renew

Remove the screws securing the vanity mirror moulding to the rear of the glove box lid (1, Fig. 38).  
Remove the assembly (2, Fig. 38).  
Remove the screws securing the veneer panel to the glove box lid and remove the panel.  
On refitting, ensure that the veneer panel is correctly aligned before fully tightening the securing screws.




Fig. 38

## GLOVE BOX LINER

### Renew

Remove the screws securing the liner to the fascia (1, Fig. 39).  
Carefully prising the liner around the latch withdraw the liner from the fascia (2, Fig. 39).




Fig. 39

## FASCIA SWITCH PANEL — VENEER PANEL

Disconnect the battery.  
Remove the electric clock, or trip computer (1, Fig. 40) and disconnect the leads (2, Fig. 40).  
By using a long thin bladed instrument, carefully unclip and displace the switch panel (3, Fig. 40).  
Note and disconnect the switch block connectors and the switch illuminator bulb holders.  
Remove the panel assembly.  
Unclip and remove the switches from the panel.  
Remove the spire nuts securing the bulb holders to the panel and remove the bulb holders.

## BODY

On refitting, use new spire nuts to secure the bulb holders.

Ensure the electrical connectors are secure and the correct operation of components.




Fig. 40

## FASCIA

### Renew

Disconnect the battery earth lead.

Slacken the steering wheel adjusting collar and pull the steering wheel out to its fullest extent (1, Fig. 40).

Remove the screws securing the lower and upper shroud to the steering column and remove the shrouds from the column (2, Fig. 40).

Slacken the steering wheel grub screw locknut and remove the grub screw.

Remove the steering wheel pinch bolt and nut.

Note the position of and remove the steering wheel (3, Fig. 40).

Remove the screws securing the fascia side trim and remove the side trims.

Remove the screws securing the driver's dash liner, note and disconnect the cables from the rheostat, then remove the dash liner (4, Fig. 40).

Slacken the screws securing the light switch surround, remove the lower screws and displace the shroud.

Depress the light switch knob retaining peg and remove the switch knob (5, Fig. 40).

Remove the lower and slacken upper screws securing the ignition switch surround.

Remove the screws securing the instrument panel surround and remove the centre finisher (6, Fig. 40).

Displace the switch surround.

Remove the instrument panel side finishers. Remove the switch surround upper securing screws and nuts.

Ease the surrounds from the mounting positions.

Displace the fibre optic strands and remove the surrounds.

Remove the instrument panel blanking plates and remove the screws securing the instrument panel (7, Fig. 40).

Displace the panel and disconnect the cable harness block connectors then remove the instrument panel.

Displace the interior lamps from the fascia, disconnect the cables and remove the interior lamps (8, Fig. 40).





Fig. 41

J76-097

Remove the screws securing the passenger side dash liner and remove the dash liner (9, Fig. 40).

Remove the screws securing the glove liner, displace and remove the liner (10, Fig. 40).

By using a long thin bladed instrument, carefully unclip and displace the switch panel (11, Fig. 40).

Note and disconnect the switch block connectors and the switch illuminator bulb holders.

Remove the panel assembly.

Remove the air conditioning and radio control knobs.

Remove the air conditioning and radio control panel securing bezels (12, Fig. 40).

Displace the panel and remove the fascia securing screws (13, Fig. 40).

Slacken the fascia to fascia rail securing nuts (14, Fig. 40).

Remove the fascia side securing nuts and bolts (15, Fig. 40).

Remove the nut securing the light switch to the fascia and displace the switch from the fascia.

Displace the fascia from its location and reposition over the column stalks.

Disconnect the air conditioning in car temperature sensor tube and remove the fascia assembly.

Remove the screws securing the glove compartment lid liner and remove the liner (16, Fig. 40).

Remove the nuts securing the glove box lid stay and remove the stay (17, Fig. 40).

Remove the screws securing the lid to the fascia and remove the lid (18, Fig. 40).

Unclip and remove the fascia centre veneer panel and remove the centre vent (19, Fig. 40).

Unclip and remove the side veneer panel and remove the side vents (20, Fig. 40).

Remove the air conditioning sensor elbow halves.

Remove the light and ignition switch brackets.

Remove the glove box lid catch (21, Fig. 40).

Remove the interior light backing mouldings.

## HEADLINING

### Renew

**WARNING: THIS OPERATION SHOULD NOT BE ATTEMPTED BY PERSONS KNOWN TO BE ALLERGIC TO GLASS FIBRE (FIBREGLASS). SHOULD SKIN AREAS DEVELOP A RASH OR IF ITCHING OCCURS, WASH AFFECTED AREA WITH WATER AND SEEK MEDICAL ADVICE IMMEDIATELY. ALWAYS WEAR GLOVES, FACE MASK AND GOGGLES WHEN HANDLING HEADLINING.**

Remove the sun visors (1, Fig. 42) and sun visor retaining brackets (2, Fig. 42).

Remove the interior mirror (3, Fig. 42).

Ease the interior lamp clear of its location, disconnect the electrical leads and remove the lamp (4, Fig. 42).

Remove the cantrail crash roll from both sides.

Remove the rear seat squab and the rear shelf.

Remove the rear quarter upper trim pads from both sides.

Bend back the six tabs securing the headlining (5, Fig. 42) and remove the headlining assembly via the passenger door.




Fig. 42

### Refitting

Introduce the replacement headlining through the passenger door, raise the headlining into position and secure with the clips.

Ease the top forward edge of the rear window surround over the rear side of the headlining.

Refitting the trim etc. is the reversal of the dismantling procedure.

## REAR PARCEL SHELF AND REAR SEAT CUSHION AND SQUAB

### Renew

Move the front seats and tilt the front seat backrests forward.

Remove the screws securing the rear seat cushion (1, Fig. 43).

Displace and remove the rear seat cushion assembly (2, Fig. 43).




Fig. 43

Remove the screw and nut securing the centre trim panel and remove the panel (3, Fig. 43).

Displace the sound deadening flaps.

Remove the screws securing the seat squab (1, Fig. 44).

Lift the seat squab upwards and carefully remove.




Fig. 44

Remove the blanking plug from the child seat anchorage.

Remove the screws securing the parcel shelf assembly.

Unclip and remove the parcel shelf (1, Fig. 45).




Fig. 45

## REAR SEAT ARM REST

### Renew

With the rear seat cushion and squab removed:

Remove the upper 'B' post trim pad.

Remove the lower rear quarter trim pad.

Remove the lower rear quarter trim casing.

Remove the screws securing the arm rest to the trim casing and remove the arm rest.

## FRONT ASHTRAY

### Renew

Open the ashtray cover and withdraw the ash container.

Withdraw the screws securing the ash container holder to the console.

Withdraw the holder and the securing bracket from the console.

### Refitting

Secure the bracket with one screw to the holder unit.

Fit the holder and the bracket to the console.

Align the unsecured portion of the bracket with the hole in the holder and fully tighten both the screws.

Fit the ash container to the holder.

## REAR ASHTRAY

### Renew

Remove the screws securing the console stowage lid check strap.

Remove the screws securing the stowage lid hinge and lift the lid from the console.

Remove the screws securing the stowage liner to the console, prise the liner lock catch from the console and remove the liner.

Open the ashtray, push down and remove the ash container from the holder.

Straighten the upper clips securing the holder to the console.

Lift the holder and the bezel surround from the console.

## REAR SEAT BELT

### Renew

With the rear seat cushion and squab removed (1, Fig. 46).

Remove the bolt and washer securing the rear seat belt buckle assembly (2, Fig. 46) then remove the assembly (3, Fig. 46).

Remove the rear quarter lower trim pad for access (4, Fig. 46).

Thread the seat belt through the trim pad (5, Fig. 46).

Remove the bolt and washer securing the seat belt reel mechanism then remove the reel.




Fig. 46

## FRONT SEAT

### Renew

With the seat pushed to the full rear position (1, Fig. 47), remove the two Allen head screws securing the seat runner assembly to the floor mountings (2, Fig. 47).

Push the seat to the full forward position and remove the two Allen headed screws securing the rear of the runner assembly to the floor mountings (3, Fig. 47).

Lift the seat assembly from the car and recover the distance pieces from the front mountings.




Fig. 47

## FRONT SEAT RUNNER AND ADJUSTER ASSEMBLY

### Renew

With the front seat removed, operate the runner lever and push the runners to the rear, exposing screws securing the runners to the front of the seat (1, Fig. 48).

Remove the securing screws (2, Fig. 48).

Align the runners to the full forward position and remove the screws securing the runners to the rear of the seat (3, Fig. 48).

Lift the runner and adjuster assembly from the seat.

Retain the washers.




Fig. 48

## FRONT SEAT CUSHION

### Renew

With the front seat and adjuster assembly removed, remove the screw securing the rake angle adjustment lever, lift the lever and the plastic disc from the seat (1, Fig. 49).

Carefully prise the trim plate from the seat (2, Fig. 49).

Remove the screw securing the trim plate to the side of the seat and prise the trim plate from the seat (3, Fig. 49).

Remove the bolts securing the seat cushion and separate the cushion from the back rest.




Fig. 49

## FRONT SEAT BELT BUCKLE — LH AND RH

### Renew

Remove the centre console rear securing screws and raise the rear console for access.

Disconnect the seat belt buckle cable harness block connector.

Remove the seat belt buckle anchorage bolt cover and remove the bolt.

Tilt the seat back for access and remove the buckle assembly with the spacer.

## REAR STOWAGE COMPARTMENT

### Renew

Tilt and push the driver and passenger seats fully forward.

Unlock and open both stowage container lids.

Remove the container slip mats.

Remove the five screws securing the stowage container.

Displace the passenger side rear courtesy lamp, note and disconnect the electrical cables.

Remove the lamp and return the cables to inside the aperture.

Extend and displace the passenger side seat belt.

Tilt the passenger side of the container upwards past the courtesy light aperture, tilt towards the front of the vehicle and manoeuvre the stowage container through the passenger door.

Invert the stowage container for access.

Remove the nuts securing the rail and remove the rail.

Refitting is the reversal of the above operations. Ensure care is taken manoeuvring the container into position.



## HOOD CANOPY GUIDES

### Renew

Release the hood locking catch.  
Release the headlining trim to 'D' post velcro fastening (1, Fig. 50).  
Fold the hood to the rearward position.  
Remove the canopy guide securing screws and remove the guides (2, Fig. 50).  
On fitting new guides fit but do not tighten the canopy guide securing screws.  
Seat the hood and secure the top catches on the roll bar mountings.  
Lock the hood catch.  
Position guides to the hood guide pin and tighten the guide securing screws.




Fig. 50

## HOOD CANOPY

### Renew

Release the hood locking catch.  
Release the headlining trim from the 'D' post velcro fastening (1, Fig. 50).  
Release the headlining from the double velcro fastening and the rear of the parcel shelf.  
Fold the hood to rearward position (Fig. 51).




Fig. 51

Release the outer cover velcro fastening (1, Fig. 52) and with a  $\frac{5}{32}$  allen key or a suitable tool remove the hood to body securing screws (2, Fig. 52).




Fig. 52

Push the rear of the hood upwards and release the headlining fasteners (1, Fig. 53).




Fig. 53

Manoeuvre the hood and carefully remove the hinge plate securing screws (1, Fig. 54), displace and remove the hood assembly.




Fig. 54

### Refitting

Place the new hood on to the car body.  
Fit rubber spacers to the headlining fasteners, fit and tighten the headlining fastener (Fig. 53).  
Fit new 'O' rings to the hood securing screws (3, Fig. 52).  
Fit and secure the hood with the securing screw using appropriate tool (2, Fig. 52).  
Manoeuvre the hood to align the hinge plate to the securing position.  
Secure and tighten the securing screws (Fig. 54).

Raise the hood and lock in position, reposition the headlining to the 'D' post and to the rear of the parcel shelf, secure with the velcro fastening.

Position the outer cover, secure with the velcro and stud fasteners.

## HOOD CANOPY LATCHES

### Renew

Release the hood locking catch.  
Release the headlining trim from the 'D' post velcro fastening.  
Fold the hood to the rearward position.  
Remove the screws securing the canopy latches and remove the latches from the roll bar.  
When refitting new catches fit but do not fully tighten the securing screws.  
Raise the hood and position in the guides, lock the hood locking catch, adjust the hood latches and tighten the securing screws.  
Reposition the headlining to the 'D' post velcro fastening.

## HOOD CANOPY SEAL

### Renew

Release the hood locking catch.  
Release the headlining trim from the 'D' post velcro fastening (1, Fig. 55).  
Fold the hood to the rearward position.  
Release the outer hood velcro fastening.  
Remove the three outer hood securing screws from each side of the hood canopy and displace the hood for access.  
Remove the screws securing the hood latches and remove the latches (2, Fig. 55).  
Displace and remove the seal (3, Fig. 55).  
Ensure the sealing surfaces are clean.  
Fit the new seal ensuring great care is taken to avoid splitting the seal when pushing the seal into position at the corners of the roll bar and side panels.  
Fit and secure the retaining clamps.  
Fit new 'O' rings to the hood securing screws, secure the hood and refit the velcro fastening.  
Secure and lock the hood to the roll bar and reposition the headlining to the 'D' post velcro fastening.




Fig. 55

## BODY

### TARGA TOP SEAL

#### Renew

Unlock and remove.

Remove screws securing the targa top latches and remove the latches.

Displace and remove the seal.

On refitting new seal ensure the seal seating surfaces are clean.

Place the seal into aperture with the red marker to the front central position. To avoid splitting the seal carefully push the seal fully into position.

Refit the latches but do not fully tighten the securing screws.

Fit and engage the latches to the targa tops, adjust the latches into the correct position then tighten the latch securing screws.

### FRONT HEADLINING

#### Renew

Unlock and remove the targa tops.

Remove the screws securing the two 'A' post trims and remove the trims.

Remove the sun visors and the sun visor guides.

Remove the screws securing the interior rear view mirror and remove the mirror.

Displace the interior lamp, note and disconnect the electrical cables and remove the lamp.

Remove the two front targa top catches.

Displace the forward edge of the targa top seal.

Remove the front screws securing the cant rail trims and displace the front of the trims.

Remove the screws securing the headlining trim and remove the trim.

Refitting is a reversal of the above procedure.

### ROLL BAR TRIM

#### Renew

Unlock and fold back the hood canopy.

Unlock and remove the targa tops.

Remove the screws securing the targa top catches and the hood canopy catches, remove the catches.

Remove the screws securing the 'B' post trim and the seat belt anchor bolt, remove the 'B' post trim.

Displace the canopy hood and the targa top seal from the roll bar.

Displace and remove the roll bar trim.

Refitting is the reversal of the above procedure.

### CANT RAIL TRIM

#### Renew

Unlock and remove the targa tops.

Remove the 'A' post trim.

Remove the 'B' post trim.


Displace the targa top seal.


Remove the roll bar trim.

Remove the screws securing the cant rail trim and remove the trim.



**XJ-S 3·6  
XJ-SC 3·6  
SERVICE  
MANUAL**





## BOOK 8

Containing  
Section

**82 AIR CONDITIONING**

**XJ-S 3·6**  
**XJ-SC 3·6**

**SERVICE MANUAL**

---

## INTRODUCTION

This Service Manual covers the Jaguar XJ-S 3.6 and XJ-SC 3.6. It is primarily designed to assist skilled technicians in the efficient repair and maintenance of this range of Jaguar cars.

Using the appropriate service tools and carrying out the procedures as detailed will enable the operations to be completed within the time stated in the 'Repair Operation Times'.

The Service Manual has been produced in 9 separate books; this allows the information to be distributed throughout the specialist areas of the modern service facility.

A table of contents in Book 1 lists the major components and systems together with the section and book numbers. The cover of each book depicts graphically and numerically the sections contained within that book.

The title page of each book carries the part numbers required to order replacement books, binders or complete Service Manuals. This can be done through the normal channels.

The contents section of each book lists the repair operations in the section or sections contained within that book. Each operation is given an operation number that corresponds with those listed in the Repair Operation Times.

The method described on the page number listed against the operation will be the one we consider will meet the requirements of safety and enable the operation to be carried out in the time specified in the Repair Operation Times.

Where no page number is given against an operation, we feel that the method is so obvious as to warrant no explanation. It is, however, included so that a warranty time can be given in the Repair Operation Times.

Extensive research has gone into the diagnosis of faults and where appropriate this is covered in the various areas of the manual. By following the sequence of the diagnosis charts, speedy isolation of faults may be expected, and consequent correction will reduce the vehicle off-the-road time to the minimum.

### Service Tools

Where performance of an operation requires the use of a service tool the tool number is quoted under the operation heading and is repeated in, or following, the instruction involving its use. A list of all necessary tools is included in Book 1, Section 99.

### References

References to the LH or RH side in the manual are made when viewing from the rear. With the engine and gearbox assembly removed the timing cover end of the engine is referred to as the front. A key to abbreviations and symbols is given in Book 1, Section 01.

## REPAIRS AND REPLACEMENTS

When service parts are required it is essential that only genuine Jaguar or Unipart replacements are used.

Attention is particularly drawn to the following points concerning repairs and the fitting of replacement parts and accessories.

1. Safety features embodied in the vehicle may be impaired if other than genuine parts are fitted. In certain territories, legislation prohibits the fitting of parts not to the vehicle manufacturer's specification.
2. Torque wrench setting figures given in this Service Manual must be strictly adhered to.
3. Locking devices, where specified, must be fitted. If the efficiency of a locking device is impaired during removal it must be replaced.
4. Owners purchasing accessories while travelling abroad should ensure that the accessory and its fitted location on the vehicle conform to mandatory requirements existing in their country of origin.
5. The vehicle warranty may be invalidated by the fitting of other than genuine Jaguar or Unipart parts. All Jaguar and Unipart replacements have the full backing of the factory warranty.
6. Jaguar Distributors and Dealers are obliged to supply only genuine service parts.

## SPECIFICATION

Purchasers are advised that the specification details set out in this Manual apply to a range of vehicles and not to any one. For the specification of a particular vehicle, purchasers should consult their Distributor or Dealer.

The Manufacturers reserve the right to vary their specifications with or without notice, and at such times and in such manner as they think fit. Major as well as minor changes may be involved in accordance with the Manufacturer's policy of constant product improvement.

Whilst every effort is made to ensure the accuracy of the particulars contained in this Manual, neither the Manufacturer nor the Distributor or Dealer, by whom this Manual is supplied, shall in any circumstances be held liable for any inaccuracy or the consequences thereof.

## COPYRIGHT

© Jaguar Cars Ltd. 1983

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, electronic, mechanical, photocopying, recording or other means without prior written permission of Jaguar Cars Ltd., Service Department, Radford, Coventry CV6 3GB.

## CONTENTS

| Operation   | Operation No. | Page No. |
|---|---------------|----------|
| Air conditioning system — Charge .....                                    | 82.30.08      | 82—29    |
| Air conditioning system — Charging valve core — Renew .....               | 82.30.12      | 82—41    |
| Air conditioning system — Component layout .....                          | —             | 82—3     |
| Air conditioning system — Defrost and demist tests .....                  | 82.30.15      | 82—41    |
| Air conditioning system — Depressurize .....                              | 82.30.05      | 82—28    |
| Air conditioning system — Description .....                               | 82.00.00      | 82—5     |
| Air conditioning system — Evacuate .....                                  | 82.30.06      | 82—28    |
| Air conditioning system — Leak test .....                                 | 82.30.09      | 82—34    |
| Air conditioning system — Special tools and equipment for servicing ..... | —             | 82—11    |
| Air conditioning system — Sweep (flushing) .....                          | 82.30.07      | 82—28    |
| Air conditioning system — System check .....                              | 82.30.16      | 82—42    |
| Air conditioning system — Test operation .....                            | 82.30.11      | 82—41    |
| Blower motor assembly — LH — Remove and refit .....                       | 82.25.14      | 82—39    |
| Blower motor assembly — RH — Remove and refit .....                       | 82.25.13      | 82—37    |
| Blower motor — Overhaul — LH .....  | 82.25.28      | 82—40    |
| Blower motor — Overhaul — RH .....  | 82.25.30      | 82—40    |
| Blower motor relay — Renew .....  | 82.20.27      | 82—36    |
| Blower motor resistance unit — Renew .....                                | 82.20.26      | 82—36    |
| Charging and testing equipment — Fit and remove .....                     | 82.30.01      | 82—24    |
| Compressor — Remove and refit .....                                       | 82.10.14      | 82—30    |
| Compressor — Overhaul .....   | 82.10.08      | 82—31    |
| Compressor — Oil level check .....  | —             | 82—30    |
| Condenser — Renew .....   | 82.15.07      | 82—35    |
| Control system — Ambient temperature sensor — Renew .....                 | 82.20.02      | 82—35    |
| Control system — Amplifier unit — Renew .....                             | 82.25.29      | 82—40    |
| Control system — Description .....  | 82.00.00      | 82—5     |
| Control system — in-car temperature sensor — Renew .....                  | 82.20.03      | 82—35    |
| Control system — mode selector — Renew .....                              | 82.20.11      | 82—36    |
| Control system — Ranco thermostat — Renew .....                           | 82.20.18      | 82—36    |
| Control system — servo and control unit — Overhaul .....                  | 82.25.25      | 82—40    |
| Control system — servo and control unit — Remove and refit .....          | 82.25.24      | 82—39    |
| Control system — temperature control switch — Renew .....                 | 82.20.10      | 82—36    |
| Control system — vacuum solenoid — Renew .....                            | 82.25.23      | 82—40    |
| Control system — water valve — Renew .....                                | 82.20.33      | 82—37    |

| Operation   | Operation No. | Page No. |
|---|---------------|----------|
| Control system — water valve temperature switch — Renew ..... | 82.20.29      | 82—37    |
| Evaporator unit — Renew .....                                 | 82.25.20      | 82—39    |
| Expansion valve — Renew .....                                 | 82.25.01      | 82—37    |
| Fault finding .....   | —             | 82—12    |
| Flap link — Adjust .....                                      | 82.20.17      | 82—34    |
| General section — Good practice .....                         | —             | 82—11    |
| Heater/cooler unit — Remove and refit .....                   | 82.25.21      | 82—38    |
| Receiver/drier unit — Renew .....                             | 82.17.01      | 82—35    |
| Superheat switch and thermal fuse — Description .....         | 82.20.00      | 82—29    |
| Superheat switch — Renew .....                                | 82.10.12      | 82—30    |
| Thermal fuse — Renew .....                                    | 82.20.50      | 82—37    |

**WARNING: EXTREME CARE SHOULD BE EXERCISED IN HANDLING THE REFRIGERANT. LIQUID REFRIGERANT AT ATMOSPHERIC PRESSURE BOILS AT -29°C (-20°F). SERIOUS DAMAGE OR BLINDNESS MAY OCCUR IF REFRIGERANT IS ALLOWED TO CONTACT THE EYES.**  
**Goggles and gloves must be worn while working with Refrigerant.**

**FIRST AID:** If refrigerant should contact the eyes or skin, splash the eyes or affected area with cold water for several minutes. Do not rub. As soon as possible thereafter, obtain treatment from a doctor or eye specialist.

- SPECIAL TOOLS AND EQUIPMENT FOR SERVICING AIR CONDITIONING SYSTEM ON JAGUAR SERIES III**
- 1 Pektron test unit
  - 1 Charging station
  - 1 Leak detector
  - 1 Temperature test box
  - 1 Compressor service tool kit
  - 1 Setting jig for temperature differential control, 18G1363.
  - 1 Voltmeter
  - 1 Ohmmeter

TORQUE LEVELS FOR THE AIR CONDITIONING HOSE CONNECTIONS

| Item  | Nm             | Kgf/m        | lbf/ft   |
|---|----------------|--------------|----------|
| 1. Compressor/Condenser (Compressor End)            | 40,67 to 47,45 | 4,15 to 4,84 | 30 to 35 |
| 2. Condenser/Compressor (Condenser End)             | 28,47 to 36,30 | 2,90 to 3,73 | 21 to 27 |
| 3. Condenser/Receiver Drier (Condenser End)         | 20,34 to 27,12 | 2,10 to 2,76 | 15 to 20 |
| 4. Receiver Drier/Condenser (Receiver Drier End)    | 40,67 to 47,45 | 4,15 to 4,84 | 30 to 35 |
| 5. Receiver Drier/Evaporator (Receiver Drier End)   | 40,67 to 47,45 | 4,15 to 4,84 | 30 to 35 |
| 6. Evaporator/Receiver Drier (Evaporator End)       | 14,91 to 17,62 | 1,52 to 1,80 | 11 to 13 |
| 7. Expansion Valve/Evaporator (Expansion Valve End) | 20,34 to 27,12 | 2,10 to 2,76 | 15 to 20 |
| 8. Evaporator/Compressor (Evaporator End)           | 28,47 to 36,60 | 2,90 to 3,73 | 21 to 27 |
| 9. Compressor/Evaporator (Compressor End)           | 40,67 to 47,45 | 4,15 to 4,84 | 30 to 35 |




Fig 1

**KEY TO COMPONENTS (Fig. 1)**

1. Compressor
2. Evaporator
3. Expansion valve
4. Vacuum valve
5. In-car sensor
6. Ambient temperature sensor
7. Water control valve
8. Vacuum reservoir
9. Non-return valve
10. Water valve temperature switch
11. Condenser
12. Receiver-drier
13. High pressure schrader valve
14. Low pressure schrader valve
15. Heater matrix

J82 085






Fig 2

KEY TO COMPONENTS (Fig. 2)

- 1. Ranco thermostat
- 2. Expansion valve
- 3. Servo control unit
- 4. Control rod
- 5. Vacuum valve




Fig 3

KEY TO COMPONENTS (Fig. 3)

- 1. Amplifier
- 2. Relays
- 3. Fan speed resistance
- 4. Vacuum actuator motor
- 5. Water thermostat





Fig 4

J82 035

## REFRIGERATION CYCLE

### Description

82.00.00

A belt-driven compressor (1, Fig. 4) draws in superheated refrigerant vapour at low pressure and compresses it.

The pressure forces the refrigerant round the refrigeration system.

The pressurized refrigerant is forced into a condenser (3, Fig. 4) located in front of the engine cooling radiator. The condenser is a matrix of tubes surrounded by fins. The refrigerant vapour travelling inside the tubes gives up its heat to the air-flow through the condenser. With the heat removed the vapour condenses to a cool liquid. The dimensions of the condenser determine that further heat transference occurs and the liquid becomes sub-cooled. Complete condensation has occurred.

The sub-cooled refrigerant still under pressure is forced into a receiver/drier (4, Fig. 4). The receiver/drier has several functions. It is a reservoir for the liquid; a filter to remove any particles which would contaminate the liquid; and it contains a quantity of molecular sieve desiccant to soak up any moisture in the liquid. Moisture would impair the efficiency of the refrigerant and cause damage at a later stage. The clean 'dry' liquid now passes into an expansion valve (5, Fig. 4) located at the inlet to the air conditioning unit. The liquid refrigerant is metered by the expansion valve so that the correct quantity is allowed to an evaporator matrix (2, Fig. 4) located in the air-conditioning unit. The metering orifice of the expansion valve is protected by a gauze filter located in the inlet union. The size of the metering orifice is controlled by the temperature sensed by a capillary at the evaporator outlet. If the temperature of the outlet pipe falls, the expansion valve closes to cut down the flow of refrigerant to the evaporator. As the temperature of the outlet

rises, a further quantity of refrigerant, metered by the expansion valve, enters the evaporator. The evaporator is a low pressure area so the refrigerant suddenly expands and the temperature drops. When the temperature falls below 0,6°C (33°F) it boils (i.e. vaporizes) and as any liquid requires a large amount of heat to change to vapour, the temperature of the evaporator matrix falls. Heat is taken from the air passing through the matrix on its way into the car.

Heat transfer continues until the vapour becomes low pressure super-heated vapour. The cycle recommences as the compressor draws in the super-heated low pressure vapour.

**NOTE:** Moisture from the cooled air passing over the fins of the evaporator condenses. The water is drained from the bottom of the evaporator by rubber tubes, and may form a pool of water under the vehicle when standing. This is normal and does not indicate a malfunction.

## COMPONENT DESCRIPTION

### RANCO THERMOSTAT

Ice formation on the evaporator fins due to moisture in the air is possible. Icing would damage the evaporator, so a thermostatic device to prevent this is fitted.

The Ranco thermostat (Fig. 5) is a temperature-operated switch which is normally closed in all functions and modes. It opens only when the temperature sensor capillary probe inserted in the evaporator matrix falls below 2°C (33.8°F).

It is important that the end of the capillary tube is inserted 10 cm and is in contact with the evaporator finning.




Fig 5

J82 072

The switch breaks the electric feed to the compressor magnetic clutch winding and the refrigeration cycle ceases. When the evaporator matrix temperature rises above 2°C (33.8°F) the thermostat switch closes and the refrigeration cycle re-starts.




Fig 6

J82 089

The magnetic clutch coil is mounted on the end of the compressor (1, Fig. 6) and the electrical connections are made to the coil terminals. The clutch permits the compressor to be engaged or disengaged as required for the air conditioning operation. When current passes through the clutch coil, the armature clutch plate assembly, keyed to the compressor shaft, is drawn rearwards against the belt driven pulley that is free wheeling upon the same shaft. This locks pulley and armature plate together to drive the compressor. When current ceases to flow, springs in the armature plate draw the clutch face from the pulley. The compressor comes to rest and the pulley continues to free wheel.




Fig 7

J82 073

## COMPRESSOR

The compressor (Fig. 7) is a six-cylinder, reciprocating piston type of special design in which three sets of double acting pistons are actuated by a swash plate on the compressor shaft so that the pistons move back and forth in the cylinders as the shaft is rotated. There are in effect three independent cylinders at each end of the compressor and reed valves are provided for each cylinder at both ends of the compressor. Internal 'cross-over' passages for suction and discharge are provided within the compressor so that the high and low service fittings on the rear end of the compressor control refrigerant flow to and from all the cylinders. A gear type oil pump located in the rear head provides for compressor lubrication.

## CONDENSER

The condenser (Fig. 8) consists of a refrigerant coil mounted in a series of thin cooling fins to provide a maximum of heat transfer in a minimum amount of space. It is usually mounted directly in front of the car radiator so that it receives the full flow of RAM AIR. Ram air is the air flow induced by the forward motion of the car and the suction of the cooling fan.

The condenser receives heat laden high pressure refrigerant vapour from the compressor.

The refrigerant enters the inlet at the top of the condenser as a high pressure very hot vapour and as this hot vapour passes down through the condenser coils, heat will follow its natural tendency and move from the hot refrigerant vapour into the cooler ram air as it flows across the condenser coils and fins.

When the refrigerant vapour reaches the temperature and pressure that will induce a change of state a large quantity of heat will be transferred to the outside air and the refrigerant will change from a high pressure HOT VAPOUR to a high pressure WARM LIQUID.




Fig 8

J82 074

## SIGHT GLASS

The sight glass located on the output side of the receiver-drier through which the refrigerant flows is used to indicate the condition of the refrigerant charge. A clear sight glass (Fig. 9) normally indicates the system has a correct charge of refrigerant. It may also indicate the system has a complete lack of refrigerant; this will be accompanied by a lack of any cooling action by the evaporator. Also the system may be overcharged; this must be verified with test gauge readings.




Fig 9

Foam or a constant stream of bubbles (Fig. 10) indicates the system does not contain sufficient refrigerant. Occasional bubbles when the system is first started is normal.




Fig 10

Foam or a heavy stream of bubbles (Fig. 11) indicates the refrigerant is very low.




Fig 11

Oil streaks on the sight glass (Fig. 12) indicates a complete lack of refrigerant.




Fig 12

A cloudy sight glass (Fig. 13) indicates that the desiccant contained in the receiver-drier has broken down and is being circulated through the system.




Fig 13

## EVAPORATOR

The evaporator (Fig. 15) consists of a refrigerant coil mounted in a series of thin fins to provide a maximum amount of heat transfer in a minimum amount of space. It is usually mounted in a housing under the cowl where, warm air from the passenger compartment is blown across the coils and fins.

The evaporator receives refrigerant from the thermostatic expansion valve as a low pressure cold atomized liquid. As this cold liquid refrigerant passes through the evaporator coils, heat will follow its natural tendency and move from the warm air into the cooler refrigerant.


## RECEIVER-DRIER

The receiver-drier (Fig. 14) is a storage tank which receives the high pressure warm refrigerant liquid from the condenser through an inlet line and delivers the refrigerant to the thermostatic expansion valve through the outlet line. The receiver-drier has two separate functions:

Acts as a storage tank for liquid refrigerant since the amount of refrigerant required by the evaporator varies widely under the different operating conditions.

Contains a filter and desiccant to remove and retain foreign particles and moisture from the refrigerant which would be harmful to the system if allowed to circulate with the refrigerant.

Fig 14



J82 076

When the liquid refrigerant reaches a temperature and pressure that will induce a change of state, a large quantity of heat will move from the air into the refrigerant and the refrigerant will change from a low pressure COLD ATOMIZED LIQUID to a low pressure COLD VAPOUR.




Fig 15

J82 077

## EXPANSION VALVE

The expansion valve (Fig. 16) is the dividing point between the high and low pressure sides of the system, and automatically meters the high pressure, high temperature liquid refrigerant through a small orifice, controlled by a metering valve, into the low pressure, cold temperature side of the evaporator matrix. The refrigerant must be controlled to obtain the maximum cooling while assuring complete evaporation of the liquid refrigerant within the evaporator. To do this, the valve senses the outlet pipe temperature, the inlet pipe pressure, and increases or decreases the flow of refrigerant liquid to maintain the outlet temperature constant.




Fig 16

J82 078

The thermostatic expansion valve continually meters the exact amount of refrigerant required to supply some liquid refrigerant throughout the evaporator coil while ensuring that all of the refrigerant will be vapourized at the evaporator outlet. The refrigerant vapour then returns to the low (suction) side of the compressor.

## AMPLIFIER

Automatic control is achieved by comparing car interior temperature and the temperature selected. This comparison provides an error signal to the air conditioning control unit, demanding an increase or decrease in car interior temperature. When the selected temperature is reached, the control unit will maintain it.

The error signal is detected across a Wheatstone Bridge circuit; two arms of which are fixed resistors, one arm contains the in-car thermistor and the fourth arm the temperature selection potentiometer. An error signal will be detected if car interior temperature is above or below that set on the temperature selection potentiometer. This signal is fed into the amplifier, (Fig. 17) amplified, and via relays, switches the servo motor to run clockwise or anti-clockwise. The position of the servo motor cam shaft directly determines the heating or cooling effect of the air conditioning system. Full heating and full cooling, are at opposite extremes of camshaft travel.




Fig 17

J82 079

The ambient thermistor in the Wheatstone Bridge circuit modifies the effect of the in-car thermistor. The result is a slightly colder interior temperature on hot days, and vice versa. A potentiometer driven by the servo motor is connected into the bridge circuit, modifying dynamic response. This provides control system damping, preventing excessive fluctuations in discharge air temperature.

4. Fresh/Recirculated Air — To improve performance the camshaft selects recirculated air on maximum cooling. Fresh air is selected for all other requirements.
5. Water Valve — On maximum cold, the camshaft controls a second vacuum switch to switch off the water valve controlling flow through the heater block.
6. Water Thermostat — A thermostat is fitted to prevent the system operating until engine water is hot enough to produce warm air. When on cooling mode the camshaft overrides this switch, and allows the system to operate immediately.
7. Evaporator thermostat — A thermostat is fitted to prevent icing of the evaporator. Under conditions where icing would be impossible and maximum cooling performance is required, the thermostat is overridden by the camshaft




Fig 18

J82 080

## SERVO CONTROL UNIT

The servo control unit (Fig. 18) is an electric servo motor and a reduction gearbox driving a camshaft. The camshaft controls seven functions:

1. Air discharge temperature — The camshaft moves blend flaps to vary air flow progressively from full cold to full heat. The cams are set to provide cooler air at head level, than to foot level, when the unit is in the low-medium heating mode. This prevents stuffiness at head level.
2. Fan speeds — The camshaft alters fan speed progressively to increase air flow at full cold or full heat positions. Four fan speeds are available on cooling, three on heating. On low heating or cooling the camshaft selects a low fan speed, preventing noise and excessive air flow movement.
3. Mode — The camshaft controls a vacuum switch so that the distribution of air in the car is automatically controlled by a vacuum operated flap. Cold air is distributed from the face level vents, and hot air is distributed mainly from foot level vents with a bleed of air from screen vents.

## MANUAL CONTROLS

### Temperature Selector

The left hand control (1, Fig. 19) is the potentiometer to select the temperature from 18°C (65°F) to 29°C (85°F) that is to be maintained automatically in the car.




Fig 19

J82 093

## MODE SWITCH

The right hand switch (2, Fig. 19) has five positions. When the switch is in the 'Off' position, the system is off and the fresh air intakes are closed. The 'Auto' position operates the system automatically. The high and low positions operate the fan high or low speed independently from that selected by the automatic control. The defrost position directs 90% of the air flow to the screen, closing the lower heater flap and opening the bleed flap to the screen outlets. At the same time, an additional resistor is switched into the Wheatstone Bridge circuit to ensure that the servo motor camshaft runs to full heat position.

## Air Distribution Temperature Control

The thumbwheel (3, Fig. 19) can be used to alter the temperature of the air being distributed through the face level vents. It is most effective when the main controls are set at Auto and 75, and the system has been allowed to stabilise. To increase the temperature of the air being delivered through the vents, move the thumbwheel to the right; this will open the upper heater flap, allowing the increased air temperature to the face level vents. To decrease the air temperature, move the thumbwheel to the left; the upper flap will close and the air temperature to the vents will be lower.

## METHOD OF TEMPERATURE VARIATION

### Full Cooling

All air passes through the evaporator matrix in which the air is cooled and dehumidified. After leaving the evaporator, four blend flaps control the degree of heat added by the heater matrix. On maximum cooling, the cooler flaps are fully open and the heater flaps are fully closed. Cold air only flows into the car (Fig. 20). A larger area of the cooling matrix is exposed to the upper flap than is exposed to the lower outlets, and most of the cooling output is directed out through the centre face level grille.

A vacuum switch on the camshaft is closed so that the water valve closes to prevent hot water flowing to the heater matrix.

The water temperature thermostat is overridden in the cooling mode. (Water temperature thermostat prevents the fans operating before water reaches 40°C.)

The evaporator thermostat (Ranco) is overridden by the camshaft cam in this mode as normally full cooling is only required when ambient conditions would prevent the evaporator from icing up, i.e. hot days.

### Full Heating

When full heating is selected the camshaft moves to the full heat position. The camshaft mechanically operates the four flaps in the air conditioning unit so that the upper and lower cooling flaps are fully closed preventing cold air reaching the car interior direct. The heater flaps are fully




Fig 20

J82 081




Fig 21

J82 082

open and the cool, de-humidified air blown through the evaporator now flows through the heater matrix and via the open heater flaps, to the screen rail end outlets and the front and rear footwells (Fig. 21).

The face level outlet is closed by the camshaft closing the vacuum switch so that

no hot air is delivered from the centre face level output. 90% of all air passing through the unit now passes out of the front and rear footwell outlets.

**NOTE:** Screen outlets are only open in defrost mode, although a slight air bleed is permitted for defrost purposes.

## Air Blend

The system automatically maintains any temperature selected, irrespective of external ambient conditions by blending hot and cold air to maintain the temperature selected. Both heating and cooling flaps are progressively positioned so that the correct blend is obtained.

The illustration (Fig. 22) shows possible positions the flaps could adopt to give correct in-car temperature. It can be seen that both heating and cooling flaps are in operation.




Fig 22

J82 083

## Defrost

When defrost is selected the camshaft will travel to full heating. The vacuum switch on the right hand control will be closed to vacuum allowing the defrost flaps to open to pass air on to the windscreen. The left hand actuator will relax and allow the lower heating flap to close to direct 90% of all air through the unit to the windscreen (Fig. 23).




Fig 23

J82 084

## GENERAL SECTION

This section contains safety precautions, general information, good practice and standards that must be followed when working upon the air conditioning system. A fault-finding and rectification section is included.

### Safety precautions

The air conditioning equipment is manufactured for use only with Refrigerant 12 (dichlorodifluoromethane) and extreme care must be taken NEVER to use a methyl-chloride refrigerant.

The chemical reaction between methyl-chloride and the aluminium parts of the compressor will result in the formation of products which burn spontaneously on exposure to air, or decompose with violence in the presence of moisture. The suitable refrigerant is supplied under the following trade names.

Freon 12; Arcton 12; Isceon 12 or any refrigerant to specification 12.

Goggles and gloves must be worn while working with the refrigerant.

**WARNING: EXTREME CARE SHOULD BE EXERCISED IN HANDLING THE REFRIGERANT. LIQUID REFRIGERANT AT ATMOSPHERIC PRESSURE BOILS AT -29°C (-20°F). SERIOUS DAMAGE OR BLINDNESS MAY OCCUR IF REFRIGERANT IS ALLOWED TO CONTACT THE EYES.**

**FIRST AID: If refrigerant should contact the eyes or skin, splash the eyes or affected area with cold water for several minutes. Do not rub. As soon as possible thereafter, obtain treatment from a doctor or eye specialist.**

### Good practice

1. The protective sealing plugs must remain in position on all replacement components and hoses until immediately before assembly.
2. Any part arriving for assembly without sealing plugs in position must be returned to the supplier as defective.
3. It is essential that a second backing spanner is always used when tightening all joints. This minimises distortion and strain on components or connecting pipes.
4. Components must not be lifted by connecting pipes, hoses or capillary tubes.
5. Care must be taken not to damage fins on condenser or evaporator matrices. Any damage must be rectified by the use of fin combs.
6. Before assembly of tube and hose joints, use a small amount of clean new refrigerant oil on the sealing seat.
7. Refrigerant oil for any purpose must be kept very clean and capped at all times. This will prevent the oil absorbing moisture.

8. Before assembly the condition of joints and flares must be examined. Dirt and even minor damage can cause leaks at the high pressure encountered in the system.
9. Dirty end fittings can only be cleaned using a cloth wetted with alcohol.
10. After removing sealing plugs and immediately before assembly, visually check the bore of pipes and components. Where ANY dirt or moisture is discovered, the part must be rejected.
11. All components must be allowed to reach room temperature before sealing plugs are removed. This prevents condensation should the component be cold initially.
12. Before finally tightening the hose connections ensure that the hose lies in the correct position, is not kinked or twisted, and will not be trapped by subsequent operations, e.g. closing bonnet, refitting bonnet.
13. Check that the hose is correctly fitted in clips or strapped to the sub-frame members.
14. The Frigidaire compressor must be stored horizontally and sump down. It must not be rotated before fitting and charging. Do not remove the shipping plate until immediately before assembly. Always use new 'O' ring seals beneath union housing plate, and in those pipe joints which incorporate them.
15. Components or hoses removed must be sealed immediately after removal.
16. After a system has been opened the receiver/drier must be renewed.

Before commencing checks, run the engine until normal running temperature is reached. This ensures that sufficient vacuum is available for tests. For cooling tests the engine must be running for the compressor clutch to operate.

## SPECIAL TOOLS AND EQUIPMENT FOR SERVICING AIR CONDITIONING SYSTEM ON JAGUAR SERIES III

- 1 Pektron test unit
- 1 Charging station
- 1 Leak detector
- 1 Temperature test box
- 1 Compressor service tool kit
- 1 Setting jig for temperature differential control, 18G1363.
- 1 Voltmeter
- 1 Ohmmeter

The Pektron Climatic Control tester (Fig. 24) is recommended for testing the air conditioning electrical system.





Fig 24

J86-196





KEY TO DIAGRAM

- 1. Blower motor relay
- 2. Blower motor resistor
- 3. Water temperature transmitter
- 4. Thermostat
- 5. Servo
- 6. Amplifier
- 7. Temperature selector
- 8. Vacuum valve
- 9. Ambient sensor
- 10. In-car sensor
- 11. Mode control switch
- 12. Blower motors
- 13. Compressor clutch
- 14. Thermal fuse
- 15. To fuse
- 16. To fuse


KEY TO SERVO UNIT (5, Fig. 25)

- A Thermo override
- B Recirc & Highspeed
- C Servo motor
- D Cool limit switch
- E Heat limit switch
- F Med 1 switch
- G Med 2 switch
- H Temperature bypass switch
- J Feedback potentiometer

Mode switch functions (11, Fig. 25)

| Micro switch | Off | Lo | Auto | Hi | Def |
|--------------|-----|----|------|----|-----|
| A Defrost    | NC  | NC | NC   | NC | NO  |
| B High Speed | NO  | NC | NO   | NC | NC  |
| C On/Off     | NO  | NC | NC   | NC | NC  |
| D Low Speed  | NO  | NO | NC   | NC | NC  |

NC = Normally Closed  
NO = Normally Open



MODE CONTROL

Fig 26

J86-195

KEY TO MODE CONTROL

- A Defrost micro switch
- B High speed micro switch
- C Low speed micro switch
- D On/off micro switch

AIR CONDITIONING SERVO UNIT




Fig 27

186-194

KEY TO SERVO UNIT

- 1. Full cooling micro switch
- 2. Full heating micro switch
- 3. Med 1 micro switch
- 4. Med 2 micro switch
- 5. Temperature override micro switch
- 6. Water valve vacuum switch
- 7. Centre flap vacuum switch
- 8. Feedback potentiometer
- 9. Cam S9
- 10. Cam S8
- 11. Cam S7
- 12. Cam S6
- 13. Cam S5
- 14. Cam S4
- 15. Cam S3
- 16. Cam S2
- 17. Cam S1
- 18. Cam S10
- 19. Ranco override micro switch
- 20. Recirculate Hi Speed switch

Test Procedure

Allow coolant temperature to stabilize to ambient by not running the engine for at least two hours, and open all of the vehicle windows for this period.  
Set the car mode control to off, and the temperature selector to approximately the ambient temperature in the vehicle. Ensure that the ignition is switched off, then disconnect the plug at the servo control unit. Insert the tester 15 way socket into the servo input and join the harness socket to the tester 15 way plug.

Disconnect the plug and socket at the amplifier. Insert the tester 12 way socket into the amplifier input, and join the harness to the tester 12 way plug. Connect the tester earth lead to a good earth on the vehicle. Carry out the following operations and note the effects.

| ACTION   | EFFECT   | WHEN INCORRECT   |
|--|--|--|
| A. Switch on Car Ignition  | 'VAC. SOLENOID MANUAL' will illuminate. No other lights 'ON'   | Check Ignition Supply, Fuse, etc. Ensure that A/C Mode Control is 'OFF'. Check Wiring to Vacuum Solenoid   |
| B. Start the Car Engine and switch car mode Control to LOW. Then switch SERVO POSITION to HEAT and press the DRIVE CONTROL until the DRIVE INDICATOR goes out. (Note: It only comes ON when DRIVE CONTROL is Pressed). | 1. The Fan Speed $\frac{1}{4}$ , $\frac{1}{2}$ and $\frac{3}{4}$ lights should be ON for Servo Position. | If the DRIVE INDICATOR did not light, switch SERVO POSITION to COOL and press the DRIVE CONTROL. When this also does not light the DRIVE INDICATOR check the SERVO motor and servo components and wiring.                          |
|  | 2. The vehicle cooling fans should be OFF.   | Ensure that the engine is not yet warmed up, then disconnect the water temperature switch in the car, and if fans continue to run suspect wiring and the Micro Switch Water Temp. override in the Servo Control Unit (5, Fig. 27). |
|  | 3. The VAC. SOLENOID MANUAL lights should go out.  | Check Switch C in mode control unit (Fig. 26) and wiring   |

## AIR CONDITIONING SYSTEM

| ACTION   | EFFECT   | WHEN INCORRECT   |
|--|--|--|
| C. Run the car engine fast to warm up the cooling water to working temperature.  | 1. The fans will start to run at low rate and the SERVO MED 1 light will operate (FAN SPEED SERVO LIGHT). The majority of air will be directed through the floor vents | Check water temperature switch.<br>Check low speed relay<br>Check blower resistors R1 & 2<br>Check fans.<br>Check wiring   |
|  | 2. The compressor clutch will operate as indicated by RANCO COMP. CLUTCH light.  | (A) Check 10A fuse, which if faulty will be indicated by the RANCO FUSED light being ON<br>(B) Check Ranco thermostat by shorting out at the component terminals and monitoring the COMP clutch light. |
| D. Switch the SERVO POSITION to COOL and press DRIVE CONTROL until $\frac{3}{4}$ light goes out then release.  | MED 1 FAN SPEED SERVO light goes out.  | Check MED 1 micro switch (3, Fig. 27) and wiring to SERVO Control Unit.  |
| E. Press DRIVE CONTROL until $\frac{1}{2}$ light goes out then release.  | The air emission is evenly distributed between face level and floor vents.   | Check adjustment of blend flaps, or vacuum system.   |
| F. Press DRIVE CONTROL until $\frac{1}{4}$ light goes out then release.  | MED 1 FAN SPEED SERVO light is 'ON'.   | Check MED 1 micro switch (3, Fig. 27) and wiring to SERVO Control Unit.  |
| G. Press DRIVE CONTROL until DRIVE INDICATOR goes out, then release.   | HIGH SPEED SERVO light ON.   | Check HI-SPEED/RECIRC micro switch and wiring to SERVO Control Unit  |
|  | COMP. CLUTCH light stays on when TEST O'RIDE switch is pressed.  | Check ranco override micro switch (19, Fig. 27) and wiring to SERVO Control Unit.  |
|  | MED 2 FAN SPEED SERVO light is 'ON'.   | Check MED 2 Micro Switch (4, Fig. 27) and wiring to Servo Control Unit.  |
|  | VAC-SOLENOID SERVO light 'ON'.   | Check Diode D3 in Servo control Unit harness.  |
| H. Switch car mode control to AUTO. Drive servo to $\frac{1}{4}$ position by selecting DRIVE CONTROL unit $\frac{1}{4}$ and $\frac{1}{2}$ lights are 'ON'. | This has given the cooling compressor the protection of its freezing sensing thermostat.   | -----  |
| J. Press MED 1 switch (FAN SPEED SERVO lights).  | Car Fan Speed increases.   | Check Main Relay.<br>Check Resistor R3.<br>Check Wiring.   |
| K. Keeping MED 1 pressed, operate MED 2 (FAN SPEED SERVO light).   | Car Fan Speed increases further.   | Check Main Relay.<br>Check Resistor R2<br>Check Wiring.  |
| L. Release MED 1 and MED 2 switches. Select HI on car mode control.  | Car fan speed increases to maximum.  | Check High Speed Micro Switch at mode control<br>Check Main Relay<br>Check Wiring.   |
|  | Ensure D5-FLT does not light.  | Check Diode D5 in mode control harness.<br>Check Wiring.   |
| M. Select AUTO on car mode control.  | To reduce fan speed to low rate.   | -----  |

| ACTION  | EFFECT  | WHEN INCORRECT  |
|---|---|---|
| N. Press TEST on AMPLIFIER fuse.  | AMPLIFIER Fuse light should be 'ON'. Feed to amplifier good.  | Check feed to amplifier.  |
| P. Switch to AMPLIFIER on sensing Switching System (Tester) Rotate control 0-100 fully clockwise then fully anti-clockwise alternately.   | Towards the '100' point HEATING light should come ON, then towards the '0' point COOLING light should come ON.  | Check Wiring.<br>Replace Amplifier.   |
| O. Ensure that the car temperature setting control is at approximately the ambient temperature. Switch to SENSOR on Sensing Switching System (Tester). Monitor LOW, DATUM, and HI lights and adjust rotary control 0-100 until only DATUM is illuminated.   | If it is not possible to 'balance' the DATUM light, then the ambient temperature may be incorrectly set on the vehicle temperature selector, or out of its range, or there is a fault in the sensors, wiring or Temperature Control. If OK proceed to Item R. | Check sensors and wiring.<br>Check Micro Switch overriding sensing circuit in the mode control, and wiring.<br>Check temperature SELECTOR and wiring. |
| R. Increase or decrease the car TEMPERATURE SELECTOR by 5°F from its set point, whichever is convenient.  | If increased the HI light will come ON in addition to the DATUM.  | Check TEMPERATURE SELECTOR and wiring.  |
| S. Adjust the rotary 0-100 control to cancel the HI or LOW light obtained in Item R. Return the TEMPERATURE SELECTOR to its original point.   | If decreased to its original point the LOW light will come ON in addition to the DATUM. If increased to its original point the HI light will come ON in addition to the DATUM.  | Check TEMPERATURE SELECTOR and wiring.  |
| T. Adjust the rotary 0-100 control to cancel the HI or LOW light obtained in Item S. Switch the mode control from AUTO to DEF.  | The HI light operates in addition to the DATUM.   | Check Micro Switch override sensing circuit at mode control and resistance unit in mode control harness.  |
| U. Select the OFF on the Mode control. Switch off the vehicle engine and ignition circuit.  | All tester indicators are OFF.  | Check vehicle ignition switch.<br>Check relays and wiring.  |
| V. Remove tester connectors and return the vehicle wiring and plugs and sockets to standard.  | The complete system can now be tested following any corrective action taken as a result of the checks.  | Identify the problem area, and after carrying out the preliminary procedure of tester connection, repeat only the relevant parts of the schedule      |
| Familiarity with the tester should be easily acquired, and then the Operator will find the flexibility of control offered by having access to test each sub-assembly will lead to quick identification of faults, and a system knowledge which allows him to extend this scope of the scheduled checks. |   |   |

## 'IN-CAR' FAULT FINDING CHART

### Equipment required

1. Voltmeter capable of covering 0 to 13 volts d.c.
2. Continuity tester.
3. Ohmmeter capable of covering 0 to 20K ohms.
4. Vacuum gauges (not essential) to check vacuum level.


The battery should be disconnected whenever an electrical unit is being removed or refitted.

### TEST 1

R.H. OFF


L.H. 75°

#### 1. A



#### 1. B

RECIRCULATION FLAPS OPEN  
FRESH AIR FLAPS CLOSED



TEST 2

R.H. 'DEFROST'

L.H. 75°

BLOWERS TO HIGH SPEED

Listen to both sides

Check voltages at connectors  
(each side)

BLOWER(S) OFF

0V

Voltage not present  
Blower electrical  
fault

Check voltage at triple  
relay, GS lead and terminal

Break in GS  
line(s) relay  
to blower  
connections

12V Switching OK

10V Blowers at Med. 2

5V Blowers on low speed

Blowers at low  
speed

Check earth resistance  
at BU lead

Relay

Low resistance

High resistance

Check voltage in  
Relay lead BG

Harness breaks  
in BU lead or  
switch fault  
in hand switch  
D or bad earth

0V—Relay fault  
replace

12V

Fault in resistor  
assembly or  
connection to  
harness—lead R

Check  
relay voltage  
at BW lead

0V

Harness break in  
BW line to hand  
control

12V

Relay fault—replace

0V

Check voltage at NW lead  
on relay

12V

0V

Check relay voltage  
at NY lead

Electrical fault  
in main supply

12V

0V

Check Relay earth resistance

Harness breaks  
in NY lead or  
switch fault

Low resistance


High resistance—earth  
contact loose

Check relay  
Y terminal

12V Resistor assembly  
fault—check Y and GS  
connections

0V Relay  
fault—replace

# AIR CONDITIONING SYSTEM




**R.H. AUTO—HI**


**L.H. HEATING MODE (HIGHER THAN AMBIENT)**

## TEST 3

**3A**



**3B**




## TEST 4

R.H. AUTO—LOW

L.H. 85°


## BLOWERS AT LOW SPEED





## TEST 5

## AMPLIFIER/SERVO RESPONSE




6.1


**AUTOMATIC FUNCTIONS**




LIMITED COOLING/HEATING  
 SERVO WILL NOT TRAVERSE  
 Could be damaged—check Test 5

6.2




6.3






6.7



6.8

INCORRECT AIR TEMPERATURE AND AIR DISTRIBUTION



## CHARGING AND TESTING EQUIPMENT




Fig 28

The charging and testing equipment consists of a charging manifold (1, Fig. 28) fitted with two stop valves (2 & 3, Fig. 28). One compound gauge (4, Fig. 28) reading both vacuum and pressure, and it is connected to the suction side of the system. The other gauge is a high pressure gauge (5, Fig. 28) and is connected to the delivery side of the system.

**WARNING: FOR SAFETY REASONS, THE ACCURACY OF BOTH GAUGES MUST BE CHECKED AT FREQUENT INTERVALS.**

### Gauge Manifold

The manifold is designed to control refrigerant flow. As shown in the following illustration, when the manifold test set is connected into the system, pressure is registered on both gauges at all times. During all tests, both the low and high side hand valves are in the closed position (turned inward until the valve is seated). Refrigerant will flow around the valve stem to the respective gauges and register the system low side pressure on the low side gauge, and the system high side pressure on the high side gauge. The hand valves isolate the low and high side from the central portion of the manifold.

### Low Side Gauge

This gauge (4, Fig. 28) has a dial reading from 0 to 150 psi (pressure scale) in a clockwise direction, and from 0 to 30 inches of Mercury (vacuum scale) in a counter-clockwise direction. This low side gauge is called a Compound Gauge and has a dual purpose, to register both Pressure and Vacuum. This gauge is used to measure evaporator outlet pressure.

### High Side Gauge

This gauge (5, Fig. 28) has a dial reading from 0 to 500 psi in a clockwise direction. The high side gauge is a Pressure gauge only.

A test hose connected to the fitting directly under the low side gauge is used to connect the low side of the test manifold into the low side of the system, and a similar connection is found on the high side.

Two hose connectors must be fitted with depressors to operate the schrader valves on the high and low pressure sides of the system.

**CAUTION: Do not open the high side hand valve while the air conditioning system is in operation. Under no circumstances should this be done. If the high side hand valve should be opened while the system is operating, high pressure refrigerant will be forced through the high side gauge and to the refrigerant can if it is attached. This high pressure can rupture the can or possibly burst the fitting at the safety can valve, resulting in much damage (including physical injury).**

With the engine switched off, remove the protective caps from the schrader valves. Ensure both high and low side hand valves are in the closed position. Connect the high pressure gauge hose to the high pressure schrader valve (1, Fig. 29) and connect the low pressure or compound valve hose to the low pressure schrader valve (2, Fig. 29).




Fig 29

## PURGING TEST HOSES

### Using System Refrigerant

Be sure high and low side hoses are properly connected to service valves (all hose connections tight).

Now, purge the high side test hose by opening the hand valve on the high side gauge for 3 - 5 seconds. This allows the system's refrigerant to force air through the test hoses and out of the centre service hose. Immediately close the high side gauge hand valve.

Purge the low side test hose in the same manner, using the hand valve of the low side gauge. Close hand valve after 3 - 5 seconds.

### Stabilizing the System

The manifold gauge set is attached to the system, and the test hoses purged of air. You must now operate the system for a few minutes to stabilize all pressures and temperatures throughout the system in order to obtain accurate test gauge readings. Stabilize the system as follows:

Place all test hoses, gauge set and other equipment away from all engine moving parts. Also keep hoses from touching hot manifolds. Start the engine and adjust engine speed to fast idle.

Turn air conditioner controls to maximum cooling. Set blower fan on high speed.

Open doors and/or windows (to quickly eliminate interior heat).

Operate system under these conditions for 5 to 10 minutes and the system will be stabilized and ready for test readings.

### Test Conditions

1. Use a large fan to substitute for normal ram air flow through the condenser.
2. Car adjusted to normal fast idle speed.
3. All conditions equivalent to 30 mph

## TORQUE LEVELS FOR THE AIR CONDITIONING HOSE CONNECTIONS

| Item  | Nm             | Kgf/m        | lbf/ft   |
|---|----------------|--------------|----------|
| 1. Compressor/Condenser (Compressor End)            | 40,67 to 47,45 | 4,15 to 4,84 | 30 to 35 |
| 2. Condenser/Compressor (Condenser End)             | 28,47 to 36,30 | 2,90 to 3,73 | 21 to 27 |
| 3. Condenser/Receiver Drier (Condenser End)         | 20,34 to 27,12 | 2,10 to 2,76 | 15 to 20 |
| 4. Receiver Drier/Condenser (Receiver Drier End)    | 40,67 to 47,45 | 4,15 to 4,84 | 30 to 35 |
| 5. Receiver Drier/Evaporator (Receiver Drier End)   | 40,67 to 47,45 | 4,15 to 4,84 | 30 to 35 |
| 6. Evaporator/Receiver Drier (Evaporator End)       | 14,91 to 17,62 | 1,52 to 1,80 | 11 to 13 |
| 7. Expansion Valve/Evaporator (Expansion Valve End) | 20,34 to 27,12 | 2,10 to 2,76 | 15 to 20 |
| 8. Evaporator/Compressor (Evaporator End)           | 28,47 to 36,60 | 2,90 to 3,73 | 21 to 27 |
| 9. Compressor/Evaporator (Compressor End)           | 40,67 to 47,45 | 4,15 to 4,84 | 30 to 35 |

## PRESSURE — TEMPERATURE RELATIONSHIP

**NOTE:** Pressures shown are under exact conditions (see Test Conditions below) and are not necessarily true for every car checked.

Ambient Temperature is given as the temperature of the air surrounding the condenser and is taken 2 inches in front of the condenser.

| Ambient Temperature °F | High Pressure Gauge Reading |
|------------------------|-----------------------------|
| 60                     | 95-115                      |
| 65                     | 105-125                     |
| 70                     | 115-135                     |
| 75                     | 130-150                     |
| 80                     | 150-170                     |
| 85                     | 165-185                     |
| 90                     | 175-195                     |
| 95                     | 185-205                     |
| 100                    | 210-230                     |
| 105                    | 230-250                     |
| 110                    | 250-270                     |
| 115                    | 265-285                     |
| 120                    | 280-310                     |

Normal operating ranges shown by dotted line boxes.

| Low Pressure Gauge Reading | Evaporator Temperature °F |
|----------------------------|---------------------------|
| 10                         | 2                         |
| 12                         | 6                         |
| 14                         | 10                        |
| 16                         | 14                        |
| 18                         | 18                        |
| 20                         | 20                        |
| 22                         | 22                        |
| 24                         | 24                        |
| 26                         | 27                        |
| 28                         | 29                        |
| 30                         | 32                        |
| 35                         | 36                        |
| 40                         | 42                        |
| 45                         | 48                        |
| 50                         | 53                        |
| 55                         | 58                        |
| 60                         | 62                        |
| 65                         | 66                        |
| 70                         | 70                        |




Fig 30

### Complaint

Little or no cooling.

### Condition

1. Low side gauge reading too low. Should be 15 - 30 psi.
2. High side gauge reading too low. Should be 185 - 205 psi at ambient temperature of 95°F.
3. Stream of bubbles evident in sight glass.
4. Discharge air from evaporator only slightly cool.

### Diagnosis

System low on refrigerant. May be caused by small leak.

### Correction

1. Leak test system.
2. Discharge refrigerant from system if necessary to replace units or lines.

3. Repair leaks.
4. Check compressor oil level. System may have lost oil due to leakage.
5. Evacuate system using vacuum pump.
6. Charge system with NEW Refrigerant.
7. Operate system and check performance.




Fig 31

### Complaint

Cooling is not adequate.

### Condition

1. Low side gauge reading is very low. Should be 15 - 30 psi.
2. High side gauge reading very low. Should be 185 - 205 psi at ambient temperature of 95°F.
3. No liquid and no bubbles evident in sight glass.
4. Discharge air from evaporator is warm.

### Diagnosis

System excessively low of refrigerant. Serious leak indicated.

### Correction

1. Leak test system.

**NOTE:** Add partial refrigerant charge before leak testing to ensure a leak test indication. Leak test compressor seal area very carefully.

2. Discharge refrigerant from system.
3. Repair leaks.
4. Check compressor oil level. System may have lost oil due to leakage.
5. Evacuate system using vacuum pump.
6. Charge system with NEW Refrigerant.
7. Operate system and check performance.




Fig 32

### Complaint

Cooling is not adequate.

### Condition

1. Low side gauge reading is constant and does not drop. Pressure should drop until compressor cycles (thermostat control).
2. High side gauge reading slightly high (or slightly lower especially if large fan used to substitute ram air): High side gauge reading should be 185 - 205 psi at ambient temperature of 95°F.
3. Sight glass free of bubbles or only shows occasional bubble.
4. Discharge air from evaporator only slightly cool.

### Diagnosis

Non condensables present in system. Air or moisture present instead of full refrigerant charge.

### Correction

1. Leak test system.
- Leak test compressor seal area very carefully.
2. Discharge refrigerant from system.
3. Repair leaks as located.
4. Replace receiver-drier. Drier probably saturated with moisture.
5. Check compressor oil level.
6. Evacuate system using vacuum pump.
7. Charge system with NEW Refrigerant 12.
8. Operate system and check performance.




Fig 33

## Complaint

Cooling is not adequate.

## Condition

1. Low side gauge reading too high. Should be 15 - 30 psi.
2. High side gauge reading too low. Should be 185 - 205 psi at temperature of 95°F.
3. Sight glass free of bubbles (system is fully charged).
4. Discharge air from evaporator not sufficiently cool.

## Diagnosis

Internal leak in compressor.

## Correction

1. Discharge the system and replace compressor and receiver-drier.
2. Evacuate the system using a vacuum pump.
3. Charge the system with new refrigerant.
4. Operate system and check performance.




Fig 34

## Complaint

Little or no coolant. Engine overheating may also be noted.

## Condition

1. Low side gauge reading excessively high. Should be 15 - 30 psi.
2. High side gauge reading excessively high. Should be 185 - 205 psi at 95°F.
3. Bubbles may appear occasionally in sight glass. Liquid line very hot.
4. Discharge air from evaporator is warm.

## Diagnosis

Improper condenser operation with lack of cooling caused by too high a high side pressure. System may have either normal or overcharge of refrigerant.

## Correction

1. Check for loose or worn driver belts causing excessive compressor head pressures.
2. Inspect condenser for clogged air passages, bug screen, or other obstructions preventing air flow through condenser.
3. Inspect condenser mounting for proper radiator clearance.
4. Inspect clutch type fan for proper operation.
5. Inspect radiator pressure cap for correct type and proper operation.

After making the above checks:

Operate system and check performance.

## If condition not corrected:

1. Inspect system for overcharge of refrigerant and correct as follows:
  - (a) Discharge refrigerant until stream of bubbles appears in sight glass and both high and low gauge readings drop below normal.
  - (b) Add new Refrigerant 12 until bubbles disappear and pressures are normal, then add  $\frac{1}{4}$  -  $\frac{1}{2}$  lb of additional refrigerant.
2. Operate system and check performance.

## If gauge readings still too high:

1. Discharge system.
2. Remove and inspect condenser for oil clogging. Clean and flush condenser to ensure free passage of refrigerant or replace condenser.
3. Replace receiver-drier.
4. Evacuate system using vacuum pump.
5. Charge system with NEW Refrigerant 12.
6. Operate system and check performance.




Fig 35

## Complaint

Cooling is not adequate during hot part of day.

**NOTE:** Cooling may be satisfactory during early morning or late evening hours but is not adequate during hot part of the day.

## Condition

1. Low side gauge reading (15 - 30 psi) but may drop into vacuum during testing.
2. High side gauge reading normal (205 psi at 95°F) but will drop when low side gauge reading drops into vacuum.
3. Sight glass may show tiny bubbles.
4. Discharge air from evaporator is sharp and cold but becomes warm when low side gauge reading drops into a vacuum.

## Diagnosis

Excessive moisture in system. Desiccant agent saturated with moisture which is released during high ambient temperatures. Moisture collects and freezes in expansion valve and stops refrigerant flow.

## Correction

1. Discharge refrigerant from system.
2. Replace receiver-drier.
3. Evacuate system with vacuum pump.
4. Charge system with NEW Refrigerant 12.
5. Operate system and check performance.




Fig 36

## Complaint

Little or no cooling.

## Condition

1. Low side gauge reading too high. Should be 15 - 30 psi.
2. High side gauge reading too high. Should be 185 - 205 psi at ambient temperature of 95°F.
3. Occasional bubbles in sight glass.
4. Discharge air from evaporator is not cool.

## Diagnosis

Air in system. Refrigerant contaminated by non-condensables (air and/or moisture).

## Correction

1. Discharge refrigerant from system.
2. Replace receiver-drier which may be saturated with moisture.
3. Evacuate system using vacuum pump.
4. Charge system with NEW Refrigerant.
5. Operate system and check performance.




Fig 37

### Complaint

Little or no cooling.

### Condition

1. Low side gauge reading too high. Should be 15 - 30 psi.
2. High side gauge reading normal or slightly low. Should be 185 - 205 psi at an ambient temperature of 95°F.
3. Discharge air from evaporator warm.
4. Suction hose and evaporator show heavy sweating.

### Diagnosis

Expansion valve allowing excessive flow of refrigerant through evaporator causing flooding of evaporator coils.

### Testing

Check for expansion valve stuck open of incorrect mounting or temperature sensing bulb as follows:

- (a) Set air conditioner for maximum cooling and operate the system.
- (b) Spray liquid Refrigerant 12 on head of valve or capillary bulb, not low side gauge reading. Low side gauge should drop into a vacuum.
- (c) If low side vacuum reading obtained, warm expansion valve diaphragm chamber with hand, then repeat test (step 'b').

### Correction

1. If expansion valve test indicates valve operation is satisfactory, proceed as follows:
  - (a) Clean contact surface of evaporator outlet pipe and temperature sensing bulb, clamp bulb securely in contact with pipe.
  - (b) Operate system and check performance.
2. If expansion valve test indicates valve is defective, proceed as follows:
  - (a) Discharge system.
  - (b) Replace expansion valve.
  - (c) Evacuate system using vacuum pump.
  - (d) Charge system with NEW Refrigerant.
  - (e) Operate system and check performance.




Fig 38

### Complaint

Cooling is not adequate

### Condition

1. Low side gauge reading too low (0 psi or a vacuum). Should be 15 - 30 psi.
2. High side gauge reading too low. Should be 185 - 205 psi at ambient temperature of 95°F.
3. Discharge air from evaporator only slightly cool.
4. Expansion valve inlet may show heavy sweating or frost.

### Diagnosis

Expansion valve restricting refrigerant flow due to clogged screen, stuck valve, or temperature sensing bulb having lost its charge.

### Testing

1. If expansion valve inlet is cool to touch, proceed as follows:
  - (a) Set air conditioner for maximum cooling and operate the system.
  - (b) Spray liquid Refrigerant 12 on head of valve or capillary bulb, note low side gauge reading. Low side gauge should drop into a vacuum.
  - (c) If low side vacuum reading obtained, warm expansion valve diaphragm chamber with hand, then repeat test (step 'b').
  - (d) If expansion valve test indicates valve operation is satisfactory, clean contact surface of evaporator outlet pipe and temperature sensing bulb, clamp bulb securely in contact with pipe. Proceed with correction procedure (below).
2. If expansion valve inlet shows sweating or frost proceed as follows:
  - (a) Discharge system
  - (b) Disconnect inlet at expansion valve, remove and inspect filter.
  - (c) Clean and replace filter, reconnect inlet line.
  - (d) Proceed with correction, procedure (below).
3. If expansion valve test (step '1' preceding) indicates valve is defective, proceed as follows:
  - (a) Discharge system.
  - (b) Replace expansion valve, then proceed with correction procedure.

### Correction

1. After cleaning expansion valve screen, or replacing expansion valve if necessary, and properly mounting temperature sensing bulb on evaporator outlet pipe, proceed as follows:
  - (a) Evacuate system using vacuum pump.
  - (b) Charge system with NEW Refrigerant 12.
  - (c) Operate system and check performance.




Fig 39

### Complaint

Cooling is not adequate.

### Condition

1. Low side gauge reading too low. Should be 15 - 30 psi.
2. High side gauge reading will build excessively high. Should be 185 - 205 psi at an ambient temperature of 95°F.

**NOTE:** An overcharged system, or a Condenser or receiver-drier that is too small, will cause high side gauge reading to be normal or excessively high.

3. Discharge air from evaporator only slightly cool.
4. Liquid line cool to the touch, line or receiver-drier may show heavy sweating or frost.

### Diagnosis

Restriction in receiver-drier or liquid line with compressor removing refrigerant from evaporator faster than it can enter resulting in a 'starved' evaporator.

### Correction

1. Discharge system.
2. Remove and replace receiver-drier, liquid lines, or other defective parts.
3. Evacuate system using vacuum pump.
4. Charge system with NEW Refrigerant 12.
5. Operate system and check performance.



## AIR CONDITIONING SYSTEM




Fig 40

### Complaint

Compressor cycles (cuts in and out) too rapidly. Compressor cycles on 34 psi (1, Fig. 40). Compressor cycles off 28 psi (2, Fig. 40).

### Condition

1. Low side pressure cycle too high with insufficient range between OFF and ON. Cycle should be:  
Cycle 'Off' — 12 - 15 psi.  
Cycle 'On' — 36 - 39 psi.  
Cycle Range — 24 - 28 psi.
2. High side gauge reading Normal (200 psi). Should be 185 - 205 psi at ambient temperature of 95°F.

### Diagnosis

Ranco thermostat faulty.

### Correction

1. Stop car engine, turn air conditioning off and disconnect the battery.
2. Remove and discard old thermostatic switch, install new switch of same type.
3. When installing new thermostatic switch, make certain that capillary tube installed in same position and to same depth in evaporator core as old switch tube.

**CAUTION: Do not kink or bend capillary tube too sharply — tube is gas filled.**

Operate system and check performance of new thermostatic switch.

## AIR CONDITIONING SYSTEM

### Depressurise

Observe all safety precautions and do not smoke while carrying out the following procedure.

With the engine switched off, remove the protective caps from the schrader valves. Connect the manifold gauge set with the red hose to the high pressure side (1, Fig. 41) and the blue hose to the low pressure side (2, Fig. 41).

Place the free end of the centre hose (3, Fig. 41) into a suitable container. Slowly open the high or low side manifold hand valve and adjust the valve for a smooth




Fig 41

refrigerant flow. Watch for any signs of escaping oil and adjust the hand valve so that no oil escapes. If oil is lost during the discharge, the compressor oil level will have to be checked and topped up.

As the discharge rate slows down, open the other manifold hand valve. Refrigerant will now flow from the high and low pressure sides of the system. Constantly adjust the hand valves to ensure that oil does not flow. When a zero reading is shown on both the high and the low pressure gauges the system is discharged. Close both hand valves.

### Evacuate

Once a system has been opened for repairs, or is found low of refrigerant, it must be fully evacuated with a vacuum pump to remove all traces of moisture before a new refrigerant charge is added.

Moisture may collect and freeze in the expansion valve which will block the refrigerant flow and stop the cooling action. Moisture will also react with Refrigerant 12 and cause corrosion of the small passages and orifices in the system.

The desiccant in the receiver-drier can absorb only a limited amount of moisture before it becomes saturated, therefore it is important to prevent moisture entering the system, and to remove any moisture which may have entered the system through a leak or an open connection.

Unwanted air and moisture are removed from the system by a vacuum pump. A vacuum pump is the only piece of equipment designed to lower the pressure sufficiently so that the moisture boiling temperature is reduced to a point where the water will vaporise and then can be evacuated from the system.

The compressor cannot be used as a vacuum pump because the refrigeration oil circulates with the refrigerant. The compressor depends to a large extent on the refrigerant distributing oil for lubrication and damage to the compressor may result due to lack of refrigerant which carries the oil for lubrication.

After the system has been fully discharged, and with the test gauge set still connected, attach the centre hose of the manifold gauge set, to the inlet fitting of the vacuum pump.

Open the low and high side manifold hand valves to their maximum positions.

Open the discharge valve on the vacuum pump or remove the dust cap on the discharge outlet whichever is appropriate.

Turn the vacuum pipe on, note the low side gauge to make certain that a vacuum is being created in the system by the vacuum pump.

From the time the lowest vacuum is attained, continue to operate the vacuum pump for a few minutes to be sure complete evacuation has been performed.

Close both gauge hand valves, turn off the vacuum pump, note the low side gauge reading. The gauge needle should remain stationary at the point where the pump was turned off. Should the gauge needle return towards zero a leak exists in the air conditioning system.

If a leak exists charge the system with R12 refrigerant, locate the leak with a leak detector, discharge the refrigerant from the system. Repair the leak and repeat the evacuation procedure.

If the gauge needle remains stationary and vacuum is maintained for 3 to 5 minutes, close both the high and low manifold hand valves, and disconnect the hose from the vacuum pump.

The air conditioning system is now ready for charging.

### Flushing

If contamination of the expansion valve and associated pipework occurs it is essential that the whole of the air conditioning is fully flushed out using Freon 12, or other suitable charging gas.

Discharge the system.

Disconnect the inlet (low pressure) and the outlet (high pressure) pipes from the compressor.

Fit a suitable blanking plate over the end of the high pressure pipe and retain the plate with a suitable G clamp, also remove the schrader valve from the charging connection on the high pressure pipe.

Place the low pressure pipe into a suitable metal container and cover.

Disconnect the high pressure pipe from the expansion valve and carefully remove the conical filter, then reconnect the pipe on the expansion valve.

Carefully remove the thermal bulb coil attached to the evaporator outlet pipe and allow the thermal bulb to remain in the ambient air.

This will prevent the expansion valve closing when refrigerant is flushed through it.

Connect a suitable hose, from the liquid connection of a recommended refrigerant canister, to the charging connection on the high pressure pipe.

Open the canister (the pressure in the canister should be approximately 4.22 kgf/cm<sup>2</sup> (60 lbf/in<sup>2</sup>)) and allow the refrigerant to flush through the air conditioning system for approximately 30 seconds, or until a steady liquid flow is observed from the low pressure pipe.

Turn the refrigerant canister off and remove the connections.

**IMPORTANT:** On re-assembling the system. Fit a new receiver-drier.

Check the compressor oil level.

Thoroughly clean and refit the expansion valve filter.

Refit the thermal bulb on to the evaporator outlet pipe.

Refit the schrader valve into the high pressure pipe.

Refit all the pipe connections and recharge the system.

## Charge

Charging the air conditioning system is the process of adding a specific quantity of refrigerant to the circuit. Before attempting the charging operation the system **must** have been evacuated and, if necessary, flushed through immediately beforehand. No delay between evacuation and charging procedures is permissible. The equipment should be fitted with a means of accurately weighing the refrigerant during the charging process. Great care must be taken to charge correctly, as undercharging will result in very inefficient operation, and overcharging will result in very high pressures and possible damage to components.

Evacuate the system with hoses (1 & 2, Fig. 42) connected as shown.

Connect the centre hose of the charging manifold (3, Fig. 42) to a supply of refrigerant. The supply available must be at least 3,3 kg (7.2 lb) weight.

Open the refrigerant supply valve.

Purge the centre hose by momentarily cracking the connection at the manifold block: retighten the connector.

Record the weight of refrigerant supply source. Open both valves on the charging manifold and allow the refrigerant source pressure to fill the vacuum in the system.

Between 0,23 kg and 0,45 kg ( $\frac{1}{2}$  lb to 1 lb) weight will enter the system.

Record the quantity.

**NOTE:** The quantity drawn in will vary with ambient temperature.

Close the high pressure side valve on the manifold block.

Ensure that all is clear and start the vehicle engine. Run the engine at 1500 rev/min.

Set the air conditioning system blower speed control to 'Fast'.

**NOTE:** This engages the compression clutch to start system circulation, and runs the blower motors at fast speed to heat the evaporator coil. Vapour will be turned to liquid in the condenser and stored in the receiver-drier.

Control the flow of refrigerant with the suction side valve on the charging manifold, and allow a total weight of 1,13 kg  $\pm$  0,028 kg ( $2\frac{1}{2}$  lb  $\pm$  2 oz) refrigerant to enter system.

Close the suction side valve.

**NOTE:** Alternatively, observe the sight glass on receiver-drier until the sight glass clears, and no bubbles or foam are visible.

Re-open the suction valve for 2 to 5 minutes (2 minutes if the ambient temperature is low, 5 minutes if high).

This will allow an additional 0,11 kg ( $\frac{1}{4}$  lb) of refrigerant to enter the system.

Run the system for 5 minutes, observing the sight glass.

If foaming is very slight, switch off the engine.

**NOTE:** It is normal for there to be slight foaming if the ambient air temperature is 21°C (70°F) or below.

Close the refrigerant supply valve, disconnect the hose.

Quickly disconnect the hoses from the schrader valves.

Fit protective sealing caps.

Switch on the engine and check the function of the air conditioning system.

Switch off the engine; flush the engine compartment and interior of the vehicle with shop compressed air line.

Conduct a leak test on the installation.

## SUPERHEAT SWITCH AND THERMAL FUSE

### Description

The superheat switch and a thermal fuse are included in the clutch circuit to provide a compressor protection system. This guards against low refrigerant charge and blockages causing extreme superheated inlet gas conditions and resulting compressor damage.

### KEY TO DIAGRAM (Fig. 43)

1. To compressor clutch
2. Superheat switch
3. Thermal fuse
4. + Feed cable




Fig 43

The superheat switch is located in the rear of the compressor in contact with the suction side gas, whose pressure drops and temperature rises with low refrigerant charge (ie Freon leak). This condition closes the superheat switch contacts.

The thermal fuse is a sealed unit containing a heater and meltable fuse. The superheat switch brings in the heater which melts the fuse and disconnects the compressor clutch and heater. The compressor stops and damage from insufficient lubrication will be avoided.

**CAUTION:** After a thermal fuse melt, establish and rectify the cause before replacing the thermal fuse unit complete.

Thermal fuse melt:

Temperature: 157 to 182°C (315 to 360°F)

Time: 2 minutes — 14V system voltage

5.5 minutes — 11,5V system voltage

Heater resistance, cold: 8 to 10 ohms:

## Air Conditioning Superheat Switch

### Testing

If the refrigerant level is satisfactory and there is not a blockage in the air conditioning system but the thermal fuse persists in melting.

Carry out the following checks.

**Test Procedure 'A' —** for use with a cold engine and at ambient temperatures below 30°C (86°F).

Connect a test lamp in series with the superheat switch (Fig. 44).

**NOTE:** With the test lamp connected in the circuit it will prevent the thermal fuse from operating as a safety device therefore care should be taken when carrying out the test.




Fig 44

### KEY TO DIAGRAM (Fig. 44)

1. Air conditioning switch
2. Ambient switch
3. Compressor clutch fuse
4. Thermal fuse
5. Compressor clutch coil
6. Superheat switch
7. Test lamp




Fig 42

With the ignition and air conditioning switched on.  
Ensure a serviceable thermal fuse is fitted.  
Evacuate the air conditioning system and then close the taps.  
The test lamp should not light. If the test lamp does light then follow test procedure 'B'.

With the lamp not illuminated start and run the engine at about 2000 rpm. After a few minutes the lamp should light. As soon as the test lamp lights, open the taps to allow refrigerant to charge into the system. As the air conditioning system becomes charged the lamp should go out.

If the above lamp functions do not occur, replace the superheat switch.  
After checking remove the test lamp from the circuit and reconnect the superheat switch lead onto the terminal.  
Operate and check the system.

## Test Procedure B — for use with a hot engine or at ambient temperatures above 30°C (86°F).

Connect the test lamp in series with the superheat switch.

Switch the ignition and air conditioning on.  
Ensure a serviceable thermal fuse is fitted.  
Evacuate the air conditioning system and then close the taps.

The test lamp should light. (If the lamp does not light carry on checks as in Procedure 'A').

With the test lamp illuminated open the taps and allow refrigerant to charge the system. As the system becomes charged the test lamp should go out.

If the lamp functions do not occur, then replace the superheat switch.

After checking remove the test lamp and reconnect the superheat switch lead onto the terminal.

Operate and check the system.

## SUPERHEAT SWITCH

### Renew

Discharge system.

Disconnect harness connector from superheat switch.

Remove suction (low pressure) and out-put (high pressure) hoses.

Remove superheat switch retaining circlip and remove switch by pulling out of the compressor housing.

Remove the superheat switch 'O' ring located in the compressor housing.

Lightly lubricate the new 'O' ring seal and fit into compressor housing.

Locate the replacement superheat switch into the compressor housing and gently push switch into housing until seated.

Fit new circlip and secure.

Connect the suction (low pressure) and out put (high pressure) hoses to the compressor. Evacuate and recharge system and check system for leaks using suitable leak detection equipment.

## COMPRESSOR

### Remove and Refit

**WARNING: BEFORE COMMENCING WORK, REFER TO THE GENERAL SECTION. DO NOT OPERATE THE COMPRESSOR UNTIL THE SYSTEM IS CORRECTLY CHARGED.**

**NOTE:** Ensure that clean, dry male and female caps are to hand.

Disconnect the battery earth lead.

Depressurize the system.

On NAS vehicles, remove the air pump. Note the position of the hoses.

Remove the clamping plate securing the high and low pressure hoses (1, Fig. 45). Displace the hoses (2, Fig. 45). Fit blanking caps to the hoses and the compressor.

Remove the superheat switch cable connector (3, Fig. 45).

Slacken the compressor front and rear pivot bolts (4, Fig. 45).

Slacken the adjusting link locking and adjusting nuts.

Remove the bolts securing the adjusting link and remove the link.

Displace the drive belt. Disconnect the clutch cable connector (5, Fig. 45).

Remove the nuts securing the cruise control actuator and displace the actuator unit.

Remove the compressor pivot bolts and displace the compressor.

Manoeuvre the compressor from the engine compartment, keeping it horizontal and the sump down.

If a new compressor is being fitted, remove the mounting brackets from the old compressor and fit to new unit.

On refitting, ensure that new 'O' sealing rings are fitted.

Ensure the compressor drive belt is adjusted to the correct tension.

Correct tension as follows:

A load of 2.9 kg (6.4 lb) must give a total belt deflection of 4.32 mm (0.17 in) when applied at mid-point of the belt.

Recharge the air conditioning system.




Fig 45

**CAUTION:** After recharging, cycle the clutch in and out 10 times by selecting OFF-LOW, AUTO-OFF on the mode selector switch with the engine running. This ensures that the pulley face and the clutch plate are correctly bedded-in before a high demand is made upon them.

Check the system for correct operation.  
Check the cruise control for correct operation.

## COMPRESSOR OIL — CHECKING PROCEDURE

The following procedure should be adopted when checking the amount of oil in a compressor prior to its being fitted to a car:

1. Remove drain plug from compressor sump and drain oil into container having capacity of at least 285 cc (10 fl oz).
2. Remove pressure plate across inlet and outlet ports at rear of compressor; more oil may flow from sump plug hole.
3. With pressure plate still removed, set compressor on its rear end so that inlet and outlet ports are over container; slowly rotate drive plate through several revolutions both clockwise and anti-clockwise. Oil may flow from ports.
4. Measure quantity of oil drained out; make this up to 199 cc (7 fl oz) and re-fill compressor with this amount of 525 viscosity refrigerant oil.

If the compressor is not to be fitted immediately, it is important that the pressure plate be refitted over the ports and secured there, to prevent ingress of foreign matter.

Should it be suspected that the compressor oil level is low, on a car in service, the checking procedure detailed should be followed after the car engine has been run for at least 10 - 15 minutes with the air conditioning system switched on; this will cause the refrigerant oil to be returned to the compressor sump.

Should a new receiver-drier bottle, condenser or evaporator be fitted, without the car engine being run as above, immediately before dismantling, the following quantities of 525 viscosity refrigerant oil must be added to the system:

- (a) For a new receiver-drier bottle — add 28 cc (1 fl oz).
- (b) For a new condenser — add 85 cc (3 fl oz).
- (c) For a new evaporator — add 85 cc (3 fl oz).

Additional oil is not needed after renewal of hose assemblies.

Oil may be added to the system either directly into the compressor or into the compressor charging port.

## Compressor Servicing Procedure

To enable the servicing of the air conditioning compressor the following components are now available. The following servicing procedures should be adopted in the event of a malfunction of the compressor which involves any of the parts listed, as opposed to the replacement of the compressor unit.

### Part Description

Pulley Bearing  
Superheat Switch  
Pressure Relief Valve  
'O' Ring Suction Discharge Port  
 $\frac{1}{4}$  Pint 525 Viscosity Oil  
Clutch Drive Assembly  
Shaft Nut  
Woodruff Key  
Coil and Housing Clutch  
Pulley Bearing Assembly  
Retainer Ring Kit  
Body of Compressor less Clutch, Pulley and Coil Housing Assembly  
Shaft Kit for Seal  
Bearing Retaining Ring

The specialist tool kit required to service the compressor unit in conjunction with the following procedures are available from KENT MOORE.

|                    |       |
|--------------------|-------|
| Tool Kit           | 10500 |
| Hub Holding Tool   | 10418 |
| Thin Walled Socket | 10416 |

### Tool Kit Contents

Pulley Extractor Kit  
Pulley Bearing Remover and Installer Kit  
Seal Assembly Remover and Installer  
Hub Drive Plate Remover Kit  
Hub and Drive Plate Assembly Installer  
'O' Ring Remover  
'O' Ring Installer  
Snap Ring Installer  
Ceramic Seal Remover and Installer, and Shaft  
Seal Protector  
Hub Holding Tool  
Thin Walled Socket

When Servicing the compressor, remove only the necessary components that preliminary diagnosis indicates are in need of service.

Seven service operations may be performed on the GM 6 cylinder compressor.

- Replacement of compressor assembly.
- Replacement of clutch drive and pulley assembly.
- Replacement of pulley bearing.
- Replacement of clutch coil and housing assembly.
- Replacement of shaft seal.
- Replacement of superheat switch.
- Replacement of compressor cylinder and shaft assembly (less clutch drive, coil housing and pulley).

### General Instructions During Servicing Operations

- Discharge system prior to removal of compressor unit.

- During removal, maintain the compressor positioned so that the sump is downward. Do not rotate compressor shaft.
- If the compressor is being replaced due to a component failure within the main body of the compressor, the clutch coil housing and clutch plate drive and hub assembly must be removed from the original compressor unit and fitted to the replacement unit. This also applies when fitting a replacement compressor body.
- If the original compressor is being reinstalled following servicing, replace with the right quantity of 525 viscosity oil.
- Discard 'O' rings from suction and discharge ports of compressor and replace with new 'O' rings.
- Install compressor and adjust drive belt tension to service manual specifications.
- Lubricate 'O' rings with refrigerant oil and attach suction and discharge hose connections and retaining plate to compressor torque to 2,764 - 3,455 kgfm (20 - 25 ft lbs).

### Replacement of Clutch Drive Plate and Hub Pulley, Clutch Coil and Housing Assemblies.

Discharge the system.

Remove the compressor from the engine.

Using suitable mounting jig or vice, secure compressor.

Holding the hub of the clutch drive plate with the hub holding tool. Using the thin walled  $\frac{9}{16}$  in socket remove the shaft nut. Refer to Fig. 46.



Fig 46

Screw the threaded hub puller to the hub. Hold the body of the hub puller with a suitable spanner, tighten centre screw of hub pulley (Fig. 47), until drive plate, hub and woodruff key can be removed (Fig. 48).



Fig 47




Fig 48

Using suitable circlip pliers remove the bearing to head retainer ring (Fig. 49).




Fig 49




Fig 50

Remove the absorbent felt sleeve retainer ring to enable the location of the pulley extraction tool.

Using the pulley extraction tool locate the puller pilot on hub of front head and remove the pulley assembly (Fig. 50).

**NOTE:** The next operation details removal of pulley bearing. DO NOT remove the pulley bearing unless it is to be replaced. Removal may cause the bearing to be damaged.




Fig 51



Fig 52

Remove bearing to pulley retaining ring with small screwdriver (Fig. 51). Drive out the bearing using bearing remover and handle (Fig. 52).




Fig 53

Mark position of the coil and housing assembly in relationship to the shell of the compressor. Remove the coil housing retainer ring using suitable circlip pliers (Fig. 53) and lift off the coil and housing assembly (Fig. 54).

Examine coil for loose or distorted terminals and cracked insulation. Check that the current consumption is 3.2 Amps at 12 volts. The resistance should be 3.75 Ohms at room temperature.




Fig 54

Reassemble coil and housing assembly by reversing the dismantling procedure. Be sure coil and housing assembly markings line up.

**NOTE:** If the pulley assembly is going to be reused, clean the friction surface with suitable solvent cleaner.



Fig 55

Drive the new bearing into the pulley assembly with the bearing installer and handle. The bearing installer will ride on the outer race of the bearing (Fig. 55).



Fig 56

Lock the bearing in position with the bearing to pulley retainer ring.

Press or tap the pulley assembly into the hub of front head using installer tool and handle (Fig. 56).

Check the pulley for binding or roughness, and that the pulley rotates freely.

Using suitable circlip pliers lock pulley assembly in position with bearing to head retainer ring (flat side of retainer ring should face towards pulley).

Install square drive woodruff key in the key way of the clutch drive hub.

Wipe frictional surface of clutch plate and pulley clean. Using a suitable solvent.

Place clutch plate and hub assembly on shaft, aligning shaft key way with key in hub (refer to Fig. 48 dismantling procedure).



**NOTE:** The woodruff key is made with a slight curvature to help hold it in the plate hub during assembly.

**IMPORTANT:** To avoid damage to the compressor, undue force should not be applied to the hub or shaft. This could misplace axial plate on shaft, resulting in damage to the compressor.




Fig 57

Place spacer on hub. Thread clutch plate and hub assembly installer tool onto end of the shaft (Fig. 57).

Hold the head of the bolt and turn tool body several revolutions to press hub partially on shaft. Remove clutch plate and hub assembly installer and spacer.

Check alignment of woodruff key with key way in shaft. If alignment is correct, replace installer tool and continue to press hub into shaft until there is approximately 2,38 mm ( $\frac{3}{32}$  in) air gap between the frictional surfaces of pulley and clutch plate. Remove installer tool and spacer.

Install a new shaft lock nut with the small diameter boss of the nut against the hub using a thin wall  $\frac{9}{16}$  in socket. Hold clutch with holding tool and tighten nut to 2,07 kg/fm (15 ft/lbs), using a 3,455 kg/fm (25 ft/lbs) torque wrench. The air gap between the frictional surfaces of pulley and clutch plate should now be approximately 0,56 mm to 1,45 mm (0,022 in to 0,057 in).

### Shaft Seal Leak Detection

A compressor shaft seal should not be changed because of an oil line on the underside of the bonnet. The seal is designed to seep some oil for lubrication purposes. Only change a shaft seal when a leak is detected by the following procedures:

Ensure there is refrigerant in the system.  
Turn off the engine.

Blow off compressor clutch area with compressed air. Blow out clutch vent holes to completely remove any freon and oil deposits.

Allow car to stand for 5 minutes, without operating compressor.

Rotate the compressor clutch drive plate by hand until one of the vent holes is at the lower side of drive plate. Using leak detector, sense through vent hole at lower side of drive plate only.

Some compression shaft seal leaks may be the result of misplacement of the axial plate on the compressor shaft. The mispositioning of the axial plate may be caused by improper procedures used during pulley and driven plate removal, undue force collisions, or dropping the compressor.

### Replacement of Shaft Seal

Remove clutch driven plate and hub assembly as previously described.

Remove compressor absorbent felt retaining ring and felt sleeve.




Fig 58

Thoroughly clean the area inside the compressor neck surrounding the shaft, the exposed portion of the seat and the shaft itself of any dirt or foreign material. This is absolutely necessary to prevent any such material from getting into the compressor.

Remove the seal seat retaining circlip (Fig. 58) using suitable circlip pliers.



Fig 59

Remove the ceramic seal seat using the seal seat remover and installer tool (Fig. 59). Position tool into seal seat recess, grasp flange of shaft seal seat and pull straight out.



Fig 60

Using the seal remover and installer tool grip the seal by inserting the tool into the seal recess. Turning clockwise. Withdraw the tool and seal (Fig. 60).



Fig. 61

Remove the seal seat 'O' ring (Fig. 61) using the 'O' ring remover tool.

Recheck the inside of the compressor neck and the shaft. Be sure these areas are perfectly clean and free of burrs before installing new parts.

Coat shaft and 'O' ring with clean compressor 525 viscosity oil.



Fig 62

Place 'O' ring on 'O' ring installer (Fig. 62) and insert tool and 'O' ring into seal recess. Release 'O' ring by sliding down tool hook, and remove tool.

(Fig. 63) illustrates the tool being removed following 'O' ring installations.



Fig 63

Place the seal protective sleeve over the compressor shaft and fit new shaft seal. Gently twisting the tool clockwise to engage the seal housing flats onto the compressor shaft. Withdraw the tool by pressing downwards and twisting the tool anti-clockwise.

Coat the seal face of the new ceramic seal seat with clean 525 viscosity oil. Mount the seal seat on to the remover and installer tool and carefully guide the seal into the compressor neck gently twisting it into the 'O' ring seal.

Disengage and remove tool, and compressor shaft protective sleeve.

Install new circlip with the flat side against seal seat, and press home.

Install the new absorbent sleeve by rolling the material into the cylinder, overlapping the ends and slipping it into the compressor neck with the overlap at the top of the compressor. Using a small screwdriver or similar tool carefully spread the sleeve so that in its final position, the ends butt together at the top vertical centre line.

Install the new absorbent sleeve retainer so that its flange face will be against the front end of the sleeve, press and tap with a mallet setting the retaining ring and absorbent sleeve until the outer edge of the sleeve retainer is recessed approximately 0.8 mm ( $\frac{1}{32}$  in) from the face of the compressor neck.

Lightly lubricate absorbent felt sleeve with 525 viscosity oil.

Refit clutch drive plate and hub assembly.

Check compressor oil level.

Refit compressor to vehicle, and connect the suction (low pressure) and discharge (high pressure) hoses using new 'O' ring seals. Prior to fitment of compressor drive belt, rotate the compressor drive plate clockwise several revolutions to prime lubrication pump.

Evacuate and recharge system.

**NOTE:** During charge procedure check compressor seals for leaks using suitable leak detection equipment.

## Leak Test

A high proportion of all air conditioning work will consist of locating and repairing leaks. Many leaks will be located at points of connections and are caused by vibration. They may only require the retightening of a connection or clamp. Occasionally a hose will rub on a structural part of the vehicle and create a leak, or a hose will deteriorate and require a replacement. Any time the system requires more than  $\frac{1}{2}$  lb of refrigerant after a period of operation, a leak is indicated which must be located and rectified.

The 'Robinair Robbitek 30001 Leak Detector' is designed for speedy detection of leaks. The leak detector is small and portable, and is battery operated. This instrument will indicate leaks electronically by sounding an alarm signal. Provision is made to plug in an earphone, which is useful in a noisy workshop; and it has the recommended sensitivity of 0.45 kg (1 lb) in 32 years.

## FLAP LINKAGE

### Adjust Air

**Service Tools:** 18G 1363, Setting Jig (Fig. 64)

Remove the console right hand panel and underscuff trim panels to gain access to the air conditioning unit flap linkages. Note: On LH drive cars it is necessary to remove the glovebox compartment.

Remove the footwell outlet vent from the air conditioning unit.

Switch on the ignition, position the right hand control knob to 'DEF'. When the servo has reached its full heat position, switch off the ignition and disconnect the battery.

Disconnect the linkage rods (1, Fig. 66) from the servo lever connections.

Set the link bolt adjuster (2, Fig. 66) in its mid position.

Gently pull the wire link (3, Fig. 66) to detach it from the grommet in link (4, Fig. 66).




Fig 64

Move the thumbwheel (Fig. 65), located in the radio console panel, fully to the right.

Using the jig setting tool 18G 1363, locate peg (1, Fig. 64) into the hole (7, Fig. 66) on the linkage protection bracket, and peg (2, Fig. 64) in the hole in linkage (4, Fig. 66), from which link (3, Fig. 66) was removed. The parallel end guides on the setting jig tool (3, Fig. 64), should locate over the linkage assembly (8, Fig. 66) so that the linkage is in a straight line. If linkage (8, Fig. 66) is not in line adjust the distribution temperature control cable (9, Fig. 66), until the linkage is straight. Tighten the cable clamp (6, Fig. 66).

With the jig setting tool in position adjust the linkage (10, Fig. 66) until post (11, Fig. 66) is at the top of the slot.

Remove the jig setting tool.

Position the setbolt adjuster (12, Fig. 66) at its furthest point away from fulcrum (13, Fig. 66). Refit the link rod (3, Fig. 66) to linkage (4, Fig. 66).

Reconnect the servo linkage rods (1, Fig. 66) to the servo motor levers, ensure that the servo lever cam followers locate against the servo cams.

Reconnect the battery and switch on the ignition. Motor the system to the full cooling position.

Switch off the ignition.

Check that the linkage (14, Fig. 66) abuts against the snail cam (15, Fig. 66).

The lower heat flap should now be fully sealed; check by manually pushing the snail cam, no movement should be evident.




Fig 65




Fig 66

J82 070

If there is movement, switch on the ignition and motor the system to its full heat position, switch off the ignition. Slacken the set bolt adjuster (12, Fig. 66) and move it slightly towards the fulcrum point (13, Fig. 66). Reset the servo lever linkage rods (1, Fig. 66) so that the servo lever cam followers locate against the servo cam.

Switch on the ignition and motor the system to its full cooling position (AUTO 65). Check that linkage (14, Fig. 66) abuts against the snail cam (15, Fig. 66). Check manually by pressing the snail cam, if movement is evident, repeat the procedure in the previous paragraph.

If no movement is evident, then the lower heat flap is sealing correctly and the flap linkages and distribution temperature control are correctly set.

Ensure that all linkages and adjustments are secure.

Refit the footwell outlet vent, the underscuttle trim panels and console right hand side panel.

## CONDENSER UNIT AND RECEIVER-DRIER

### Renew

Before commencing this operation, ensure that suitable clean, dry sealing plugs and caps are to hand.

Disconnect the battery earth lead.

Depressurise the air conditioning system.

Remove the nuts and washers securing the fan cowl to the radiator (1, Fig. 67) top rail and pull the fan cowl clear of the mounting studs.

Disconnect the pipes from the receiver-drier (2, Fig. 67) and the pipe from the compressor to the condenser (3, Fig. 67). Fit blanking plugs to all the disconnected pipes to avoid contamination.

Remove the nuts and washers securing receiver-drier (4, Fig. 67).

Remove the receiver-drier (5, Fig. 67).

Note the connections and disconnect the cable harness to the ignition amplifier.

Remove the nuts and washers securing the condenser mounting bracket to the radiator top rail (6, Fig. 67).

Remove the four bolts and washers securing the radiator top rail to the wing valances (7, Fig. 67).

Ease the top rail clear of the condenser and lift the condenser clear of the car.

On refitting, reverse the above operations and fit a new receiver-drier.

**NOTE:** If the system is opened, even for a short time, the receiver-drier must be renewed. Do not remove the protective sealing caps from the new unit until it has been fitted and is ready for the pipes to be connected.

## AMBIENT TEMPERATURE SENSOR

### Renew

Disconnect the battery earth lead.

Remove the right hand underscuttle casing.

Remove the component panel securing screws and displace the component panel.

Note the position of the electrical connections and disconnect the cables from the sensor.

Remove the two screws securing the sensor and remove the sensor.

## IN CAR TEMPERATURE SENSOR

### Renew

Disconnect the battery earth lead.

Remove the screws securing the passengers underscuttle casing and remove the casing.

Remove the screws securing the glove box liner and the glove box latch. Remove the latch and carefully withdraw the liner.

Carefully manoeuvre the elbow hose from the sensor outlet.

Disconnect and remove the sensor assembly (1, Fig. 68) from the air pick-up tube (2, Fig. 68).

Remove the sensor assembly from the elbow hose (3, Fig. 68).




Fig 67

J82 111




Fig 68

J82 092



## TEMPERATURE SELECTOR

### Renew

## MODE SELECTOR

### Renew

Disconnect the battery lead.

Carefully prise off the switch knobs from the temperature and fan controls.

Unscrew the fasteners from behind the control knobs and detach the control panel.

Disconnect the optical fibre elements, remove the control panel and the radio escutcheon assemblies.

Remove the right and left hand side pads.

Unscrew the gear selector control knob.

Remove the screws securing the switch panel to the centre console, ease the switch panel from the centre console, note the position of the wiring connectors, disconnect the connectors and remove the switch panel.

Remove the screws securing the front and rear ends of the console.

Displace the stop lamp bulb failure sensor and remove the console assembly.

Remove the bolts and washers securing the stays to the transmission tunnel (1, Fig. 69).

Ease the stays aside to give access to the switch panel.

Remove the nuts and washers securing the switch panel to the left hand of the unit (2, Fig. 69).

Remove the screws securing the switch cover to the switch panel (3, Fig. 69). Note the position and disconnect the vacuum pipes.

Remove the nut and washer securing the switch cover to unit at lower right hand side.

Release the harness and remove the switch cover.

Remove the nut and washer securing the switch panel at the upper right hand side of the panel (5, Fig. 69).

Ease the panel clear of the mounting studs, remove the two screws securing the temperature selector (4, Fig. 69), note the

position of the cable connections, disconnect the cables at the connections (6, Fig. 69) and remove the selector.

Note the position of and disconnect the cables from the mode selector micro-switches (1, Fig. 70).

Note the position of the micro-switches, remove the two screws and nuts securing the switches (2, Fig. 70).

Remove the switches and retain the distance pieces.

Remove the screws securing the vacuum switch mounting bracket (3, Fig. 70) and remove the vacuum switch assembly.

Remove the circlip securing the cam assembly and remove the cam assembly.

**NOTE:** Care must be taken to ensure that correct replacement parts are used, and that the items are replaced in the correct position.

When refitting the cams, ensure that the vacuum switch operating rod is pressed back to allow the camshaft into position.

## THERMOSTAT

### Renew

Disconnect the battery earth lead.

Remove the right hand underscuttle casing and the right hand side casing.

On left hand drive cars remove the glove box liner.

Remove the nut securing the thermostat to the bracket (1, Fig. 71).

Note the position of and disconnect the cables from the lucar connectors (2, Fig. 71).

Carefully remove the thermostat by withdrawing the capillary tube from the air conditioning unit (3, Fig. 71).

**NOTE:** Ensure the replacement thermostat capillary tube is formed to the exact dimensions of the unserviceable unit, ensuring that the capillary tube makes contact with the evaporator matrix.

## BLOWER MOTOR RESISTANCE UNIT

### Renew

Disconnect the battery earth lead.

On right hand drive cars, remove the left hand underscuttle casing and the glove box liner.

On left hand drive cars, remove the left hand underscuttle casing and the left hand side casing.

Note the position of and disconnect the cables from the resistance unit lucar connectors (1, Fig. 72).

Remove the screw securing the vacuum hose clip, move the hose to one side (2, Fig. 72).

Remove the screws securing the resistance unit and withdraw the unit from the air conditioning unit case (3, Fig. 72).

On refitting, ensure the cable connectors are secure and connected correctly.

## WATER VALVE TEMPERATURE SWITCH

### Renew

Disconnect the battery earth lead.

Remove the left hand underscuttle casing and the console side casing.


On right hand drive cars remove the glove box liner.

Disconnect the cables at the lucar connectors on the switch (1, Fig. 73).

Withdraw the securing screws and remove the switch (2, Fig. 73).

On refitting, ensure the connectors are clean and tight.

Figs 69 — 73



## BLOWER MOTOR RELAY

### Renew

Disconnect the battery earth lead.  
Remove the left hand console side casing.  
Remove the screws securing the footwell air outlet duct and remove the duct.  
Note the position of the cable connectors.  
Disconnect the block connector, the lucars and the main feed cable from the relay (1, Fig. 74).  
Remove the nuts securing the relay and remove the relay (2, Fig. 74).  
On fitting replacement relay, ensure the cables are secure and connected correctly.




Fig 74

## WATER VALVE

### Renew

Remove the engine coolant filter and header tank caps, then open the radiator drain tap.  
Allow the coolant to drain from the system.  
Slacken the securing clip on the water valve to cylinder head hose and disconnect the water valve from the hose (1, Fig. 75).  
Disconnect the vacuum hose from the water valve (2, Fig. 75).  
Reposition the valve for access to the water valve to heater hose clip (3, Fig. 75).  
Slacken the clip and remove the water valve.




Fig 75

On refitting, ensure the cooling system is refilled with coolant to the correct specification.

## THERMAL FUSE

### Renew

Disconnect the cable block connector from the thermal fuse (1, Fig. 76) assembly located to the front of the right hand wing valance.  
Remove the nut and screw securing the thermal fuse (2, Fig. 76).  
Remove the thermal fuse.




Fig 76

## EXPANSION VALVE

### Renew

Depressurize the air conditioning system.  
Partially drain the engine coolant.  
Disconnect the hose unions (1, Fig. 77) and seal with clean blanking caps.  
Release the clip securing the water valve to the cylinder head hose, disconnect the water valve from the hose, and move the water valve clear of the expansion valve.  
Remove the padding from the capillary tube (2, Fig. 77).  
Disconnect the capillary tube at the union (3, Fig. 77).  
Release the valve by unscrewing the union nut (4, Fig. 77).

**NOTE:** To avoid straining the joint or the pipe, ensure the valve is held firmly as the union is unscrewed.

Slacken the two screws securing the capillary tube clear of the clamp.  
Remove the valve assembly carefully, manoeuvring the capillary tube clear of the clamp.  
On fitting replacement unit, ensure new 'O' rings are fitted, the cooling system is refilled, and the air conditioning system is recharged.




Fig 77

## BLOWER ASSEMBLY

### Remove and refit RH Unit

The blower fans are heavy duty motors with impellers attached. Speed is varied by controlled switching of resistances in series with the motors. The right hand unit has the ambient temperature sensor mounted in the inlet duct. Air flow control flaps are operated by a vacuum actuator situated in the side of the inlet duct.




Fig 78

Disconnect the battery earth lead.  
Remove the right hand underscuffle casing and right hand console casing.  
On left hand drive cars, remove the glove box liner.  
Remove the nuts securing the component panel to the blower (1, Fig. 78) assembly, secure the component panel clear for access to the blower assembly mounting bolts.  
Disconnect the ambient temperature sensor leads at the lucar connectors (2, Fig. 78).  
Disconnect the pliable trunking from the stub pipes on the side of the air conditioning unit (3, Fig. 78).  
Disconnect the blower motor harness block connector.  
Disconnect the vacuum pipe from the flap operating servo on blower assembly (4, Fig. 78).  
Open the recirculation flap and fit a wedge to retain it in the open position (5, Fig. 78).  
Remove the bolts securing blower assembly to mounting brackets (6, Fig. 78).  
Ease the blower assembly from its location.  
Remove the tape securing the ducting to the assembly (7, Fig. 78).

## AIR CONDITIONING UNIT

### Remove and refit

#### Removing

Disconnect the battery earth lead.  
Withdraw the steering wheel and the adjuster assembly from the upper steering column.  
Remove the left and right hand underscuttle casing.  
Remove the instrument panel module and carefully remove switch panel.  
Withdraw the air conditioning knobs from the air conditioning selector switches, remove the radio, remove the screws securing the fascia and the console to the air conditioning unit.  
Remove the glove box liner.  
Slacken the nuts securing the top rear portion of the fascia to the bulkhead, remove the bolts securing the sides of the fascia to the bulkhead, remove the nut securing the main light switch, displace the switch and carefully remove the fascia from the car.  
Disconnect the air conditioning hoses at the bulkhead connectors to the expansion valve on the engine compartment (1, Fig. 79).  
Disconnect the coolant hoses at the heater bulkhead connectors in the engine compartment.  
Remove the nuts securing the air conditioning unit to the bulkhead (2, Fig. 79).

Unclip the main harness from the securing clips on the screen rail (3, Fig. 79).  
Remove the bolts securing the demist duct support rail to the body mounting points and remove the support rail (4, Fig. 79).  
Disconnect the pliable ducting between the air conditioning unit and the blower motors from the stub pipes (5, Fig. 79).  
Remove the rear compartment ducts (6, Fig. 79).  
Remove the nuts and bolts securing the unit support stays (7, Fig. 79); recover the stays.  
Remove the automatic gearbox selector quadrant cover.  
Remove the bolts securing the upper steering column to the mounting bracket; remove the spacers and the packing washers (8, Fig. 79).  
Remove the bolts securing the earth leads and the support stays to the steering column mounting bracket. Retain the washers (9, Fig. 79).  
Remove the bolt securing the mounting bracket to the screen rail (10, Fig. 79) and retain the bracket.

**NOTE:** To facilitate refitting, it is advised that the position of all the electrical multi-pin connectors are noted and marked. The position and the routes of all the vacuum pipes noted and marked.

Disconnect the blower motor flap vacuum pipes at the 'T' piece (11, Fig. 79), and the demister duct vacuum pipe at the servo (12, Fig. 79).

Disconnect the main panel harness electrical connectors and remove the harness from the securing clips.  
Remove the nuts securing the air conditioning switch panel to the air conditioning unit (13, Fig. 79) and remove the screws securing the mode switch cover, retain the switch cover (14, Fig. 79).  
Disconnect the mode switch vacuum pipes and the mode switch electrical connectors.  
Disconnect the earth cable and the motor harness multi-pin at the air conditioning main harness.  
Disconnect the remaining block connectors including the multi-pin connector of the windscreen wiper motor harness at the bulkhead.  
Disconnect the ambient and in car sensors.  
Ease the drain tubes clear of the grommets in the transmission tunnel, ease the main panel harness clear of the unit and ease the demist duct vane securing studs from the screen rail.  
Retain the demist duct assembly.  
Remove the screw securing the air conditioning unit to the top rail (15, Fig. 79).  
Manoeuvre the unit from its location taking great care to prevent damage to the unit or to the surrounding components.  
With the unit on a workbench, remove the face level vent, the brackets and the demist duct assembly from the unit.  
Refit by reversing the above procedure noting that the receiver-drier must be replaced.







Fig 79

## BLOWER ASSEMBLY

### Remove and refit LH Unit

#### Removing

Disconnect the battery earth lead.  
Remove the left hand underscuttle casing and the left hand console casing.  
On right hand drive cars, remove the glove box liner.  
Remove the nuts securing the compartment panel (1, Fig. 80) to the blower motor assembly, ease the panel clear and secure for access to blower assembly (2, Fig. 80).  
Disconnect the pliable ducting from the stub pipes at the side of the air conditioning unit (3, Fig. 80).  
Disconnect the blower motor harness at the block connector.  
Disconnect the vacuum pipe from the flap operating servo on the blower assembly (4, Fig. 80).  
Open the recirculation flap in the base of the blower assembly and hold open with a suitable wedge (5, Fig. 80).  
Remove the bolts securing the blower assembly to the mounting brackets, and ease the blower assembly from its location (6, Fig. 80).  
Remove the tape securing the ducting to the assembly and remove the ducting (7, Fig. 80).




Fig 80

## VENTILATORS

### Remove and refit — Centre Right hand Left hand

#### Removing

For the centre and passengers side veneer panels, open the glove box for access. By using a suitable long thin-bladed instrument, carefully release the veneer panel, retaining clips, and remove the appropriate panel.  
Withdraw the appropriate ventilator.

## HEATER MATRIX

#### Renew

With the air conditioning unit removed and located on a workbench, the heater matrix can be removed.




Fig 81

**IMPORTANT:** It is recommended that the positions of all the operating rods are marked with a scribe, or a similar methods.

Note and disconnect all the cables from the blower motor resistance unit (1, Fig. 81) and the water valve temperature switch (2, Fig. 81).  
Remove the screws securing the cable harness clip and the bracket (3, Fig. 81).  
Remove the screws securing the vacuum pipe clips (4, Fig. 81).  
Disengage the return springs from the operating levers (5, Fig. 81), remove the screw securing the lower flap operating lever to flap hinge (6, Fig. 81) and remove the lever.  
Slacken the screw securing the operating rod from the vacuum servo to the flap operating lever on the matrix cover (7, Fig. 81) and release the lever from the rod.  
Remove the screws securing the matrix cover plate to the unit (8, Fig. 81).  
Remove the screws securing the heater matrix pipes retaining bracket to unit and remove the bracket (9, Fig. 81).  
Remove the pipe clips (10, Fig. 81).  
With a straight pull, ease the matrix clear of the unit (11, Fig. 81).  
Remove the sleeve from the top pipe, the cover plate and the water valve temperature switch from the lower pipe.

## EVAPORATOR

#### Renew

With the air conditioning unit removed from the car and placed on a workbench.  
Remove the screws securing the heater matrix pipe retaining bracket to the unit and remove the bracket.  
Remove the screws securing the back plate to the unit, ease the rubber pad from the back plate (1, Fig. 82), remove the screws securing the expansion valve mounting plate to the back plate (2, Fig. 82), and ease the back plate (3, Fig. 82) over the expansion valve.

**NOTE:** Take care to prevent damage to the capillary tube.

Remove the thermostat (4, Fig. 82) by disconnecting the cables and removing the fixing nut. Carefully ease the thermostat capillary tube from the air conditioning unit. Ease the evaporator clear of the air conditioning unit (5, Fig. 82).




Fig 82

## SERVO AND CONTROL UNIT

### Remove and refit

Disconnect the battery.  
Remove the RH console side casing.  
Remove the RH footwell vent by withdrawing the four securing screws (1, Fig. 83).




Fig 83

Disconnect the two flap operating rods from the cam followers, marking the rods to facilitate correct refitting (2, Fig. 83).  
Mark the vacuum tubes for identification before disconnecting them from the vacuum switches (3, Fig. 83).  
Disconnect the cable harness at the multi-pin plug and socket.  
Remove the servo unit chrome dome nut and ease the servo clear of the unit.  
Refit by reversing the above procedure.

## SERVO AND CONTROL UNIT ASSEMBLY

### Overhaul

**CAUTION:** No attempt must be made to dismantle the servo motor from the gearbox. 12 volts must never be applied direct to the motor connections. The motor will over-run the limit switches and could strip the gear assembly. Do not attempt to dismantle the camshaft assembly.

The servo and control unit must not be serviced under warranty.

### Dismantling

To remove the Ranco thermostat and recirculation over-ride micro-switches, withdraw the two securing screws and take the switch from the end plate (1, Fig. 84). The other micro-switches can now be removed by easing the friction washers from the ends of the micro-switch locating rods (2, Fig. 84). Push the rods through the micro-switch pack (3, Fig. 84) and ease the micro-switches from the assembly (4, Fig. 84).




Fig 84

The vacuum switches can be removed by removing the two nuts and screws retaining the vacuum switch mounting bracket (5, Fig. 84). Pull the bracket from the assembly (6, Fig. 84). Remove the nut and screw clamping mounting plates together. Remove the plates to free the switches (7, Fig. 84).

The feedback potentiometer is removed by withdrawing the two securing screws (8, Fig. 84). Note the position of cables and unsolder.

### Reassembling

Re-solder the cables to the potentiometer and secure with the two fixing screws. Reposition the vacuum switches to the clamping plates. Fit the bracket to the assembly. Secure with the nuts and screws. Ease the micro-switch pack into the assembly. Push the locating rods through the micro-switch pack and ease the friction washers onto the end of the rods.

Refit the Ranco thermostat and recirculation over-ride micro-switch with the two securing screws.

## VACUUM SOLENOID

### Renew

Remove the left hand console side pad (1, Fig. 85).

Remove the screws securing the footwell outlet vent to air conditioning unit and remove the vent.

Remove the nut securing the earth leads to the mounting bolt (2, Fig. 85).

Remove the nut and bolt securing the vacuum solenoid (3, Fig. 85).

Disconnect the vacuum pipes and electrical cables from the solenoid (4, Fig. 85).

Remove the vacuum solenoid.




Fig 85

## AMPLIFIER UNIT

### Renew

Disconnect the battery.

Remove the left-hand console side panel.

Remove the screws securing the footwell vent to the air-conditioning unit and remove the duct (1, Fig. 86).

Remove the nut securing the blower motor relay to the mounting bracket on the air conditioning unit (2, Fig. 86).

Displace the vacuum solenoid from its location and swing aside (3, Fig. 86).

Disconnect the amplifier cable harness multi-pin plug and socket (4, Fig. 86).

Displace the amplifier from the spring clip under the unit and move the harness aside.

Remove the nylon strap securing the harnesses and remove the amplifier (5, Fig. 86).




Fig 86

## BLOWER ASSEMBLY

### LH

### Overhaul RH

**NOTE:** The blower assembly must not be dismantled under warranty.

### Dismantling

Remove the three self tapping screws from the air intake casing (1, Fig. 87).

Part the air inlet casing (2, Fig. 87) from the motor assembly (3, Fig. 87) and disconnect electrical connections at the lucar connectors (4, Fig. 87).

**NOTE:** It is recommended at this stage that the positions of the various components are marked either with paint or a scribe. This will facilitate reassembly.

One cable Lucar has a raised projection which matches the aperture in the motor casing. This ensures that the connections are replaced correctly and that the rotation of the motor is not altered.

Remove the bolts securing the motor mounting bracket to the fan housing (5, Fig. 87).

Remove the motor and fan assembly from the fan housing.

Remove the mounting bracket from the motor.

Using the appropriate Allen key, remove the impeller fan from the spindle.




Fig 87

### Reassembling

Refit the fan to the motor and secure it to the spindle.

Refit the mounting bracket to the motor.

Locate the fan and mounting assembly into the fan-housing.

Fit and tighten the bolts securing the assembly to the fan housing.

Place the flap box assembly to the fan housing and reconnect the electrical connections.

Fit and tighten the screws securing the flap box to the housing.

Raise the recirculation flap, fit and tighten the remaining screw.

Refit the blower motor assembly.

Reconnect the battery.

## CHARGING VALVE CORE

### Renew

A possible reason for very slow charging is a bent or damage schrader valve depressor. Do not attempt to straighten. The valve core must be replaced.

If excessive leakage is detected from the schrader valve cores at the rear of the compressor, use a soap solution to ensure that the valve core itself is at fault. If the valve core is leaking replace it by following this procedure.

Ensure replacement clean dry valve core is to hand before commencing operation.

Depressurize the system.

Remove the valve core using a schrader removing tool.

**NOTE:** Do not overtighten when refitting, then charge the system.

## AIR CONDITIONING

### Test operation

**NOTE:** During the following tests windows should be closed and footwell fresh air vents shut 'off'.

Warm the engine up and check operation of thermostatic cut-out and low speed over-ride. RH control to 'auto'.

With the engine cold, turn the LH knob to 'full heat'. Start the engine and run at 1000 rpm. If, after any previous running the camshaft has turned to the cold position, the servo will operate for a few seconds and then shut down. As the water temperature reaches 40°C the system will start up, the centre outlet will close if not already closed, and the fans will slip up to speed 2. This can be checked by turning the RH knob to low, when a drop in speed should be noticed.

### Sequence of operation check. RH control to 'auto'

With the engine warm, turn the LH knob to 65°. Operate the cigar lighter or other heat source and hold the heated unit about 1 in below the sensor inlet hole, which is situated below the centre parcel shelf. The unit should then go through the following sequence in approximately 20 seconds.

Blower speeds will drop to low.

Temperatures will decrease, the upper temperature dropping more quickly than the footwell temperature.

After approximately ten seconds the centre outlet flap will open.

Approximately one second after this the fan speeds will shift up to a medium 1.

A further one second later the fan speed will shift up to medium 2.

Another one second later the fan speeds will shift to maximum, at the same time the fresh air vents will close and the recirculating flaps will open. The rush of air into the air boxes will be felt along the bottom edge of the lower trim panels. Turn the RH knob to 'LOW' which should cause the fan speeds to drop. Return RH knob to auto setting.

On some cars in which the servo action is

fairly fast the separation of the fan speeds may not be discernible.

### Aspiration and intermediate position check

Remove the heat source from the sensor. Within ten seconds, depending upon ambient conditions, the unit should shift off recirculation and the blowers will drop to one of the intermediate speeds. This test can be carried out on the road since thermistor aspiration will be better and hence the test will be performed more quickly. In certain high ambient conditions the system will be reluctant to come off recirculation, in which case the intermediate modes can be checked by inching the servo through these positions. This is done by turning the LH knob slightly clockwise until the servo motor is heard to operate, and then returning it to a lower position to stop the servo motor at the desired position.

### Defrost and fan vibration check

Turn the RH knob to defrost. The centre outlet flap should close and the screen outlets open. Air to the footwells should be cut off leaving air to the upper ducts only. The fans should shift to maximum speed and hot air should issue from the upper ducts. Fan vibration is best assessed under these conditions. Tests in accordance with the defrost schedule can be carried out at this point if desired.

### Outlet vent valve check

Check that air can be cut off from the outer face-level vents by rotating the wheels beneath the outlets.

### Settled mid-range and High speed over-ride check

Set the RH knob to 'Auto'. Set the LH knob to 75° and wait for the unit to settle. The fans should now be on low speed. Turn the RH knob to 'HIGH'. Maximum fan speeds should now be engaged.

## DEFROST AND DEMIST TESTS

### Purpose

To ascertain that the heating/air conditioning system is functioning correctly in the 'Defrost' mode, and that adequate airflow is maintained in the heat mode to ensure that the windscreen remains mist-free.

### Method

Set the LH control to '85°C'.

Set the RH control to 'Defrost'.

Close the end of dash outlets.

Start the engine and run it for seven minutes at 1500 rpm.

During the running period measure the airflow from each screen outlet using checking ducts and velometer. Ensure that the centre dash outlet is closed and that it seals satisfactorily. The velocity from the screen outlets should be 1550 ft/min.

Also during the running period turn the RH

control to 'HIGH' and open the end of the dash outlets. Using the screen outlet and end of dash checking ducts measure the resulting air velocity. This should be:

| Minimum velocity (ft/min) |             |
|---------------------------|-------------|
| Screen                    | End of dash |
| 500                       | 850         |

At the end of seven minutes running at 1500 rpm check that the water temperature gauge indicates 'Normal'. Using mercury in glass thermometers check that the following minimum screen outlet temperatures are achieved.

| Plenum inlet |      | Screen outlet (minimum) |       |
|--------------|------|-------------------------|-------|
| °C           | °F   | °C                      | °F    |
| 10           | 50   | 54                      | 129.2 |
| 12           | 53.6 | 55                      | 131   |
| 14           | 57.2 | 55.5                    | 131.9 |
| 16           | 60.8 | 56.5                    | 133.7 |
| 18           | 64.4 | 57                      | 134.6 |
| 20           | 68   | 58                      | 136.4 |
| 22           | 71.6 | 58.5                    | 137.3 |
| 24           | 75.2 | 59.5                    | 139.1 |

### Conclusions

If the above minimum requirements are met, then it can be assumed that:

- (a) The thermostats are opening correctly.
- (b) The water valve is opening fully.
- (c) The flaps and linkages are correctly adjusted for the heating mode.
- (d) The fans give adequate airflow at maximum speed.

If the above criteria are not met, the causes may be related to:

### Thermostats

The water temperature gauge will not achieve 'Normal' position within seven minutes and the air outlet temperature remains low. The thermostat(s) must be removed and checked for sticking open.

### Water valve

The temperature gauge reads 'Normal' but the air outlet temperature remains low. Check that the vacuum-operated water valve is subjected to at least 21.6 cmHg (8.5 inHg) of vacuum. If the valve is under adequate vacuum, change the valve. However, if the vacuum is low, check that the vacuum is being supplied to the whole system, that the water valve vacuum actuator is operational and that the water valve vacuum switch is operational. (See that the supply from the switch to valve is not pinched or trapped).

## Flaps and linkages

Inadequate flap sealing will result in low air velocity at the screen outlets. Check that the centre fascia flap closes fully on 'Defrost' and that only a small air bleed to the footwells occurs. These leaks can be detected by hand and may be rectified by adjusting the linkage. Excessive air-flow from the screen outlets in heat mode may be caused by the demist control flap sticking open.

## Blowers

If following flap inspection the air flow is still low, investigations should be carried out into the blower assemblies. Check that full voltage is being received on maximum speed and that the units are correctly wired for rotation. If all is correct the only remaining procedure is to change the fan assembly.

**NOTE: The engine must be running for this check.**

Check that the compressor drive belt is correctly adjusted and is not slipping at higher engine speeds, at idle speed, or on sudden acceleration of the engine, with the compressor clutch speed.

Observe the sight glass on the receiver-drier and check for frothing or bubbles with engine running at 1000 rpm.

Slowly increase engine speed and repeat check at 1800 rpm.

**NOTE: It is normal for there to be slight foaming if ambient air temperature is below 21°C (70°F).**

Check for frosting on the connector union housing; the region around the suction part is normally cold, and slight frosting is permissible.

Check by feel along pipe lines for sudden temperature changes that would indicate blockage at that point.

Place a thermometer in the air outlet louvres.

Run the vehicle on the road and note the drop in temperature with air conditioning system switch on or off.

Ensure that the condenser matrix is free of mud, road dirt, leaves or insects that would prevent free air-flow. If necessary, clear the matrix.

If the foregoing checks are not met satisfactorily, refer to rectification and fault-finding procedures.

## System check

The following check must be carried out to ensure that the system is basically functional. These checks may also be used to ensure satisfactory operation after any rectification has been done. If the system proves unsatisfactory in any way, refer to fault finding.

Check that blower fans are giving an air flow expected in relation to control switch position.

Check that air delivered is equal at both outlets.

Check that compressor clutch is operating correctly, engaging and releasing immediately control switch is set to an 'on' position.


**NOTE: the engine must be running and the thermostat control set fully cool.**

Check that the radiator cooling fan starts operating when the compressor clutch engages.




**JAGUAR**

**XJ-S 3.6  
XJ-SC 3.6  
SERVICE  
MANUAL**







## **BOOK 9**

**Containing  
Sections**

**84 WINDSCEEN WIPERS &  
WASHERS  
86 ELECTRICAL  
88 INSTRUMENTS**

**XJ-S 3·6  
XJ-SC 3·6**

**SERVICE MANUAL**

## INTRODUCTION

This Service Manual covers the Jaguar XJ-S 3.6 and XJ-SC 3.6. It is primarily designed to assist skilled technicians in the efficient repair and maintenance of this range of Jaguar cars.

Using the appropriate service tools and carrying out the procedures as detailed will enable the operations to be completed within the time stated in the 'Repair Operation Times'.

The Service Manual has been produced in 9 separate books; this allows the information to be distributed throughout the specialist areas of the modern service facility.

A table of contents in Book 1 lists the major components and systems together with the section and book numbers. The cover of each book depicts graphically and numerically the sections contained within that book.

The title page of each book carries the part numbers required to order replacement books, binders or complete Service Manuals. This can be done through the normal channels.

The contents section of each book lists the repair operations in the section or sections contained within that book. Each operation is given an operation number that corresponds with those listed in the Repair Operation Times.

The method described on the page number listed against the operation will be the one we consider will meet the requirements of safety and enable the operation to be carried out in the time specified in the Repair Operation Times.

Where no page number is given against an operation, we feel that the method is so obvious as to warrant no explanation. It is, however, included so that a warranty time can be given in the Repair Operation Times.

Extensive research has gone into the diagnosis of faults and where appropriate this is covered in the various areas of the manual. By following the sequence of the diagnosis charts, speedy isolation of faults may be expected, and consequent correction will reduce the vehicle off-the-road time to the minimum.

### Service Tools

Where performance of an operation requires the use of a service tool the tool number is quoted under the operation heading and is repeated in, or following, the instruction involving its use. A list of all necessary tools is included in Book 1, Section 99.

### References

References to the LH or RH side in the manual are made when viewing from the rear. With the engine and gearbox assembly removed the timing cover end of the engine is referred to as the front. A key to abbreviations and symbols is given in Book 1, Section 01.

## REPAIRS AND REPLACEMENTS

When service parts are required it is essential that only genuine Jaguar or Unipart replacements are used.

Attention is particularly drawn to the following points concerning repairs and the fitting of replacement parts and accessories

1. Safety features embodied in the vehicle may be impaired if other than genuine parts are fitted. In certain territories, legislation prohibits the fitting of parts not to the vehicle manufacturer's specification.
2. Torque wrench setting figures given in this Service Manual must be strictly adhered to.
3. Locking devices, where specified, must be fitted. If the efficiency of a locking device is impaired during removal it must be replaced.
4. Owners purchasing accessories while travelling abroad should ensure that the accessory and its fitted location on the vehicle conform to mandatory requirements existing in their country of origin.
5. The vehicle warranty may be invalidated by the fitting of other than genuine Jaguar or Unipart parts. All Jaguar and Unipart replacements have the full backing of the factory warranty.
6. Jaguar Distributors and Dealers are obliged to supply only genuine service parts.

## SPECIFICATION

Purchasers are advised that the specification details set out in this Manual apply to a range of vehicles and not to any one. For the specification of a particular vehicle, purchasers should consult their Distributor or Dealer.

The Manufacturers reserve the right to vary their specifications with or without notice, and at such times and in such manner as they think fit. Major as well as minor changes may be involved in accordance with the Manufacturer's policy of constant product improvement.

Whilst every effort is made to ensure the accuracy of the particulars contained in this Manual, neither the Manufacturer nor the Distributor or Dealer, by whom this Manual is supplied, shall in any circumstances be held liable for any inaccuracy or the consequences thereof.

## COPYRIGHT

© Jaguar Cars Ltd. 1983

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form, electronic, mechanical, photocopying, recording or other means without prior written permission of Jaguar Cars Ltd., Service Department, Radford, Coventry CV6 3GB.

## CONTENTS

| Operation                                    | Operation No. | Page No. |
|--|---------------|----------|
| Headlamp wash/wipe — Description .....       | 84.00.00      | 84—5     |
| Headlamp wash/wipe diode pack — Renew .....  | 84.25.36      | 84—6     |
| Headlamp wash/wipe — Fault finding .....     | 84.00.00      | 84—5     |
| Headlamp wash/wipe relay — Renew .....       | 84.25.35      | 84—6     |
| Headlamp washer pump — Renew .....           | 84.25.21      | 84—6     |
| Headlamp water pump — Renew .....            | 84.25.21      | 84—6     |
| Headlamp washer reservoir — Renew .....      | 84.25.01      | 84—6     |
| Headlamp wiper arm — Renew .....             | 84.25.03      | 84—6     |
| Headlamp wiper blade — Renew .....           | 84.25.07      | 84—6     |
| Headlamp wiper motor — Renew .....           | 84.25.15      | 84—5     |
| Washer jets — Renew .....                    | 84.10.09      | 84—4     |
| Washer pump — Renew .....                    | 84.10.21      | 84—4     |
| Windscreen washer/wiper switch — Renew ..... | 84.15.34      | 84—4     |
| Windscreen wiper arms — Renew .....          | 84.15.03      | 84—3     |
| Windscreen wiper blades — Renew .....        | 84.15.05      | 84—3     |
| Windscreen wiper delay unit — Renew .....    | 84.15.36      | 84—4     |
| Windscreen wiper description .....           | —             | 84—2     |
| Windscreen wiper gear assembly — Renew ..... | 84.15.14      | 84—3     |
| Windscreen wiper motor — Renew .....         | 84.15.12      | 84—3     |
| Windscreen wiper rack drive — Renew .....    | 84.15.24      | 84—3     |
| Windscreen wiper wheel boxes — Renew .....   | 84.15.28      | 84—3     |

## WINDSCREEN WIPERS

### Description

The windscreen wiper motor and gearbox assembly is a two speed self parking unit driving two wiper arm wheel boxes via a flexible drive. The motor is a two pole permanent magnet type, the field assembly comprising two ceramic magnets housed in a cylindrical yoke. A worm gear formed on the extended armature shaft drives a moulded gear within the gearbox. The rotary motion of the motor being converted to a linear movement by a connecting rod actuated by a crankpin carried on the gear. The gearbox incorporates the self park mechanism which automatically parks the wiper blades at the end of the wiping cycle. Two speed operation is obtained by switching the positive feed to the third brush when the higher speed is selected.

The following description of the Windscreen Wiper Operation should be studied with the accompanying circuit diagram.

**OFF** The Load Relay is energised by selection of 'IGN ON' and applies 12 volts through fuse 9 to terminal 1 on the wiper switch 12 volts is internally fed via the wiper switch contacts to terminal 7 and from there passes to terminal 1 on the Wiper Motor. This applies 12 volts to one side of the motor winding and, via the closed 'PARK' switch to the closed contacts of the Wiper Timer at terminal 31 b1. Terminal 31 b2 of the timer passes the 12 volts via terminal 6 of the switch and internal connection to terminal 5. From terminal 5 the 12 volt supply is applied to terminal 5 on the motor and thereby the opposite brush to terminal 1, completely stalling the motor.

**SLOW** The 12 volts on terminal 1 of the switch is applied to terminal 5 and to terminal 5 on the wiper motor. An earth connection to terminal 2 on the switch is

internally applied to terminal 7 and thereby to terminal 1 on the motor. The motor then runs in a forward direction at a slow speed.

**FAST** The earth connection detailed in 'SLOW' is maintained but the 12 volt supply is moved via terminal 4 on the switch and terminal 3 on the motor to the high speed brush. The motor then runs in a forward direction at a high speed.

**OFF** When 'OFF' is selected the 'RUN' position of the Park/Run contact in the motor applies an earth at connection 4 of the motor via connection 2 and the timer contacts to position 6 on the switch. Then via the internal connection to 5 on the switch applying the earth to terminal 5 on the motor and the brush previously supplied with 12 volts. The motor therefore stops. Meanwhile 12 volts is applied to the previously earthed motor contact 1 via switch contacts 1 and 7, the motor therefore immediately stops the sweep and runs in a reverse direction to the limit of its travel. At that point the internal Park/Run switch moves to the 'PARK' position, removes the earth at 4 and applies 12 volts via the timer contact to the opposite brush. The motor instantly stalls.

### Single Sweep Operation

A single sweep of the wiper is obtained by pulling the lever towards the steering wheel and releasing.

When this position is selected and released, 12 volts are applied both to the coil of the timer unit, operating its contact, and to the terminal 1 on the motor. An earth is applied to the opposite brush of the motor, terminal 5 via the timer contact 31 b2 and an internal connection to terminal 31. The motor therefore starts and runs in a reverse direction. As the supply to the timer is

applied then instantly removed the contacts operate then relax to the 'AT REST' position. The motor earth on the brush of terminal 5 is then achieved through the Park/Run contacts at the 'RUN' position until the motor reaches the end of the sweep. The Park/Run switch then returns to the 'PARK' position, applying 12 volts to brush 5 as previously described. The motor therefore stalls.




Fig. 2

J84 016

### Intermittent Operation

When position 'D' is selected 12 volts are applied to the operating coil of the timer and simultaneously to terminal 1 of the wiper motor. Terminal 5 of the wiper motor is connected via terminal 5 and 6 of the switch to the timer contact 31 b2(1). When 12 volts are applied to the timer its operation consists of an instantaneous 'flip flop' then a delay of approximately 5 seconds and another 'flip flop'. This action applies instantaneous earth to terminal 5 of the motor, starting it running in a reverse direction. The motor then obtains its own earth via the Park/Run contact at 'RUN' to sustain it for one sweep. As the motor is running in a reverse direction, the 'PARK' switch closes at the end of the sweep and applies 12 volts via the new closed contacts of the Timer to the opposite brush to stall the motor in the 'PARK' position.

### WINDSCREEN WIPER CIRCUIT




Fig. 1

### KEY TO DIAGRAM

1. Control switch
2. Delay unit
3. Wiper motor
4. To fuse No. 9

### Switch Positions

- A Intermediate/Flick wipe
- B Fast wipe
- C Slow wipe
- D Off

### Park Switch Position

- Z Park  
Y Run

### Earth Point

- E Earth on steering column bracket behind instrument panel

After approximately 5 seconds the Timer again 'flip flops' removing the 12 volts from the motor brush at 5 and replaces it with an earth. The cycle already described then repeats itself until the Wiper Switch is restored to the 'OFF' position cancelling the operation of the timer contacts. The motor then stalls as previously described.

## Fault Finding

Check the fuse and all connections ensuring the earth connections are clean and tight. With the ignition switched on battery voltage should be obtained at terminals 1, 2 and 5 of the wiper motor. Battery voltage should also be obtained at terminals 31 b1 and 31 b2 on the delay unit. With the wiper switch in the slow run position and the ignition switched on battery voltage should be obtained at terminal 5 of the wiper motor. The wiper motor earth circuit is via terminals 7 and 2 of the wiper switch. In the fast run position battery voltage should be obtained at terminal 3 of the wiper motor. The earth circuit is the same as the slow run position.

In the intermittent wipe position battery voltage should be obtained at terminal 1 of the wiper motor and terminal 54 on the delay unit. The earth is switched intermittently via the delay unit and the Park/Run switch in the wiper motor.

To operate the windscreen washer, press the knob on the end of the control.

The washer reservoir should be filled with soft water where possible. If soft water is not available and continued use of hard water is necessary occasional attention should be paid to washer jet outlet holes. It is permissible to clear deposits from outlets with thin wire when necessary. The washer bottle should also be cleaned out, and the filter flushed occasionally. Windscreen washer additives should be confined to proprietary brands or a mild detergent.

**CAUTION:** Denatured alcohol or methylated spirit must NOT be used.

Washer jets can be adjusted with a screwdriver as illustrated (Fig. 3), the jet should be adjusted to strike the top of the windscreen.




Fig. 3

## WINDSCREEN WIPER ARMS AND BLADES

### Renew

Raise the plastic cover from the spindle nut (1, Fig. 4).

Remove the arm retaining nut from the spindle (2, Fig. 4).

Remove the arm assembly from the spindle (3, Fig. 4).

**NOTE:** The position of arm in relationship to spline should be noted at this point.




Fig. 4

Depress the blade retaining clip (1, Fig. 5) and remove the blade (2, Fig. 5).




Fig. 5

On refitting ensure the wiper arms and blades are fitted and positioned as shown at (A, Fig. 6) RH Drive or (A, Fig. 7) LH Drive. Prior to testing the operation of windscreen wipers ensure the windscreen is wet.




Fig. 6




Fig. 7

## WIPER MOTOR

### Renew

Disconnect the battery earth lead.

Remove the wiper arms (1, Fig. 8).

Remove the air inlet grille retaining nuts, bolts and washers (2, Fig. 8).

Manoeuvre and raise the grille (3, Fig. 8). Disconnect the washer tube at the jet assembly and remove the multi-plug (4, Fig. 8) connector at the bulkhead.

Remove the four 7 mm bolts securing the motor mounting bracket to the grille (5, Fig. 8).

Remove the wheel box spindle nuts and remove the complete assembly from the grille (6, Fig. 8).

Remove the three 8 mm nuts securing the brackets to the motor and remove the brackets (7, Fig. 8).

Remove the rack cover plate retaining bolts (8, Fig. 8) and lift off the cover (9, Fig. 8) and remove the rack assembly.




Fig. 8

Remove the screws securing the gearbox cover (1, Fig. 9) and remove the cover (2, Fig. 9).

Remove the circlip washer retaining the gear assembly (3, Fig. 9).

Remove the gear and crankpin assembly noting the position of the belled washer (4, Fig. 9).




Fig. 9

Refitting is the reversal of the above operations.

## WINDSCREEN WIPER MOTOR RACK DRIVE AND WIPER WHEEL BOXES

With the wiper motor removed.

Remove the wheel box back plate nuts (1, Fig. 10).




Fig. 10

Remove the wheel box back plate (2, Fig. 10) and the shroud (3, Fig. 10). Pull the wheelbox (4, Fig. 10) clear of the rack drive. Remove the Bundy tube from rack (5, Fig. 10).

## WINDSCREEN WIPER/WASHER CONTROL SWITCH

### Renew

Disconnect the battery earth lead. Slacken the steering wheel adjustment ring (1, Fig. 11) and extend to its maximum travel. Remove the screws securing the steering column lower shroud (2, Fig. 11) and remove the shroud. Remove the screws securing the horn pad (3, Fig. 11) and remove the pad (4, Fig. 11). Adjust the wheels to the straight ahead position, remove the ignition key to lock the steering. Remove the horn contact rod from the upper column. Remove the nut securing the steering wheel to the upper column and gently tap the steering wheel withdrawing the wheel from the column. Remove the screws securing the upper shroud to the bracket on the steering column (5, Fig. 11). Slacken the pinch screw securing the switch assembly to steering column (6, Fig. 11). Ease the switch assembly and upper shroud off the steering column. Remove the shroud from the switch assembly (7, Fig. 11). Remove the spire and screws (8, Fig. 11) securing the switch mounting. Disconnect the earth cable at the snap connector (9, Fig. 11).




Fig. 11

J84 022

## WINDSCREEN WIPER MOTOR HARNESS — BULKHEAD CONNECTOR

### Renew

Disconnect the battery earth lead. Remove the wiper arms and the fresh air intake (1 & 2, Fig. 12). Disconnect the harness at the multi-pin connection (3, Fig. 12). Disconnect the washer tube. Remove the bulkhead connector retaining screws (4, Fig. 12) and ease the connector from its location (5, Fig. 12). Disconnect the panel harness connector (6, Fig. 12) and secure the harness.




Fig. 12

J84 023

## WIPER MOTOR DELAY UNIT

### Renew

Disconnect the battery. Remove the passenger's side dash casing. Remove the delay unit from the retaining socket behind the auxilliary fuse box (1, Fig. 13).




Fig. 13

J 86-086

## WASHER PUMP

### Renew

Disconnect the battery earth lead. Displace the washer reservoir from the reservoir bracket (1, Fig. 14). Disconnect the harness connector from the washer motor (2, Fig. 14). Ensure the reservoir is empty of water. Loosen the clip retaining the washer tube to motor and remove the tube (3, Fig. 14). Withdraw the motor from the reservoir (4, Fig. 14).




Fig. 14

J84 024

## WASHER JETS

### Renew

Disconnect the battery earth lead. Remove the wiper arms (1, Fig. 15). Remove the air inlet grille retaining nuts, bolts and washers (2, Fig. 12). Raise the grille and the wiper motor assembly (3, Fig. 15). Disconnect the washer pump to jet tube at the jet (4, Fig. 15). Remove the jet assembly retaining nut and shake proof washer (5, Fig. 15). Remove the jet assembly (6, Fig. 15).




Fig. 15

J84 025

## HEADLAMP WASH WIPE




Fig. 16

J86-122

## KEY TO DIAGRAM

1. RH headlamp wiper motor
2. Wash wipe relay
3. Windscreen washer pump
4. Windscreen washer switch
5. LH headlamp wiper motor
6. Headlamp washer pump
7. Diode pack
8. To headlamp dip beam
9. To headlamp main beam
10. Fuse No. 11
11. Earth point on radiator crossmember
12. Earth point on steering column bracket

## HEADLAMP WASH WIPE

## Description

The headlamp wash wipe circuits will only be activated with headlamps switched to main or dip beam. When the headlamps are switched on power is applied to the wash wipe relay via a diode in the wash wipe diode unit. Power is also supplied to the windscreen washer motor via a diode in the wash wipe diode unit. When the windscreen washer switch is operated the circuit is completed to earth energising the wash wipe relay and the headlamp washer motor. Power is now supplied to the headlamp wiper motors via the relay contacts. When the windscreen washer switch is released the relay is de-energised thus switching off the headlamp washer motor. The headlamp wiper motors will continue to operate via power being applied to terminal 53a on the wipers until the wiper internal switch contacts open.

## Fault finding

Check that all connections are clean and tight. Check the fuse.

Ensure the earth connections are clean and tight.

With the ignition switched on. Battery voltage should be obtained at terminals 1 and 3 of the diode module. If battery voltage is obtained at terminal 3 but a zero reading at terminal 1 a faulty diode is indicated in the diode module.

With the headlamps switched to main beam. Battery voltage should be obtained at terminals 5 and 4 of the diode module. With the headlamps switched to dip beam. Battery voltage should be obtained at terminals 2 and 4 of the diode module. A zero reading at terminal 4 in either main or dip beam position indicates a faulty diode in the module.

With the ignition switched on. Battery voltage should be obtained at terminal 30/51 of the wipe/wash relay. With headlamps switched on. Battery voltage should be obtained at terminals 85 and 86 of the relay. When the windscreen washer is operated the terminal 86 of the relay should drop to zero, and battery voltage should then be obtained at terminal 87 of the relay. If the voltage remains at 12 volts at terminal 86 of the relay. Check the wash/wipe switch, and wiring. If the terminal 86 voltage drops to zero voltage but the terminal 87 voltage remains at zero, replace the relay.

With the ignition switched on. Battery voltage should be obtained at terminal 53a of the headlamp wiper motor. With headlamps switched on and the washer

button pressed, battery voltage should be obtained at terminal 53 of the wiper motor. Terminal 31 of the motor should be earthed. If the voltage reading and the earth are satisfactory remove the wiper motor and bench check.

## HEADLAMP WIPER MOTOR

## Renew

Disconnect the battery earth lead.

Raise the plastic covers from the wiper motor spindle nuts and remove the wiper arm retaining nuts.

Remove the wiper arm assembly from the spindles.

Remove the screws securing the top finisher to the top of the lamp housing, then ease the top of the finisher away from the lamp unit and lift the bottom locating spigots from the housing.

Depress the nylon securing tabs retaining the lamp unit.

Withdraw the unit from its housing and disconnect the cable harness at the block connectors behind the unit.

Remove the two nuts and washers securing the wiper motor assembly bracket (1, Fig. 17).

Manoeuvre the motor assembly clear of its location.

Disconnect the motor assembly clear of its location.

Disconnect the cable harness block connector and remove the motor.

Remove the two nuts and washers securing the bracket to the motor (2, Fig. 17) and remove the bracket (3, Fig. 17).




Fig. 17

## HEADLAMP WASH/WIPE RELAY

### Renew

Disconnect the battery earth lead.  
Remove the relay from the retaining tab on the radiator cross member.  
Disconnect the cable harness block connector and retain the relay.

## HEADLAMP WASH/WIPE DIODE PACK

### Renew

Disconnect the battery earth lead.  
Remove the diode pack from the retaining tab on the radiator top cross member.  
Disconnect the cable harness block connector and retain the diode.




Fig. 18

## HEADLAMP WIPER ARM ASSEMBLY

### Renew

Raise the plastic covers from the headlamp wiper motor spindle nuts and remove the nuts from the spindles (1, Fig. 18).  
Remove the wiper arm assembly (2, Fig. 18) from the spindles.  
Remove the washer tube from the headlamp washer jet located on the arm assembly and recover the arm.

## HEADLAMP WIPER BLADE

### Renew

Lift the wiper arm assembly from the headlamp.  
Prise the blade from the arm.

## HEADLAMP WASHER PUMP

### Renew

On cars fitted with the headlamp wash/wipe facility the washer reservoir is of larger capacity than the normal windscreen washer only reservoir. The reservoir contains both the headlamp and windscreen washer pumps.

Disconnect the battery earth lead.

Remove the reservoir retaining bar securing nuts and remove the retaining bar.

Displace the reservoir and ensure the reservoir is empty of water.

Disconnect the cable harness connectors from the washer pump motors (2, Fig. 14).

Loosen the clip retaining the washer tube to the washer motor and remove the tube.

Withdraw the motor from the retaining clip and the reservoir.



## CONTENTS

| Operation   | Operation No. | Page No. |
|---|---------------|----------|
| Aerial circuit — Description .....                              | 86.50.00      | 86—33    |
| Aerial circuit — Fault finding .....                            | —             | 86—33    |
| Alternator — Bench test .....                                   | 86.10.14      | 86—8     |
| Alternator — Description .....                                  | 86.10.00      | 86—5     |
| Alternator — Drive belt — Renew .....                           | 86.10.03      | 86—8     |
| Alternator — Drive belt — Adjust .....                          | 86.10.05      | 86—8     |
| Alternator — Overhaul .....                                     | 86.10.02      | 86—7     |
| Alternator — Testing on vehicle .....                           | 86.10.01      | 86—5     |
| Battery — Renew .....   | 86.15.01      | 86—10    |
| Battery — Test .....  | 86.15.02      | 86—9     |
| Cigar lighter assembly — Renew .....                            | 86.65.60      | 86—33    |
| Cigar lighter bulb — Renew .....                                | 86.45.55      | 86—33    |
| Circuit breakers — Renew .....                                  | 86.25.31      | 86—11    |
| Clock illumination bulb — Renew .....                           | 86.45.54      | 86—23    |
| Combined headlight/direction indicator/dip switch — Renew ..... | 86.55.65      | 86—27    |
| Cooling fan circuit — Description .....                         | 26.25.00      | 86—30    |
| Cooling fan motor — Renew .....                                 | 26.25.22      | 86—30    |
| Cooling fan diode pack — Renew .....                            | 26.25.31      | 86—30    |
| Cooling fan relay — Renew .....                                 | 26.25.32      | 86—30    |
| Distributor — Overhaul .....                                    | 86.35.26      | 86—15    |
| Distributor — Renew .....                                       | 86.35.20      | 86—15    |
| Door lock solenoid — Renew .....                                | 86.25.32      | 86—12    |
| Door lock solenoid relay — Renew .....                          | 86.25.33      | 86—12    |
| Door pillar switch — Renew .....                                | 86.65.15      | 86—27    |
| Electric door mirrors — Description .....                       | —             | 86—31    |
| Flasher lamp circuit — Description .....                        | 86.40.00      | 86—20    |
| Front flasher lamp — Renew .....                                | 86.40.42      | 86—21    |
| Front flasher bulb — Renew .....                                | 86.40.40      | 86—21    |
| Front flasher repeater bulb — Renew .....                       | 86.40.51      | 86—21    |
| Front flasher repeater lens — Renew .....                       | 86.40.52      | 86—21    |
| Front flasher repeater lamp — Renew .....                       | 86.40.53      | 86—21    |
| Fuel pump inertia switch — Renew .....                          | 86.65.58      | 86—31    |
| Fuel pump inertia switch — Reset .....                          | 86.65.59      | 86—31    |
| Handbrake warning switch — Renew .....                          | 86.65.45      | 86—29    |
| Hazard/flasher unit — Renew .....                               | 86.55.12      | 86—20    |

## ELECTRICAL SYSTEM

| Operation  | Operation No. | Page No. |
|--|---------------|----------|
| Headlamp circuit — Description .....                 | 86.40.00      | 86—16    |
| Headlamp assembly — Renew .....                      | 86.40.02      | 86—17    |
| Headlamp — Alignment .....                           | 86.40.18      | 86—18    |
| Headlamp — Fault finding .....                       | —             | 86—16    |
| Headlamp relay — Renew .....                         | 86.55.17      | 86—18    |
| Headlamp inhibit relay — Renew .....                 | 86.55.58      | 86—18    |
| Heated rear window circuit — Description .....       | 86.55.00      | 86—34    |
| Heated rear window relay — Renew .....               | 86.55.19      | 86—34    |
| Horns circuit — Description .....                    | 86.30.00      | 86—12    |
| Horns — Renew .....                                  | 86.30.09      | 86—13    |
| Horns circuit — Test .....                           | 86.30.17      | 86—12    |
| Horn push — Renew .....                              | 86.30.01      | 86—13    |
| Horn relay — Renew .....                             | 86.30.18      | 86—13    |
| Ignition amplifier — Renew .....                     | 86.35.30      | 86—17    |
| Ignition circuit — Description .....                 | 86.35.00      | 86—13    |
| Ignition coil — Renew .....                          | 86.35.32      | 86—15    |
| Ignition distributor — Overhaul .....                | 86.35.26      | 86—15    |
| Ignition load relay — Renew .....                    | 86.60.28      | 86—16    |
| Ignition system — Testing .....                      | 86.35.29      | 86—14    |
| Ignition/starter switch — Renew .....                | 86.65.03      | 86—15    |
| Instrument illumination bulb — Renew .....           | 86.45.48      | 86—23    |
| Low coolant warning light control unit — Renew ..... | 86.55.33      | 86—33    |
| Luggage compartment lamp — Renew .....               | 86.45.15      | 86—23    |
| Luggage compartment light switch — Renew .....       | 86.65.22      | 86—27    |
| Master light switch — Renew .....                    | 86.65.09      | 86—18    |
| Number plate and reverse lamp assembly — Renew ..... | 86.40.87      | 86—21    |
| Number plate lamp bulb — Renew .....                 | 86.40.85      | 86—21    |
| Number plate lamp lens — Renew .....                 | 86.40.84      | 86—21    |
| Opticell — Renew .....                               | 86.45.27      | 86—23    |
| Opticell bulb — Renew .....                          | 86.45.28      | 86—23    |
| Overcharge control unit — Renew .....                | 86.55.32      | 86—32    |
| Overcharge control warning light — Description ..... | —             | 86—32    |
| Panel switches — Renew .....                         | 86.65.06      | 86—27    |
| Panel switch illumination bulb — Renew .....         | 86.45.31      | 86—23    |
| Panel light rheostat — Renew .....                   | 86.65.07      | 86—27    |
| Parking lamp bulb — Renew .....                      | 86.40.11      | 86—19    |

| Operation   | Operation No. | Page No.       |
|---|---------------|----------------|
| Parking lamp circuit .....                                | 86.40.00      | 86—19          |
| Parking lamp failure warning sensor — Renew .....         | 86.55.22      | 86—19          |
| Rear passenger and map lights — renew .....               | 86.45.04      | 86—22          |
| Rear passenger and map lights bulb — Renew .....          | 86.45.03      | 86—22          |
| Reverse lamp switch — Renew .....                         | 86.65.20      | 86—27          |
| Roof lamp assembly — Renew .....                          | 86.45.02      | 86—22          |
| Seat belt logic unit — Renew .....                        | 86.55.13      | 86—32          |
| Seat belt switch — Renew .....                            | 86.57.25      | 86—29          |
| Side marker lamp assembly — Renew .....                   | 86.40.59      | 86—21          |
| Side marker lamp bulb — Renew .....                       | 86.40.58      | 86—21          |
| Side marker lamp lens — Renew .....                       | 86.40.57      | 86—21          |
| Starter — Bench check .....                               | 86.60.14      | 86—25          |
| Starter circuit — Test .....                              | 86.60.00      | 86—23          |
| Starter motor — Renew .....                               | 86.60.01      | 86—24          |
| Starter — Overhaul .....                                  | 86.60.13      | 86—25          |
| Starter solenoid — Renew .....                            | 86.60.08      | 86—25          |
| Starter solenoid — Test .....                             | 86.60.09      | 86—25          |
| Starter relay — Renew .....                               | 86.55.05      | 86—24          |
| Stop light switch — Renew .....                           | 86.65.56      | 86—29          |
| Stop light failure unit — Renew .....                     | 86.55.34      | 86—28          |
| Warning lamp bulb — Renew .....                           | 86.45.61      | 86—29          |
| Warning lamp bulb failure — Circuit .....                 | 86.55.00      | 86—28          |
| Warning lamp bulb failure — Renew .....                   | 86.55.59      | 86—28          |
| Window lift description .....                             | —             | 86—10          |
| Window lift motor — Renew .....                           | 86.25.05      | 86—10          |
| Window lift relay — Renew .....                           | 86.25.28      | 86—11          |
| Wiring diagram, symbols, fuses and component layout ..... | —             | End of section |

### INTRODUCTION

Fault diagnosis is the method of locating faults while the electrical equipment is still fitted to the vehicle. In the interests of efficiency and economy, the diagnosis must be carried out in the shortest possible time. It is the aim of this manual to present a series of tests that may be carried out in order to achieve this objective. The electrical systems of Jaguar Cars are sophisticated and, of necessity, complex. Besides the main wiring diagram, this manual divides the circuitry into more readily understood subsystems. With each system diagram is a description of the circuit and a test procedure to ensure the fast diagnosis of electrical faults.

Some of the tests described require the use of specialised equipment, and it is in the interest of efficiency and economy that this is used.

### GENERAL PRACTICE

1. Always disconnect the battery earth lead before disconnecting any components.
2. Always disconnect the battery earth lead before connecting an ammeter into a circuit.
3. When connecting electrical components, always ensure that a good contact is made by the connectors. Ensure that earth connections are made to a clean metal surface, and are tightly fastened using the correct screws and washers.

### WARNING

1. When using an arc or spot welder on the vehicle, disconnect the battery and remove any electrical equipment in the close proximity of the welding.
2. Do not disconnect the battery with the engine running.
3. Do not use a high speed charger as a starting aid.
4. When using a high speed charger to charge the battery, the battery must be disconnected from the rest of the vehicle's electrical system.
5. When installing, ensure that the battery is 12 volts and is connected with the right polarity, i.e. negative earth.
6. Ensure that the battery is kept in an upright position when removing or refitting.
7. All car batteries generate hydrogen gas which is highly inflammable. If ignited by a spark or flame, the gas may explode, causing spraying of acid, fragmentation of the battery, and possible personal injuries. Wear safety glasses when working near batteries. In case of contact with acid, flush immediately with water.

## ALTERNATOR

## ALTERNATOR CIRCUIT




Fig. 1

## Description

The A133 alternator is a three phase machine with a delta wound stator, twelve pole rotor, full wave rectification, and a 15TR voltage regulator.

The alternator is machine sensed with an externally fitted radio suppression capacitor. When the ignition switch is turned on, the rotor winding (6, Fig. 1) is connected to the battery via the warning lamp (9, Fig. 1).

The small current flowing through the rotor (6, Fig. 1) to earth via the voltage regulator (7, Fig. 1) produces a magnetic field which is sufficient to begin the build-up of the alternator output voltage through the output diodes (2, Fig. 1) and the auxiliary diodes (3, Fig. 1). As the voltage builds-up, the same voltage will be applied to both sides of the warning lamp and the lamp will be extinguished. The action of the regulator is similar to that of the vibrating contact type of voltage control unit, but the switching of the field circuit is achieved by transistors instead of vibrating contacts. When the battery voltage reaches approximately 14 volts, the transistors located in the control box switch off and on very quickly in order to maintain the 14 volts.

A surge protection device is connected between the 'IND' terminal and the frame which is an avalanche diode (8, Fig. 1). This device protects the alternator by absorbing the high transient voltages caused by faulty connections, or the removal of the battery leads while the engine is running.

## Testing

**NOTE:** Check that all connections are clean and tight. Check the fan belt. A load of 1,5 kg (3.3 lb) must give a total belt deflection of 4,4 mm (0.17 in) when applied at the mid-point of the belt. Check the battery hydrometer readings.

## Test 1

Remove the connectors from the alternator. Switch the ignition on.

Connect the voltmeter between a good earth and each of the disconnected leads in turn (Fig. 2). The voltmeter should indicate battery voltage.

If the voltmeter indicates a zero reading when connected to the main output lead, check the wiring to the starter solenoid and battery.




Fig. 2

If the voltmeter indicates a zero reading when connected to the 'IND' lead, check for earth or open-circuit between the warning light and the alternator connector. Check the warning light bulb and all connections to the warning light.

## Test 2

Refit the alternator connectors.

Switch the ignition on.

Connect the voltmeter between a good earth and the 'IND' terminal (Fig. 3).

The voltmeter should indicate approximately 2 volts.




Fig. 3

If the voltmeter indicates a zero reading, the surge protection diode is suspect and should be checked.

If the voltmeter indicates battery voltage the brushes, rotor, or regulator are suspect. Proceed to the next test.

**NOTE:** If the warning light operates with the ignition off but goes out when the ignition is switched on, check the voltage at the 'IND' terminal with the ignition switched 'off'. If battery voltage is indicated, the diode pack is faulty.

### Test 3

Connect the voltmeter between a good earth and the metal link on the regulator (Fig. 4). Switch the ignition on. The voltmeter should indicate approximately 0.5 volt. If 12 volts is indicated, the regulator is faulty.




Fig. 4

### Test 4

Start and run the engine at a constant 2500 rev/min.

Connect the voltmeter to a good earth and the 'IND' terminal; note the voltage. Connect the voltmeter to the main output terminal; the voltmeter readings should be the same (Fig. 5). If there is a difference of more than 0.5 volt, the diode pack is suspect.




Fig. 5

### Test 5

Connect the voltmeter between the battery insulated terminal and the alternator main output terminal (Fig. 6).

Start and run engine at approximately 2500 rev/min. The voltmeter should not exceed 0.5 volt.

If the voltmeter reading is higher than 0.5 volt, check the wiring from the alternator to the battery for loose or dirty connections.




Fig. 6

**NOTE:** The warning light glowing while the engine is running at normal charging speeds usually indicates a faulty diode pack or dirty or loose connections in the wiring from alternator to battery.

### Test 6

Disconnect the battery earth lead.

Disconnect the alternator.

Connect an ammeter between the main output terminal of the alternator and the disconnected output lead.

Connect a jumper lead between the 'IND' lead and 'IND' terminal (Fig. 7)

Re-connect the battery.

Switch on all load (except wipers) for one minute.




Fig. 7

Start and run the engine at normal charging speed. The ammeter should indicate the maximum output for the alternator.

If the output is low, short the metal link on the regulator to earth with a jumper lead and repeat the test.

If maximum output is now indicated on the ammeter, the regulator is suspect.

Should the output still be low, the stator windings are suspect.

Disconnect the battery earth lead.

Connect the ammeter in series with the alternator main output cable and the starter solenoid.

Re-connect the battery.

Connect the voltmeter across the battery terminals.

Start and run engine at normal charging speed until the ammeter reads less than 10A.

The voltmeter should read 13.6 to 14.4 volts.

An incorrect reading indicates that the regulator is faulty.




Fig. 8

J86 199

## KEY TO ALTERNATOR

1. Capacitor
2. Cover
3. Surge protective diode
4. Regulator
5. Brush box assembly
6. Rectifier pack
7. Through bolts
8. Slip-ring end bracket
9. Stator
10. Rotor shaft
11. Bearing kit
12. Slip-ring
13. Slip-ring end bearing
14. Rotor

## Specification

|                                     |                   |
|-------------------------------------|-------------------|
| Voltage                             | 12 volts          |
| Maximum rev/min                     | 15,000 rev/min    |
| Maximum output                      | 75 amps           |
| Regulated voltage                   | 13.6 — 14.4 volts |
| Rotor resistance                    | 2.46 ohms         |
| Stator winding resistance per phase | 0.144 ohms        |
| Maximum brush length                | 20 mm (0.79 in)   |
| Minimum brush length                | 10 mm (0.39 in)   |
| Warning lamp bulb                   | 2.2 watts         |

## ALTERNATOR OVERHAUL

## Dismantle

Disconnect the capacitor Lucas connector. Remove the capacitor securing screw and remove the capacitor (1, Fig. 8). Remove the two screws securing the cover and remove the cover (2, Fig. 8). Remove the surge protection diode (3, Fig. 8).

Note the arrangement of the regulator leads, disconnect the leads and remove the regulator (4, Fig. 8).

Remove the two screws securing the brush box assembly and remove the brush box (5, Fig. 8).

Apply a hot iron to the stator lead terminal tags on the rectifier pack and prise out the stator leads when the solder melts.

Remove the remaining two screws securing the rectifier pack assembly (6, Fig. 8) and lift the pack from the slip-ring end bracket (8, Fig. 8).

Remove the three through bolts (7, Fig. 8) and lift the slip-ring end bracket (8, Fig. 8) from the stator (9, Fig. 8) using a mallet if necessary.

Note the position of the stator leads, relative to the alternator fixing lugs, and then lift the stator (9, Fig. 8) from the drive end bracket. Remove the shaft nut, washer, pulley, cooling fan, woodruff key and spacers from the rotor shaft (10, Fig. 8).

Press the rotor shaft from the drive end bearing (11, Fig. 8).

To replace the slip-ring end bearing (13, Fig. 8) unsolder the outer and inner slip-rings (12, Fig. 8) then prise the slip-rings gently off the rotor shaft.

Using a suitable extractor withdraw the bearing from the rotor shaft.

**NOTE:** Care should be taken not to damage the insulation on the rotor leads when removing or refitting the slip-rings. Use a resin covered solder ensuring a build-up of solder does not occur on the upper face of the inner slip-ring.


Check all the components using normal procedures. Referring to the resistance values and brush lengths as detailed.

Re-assembly is the reversal of the dismantling procedure ensuring the brushes move freely in the brush box, also ensure the slip-rings are clean and smooth.

## ROTOR

### Testing


Connect an ohmmeter to the slip-rings (Fig. 9) and the ohmmeter should give a



J86 218

Fig. 9

reading of 2.46 ohms. With the ohmmeter connected to one slip-ring and the rotor body (Fig. 10), the ohmmeter should register infinity.




J86 219

Fig. 10

## STATOR

### Testing

Visually inspect the stator windings for signs of damage due to overheating. Check the insulation with a 110 volt test lamp. Connect the test leads to the laminated yoke and to each of the stator leads in turn (Fig. 11). If the lamp lights at any one of the stator leads, the stator is defective.




J86 220

Fig. 11

## DIODES

### Testing

With diode pack disconnected and isolated from the alternator, connect a battery lead in series with a test lamp to a diode plate.



J86 221

Fig. 12

Connect the other test lead to a pin (Fig. 12). Reverse the test lamp connections to the diode plate and diode pin. The lamp should illuminate when in one direction only. Should the lamp illuminate when connected in both ways or not illuminate at all, the diode pack is defective. The remainder of the diodes in the diode pack assembly can be checked the same way.

## ALTERNATOR — DRIVE BELT

### Renew and adjust

Slacken the pivot bolts securing the air conditioning compressor (1, Fig. 13).

Slacken the adjusting link securing bolt (2, Fig. 13) and the trunnion block bolt (3, Fig. 13).

Slacken the adjusting link lock nut and adjust the compressor towards the engine (4, Fig. 13) until the compressor drive belt can be removed.

Slacken the alternator pivot nut and bolt (5, Fig. 13).

Slacken the bolt securing the adjusting link (6, Fig. 13) and the trunnion block bolt (7, Fig. 13).

Slacken the adjusting link lock nut; adjust the alternator towards the engine by means of the adjusting nut (8, Fig. 13).

Remove the trunnion block nut; push the alternator towards the engine until the drive belt can be removed from the pulleys.

On fitting new belt, ensure the drive belts are adjusted to the correct tension. A load of 1.5 kg (3.3 lb) must give a total belt deflection of 4.4 mm (0.17 in) when applied at mid point of the belts.

## ALTERNATOR


### Renew

Disconnect the battery earth lead.

Remove the air cleaner for ease of access.

Slacken the alternator pivot bolt (1, Fig. 14). Slacken the bolt securing the adjusting link (2, Fig. 14), and the trunnion block bolt (3, Fig. 14).

Slacken the adjusting link lock nut (4, Fig. 14) and adjust the alternator towards the engine by means of the adjusting nut (5, Fig. 14).




J86 224

Fig. 14

Remove the bolt securing the trunnion block; ease the belt off the pulley.

Remove the pivot nut and bolt and manoeuvre the alternator from the engine compartment.

On refitting, ensure that the drive belt is adjusted to the correct tension. A load of 1.5 kg (3.3 lb) must give a total belt deflection of 4.4 mm (0.17 in) when applied at mid point of the belt.



J86 225

Fig. 13



## BATTERY

The battery is of advanced design and has improved performance characteristics. High and low electrolyte level marks are moulded into the case.

Topping-up should be carried out when the electrolyte level falls below the top of the separators or the low level mark on the case.

The vent cover should be left in position at all times, except during the topping-up procedure.

When battery charging is carried out, the vent cover should be left in position to allow gas to escape or flooding of electrolyte may result.

### Testing

The electrolyte consists of a mixture of sulphuric acid and water in given proportions.

The electrolyte becomes weaker as the cell discharges, and this weakening effect is directly proportional to the amount of electricity given up by the cell. Therefore the specific gravity of the electrolyte gives a direct indication of the condition of the battery.

When the tube of a hydrometer is inserted into the electrolyte and the rubber bulb is pressed and released, a small quantity of electrolyte is drawn into the hydrometer. The specific gravity of the electrolyte determines the depth of the float in the liquid. With the float in a high position, the specific gravity is high. If the specific gravity is low, the float sinks to a lower position. The specific gravity readings are taken when the liquid level crosses the scale on the float, and this gives an accurate indication of the state of charge of the battery.

The volume of electrolyte and hence its specific gravity varies with temperature. Therefore readings of electrolyte taken at temperatures other than 15°C (60°F) (Fig. 15) should be corrected to correspond with the equivalent reading at 15°C (60°F).

### Electrolyte Temperature Correction

For every 10°C below 15°C subtract 0.007 from the hydrometer reading and for every 10°C above 15°C add 0.007 to the hydrometer reading.

Example:

Specific gravity reading = 1.250

The temperature = 5°C

The equivalent specific gravity at 15°C

$$= 1.250 - 0.007$$

$$= 1.243$$

For every 10°F below 60°F subtract 0.004 from the hydrometer reading and for every 10°F above 60°F add 0.004 to the hydrometer reading.

Example:

Specific gravity reading = 1.250

The temperature = 50°F

The equivalent specific gravity at 60°F

$$= 1.250 - 0.004$$

$$= 1.246$$

### Heavy discharge test

This test can be carried out as a further check of the battery condition. A heavy discharge tester should be applied to the battery terminals as shown in (Fig. 16).

The tester should be set to discharge the battery at three times the ampere hour rate (20 hour rate) for 15 seconds. On a battery with a capacity of 68 ampere hour rate, the tester should be set to 204 amps. Observe the voltmeter during the 15 seconds the battery is being discharged. If the voltage drops below 9.6 volts, the battery is suspect, but if the voltmeter reading is above 9.6 volts, the battery can be considered satisfactory.




Fig. 15

### Starting with jump leads and booster battery

Both booster and discharged battery should be treated carefully when using jumper cables. Follow exactly the procedure outlined below, being careful not to cause sparks:

1. Apply hand brake and place transmission in neutral. Turn off lights, heater and other electrical loads.
2. Attach one end of one jumper cable to the positive terminal of the **booster battery** and the other end of same cable to positive terminal of **discharged battery**. DO NOT PERMIT vehicles to touch each other as this could establish an earth connection and counteract the benefits of this procedure.
3. Attach one end of the remaining negative cable to the negative terminal of the **booster battery** and the other end to earth at least 305 mm (12 inches) from the battery of the vehicle being started. (DO NOT CONNECT DIRECTLY TO THE NEGATIVE POST OF THE DEAD BATTERY).




Fig. 16

**Renew**

Remove the battery cover by releasing the two fasteners and easing the cover from beneath the retaining fold on the battery clamp (1, Fig. 17).

Ease back the battery terminal cover from the terminals; slacken the clamp bolts and disconnect the battery.

Release the battery filler cover securing strap and remove the cover (2, Fig. 17).

Release the battery clamp securing nuts (3, Fig. 17), and remove the clamp, then remove the battery from the luggage compartment.

On refitting, smear the battery terminals with petroleum jelly before re-connecting the battery leads.

Ensure the battery is kept level to prevent spillage of electrolyte.




Fig. 17

**ELECTRICALLY OPERATED WINDOWS****Description**

Power is supplied to the relay contacts from the main battery supply via a thermal circuit breaker. The window lift relay is activated when the ignition is switched on. When the control switch is operated to wind the windows down the contacts AD and CF are connected. This allows current to flow to the motor via contacts AD and the circuit to earth is completed via contacts CF. When the control switch is operated to wind the windows up, the contacts BD and CE are connected. This allows the current to flow through the motor in the opposite direction via contacts CE and the circuit to earth is completed via contacts BD.

**Fault finding**

Check the fuse and all connections, ensuring the earth connections are clean and tight.

Check the thermal circuit breaker by joining the circuit breaker leads together. Switch on the ignition and operate the window lift switches. Should the windows operate satisfactorily replace the circuit breaker.

With the ignition switched off battery voltage should be obtained at terminal C1 of the window lift relay. With the ignition switched on battery voltage should also be obtained at terminals W1 and C2 of the relay. If battery voltage is obtained at terminal C2 but a zero reading at terminal C1 replace the relay.

With the ignition switched on battery voltage should be obtained at the brown and blue lead terminal of the LH window lift switch. Operate the switch. Battery voltage should now be obtained at the red and green lead terminal when the switch is operated in one direction, or the green and red lead terminal when the switch is operated in the opposite direction. Should a zero reading be at either test point replace the switch.

The same checks apply for the RH window lift switch. Noting the switch cable colours are red and blue for one direction. Green and blue for the reverse direction.

If the checks prove satisfactory, check the window lift motor wiring for continuity. Should the wiring prove satisfactory remove the window lift motor for bench checks.

**WINDOW LIFT MOTOR****Renew**

Disconnect the battery earth lead.

Remove the screw securing the arm rest to the door trim pad, and release the arm rest finisher.

Slacken the two screws securing the interior light switch plate and pull the door pad clear of the striker plate.

Remove the screw securing the bottom of the door pad, unclip the door trim pad, disconnect the speaker and remove the door pad assembly.

Remove the inner door handle securing screws (1, Fig. 19) and disengage the remote control levers from the handle (2, Fig. 19).


**WINDOW LIFT CIRCUIT**

Fig. 18

**KEY TO DIAGRAM**

1. LH window lift motor
2. RH window lift motor
3. LH switch
4. RH switch
5. Thermal circuit breaker
6. Window lift relay
7. To ignition switch
8. Terminal post
9. Earth on passenger side of air conditioning unit
10. Earth behind fascia panel

J86 131/1

Completely lower the window, ease the waterproof sheet clear of the motor connections and disconnect the motor (3, Fig. 19).

Remove the bolts securing the motor (4, Fig. 19), ease the window lift assembly towards the rear of door, and disengage regulator from the locating channel.

Raise the glass and wedge at its highest point, withdraw the seven securing bolts (5, Fig. 19) and remove the mounting plate.

Remove the motor and quadrant assembly from the door.

Before disengaging the regulator from the motor, ensure that the lifting arm and quadrant of the regulator are clamped in a vice.

**NOTE:** This prevents the spring disengaging suddenly and causing possible damage.

Remove the bolts securing the regulator to the motor.

Reverse the above operations when fitting new unit.




Fig. 19

## WINDOW LIFT SWITCHES

### Renew

Disconnect the battery earth lead.

Withdraw the three screws securing the centre panel in the console (1, Fig. 20).

Remove the gear lever knob.

Lift the panel for access to the rear of the switches; note the position of the cables and the switches (2, Fig. 20).

Disconnect the cables from the appropriate switch, depress the switch securing tags and push the switch through the panel (3, Fig. 20).

On refitting, ensure the cable connections are clean and tight.




Fig. 20

## WINDOW LIFT RELAY AND CIRCUIT BREAKERS

### Renew

Disconnect the battery earth lead.

Remove the passenger's side dash liner.

Remove the nuts securing the component panel to the fan motor assembly, displace the component panel and remove the relay located behind the panel (1, Fig. 21).

The circuit breakers are located on the component panel (2, Fig. 21) secured by two screws.




Fig. 21

## ELECTRICALLY OPERATED DOOR LOCKS

### Description

The electric door lock circuit is activated from either of the two doors if the key is turned in either door lock, the two door solenoids will activate into the lock position, or the unlock position.

The two interior door lock control levers will also operate the two door solenoids into the locked or into the unlocked positions. The 12 volt supply is taken from the terminal post through a thermal circuit breaker to the

## DOOR LOCK CIRCUIT

### KEY TO DIAGRAM

1. Lock relay
  2. Trigger unit
  3. Unlock relay
  4. Trigger unit
  5. Thermal circuit breaker
  6. LH unlock solenoid
  7. LH lock solenoid
  8. RH unlock solenoid
  9. RH lock solenoid
  10. Fuse No. 8
  11. Terminal post
- Earth points behind the fascia panel




Fig. 22

J86-135

lock and unlock relays. 12 volts is also taken from fuse No 8 to the resistors in the RH and LH trigger units. The trigger units contains 2 diodes, 2 resistors, 2 electrolytic capacitors and 2 micro switches. The capacitors are charged to the battery potential via the resistors.

If one of the trigger units is turned to the unlocked position (by the door key or by the interior levers) the micro switches are moved to the unlock position, allowing the capacitor to discharge through a diode a surge of current to the unlock relay coil. This action closes the relay contacts thus completing the circuit to the door solenoids. After the initial discharge from the capacitor the unlock relay will de-activate reverting to its normal contacts open position. The second trigger unit will be moved to the unlocked position mechanically by the action of the solenoid to which it is attached. While the trigger units are kept in the unlocked position the door lock capacitors are kept in a charged state. The lock and unlock circuits are protected from each other by the diodes.

### Fault finding

Should the door locks not operate electrically check that all the connections are secure ensuring that the earth connections are clean and tight. Check the fuse.

Check the thermal circuit breaker by joining the thermal breaker leads together. If the door locks now operate replace the thermal circuit breaker.

To check the lock or unlock relay, battery voltage should be obtained at the C1 terminal of the appropriate relay.

Disconnect the lead from the W1 terminal and connect a voltmeter between the disconnected lead and a good earth. Operate the locks and battery voltage will be obtained from the disconnected lead which will gradually drop. If a zero reading is obtained at the disconnected lead check that battery voltage is obtained on the purple lead of the trigger unit, if satisfactory replace the door lock solenoid assembly.

## DOOR LOCK SOLENOID

### Renew

Ensure that the window is fully closed. Disconnect the battery earth lead. Remove the arm rest and door trim pad. Remove the solenoid securing screws (1, Fig. 23) disconnect the cable harness block connectors (2, Fig. 23), unhook the solenoid operating piston (3, Fig. 23) from the door lock push rod and remove the solenoid.




Fig. 23

## DOOR LOCK SOLENOID RELAY

### Renew

Disconnect the battery earth lead. Remove the appropriate side dash liner and footwell side casing.

Remove the screws securing the relay mounting bracket to the body side panel (1, Fig. 24).

Note the position of the cable connectors and disconnect the cables (2, Fig. 24).

Remove the relay from the mounting bracket.




Fig. 24

## HORNS

### Description

Twin horns are fitted, mounted on the front lower cross-member behind and beneath the front bumper. With the ignition switched on, current is supplied to the horn relay coil via fuse No. 11 and the earth circuit is completed via the horn push.

With the horn relay energised, current will flow to operate both horns simultaneously via the relay contacts.

### Fault finding

With the ignition switched on, battery voltage should be obtained at the terminals 85, 86 and 87 of the relay. If battery voltage is obtained at terminal 85 but not at terminal 86 the relay is faulty.

When the horn push is operated the terminal 86 voltage should drop to zero. If terminal 86 remains at battery voltage check the horn push and the wiring to the horn push. With the horn push pressed and the relay terminal 86 voltage at zero, battery voltage should be obtained at the terminal 30/51 of the relay. A zero reading at terminal 30/51 indicates a faulty relay.

Should the above tests prove satisfactory check the wiring to the horns and both horns.

### KEY TO DIAGRAM

1. Horn push
2. Horn relay
3. To terminal post
4. Horn
5. Horn
6. Fuse No. 11
7. Earth point on steering column bracket
8. Earth point on radiator top rail




Fig. 25

## HORN PUSH

### Renew

Disconnect the battery earth lead.

Slacken the steering column adjustment ring and extend the column to its full extent (1, Fig. 26).

Withdraw the two screws from behind the steering wheel (2, Fig. 26).

Remove the horn push from the steering wheel (3, Fig. 26).

Ease the trim pad from the horn push (4, Fig. 27) and recover the motif (5, Fig. 27).




Fig. 26

## HORN RELAY

### Renew

The horn relay is located at the front LH side of the engine compartment.

Remove by disconnecting the cable harness block connector and withdraw the relay from its locating tab.

## HORNS

### Renew

Disconnect the battery earth lead.

Remove the nut securing the horns to the mounting beneath the front bumper apron (1, Fig. 27).

Lower the horns and retain the distance pieces and washers.

Disconnect the supply leads and recover the horns (2, Fig. 27).




Fig. 27

## IGNITION SYSTEM

### IGNITION SYSTEM CIRCUIT




Fig. 28

### KEY TO DIAGRAM

1. Distributor
2. Amplifier
3. HT coil
4. To ECU
5. To tachometer
6. To ignition switch

## SYSTEM DESCRIPTION

The constant energy electronic ignition system employs output current limiting and variable dwell for optimum performance. A long dwell is provided at high speeds for adequate energy storage in the coil, and a dwell is provided at low speeds for minimum power dissipation. The output current limiting function of the amplifier maintains the coil storage energy for spark, and consequently the system open circuit output voltage constant over a wide engine speed range. It eliminates the need for a ballast resistor whilst ensuring that the correct coil current flows at all times, even when cranking. No current flows through the HT coil when the ignition is switched on but the engine is stationary.

The distributor incorporates a standard automatic advance system, anti-flash shield, rotor arm and cover but the contact breaker is replaced by a reluctor and pick-up assembly.

The reluctor is a gear-like component and it is mounted on the distributor shaft in place of the cam. The pick-up consists of a winding around a pole piece attached to a permanent magnet.

The distributor is prewired with two leads terminating in a moulded two-pin inhibited connector.

When a reluctor tooth passes across the pick-up limb, the magnetic field strength around the pick-up winding is intensified creating a voltage in the winding. The rise and fall of this voltage is sensed by the amplifier and is used to trigger the transistorised output stage of the amplifier which switches on and off the current flowing in the primary winding of the ignition coil.

The amplifier assembly consists of a solid state electronic amplifier module, a zenor diode to protect the amplifier in the event of a current surge, a suppression capacitor, and a moulding containing two resistors.

The amplifier module is a sealed unit containing 'BERYLIA'.

**WARNING: THIS SUBSTANCE IS EXTREMELY DANGEROUS IF HANDLED. DO NOT ATTEMPT TO OPEN THE AMPLIFIER MODULE.**

The engine speed signal for the electronic control unit and the tachometer is derived from the HT coil negative terminal. The voltage wave form at this point can reach as much as 400 volts when a spark is generated. It is desirable to suppress this voltage before feeding it into the wiring harness to the electronic control unit and the tachometer. The two resistors located in the moulding serve this purpose (3 and 4, Fig. 30).




Fig. 29

### KEY TO DISTRIBUTOR (45 DM6)

1. HT cover
2. Rotor
3. Flash shield
4. Reluctor
5. Pick-up
6. Vacuum




Fig. 30

**KEY TO AMPLIFIER ASSEMBLY**

1. Amplifier module
2. Surge protection diode
3. Resistor to ECU
4. Resistor to tachometer

5. Suppression capacitor
6. HT coil
7. To tachometer
8. To ECU
9. To ignition switch

**TESTING****Test 1****Battery Hydrometer Readings**

Take specific gravity readings of the electrolyte in each cell. A reading of below 1.230 — Recharge battery or substitute with a charged battery.




Fig. 31

**Test 2**

Remove the HT lead from the centre of the distributor cap and hold the lead approximately 6 mm (0.25 in) from the engine (Fig. 31). Crank the engine. If a good spark is obtained, check the HT leads, spark plugs and distributor cap.

To check the rotor, remove the distributor cap and hold the HT lead 3 mm (0.13 in) from the rotor arm (Fig. 32). Crank the engine. If a spark is obtained, the rotor is defective and should be renewed.




Fig. 32

**Test 3**

With the ignition switched on, the voltage at the HT coil positive terminal (Fig. 33) should be battery voltage. If the voltage is more than one volt less than the battery voltage, check the wiring to/from the ignition switch, the ignition switch and connections.




Fig. 33

**Test 4**

With the ignition switched on, the voltage at the HT coil negative terminal should be battery voltage or not more than one volt less than battery voltage (Fig. 34).




Fig. 34

If a zero or low reading is obtained, disconnect the lead to the amplifier from the negative terminal of the HT coil (Fig. 35). If the reading is still too low, or zero, a faulty HT coil primary winding is indicated. Should the reading be battery voltage, check the wiring to/from the ECU, the tachometer if found to be satisfactory the amplifier is suspect.




Fig. 35



**Test 5**

Disconnect the distributor pick-up leads from the amplifier and measure the resistance of the distributor pick-up coil (Fig. 36). The resistance should be 2.2 to 4.8 K ohms. An incorrect reading indicates a faulty distributor pick-up coil.




Fig. 36

**Test 6**

Connect a voltmeter between the positive terminal of the battery, and the negative terminal of the HT coil (Fig. 37). Switch the ignition on and the voltmeter should indicate a zero reading. A 12 volt reading indicates an earth on the tachometer or ECU leads or a faulty amplifier. Crank the engine and the voltmeter should rise to between 2 and 3 volts. If the voltmeter remains at zero the amplifier is suspect.




Fig. 37

During normal service the air gap between the reluctor and the pick-up module does not alter and will only require re-setting if it has been tampered with. If it is necessary to adjust the gap, then it should be set such that the minimum clearance between the pick-up and the reluctor teeth is not less than 0.20 mm (0.008 in). The gap should not be set wider than 0.35 mm (0.014 in). The air gap is measured between a reluctor tooth and the pick-up module (1, Fig. 38) and should be checked with a plastic feeler gauge.




Fig. 38

The use of a metal feeler gauge may result in a misleading gauge reading due to the pick-up module contacts being magnetic. However, their use will not affect the electrical operation of the pick-up module.

**AMPLIFIER****Renew**

Disconnect the battery earth lead. Remove the two bolts securing the amplifier to the radiator top rail. Disconnect the distributor pick-up multi-plug from the amplifier. Disconnect the tachometer and ECU cable connectors. Disconnect the amplifier Lucas connectors from the HT coil. Remove the clip holding the cable harness to the radiator top rail, carefully pull the cables through the grommet in the top rail and remove the amplifier (Fig. 39).




Fig. 39

**IGNITION SWITCH****Renew**

Disconnect the battery earth lead. Remove the driver's side dash casing. Remove the screw securing the shroud to the fascia (1, Fig. 40) and the instrument module surround. Slacken the screws securing the shroud to the mounting bracket.

Ease the shroud clear of its location to gain access to the grub screw securing the switch.

Slacken the grub screw (2, Fig. 40) ease the switch and harness clear of location.

Disconnect the block connector and remove the switch unit (3, Fig. 40).




Fig. 40

**IGNITION COIL****Renew**

Disconnect the battery earth lead. Disconnect the HT lead from the centre of the ignition coil. Note the position of and disconnect the LT leads from the positive and negative terminals of the ignition coil. Remove the bolts securing the coil to the wing valance and remove the coil.

**DISTRIBUTOR****Renew**

Disconnect the battery earth lead. Remove the distributor cap and note the position of the rotor arm. Disconnect the vacuum pipe and the amplifier cable harness multi-plug. Remove the mounting plate securing screw and carefully withdraw the distributor. On refitting ensure that the rotor arm is in the position noted when removed. To check the ignition timing, run the engine until the normal operating temperature is reached. Disconnect the vacuum pipe. Run the engine at 2000 rpm with the aid of a stroboscope, adjust the timing to 18° BTDC NAS or 21° BTDC European.

**Overhaul**

With the distributor removed from the vehicle:

Remove the rotor arm (1 Fig. 41) and the flash shield (2, Fig. 41).

With the use of circlip pliers, remove the circlip (3, Fig. 41).

Lift off the washer, 'O' ring, reluctor and coupling ring (4, Fig. 41).

Remove the two screws securing the vacuum unit and with a downward movement detach the vacuum unit (5, Fig. 41) from the peg on the underside of the pick-up plate.

Remove the two screws holding the base plate in position and lift off the plate complete with pick-up and leads.

On re-assembly, lightly smear the bearing surfaces of base and pick-up plate with grease.

After re-assembly, apply one or two drops of clean engine oil to the felt pad in the top of the reluctor carrier.




Fig. 41

## IGNITION CONTROLLED RELAY

### Renew

Disconnect the battery earth lead.  
Remove the driver's side dash liner.  
Locate and remove the ignition controlled relay from the component panel (1, Fig. 42).




Fig. 42

## HEADLAMPS North American specification




Fig. 43

### KEY TO DIAGRAM

- |                             |  |
|-----------------------------|--|
| 1. Master light switch      | 9. RH dip beam                             |
| 2. To battery terminal post | 10. LH dip beam                            |
| 3. Headlamp dip relay       | 11. RH main beam                           |
| 4. Dip switch               | 12. LH main beam                           |
| 5. RH dip beam fuse         | 13. Earth point on radiator top rail       |
| 6. LH dip beam fuse         | 14. Earth point on steering column bracket |
| 7. RH main beam fuse        | 15. Main beam warning light                |
| 8. LH main beam fuse        |  |

## HEAD AND FOG LAMPS

With the master light switch in the headlamp position the contacts A, B, C and E are connected together to supply power to the headlamp relay. The headlamp flash switch activates the headlamp relay which in turn selects the main or dip headlamp filaments.

When the rear fog guard lamps are selected contacts A, B, D and E are connected together supplying power to the rear fog guard lamps.

The headlamp inhibit relay is also energised supplying current to the headlamp dip filaments only.

The headlamp flash switch activates the headlamp relay, supplying current to the headlamp main filaments.

### Fault finding

Check the fuses and all connections. The

earth connections should be clean and tight. With the master light switch in the off position battery voltage should be obtained at terminal 81a of the headlamp relay. Short terminal 31b to earth and battery voltage should then be obtained at terminal 56a the headlamp main beam terminal. Should a zero reading be obtained replace the relay. With the master light switch in the headlamp on position battery voltage should be obtained at terminal 56. By shorting terminal 31b on and off to earth, the relay should switch battery voltage alternately to terminals 56a and 56b. The main and dip beam headlamp terminals. With master light switch in the fog-lamp position battery voltage should be obtained at terminals 85, 87 and 30/51 of the headlamp inhibit relay. If battery voltage is present at terminals 85 and 30/51 but not at terminal 87 replace the relay.





### KEY TO DIAGRAM

1. Master light switch
2. Headlamp inhibit relay
3. Headlamp flash switch
4. Headlamp relay
5. Terminal post
6. Main beam warning lamp
7. Fuse No. 2
8. LH main beam
9. Fuse No. 4

10. RH main beam
11. Fuse No. 3
12. LH dip beam
13. Fuse No. 5
14. RH dip beam
15. Fog lamp warning lamp
16. Fuse No. 6
17. To terminal post
18. Fog lamp switch

19. Fuse No. 1
20. LH front fog lamp (where fitted)
21. RH front fog lamp (where fitted)
22. LH rear fog lamp
23. RH rear fog lamp
24. Earth point radiator top rail
25. Earth point on steering column bracket

## HEADLAMP

### European specification

## Renew

Disconnect the battery earth lead. Remove the screws securing the top finisher to the top of the lamp housing (1, Fig. 45), then ease the top of the finisher away from the lamp unit and lift the bottom locating spigots from the housing (2, Fig. 45). Depress the nylon securing tabs retaining the lamp unit (1, Fig. 46). Withdraw the unit from its housing and disconnect the cable harness at the block connectors behind the unit (2, Fig. 46).



Fig. 45



Fig. 46

## HEADLAMP

North American specification

## Renew

Remove the three screws securing the finisher and remove the finisher.  
Remove the six screws securing the assembly and disconnect the cable harness at the block connectors at the rear of the sealed beam units.  
Remove the assembly.

For European cars, to renew bulb, release the clips securing the defective bulb (Fig. 47) and withdraw the bulb. On refitting the new bulb, ensure the bulb is not touched by hand or contaminated with oil or grease.




Fig. 47

The light unit on NAS cars is removed by slackening the three screws securing the light unit retaining ring (1, Fig. 48).



Fig. 48

Remove the ring by turning until it releases from the locating slots. Withdraw the light unit and disconnect the cable harness block connector from the rear of the unit (1, Fig. 49).




Fig. 49

## HEADLAMP ALIGNMENT

Headlamp beam setting should only be carried out with approved beam setting apparatus.

## Adjustment

The adjustment screws are set diagonally opposite each other. The upper screw is for vertical alignment and the lower screw is for horizontal alignment. With the headlamp rim finisher removed, turn the top screw anti-clockwise to lower the beam, clockwise to raise the beam. Turn the lower screw anti-clockwise to move the beam to the left, clockwise to move the beam to the right.

## HEADLAMP RELAY

### Renew

Disconnect the battery earth lead. Note the position of the cables at the Lucar connectors on the relay, then disconnect the cables. Remove the screws securing the relay, and retain the relay. On refitting, ensure that all connectors are clean and tight.

## MASTER LIGHTING SWITCH

### Renew

Disconnect the battery earth lead. Remove the driver's side dash liner and remove the screw securing the switch shroud to the fascia (1, Fig. 50). Slacken the screws securing the shroud to the lower mounting bracket, and ease the shroud clear to give access to the spring loaded pin retaining the switch knob (2, Fig. 50). Depress the pin and withdraw the knob. Remove the shroud, remove the nut securing the switch (3, Fig. 50). Remove the switch and disconnect the cable harness block connector.




Fig. 50

## HEADLAMP INHIBIT RELAY

### Renew

Disconnect the battery earth lead. Remove the driver's side dash liner. Locate the relay and remove the relay from the component panel (1, Fig. 51).




Fig. 51

## FRONT AND REAR PARKING LAMPS

With the master light switch in the parking lamp on position current flows to the lamp via the switch contacts A and B, the bulb failure units and fuses.

The current flowing through the bulb failure units will cause the bulb failure warning lamp to glow for 15 to 30 seconds. If the warning lamp fails to go out, then there is a bulb failure or a circuit fault in the front parking lamp, rear lamps, or number plate lamps.

The contact C on the master light switch supplies current to the panel, cigar lighter and selector illumination lamps via fuse (5, Fig. 52).

### Fault finding

Check the fuses and all connections, ensuring the earth connections are clean and tight.

With the master light switch in the parking lamp on position, battery voltage should be obtained at the B and the L terminals of the bulb failure unit.

If battery voltage is obtained at the B terminal but a zero reading at the L terminal replace the bulb failure unit.

## FRONT AND REAR PARKING LAMP CIRCUIT




Fig. 52

## KEY TO DIAGRAM

- |                               |   |   |
|-------------------------------|---|---|
| 1. Switch and clock lamps     | 13. To caravan socket                       | 25. Rear lamp in-line fuse  |
| 2. To panel lamps             | 14. To stoplamp bulb failure unit           | 26. RH number plate lamp  |
| 3. Fibre optic lamp           | 15. Warning lamp blocking diode             | 27. RH rear lamp  |
| 4. Panel light rheostat       | 16. Warning lamp                            | 28. LH number plate lamp  |
| 5. Fuse                       | 17. Warning lamp blocking diode             | 29. LH rear lamp  |
| 6. Cigar lighter lamp         | 18. RH rear bulb failure unit               | 30. LH front parking lamp   |
| 7. Gearbox selector lamp      | 19. LH rear bulb failure unit               | 31. To side marker lamp (if fitted)                                       |
| 8. To headlamp relay          | 20. LH front parking lamp bulb failure unit | 32. RH front parking lamp   |
| 9. Master light switch        | 21. RH front parking lamp bulb failure unit | 33. To side marker lamp (if fitted)                                       |
| 10. To headlamp inhibit relay | 22. Fuse                                    | 34. Earth point in luggage compartment between the battery and wheel arch |
| 11. To terminal post          | 23. Fuse                                    | 35. Earth point radiator top rail   |
| 12. To caravan socket         | 24. Rear lamp in-line fuse                  |   |

## PARKING LAMP BULB

## Renew

European specification.  
Disconnect the battery earth lead.  
Remove the headlamp assembly, withdraw the bulb holder from the mounting in the reflector (1, Fig. 53) and remove the bulb.




Fig. 53

## PARK LAMP WARNING SENSOR

## Renew

Disconnect the battery earth lead.  
Remove the passenger side dash liner.  
Locate and remove the sensor (1, Fig. 53A).




Fig. 53A

J86 243/2

FLASHER INDICATOR CIRCUIT




Fig. 54

J86 121/1

KEY TO DIAGRAM

- |                     |                             |  |
|---------------------|-----------------------------|--|
| 1. Hazard switch    | 9. RH front indicator lamp  | 17. To fuse No. 5                          |
| 2. Flasher unit     | 10. RH rear indicator lamp  | 18. To acoustic unit                       |
| 3. Flasher switch   | 11. LH rear indicator lamp  | Australia only                             |
| 4. Blocking diode   | 12. LH front indicator lamp | 19. Caravan socket                         |
| 5. LH warning lamp  | 13. LH repeater lamp        | 20. Caravan socket                         |
| 6. Blocking diode   | 14. Hazard warning lamp     | 21. Earth points on radiator top rail      |
| 7. RH warning lamp  | 15. Fuse No. 2              | 22. Earth point on steering column bracket |
| 8. RH repeater lamp | 16. To terminal post        |  |

FLASHER LAMPS

Description

With the ignition switched on and the LH flasher lamps selected, current flows at the appropriate flash rate from fuse No. 5 to the flasher lamps via the hazard switch, flasher unit and the flasher switch. The warning light is supplied with flashing signal via the C terminal on the flasher unit. The circuit to earth for the warning light is diode 6 and the RH flasher lamps.

When the hazard lamps are selected terminals C and D in the hazard switch are connected. The terminals D and G are disconnected. Terminals A, B, E and F are connected together. This allows current to flow to all the flasher lamps via fuse No. 2, the hazard switch and the flasher unit.

Fault finding

Check the fuse and all connections ensuring the earth connections are clean and tight. With the ignition switched on battery voltage should be obtained at terminal 49 on the flasher unit. If a zero reading is obtained check the wiring to/from the hazard lamp switch and the hazard lamp switch itself.


With the ignition switched on and the flasher lamps switched on to either right or left hand. Bridge terminals 49 and 49A together with an ammeter. If the lamps now illuminate and the ammeter registers approximately 3.5 amps replace the flasher unit.

Should the lamps still fail to illuminate check the flasher switch and wiring.

HAZARD FLASHER/TURN SIGNAL UNIT

Renew

Disconnect the battery earth lead. Remove the driver's side dash liner. Locate the flasher unit (1, Fig. 55) and remove from the multi-pin cable harness connector.



J86 242/5

Fig. 55



## SIDE MARKER LAMP ASSEMBLY LENS AND BULB

### Renew

Disconnect the battery earth lead. Withdraw the lens retaining screw; remove the lens and the bulb.

Remove the securing nuts and washers from the captive retaining screws inside the wheel arch.

Disconnect the cable from the snap connectors and remove the assembly from the wing (Fig. 56).




Fig. 56

## TAIL STOP AND FLASHER LAMP ASSEMBLY LENS AND BULBS

### Renew

Disconnect the battery earth lead. Remove the securing screws from the lens, and remove the lens (Fig. 57).

Remove the appropriate bulb.

Remove the three nuts and washers from the rear of the assembly.

Withdraw the assembly to gain access to the cable connectors.

Disconnect the cable harness and remove the assembly.



Fig. 57

## FRONT FLASHER LAMP ASSEMBLY BULB

### Renew

Disconnect the battery earth lead.

Remove the two screws securing the lamp assembly (Fig. 58).

Carefully ease the lamp from the energy absorbing beam.

Disconnect the cable harness block connector and remove the lamp assembly.

The bulb can be removed by turning and withdrawing the bulb holder from the rear of the lamp assembly.

Remove the bulb from the holder.




Fig. 58

## FRONT FLASHER REPEATER LAMP ASSEMBLY — LENS AND BULB (where fitted)

### Renew

Disconnect the battery earth lead.

Remove the lens and the bulb (Fig. 59).




Fig. 59

Remove two screws, two nuts and bolts securing the front wheel splash guard, then remove the splash guard.

Remove the two nuts and washers from the captive retaining screws (Fig. 60).

Disconnect the cables from the snap connectors and remove the lamp from the wing.



Fig. 60

## NUMBER PLATE AND REVERSE LAMP ASSEMBLY BULBS AND LENS

### Renew

Disconnect the battery earth lead.

Disconnect the cable harness connectors (1, Fig. 61).

Displace the grommets from the boot lid and feed the cable harness through them.

Remove the bolts securing the lamp assembly to the boot lid (2, Fig. 61) and ease the assembly clear of the boot.

To replace a bulb, remove the screws retaining the lens and remove the lens for access.

On refitting the lens, ensure the seal is in good condition.




Fig. 61

## INTERIOR LAMP CIRCUIT




Fig. 62

## INTERIOR LAMPS

## Description

The map lights each side of the fascia lower panel are controlled by the door switches, or when the doors are closed, the passenger side is operated by depressing the map light switch (1, Fig. 61).

The rear passenger lamps are controlled by the door switches, or when the doors are closed, by depressing the interior light switch (2, Fig. 61).

The rear passenger lamps and the map lights will remain on for approximately 10 seconds after the doors are closed. The roof lamp has 3 positions. When pressed rearwards, the light will be on all the time, irrespective of the door positions. The light will remain off when the lamp is in the centre position. In the forward position, the light will come on when either door is opened.

The courtesy lamp delay unit controls the operation of the vehicle interior lamps so that they remain on for approximately 10 seconds after the doors are closed. The puddle lamps are not affected by the delay unit and will switch on and off as the doors are opened and closed.

The delay unit is polarity conscious, but a reverse polarity connection will not result in damage to the unit.

With terminal 2 connected to a positive supply via the fuse No. 13 and terminal 3 connected to earth. When terminal 1 is earthed via a door switch a transistor charges a capacitor in a timing circuit which joins terminals 3 and 4 together via an internal relay. When terminal 1, earth circuit, is broken (a door closed) the capacitor commences to discharge turning

off the relay at the end of the prescribed period which in turn switches off the interior lamps.

Power is supplied to the rear passenger lamps via the map and interior lamp switches. Power supplied to the driver's lamp via the map lamp switch. The roof lamp, front passenger lamp and the puddle lamps are supplied with power from the fuse. The circuit to earth for the rear passenger lamps is through the interior lamp switch and the delay unit. The circuit to earth for the driver and passenger lamps is through the delay unit. With the interior lamps switched on by the panel switch the delay unit is by-passed and therefore the delay unit will not operate.

## Fault finding

Check the fuse and all connections ensuring the earth connections are clean and tight. Battery voltage should be obtained at terminal 2 of the delay unit. If the voltage is satisfactory bridge terminal 1 of the delay unit to earth. If the interior lamps now illuminate, check the door switches, and the wiring to the door switches. If the lamps still operate unsatisfactorily bridge terminals 3 and 4 together on the delay unit. Should the lamps now illuminate replace the delay unit.

## KEY TO DIAGRAM

1. Map light switch
  2. Interior light switch
  3. Fuse No. 13
  4. To terminal post
  5. Delay unit
  6. LH door switch
  7. RH door switch
  8. Blocking diode
  9. Puddle lamp
  10. Puddle lamp
  11. Front passenger lamp
  12. Driver's lamp
  13. Roof lamp
  14. Rear passenger lamp
  15. Rear passenger lamp
- Earth points behind fascia passenger's side

## ROOF LAMP ASSEMBLY AND BULB

## Renew

Disconnect the battery earth lead. Prise the lamp assembly from the mounting in the headlining and clear of the aperture. Remove the shroud from the rear of the lamp, and remove the bulb. Disconnect the electrical connectors from the lamp terminals and remove the lamp assembly (Fig. 63).




Fig. 63

## REAR PASSENGER AND MAP LAMPS AND BULBS

## Renew

Disconnect the battery earth lead. Prise the appropriate lamp from its location and clear of the aperture. Remove the bulb. Disconnect the electrical connections and remove the lamp (Fig. 63).

## LUGGAGE COMPARTMENT LAMPS AND BULBS

### Renew

Disconnect the battery earth lead.  
Prise the lamp from its retaining bracket.  
Remove the bulb.  
Disconnect the electrical connections and remove the lamp.

## OPTICELL UNIT AND BULB

### Renew

Disconnect the battery earth lead.  
Remove the three screws securing the console centre panel and lift the panel clear of the console.

To allow full movement of the panel, note the position of the cables to the switches and the cigar lighter, and disconnect the cables.

The bulb holder can now be prised from the rear of the opticell unit and the bulb removed (1, Fig. 64).

Remove the nuts securing the opticell mounting bracket and lift the assembly clear (2, Fig. 64).

Disconnect the fibre elements and the opticell electrical cables (3, Fig. 64).

Remove the two screws retaining the opticell unit and remove the unit from the bracket.




Fig. 64

J86-272

## INSTRUMENT ILLUMINATION BULB

### Renew

Disconnect the battery earth lead.  
Remove the instrument panel module.  
Pull the appropriate bulb holder from the module and remove the bulb.

## CLOCK ILLUMINATION BULB

### Renew

Disconnect the battery earth lead.  
Prise the clock from the fascia.  
Pull the bulb holder from the clock and remove the bulb.

## PANEL SWITCH ILLUMINATION BULB

### Renew

Disconnect the battery earth lead.  
Carefully prise the switch mounting panel from the fascia.  
Pull the bulb holder from the diffuser and remove the bulb.

## STARTER SYSTEM

### Starter circuit test

#### Checking for excessive voltage drop in the starter circuit

If tests have proved that the battery and the battery connections are satisfactory, a moving coil voltmeter (0 to 20 volt range) should be used to determine whether there is excessive voltage drop in the circuit.


**NOTE:** During the voltmeter checks, the starter should crank the engine, without starting it.

The low-tension circuit of the ignition coil should be disconnected between the coil and distributor.

To prevent fuelling while the engine is cranked the pump relay should be disconnected.

### Test 1


Check all connections ensuring the earth connections are clean and tight.



J86 179

Fig. 66

## STARTER SYSTEM CIRCUIT



J86 124/1

Fig. 65

### KEY TO DIAGRAM

1. Battery
2. Starter motor
3. Ignition/starter switch
4. Starter relay
5. Ignition controlled protection relay
6. Gearbox safety switch
7. To the ECU
8. To the HT coil
9. To fuse No. 12
10. Earth point in luggage compartment
11. Earth point on steering column bracket
12. Earth point through the unit

**Test 2****Checking the battery terminal voltage under load conditions**

Connect the voltmeter across the battery terminals (Fig. 67) and operate the starter switch. The reading should be about 10.0 volts. Proceed to Test 3.

A low voltage reading would indicate excessive current flow in the circuit. The starter should be removed for bench testing.




Fig. 67

**NOTE:** If the solenoid operates intermittently during the test or the engine is cranked at a low or irregular speed, there is insufficient voltage at the solenoid operating winding terminal or the solenoid is faulty.

To check the switching circuit for high resistance, connect the voltmeter between the solenoid operating winding terminal and earth (commutator end bracket) (Fig. 68).

When the switch contacts are closed the reading on the voltmeter should be slightly less than the reading in Test 2. A satisfactory reading will indicate that there is a negligible voltage drop in the circuit and that the fault is in the solenoid.




Fig. 68

If the reading is appreciably lower than in Test 2, check the starter relay, wiring and connection in the starter motor switching circuit.

**Test 3****Checking the starter terminal voltage under load conditions**

Having ascertained the battery voltage under load, the voltage across the starter is checked with the voltmeter connected between the starter input terminal and earth

(commutator end bracket) (Fig. 69). When the operating switch is closed, the reading should be not more than 0.5 volt below that obtained in Test 2.




Fig. 69

If the reading is within this limit, the starter circuit is satisfactory. If there is a low reading across the starter, but the voltage at the battery is satisfactory, it indicates a high resistance in the cable or at the solenoid contacts. Proceed to Test 4.

**Test 4****Checking the voltage drop on the insulated line**

The voltage drop on the insulated line is then checked with the voltmeter connected between the starter input terminal and the battery (insulated) terminal (Fig. 70).




Fig. 70

When the operating switch is open, the voltmeter should register battery voltage. When the operating switch is closed, the voltmeter reading should be practically zero. A high voltmeter reading indicates a high resistance in the starter circuit. All insulated connections at the battery, solenoid and starter should be checked. Proceed to Test 5.

**Test 5****Checking the voltage drop across the solenoid contacts**

To check the voltage drop across the solenoid contacts, connect the voltmeter across the two main solenoid terminals (Fig. 71). Crank the engine.

A zero or fractional reading on the voltmeter indicates that the high resistance deduced in Test 4 must be due either to high resistance starter cables or soldered connections.

A high reading (similar to that in Test 4) indicates a faulty solenoid or connections.




Fig. 71

**Test 6****Checking the voltage drop on the earth line**

Finally, check the voltage drop on the earth line. Connect the voltmeter between the battery earth terminal and the starter earth (commutator end bracket) (as shown in Fig. 72). When the operating switch is closed, the voltmeter reading should be practically zero.




Fig. 72

**STARTER RELAY****Renew**

Disconnect the battery earth lead. Remove the relay cover. Remove the screws securing the relay and mounting plate to the wing valance. Remove the nuts and washers securing the earth terminal and the relay to the mounting plate. Note the position of the electrical connectors and disconnect from the Lucars. Recover the relay.

**STARTER MOTOR****Renew**

Disconnect the battery earth lead. Remove the air cleaner element and the air cleaner housing. Remove the LH tie bar securing bolt and displace the tie bar over the manifold. On RH drive cars, displace the windscreen washer for access.



Remove the oil dipstick bracket assembly securing bolt and remove oil dipstick assembly.

Remove the oil filter bracket securing bolt, disconnect the hose and remove the oil filter tube.

Disconnect the cables at the starter motor solenoid.

Remove the starter motor upper securing bolt, then the lower bolt, and ease the starter motor from the engine compartment. On refitting, ensure the electrical connections are clean and tight, fit new air cleaner housing gasket.

## STARTER MOTOR

### Overhaul


Remove the nuts and washers securing the starter to solenoid connecting link (1, Fig. 75).

Remove the two bolts and washers securing the solenoid to the starter fixing bracket (2, Fig. 75).

Lift the terminal end of the solenoid clear of the connecting link and withdraw the solenoid body (3, Fig. 75). Remove the plunger by applying an upward lift at the front end of the plunger (4, Fig. 75).

### Test

Check the continuity of the solenoid windings by connecting a 12 volt battery operated test lamp between the solenoid main terminal STA and an earth point on the solenoid body (as shown in Fig. 73).




J86 236

Fig. 73

If the lamp lights, it indicates that both windings are satisfactory.

Check that the contacts open and close satisfactorily by connecting a 12 volt battery and a high wattage test lamp between the main solenoid terminals (as shown in 1, Fig. 74). The lamp should not light. Close



J86 237

Fig. 74

the switch (2, Fig. 74) and energise the solenoid windings. The solenoid should be heard to operate, and satisfactory closing of the contacts will be indicated by the lamp lighting with full brilliance.

### Starter Motor Dismantle

Remove the mutator end cap seal (5, Fig. 75).

Remove the spire retaining ring using a suitable tool to remove some of the claws on the retaining ring (6, Fig. 75).

**NOTE:** Discard the spire ring, ensure a new ring is fitted on reassembling the starter motor.

Remove the two through bolts and washers (7, Fig. 75).

Withdraw the commutator end cover, taking care when disengaging the two field coil brushes (8, Fig. 75) from the brush box moulding.

Withdraw the armature and drive assembly from the field coil assembly.

Withdraw the drive engagement lever pin (9, Fig. 75) from the fixing bracket.

The armature assembly comprising the roller clutch drive and the lever assembly can now be separated from the fixing bracket.


The roller clutch drive and the lever assembly is removed from the armature shaft as a complete unit.

Use a tubular tool to drive the thrust collar squarely off the jump ring. Remove the jump ring from its groove in the armature shaft. Slide the collar and the roller clutch drive with the lever assembly off the shaft.

### Brushes

Check that the brushes move freely in their respective guides in the brush box mouldings. A sticking brush can be cleaned with a petrol moistened cloth.

Brushes which are worn to approximately 9.5 mm (0.375 in) must be renewed. To renew the brushes, cut the worn brush flexible lead from the field coil leaving approximately 6 mm (0.25 in) of flexible lead each side of the field coil end.



J86 235

Fig. 75

Solder the new brushes to the ends of the old leads to ensure a good connection. Also ensure the soldered connection is insulated from the starter motor body.

Replace the remaining two brushes complete with terminal link. Ensure the brushes are positioned exactly as originally fitted.


### Armature

Check the armature for signs of the core folding the pole shoes. This indicates worn bearings or a distorted shaft. A damaged armature must be replaced and no attempt should be made to machine the armature core or to straighten a distorted shaft. Check for signs of thrown solder or lifted commutator segments. This indicates overspeeding of the motor and the operation of the roller clutch should be checked.

The condition of the armature should be checked as follows:

Test the armature insulation by means of a 110 volt ac 15 watt test lamp. Connect the lamp between one commutator segment and the armature shaft (as shown in Fig. 76). The test lamp should not light.

If it does the insulation has broken down, and the armature must be replaced.



J86 238

Fig. 76

If the commutator needs servicing, the copper may be skimmed to a minimum thickness of 3.55 mm (0.140 in) before a replacement armature is necessary. The surface should then be polished with fine emery cloth, and finally cleaned with a petrol-moistened cloth. The insulation between the commutator segments MUST NOT BE UNDERCUT.

**Field winding, Continuity**

Check the winding for continuity by means of a 12 volt test lamp and battery. Connect the test lamp between each of the brushes in turn, and a clean part of the yoke. If the test lamp does not light, an open-circuit in the field winding is indicated and a replacement must be fitted (Fig. 77).




Fig. 77

**Insulation**

To make a positive check of the insulation between the field winding and yoke, it will be necessary to disconnect the riveted earth connection at the yoke.

To avoid disturbing this connection unnecessarily, first inspect the inside of the yoke for obvious signs of insulation breakdown, and if so, rectify or replace the field winding assembly as necessary.

The field winding insulation can be checked, after disconnecting the end of the winding at the yoke by connecting a 110 volt ac 15 watt test lamp between the disconnected end of the winding and a clean part of the yoke (Fig. 78). If the test lamp lights, it indicates an earth at some point on the yoke or pole shoes and a replacement field winding is necessary. Check that the earth connection, brush flexibles and brushes are not contacting the yoke before suspecting the field windings.




Fig. 78

**Roller clutch and drive operating mechanism**

The roller clutch drive assembly, if in good condition will provide instantaneous take-up of the drive in one direction and rotate smoothly and easily in the other. The assembly should move freely round and along the armature shaft splines without roughness or tendency to bind. The armature shaft splines and moving parts of the engagement lever should be liberally smeared with Shell SB2628 (home and cold climates), Retinax 'A' (hot climates).

The roller clutch mechanism is a sealed unit. During production it is pre-packed with sufficient grease to last the life of the starter motor. In the unlikely event of the clutch becoming faulty, it is not possible to rectify the fault and the whole drive assembly should be renewed.

**Bearings**

Both end brackets are fitted with porous bronze bearing bushes. New bushes should be allowed to stand for 24 hours at room temperature completely immersed in clean light engine oil. Alternatively, the bush may be immersed in the above lubricant at 100°C for two hours and allowed to cool before removal.

New bushes **must not be** reamed after fitting as the porosity of the bush will be impaired.

The bushes must be renewed when there is excessive side-play of the armature shaft. Fouling of the pole shoes by the armature, or inefficient operation of the starter motor is likely to occur when the inner diameter of the bushes exceeds the following dimensions:

Commutator end cover bush 11,20 mm (0.441 in).

Drive end fixing bracket bush 12,09 mm (0.476 in).

**Reassembly**

Reassembling the starter motor is the reversal of the dismantling procedure.

Ensure that the internal thrust washer is fitted at the commutator end of the armature shaft.

When the starter motor is assembled, drive on the NEW SPIRE RETAINING RING to the armature shaft into a position which provides a maximum of 0,25 mm (0.010 in) clearance between the retaining ring and the bearing brush shoulder.

Finally, fit the end cap seal to the commutator end.

## COMBINED HEADLIGHT/ DIRECTION/FLASHER/DIP SWITCH

### Renew

Disconnect the battery earth lead.

Slacken the steering column adjustment ring and extend the column to its fullest extent (1, Fig. 83).

Remove the screws securing the steering column lower shroud and remove the shroud (2, Fig. 83).

Remove the steering wheel.

Remove the screw securing the upper shroud to the bracket on the steering column.

Slacken the pinch screw (3, Fig. 83) securing the switch assembly to the steering column, and ease the switch assembly complete with the shroud.

Remove the shroud from the switch assembly and disconnect the cable harness at the block connectors.

Remove the spire nuts and screws securing the wiper switch to the mounting plate (4, Fig. 83).

Disconnect the earth cable at the snap connector (5, Fig. 83) and remove the wiper washer switch from the assembly.





Fig. 84

J86 244

## PANEL SWITCHES

### Renew

**NOTE:** This operation applies to the following: Interior light switch, map light switch, back light switch, hazard warning switch.

Disconnect the battery earth lead.

Prise the switch panel from the fascia (1, Fig. 85).

Disconnect the cable harness block connector from the appropriate switch.

Depress the retaining clips on the top and bottom of the switch (2, Fig. 85).

Push the switch through the panel.




Fig. 85

J86 267/I

## PANEL LIGHT RHEOSTAT

### Renew

Disconnect the battery earth lead.

Remove the driver's side dash liner.

Disconnect the cables at the Lucar connectors on the rheostat (1, Fig. 86).




Fig. 86

J86 232

Remove the control knob by depressing the spring loaded pin on the shaft and pulling the knob off the shaft (2, Fig. 86).

Slacken the nut securing the rheostat to the mounting bracket and remove the rheostat (3, Fig. 86).

## REVERSE LIGHT SWITCH

### Renew

Drive the vehicle onto a ramp and raise the ramp.

Disconnect the battery earth lead.

Disconnect the lucar cable connectors (1, Fig. 87).

Unscrew and remove the switch (2, Fig. 87).




Fig. 87

J86 276

## DOOR PILLAR SWITCH AND LUGGAGE COMPARTMENT LIGHT SWITCH

### Renew

Disconnect the battery earth lead.

Remove the screws securing the switch.

Withdraw the switch and disconnect the cable at the Lucar connector.




Fig. 88

J8614/1

**KEY TO DIAGRAM**

1. Warning light failure unit

2. Reservoir brake switch

3. Brake lamp warning sensor

4. Brake warning lamp

5. Oxygen warning lamp

6. Handbrake warning lamp

7. To ignition switch
8. To bulb failure warning lamp via blocking diode

9. Handbrake switch

10. To footbrake switch

11. LH stop lamp

12. RH stop lamp

13. Stop lamp bulb failure unit

14. Starter relay

Earth point for failure unit on the steering column bracket

**STOP LIGHT BULB FAILURE SENSOR**

**Renew**

Disconnect the battery earth lead. Remove the screws securing the centre panel and raise the panel for access to the bulb failure unit. Note the position of the electrical connections to the sensor unit and disconnect. Remove the screws securing the sensor and remove the sensor.

**WARNING LIGHT FAILURE UNIT**

**Description**

When the starter motor is activated a voltage supply to the warning light failure unit switches a transistor circuit to earth which completes the circuit of the oxygen warning lamp, brake warning lamp, and the handbrake warning lamp, causing the lamps to glow. This indicates that the warning lamps are operating satisfactorily. A failure of a warning lamp should be investigated immediately.

**Fault finding**

To test the warning light failure unit, switch the ignition on and short terminal 1 of the brake light failure unit to earth. The oxygen sensor warning lamp should glow. Should the warning lamp fail to glow check the warning lamp bulb, and the warning lamp supply voltage. Repeat the test at terminal 2 for the handbrake warning lamp, and terminal 3 for the brake warning lamp. If the above checks prove satisfactory replace the failure unit.

**STOP LAMP BULB FAILURE UNIT**

**Description**

The stop lamps are supplied with current via a bulb failure unit. Should the bulb failure warning lamp glow with the master light switch off, the ignition switched on, the handbrake released and the footbrake depressed, a circuit fault or a faulty bulb is indicated.

**Fault finding**

To test the stop lamp failure unit switch on the parking lamps. The bulb failure warning lamp should glow for 30 seconds this proves the warning lamp is satisfactory. Switch off the parking lamps and switch off the ignition. Remove a stop lamp bulb, release the handbrake, and depress the foot brake. The warning lamp should glow. Should the warning lamp fail to glow replace the bulb failure unit.

**WARNING LAMP BULB FAILURE UNIT**

**Renew**

Disconnect the battery earth lead. Remove the driver's side dash liner. Remove the bulb failure unit from the component panel (1, Fig. 89).




Fig. 89

J86 242/4

**WARNING LAMP BULB(S)****Renew**

Slacken the steering column adjustment ring and extend to its fullest extent.  
 Prise out the covers from each end of the warning light strip.  
 Remove the screws securing the warning lamp cover and remove the cover.  
 Remove the defective bulb.

**STOP LIGHT SWITCH****Renew**

Disconnect the battery earth lead.  
 Disconnect the electrical connectors from the Lucar connectors on the switch.  
 Remove the switch securing bolt and remove the switch.  
 On refitting, reconnect battery and switch on the ignition.  
 Adjust the switch position until the stop lights operate when the brake pedal is depressed, and off when the pedal is fully released.

**HANDBRAKE WARNING SWITCH****Renew**

Disconnect the battery earth lead.  
 Remove the screw securing the handbrake mechanism cover and slide the cover clear of the mechanism.  
 Disconnect cable harness from the Lucar connectors on the switch.  
 Remove the bolts securing switch to the handbrake assembly.  
 Remove the bolt and spacer.  
 Remove the switch.  
 On refitting, with the battery connected and the ignition switched on, adjust the switch with the handbrake until the warning light just goes out.  
 Tighten the securing bolts.  
 Check the light comes on with handbrake applied and goes off when the handbrake is released.


**SEAT BELT WARNING SYSTEM CIRCUIT**

Fig. 90

**SEAT BELT WARNING SYSTEM****Description**


The seat belt logic unit will operate an audible signal if the driver's door is open and the ignition key is inserted into the ignition switch. The signal will cease to operate if the door is closed or the key is withdrawn from the ignition.

The unit also operates two timing circuits; one of the circuits will cause the warning light to illuminate for 10 seconds when the ignition is switched on, whether the seat belt is in use or not.

The other timed circuit operates an audible signal when the ignition is switched on which will cease when the seat belt is fastened or after 10 seconds have elapsed.

**SEAT BELT LOGIC UNIT****Renew**

Disconnect the battery earth lead.  
 Remove the passenger side dash liner.  
 Remove the nut and screw securing the unit, disconnect the cable harness block connector and remove the unit (1, Fig. 91).



J86 243/5

Fig. 91

**SEAT BELT SWITCHES****Renew**

Disconnect the battery earth lead.  
 Push the seat forward as far as possible.  
 Remove the bolt securing the seat belt unit, raise the unit and ease the connector leads clear of the carpet.  
 Disconnect the cable block connector and remove the belt switch unit.




Fig. 92

**COOLING FAN**

**Description**

With the coolant temperature cool the thermostat contacts are open which prevents the cooling fan relay from being energised, this in turn prevents the cooling fan from being activated.

With the engine running and the coolant warm the thermostat contacts close. This allows the relay coil circuit to be completed via a diode in the diode pack and the thermostat contacts. The cooling fan circuit is now completed via the relay contacts.

When the ignition is switched off but the coolant temperature is still hot the cooling fan will still be activated via the relay contacts. The relay will remain energised via a diode in the diode pack, the thermostat contacts, and the relay contacts.

When the coolant temperature cools sufficiently the thermostat contacts will open and the relay will become de-energised. The relay contacts will then switch an earth to the positive brush of the cooling fan motor.

**FAN MOTOR**

**Renew**

Disconnect the battery earth lead.

Remove the nuts securing the receiver/drier to the top rail. Also remove the nut and bolt securing the RH body stay.

Displace the receiver/drier and the body stay for access.

Remove the cable harness clip from the fan motor frame.

Disconnect the fan motor cable harness block connector.

Remove the bolts securing the fan assembly and remove the assembly.

Remove the fan blades from the fan motor shaft.

Remove the fan motor from the frame assembly.

**DIODE PACK AND COOLING FAN RELAY**

**Renew**

Disconnect the battery earth lead.

Disconnect the cable harness block connector from the appropriate unit, and withdraw the unit from its locating tab on the LH wing valance in the engine compartment.

**LOW COOLANT CONTROL UNIT**

**Description**

With a positive supply to the white wire on the control unit and the black wire earthed, the sensor will partially earth through the




Fig. 93

coolant and the warning lamp will glow for a few seconds then go out. If the coolant falls below the sensor level the partial earth circuit will be broken and the warning lamp will flash on and off.

### Fault finding

Should the warning lamp fail to glow when the ignition is switched on, check all connections and the fuse, ensuring the earth connections are clean and tight.

With the ignition switched on battery voltage should be obtained from the white lead on the control unit. With the white and blue lead from the warning lamp shorted to earth, switch the ignition on and the low coolant warning lamp should glow. Should the lamp fail to glow check the warning lamp bulb and wiring.

With the white and red lead from the sensor unit disconnected, the ignition switch on the warning lamp should flash on and off. Should the lamp fail to flash replace the control unit.

### LOW COOLANT WARNING CONTROL UNIT

#### Renew

Disconnect the battery earth lead.

Remove the passenger side dash liner.

Remove the unit from its locating clip and disconnect the cable harness block connector (1, Fig 94).




Fig. 94

### ELECTRICALLY OPERATED DOOR MIRRORS

#### Description

The RH and LH mirror controls are located on the driver's door. The horizontal and the vertical motors are operated from one control switch. With the control switch in the up position the current flow to motor 3 is via the outer ring A and contact D. The earth circuit is via contact F and the inner ring B.

With the switch in the down position the circuit is completed in the opposite direction via the outer ring A and contact F. The circuit to earth is completed via the contact D and the inner ring B. Similar current flow takes place when the control is operated in a horizontal position using the contact C, E and the motor 2.

### FUEL CUT-OFF INERTIA SWITCH

#### Reset

The inertia switch is fitted in the electrical supply to the fuel pump. Should the car be subjected to heavy impact forces, the switch will operate, isolating the fuel pumps and ensuring fuel is not pumped to a potentially dangerous area. The switch is located on the side of the fascia on the driver's side 'A' post. Press the button mounted on top of the switch to reset after operation.

### INERTIA CUTOUT SWITCH

#### Renew

Disconnect the battery earth lead.

Remove the cover from the inertia switch.

Disconnect the cables from the switch.

Withdraw the screws securing the switch and remove the switch.

### ELECTRIC DOOR MIRROR CIRCUIT




Fig. 95

#### KEY TO DIAGRAM

1. RH mirror switch
2. RH mirror vertical motor
3. RH mirror horizontal motor
4. LH mirror horizontal motor
5. LH mirror vertical motor
6. LH mirror switch
7. To fuse

Earth points behind the fascia

## OVERCHARGE WARNING LIGHT CIRCUIT




Fig. 96

## OVERCHARGE WARNING LIGHT CONTROL UNIT

## Description

With the ignition switched on the earth circuit of the overcharge voltage lamp is completed via the internal circuit of the overcharge voltage control unit.

The control unit circuit will illuminate the warning light to indicate a malfunction in the alternator. The alternator control box will be suspect by not controlling the output of the alternator and cause the alternator to overcharge the battery.

## OVERCHARGE CONTROL UNIT

## Renew

Disconnect the battery earth lead.  
Remove the driver's side dash liner.  
Disconnect the cable harness from the unit.  
Remove the nut and screw securing the unit.  
Remove the warning light control unit (1, Fig. 97).




Fig. 97

## HEATED REAR SCREEN

## Description

The timer unit switches off the heated rear screen circuit approximately ten minutes after the heated rear screen circuit has been switched on. The timer resets whenever the circuit is switched off or when the ignition is switched off.

A small relay, and the electronic components are mounted on a circuit board inside a yellow thermoplastic cover.

The unit is polarity conscious but reverse polarity connection will not result in damage.

The terminal 2 is connected to a positive supply via fuse 12, terminal 3 is connected to earth. When terminal 1 is switched to earth by the control switch the relay is energised connecting terminals 2 and 4 together, thus supplying power to the heated rear screen, heated door mirrors and the warning light. When the timing cycle is completed the relay is de-energised and the relay contacts open.

## Fault finding

Check the fuse and all connections ensuring the earth connections are clean and tight. With the ignition switched on and a voltmeter connected between a good earth and terminal 2 of the relay, the voltmeter should indicate battery voltage. With the ignition switched on, the heated rear screen switched on and the voltmeter connected between terminals 1 and 2 of the relay, the voltmeter should indicate battery voltage. If a satisfactory reading was obtained in the first check but a zero reading is obtained in the second check, check the wiring to/from the control switch and the control switch itself. With the ignition and the heated rear screen switched on battery voltage should be obtained at terminal 4 of the relay. If terminal 4 gives a zero reading and the previous tests are satisfactory replace the relay.

## HEATED REAR SCREEN CIRCUIT




Fig. 98

## KEY TO DIAGRAM

1. Delay unit
  2. Control switch
  3. Fuse
  4. To ignition switch protection relay
  5. Warning lamp
  6. Heated rear screen
- Earth point for heated rear screen adjacent to the battery

## HEATED REAR SCREEN DELAY UNIT

## Renew

Disconnect the battery earth lead.  
Remove the driver's side dash liner.  
Disconnect the multi plug connector and remove the delay unit (1, Fig. 99).




Fig. 99



## CIGAR LIGHTER

## Renew


Disconnect the battery earth lead.  
Remove the screws securing the centre panel to the console.

Raise the panel for access to the cigar lighter assembly and disconnect the electrical connectors from the assembly (1, Fig. 100).

Remove the lamp holder by depressing the sides and unclipping from the cigar lighter (2, Fig. 100).

Unscrew and remove the cigar lighter lower sleeve (3, Fig. 100).

Remove the cigar lighter (4, Fig. 100).



J86 245

Fig. 100

## AERIAL

## Circuit

The aerial maintains its extended position for a period of 10 seconds after the radio has been switched off. The aerial will then retract. If the radio is switched on before the 10 seconds has elapsed, the aerial will remain in the extended position.


With terminal 1 of the relay connected to a positive supply via fuse 5 and terminal 2 connected to earth. The positive supply from the radio to terminal 3 of the relay turns on a transistor which charges a capacitor in a timing circuit. It also activates a relay which connects terminals 1 and 5. This allows current to flow to the aerial motor and thus drive the aerial to the extended position. On switching the aerial off the aerial will remain extended for a period of 10 seconds then the relay will become de-activated the contact between terminals 1 and 5 will become disconnected, but the contact will be made between terminals 1 and 4. This will allow current to flow to the aerial motor to retract the aerial.

## Fault finding

Should the aerial fail to extend when the radio is switched on.

Check the fuse and all connections ensuring the earth connections are clean and tight. Battery voltage should be obtained at terminals 1 and 3 of the delay unit. If the battery voltage is obtained bridge the leads from terminals 1 and 5 together. Should the aerial now extend replace the delay unit.

## RADIO, CLOCK AND LUGGAGE COMPARTMENT LAMPS CIRCUIT



## KEY TO DIAGRAM

1. Clock
  2. Line fuse
  3. Radio
  4. Aerial motor
  5. Delay relay
  6. Boot lamps switch
  7. Boot lamps
  8. Fuse No. 3
  9. Terminal post
  10. To ignition switch
- Earth point adjacent to the battery

Fig. 101

J86-125




Fig. 102

**COMPONENT LOCATION KEY**

- |   |   |  |
|---|---|--|
| 1. Main fuse box                          | } | Component<br>Panel-A<br>Driver's Side  |
| 2. Heated rear screen delay unit          |   |  |
| 3. Headlamp inhibit relay                 |   |  |
| 4. Ignition protection relay              |   |  |
| 5. Warning light bulb check unit          |   |  |
| 6. Direction indicator flasher unit       |   |  |
| 7. Voltage over-charge warning light unit | } | Component<br>Panel-B<br>Passenger Side |
| 8. Door lock thermal circuit breaker      |   |  |
| 9. Low coolant warning light control unit |   |  |
| 10. Seat belt logic unit                  |   |  |
| 11. Interior light delay unit             |   |  |
| 12. Auxiliary fuse box                    |   |  |
| 13. Windscreen wiper delay unit           |   |  |
| 14. Speed control unit (if fitted)        |   |  |
| 15. Window lift relay                     |   |  |
| 16. Front parking lamp bulb failure unit  |   |  |
| 17. Window lift thermal circuit breaker   |   |  |
| 18. Door lock relay                       |   |  |
| 19. Door unlock relay                     |   |  |
| 20. Stop lamp bulb failure unit           |   |  |

## COMPONENT LOCATION — LUGGAGE COMPARTMENT




Fig. 103

## COMPONENT LOCATION KEY

1. LH rear bulb failure unit
2. LH rear lamp in-line fuse
3. Electronic control unit (ECU)
4. Main relay
5. Pump relay
6. Interface unit
7. RH rear bulb failure unit
8. RH rear lamp in-line fuse
9. Aerial motor
10. Aerial motor delay unit
11. Fuel pump
12. Caravan socket

## COMPONENT LOCATION — ENGINE COMPARTMENT




Fig. 104

## COMPONENT LOCATION KEY

1. Headlamp relay
2. Cooling fan diode pack
3. Horn relay
4. Cooling fan relay
5. Overdrive inhibit relay
6. Headlamp fuse box
7. Ballast resistors
8. HT coil
9. Super heat switch thermal fuse
10. Feedback relay
11. Starter relay
12. Horns

## MAIN FUSE BOX — LH Steering

| Fuse No. | Protected Circuit  | Fuse Capacity | Unipart Number |
|----------|--|---------------|----------------|
| 1.       | Front fog lights   | 20A           | GFS240         |
| 2.       | Hazard warning, seat belt logic                                | 15A           | GFS415         |
| 3.       | Clock, aerial, caravan, boot lamp                              | 35A           | GFS435         |
| 4.       | Panel instruments, reverse light                               | 10A           | GFS410         |
| 5.       | Direction indicators, stop lamps, auto kick down switch        | 15A           | GFS415         |
| 6.       | Fog rear guard   | 10A           | GFS410         |
| 7.       | Panel/cigar lighter/selector illumination                      | 10A           | GFS410         |
| 8.       | Door locks, electric mirrors                                   | 3A            | GFS43          |
| 9.       | Wipers   | 35A           | GFS435         |
| 10.      | Air conditioning motors  | 50A           | GFS450         |
| 11.      | Air conditioning controls, horn, washers, radiator cooling fan | 35A           | GFS435         |
| 12.      | Heated rear screen, heated mirrors                             | 35A           | GFS435         |

## MAIN FUSE BOX — RH Steering

| Fuse No. | Protected Circuit  | Fuse Capacity | Unipart Number |
|----------|--|---------------|----------------|
| 1.       | Cigar lighter  | 20A           | GFS420         |
| 2.       | Hazard warning, seat belt logic                                | 15A           | GFS415         |
| 3.       | Clock, aerial, caravan, boot lamp                              | 35A           | GFS435         |
| 4.       | Panel instruments, reverse light                               | 10A           | GFS410         |
| 5.       | Direction indicators, stop lamps, auto kick down switch        | 15A           | GFS415         |
| 6.       | Fog rear guard   | 10A           | GFS410         |
| 7.       | Panel/cigar lighter/selector illumination                      | 10A           | GFS410         |
| 8.       | Door locks, electric mirrors                                   | 3A            | GFS43          |
| 9.       | Wipers   | 35A           | GFS435         |
| 10.      | Air conditioning motors  | 10A           | GFS410         |
| 11.      | Air conditioning controls, horn, washers, radiator cooling fan | 35A           | GFS435         |
| 12.      | Heated rear screen, heated mirrors                             | 35A           | GFS435         |

## HEADLAMP FUSE BOX

| Fuse No. | Protected Circuit                          | Fuse Capacity | Unipart Number |
|----------|--|---------------|----------------|
| 1.       | Radiator auxiliary cooling fan motor relay | 25A           | GFS425         |
| 2.       | LH main beam                               | 25A           | GFS425         |
| 3.       | LH dip beam                                | 10A           | GFS410         |
| 4.       | RH main beam                               | 25A           | GFS425         |
| 5.       | RH dip beam                                | 10A           | GFS410         |

**AUXILIARY FUSE BOX — RH Steering**

| Fuse No. | Protected Circuit             | Fuse Capacity | Unipart Number |
|----------|-------------------------------|---------------|----------------|
| 13.      | Interior and map lights ..... | 10A           | GFS410         |
| 14.      | LH side lights .....          | 3A            | GFS43          |
| 15.      | RH side lights .....          | 3A            | GFS43          |
| 16.      | Front fog lights .....        | 20A           | GFS420         |

**AUXILIARY FUSE BOX — LH Steering**

| Fuse No. | Protected Circuit             | Fuse Capacity | Unipart Number |
|----------|-------------------------------|---------------|----------------|
| 13.      | Interior and map lights ..... | 10A           | GFS410         |
| 14.      | LH side lights .....          | 3A            | GFS43          |
| 15.      | RH side lights .....          | 3A            | GFS43          |
| 16.      | Cigar lighter .....           | 20A           | GFS420         |

**BULB CHART**

|  | Watts   | Lucas Part No. | Unipart No. | Notes                       |
|--|---------|----------------|-------------|-----------------------------|
| Headlamps — not France or USA — main/dip | 60/55   | 472            | GLB 472     | Halogen H4 base bulb        |
| — France only — main/dip                 | 60/55   | 476            | GLB 476     | Yellow Halogen H4 base bulb |
| — USA only — outer                       | 37.5/60 |                |             | Quartz Halogen              |
| — USA only — inner                       | 50      |                |             | Quartz Halogen              |
| Headlamp pilot bulb — not USA            | 4       | 233            | GLB 233     |                             |
| Front flasher lamp                       | 21      | 382            | GLB 382     | Not USA                     |
| Front flasher and side lamp              | 21/5    | 380            |             | USA only                    |
| Stop lamp                                | 21      | 382            | GLB 382     |                             |
| Tail lamp                                | 5       | 207            | GLB 207     |                             |
| Rear flasher                             | 21      | 382            | GLB 382     |                             |
| Reversing lamp                           | 21      | 273            | GLB 273     | Festoon bulb                |
| Number plate lamp                        | 6       | 254            | GLB 254     | Festoon bulb                |
| Sidemarkers                              | 4       | 233            |             | USA only                    |
| Flasher side repeaters — when fitted     | 4       | 233            | GLB 233     |                             |
| Rear fog guard lamps                     | 21      | 382            | GLB 382     | Not USA                     |
| Interior/map lamps                       | 6       | 254            | GLB 254     | Festoon bulb                |
| Roof lamp                                | 10      |                |             | Festoon bulb                |
| Boot lamp                                | 5       | 239            | GLB 239     | Festoon bulb                |
| Fibre optic light source                 | 6       | 254            | GLB 254     |                             |
| Instrument illumination                  | 2.2     | 987            | GLB 987     |                             |
| Warning lights                           | 1.2     | 286            | GLB 286     |                             |
| Automatic selector illumination          | 2.2     | 987            | GLB 987     |                             |
| Cigar lighter illuminator                | 2.2     | 987            | GLB 987     |                             |
| Door puddle lamp                         | 5       |                | GLB 501     |                             |

# ELECTRICAL SYSTEM


## COMPONENT LOCATION — WIRING DIAGRAMS

| COMPONENT                                 | Grid |      | COMPONENT                                 | Grid |      |
|---|------|------|---|------|------|
|   | No.  | ref. |   | No.  | ref. |
| Alternator                                | 1    | A1   | Interior light switch                     | 59   | C1   |
| Aerial motor                              | 185  | C1   | Line fuse                                 | 67   |      |
| Aerial motor relay                        | 186  | C1   | Low coolant control unit                  | 303  | B1   |
| Air conditioning blower                   | 33   | C3   | Low coolant sensor                        | 309  | B1   |
| Air conditioning blower relay             | 189  | C3   | Low coolant warning light                 | 320  | B1   |
| Air conditioning blower resistor          | 188  | C3   | Main beam warning light                   | 10   | A2   |
| Air conditioning compressor clutch        | 190  | *    | Main light switch                         | 6    | A2   |
| Air conditioning control switch           | 192  | C3   | Map light                                 | 102  | C1   |
| Battery                                   | 3    | A1   | Map light switch                          | 101  | C1   |
| Battery condition indicator               | 146  | B1   | Number plate lamp                         | 15   | A2   |
| Blocking diode — brake warning            | 256  | A3   | Oil pressure gauge                        | 48   | B1   |
| Blocking diode — direction indicators     | 289  | A3   | Oil pressure switch                       | 42   | B1   |
| Boot light                                | 66   | C1   | Oil pressure transmitter                  | 147  | B1   |
| Boot light switch                         | 65   | C1   | Oil pressure warning lamp                 | 43   | B1   |
| Brake failure warning light               | 323  | A3   | Overdrive inhibit relay                   | 360  | B3   |
| Brake fluid level switch                  | 182  | B1   | Overvoltage CU                            | 302  | B1   |
| Brake fluid level warning light           | 159  | B1   | Overvoltage W/L                           | 321  | B1   |
| Buzzer alarm                              | 168  | C1   | Panel lamps                               | 14   | B1   |
| Cigar lighter                             | 57   | C2   | Panel lamps rheostat                      | 13   | B1   |
| Cigar lighter illumination                | 208  | B1   | Park lamp failure sensor                  | 304  | A2   |
| Clock                                     | 56   | C1   | Park lamp failure warning light           | 32   | A2   |
| Computer                                  | 357  | C1   | Pulse generator                           | 359  | C2   |
| Computer interface unit                   | 358  | C1   | Puddle lamps                              | 20   | C1   |
| Cold start injector                       | 300  | **   | Radiator cooling fan motor                | 179  | C3   |
| Direction indicator switch                | 26   | A3   | Radiator cooling fan relay                | 177  | C3   |
| Direction indicator warning light         | 27   | A3   | Radiator cooling fan thermostat           | 178  | C3   |
| Distributor                               | 40   | A1   | Radiator diode pack                       | 174  | C3   |
| Door lock solenoid                        | 257  | B3   | Radio                                     | 60   | C1   |
| Door lock solenoid relay                  | 258  | B3   | Rear fog guard lamp                       | 288  | A2   |
| Door lock switch                          | 260  | B3   | Rear fog guard warning lamp               | 287  | A2   |
| Door thermal cut-out                      | 259  | B3   | Rear window delay unit                    | 340  |      |
| Fibre optics illumination lamp            | 255  | B1   | Rear window demist switch                 | 115  | B2   |
| Flasher unit (part of 154)                | 25   | A3   | Rear window demist unit                   | 116  | B2   |
| Flasher lamp RH front                     | 28   | A3   | Rear window demist warning lamp           | 150  | B2   |
| Flasher lamp LH front                     | 29   | A3   | Reverse lamps                             | 50   | A3   |
| Flasher lamp RH rear                      | 30   | A3   | Reverse lamps switch                      | 49   | A3   |
| Flasher lamp LH rear                      | 31   | A3   | Revolution counter                        | 95   | B1   |
| Fog lamp RH (if fitted)                   | 54   | A2   | Roof light                                | 280  | C1   |
| Fog lamp LH (if fitted)                   | 55   | A2   | Seat belt switch — driver                 | 198  | C1   |
| Fuel injection control unit (ECU)         | 292  | **   | Seat belt warning control unit            | 290  | C1   |
| Fuel injection main relay                 | 312  | **   | Seat belt warning lamp                    | 202  | C1   |
| Fuel level warning light                  | 319  | B1   | Side lamp RH or (headlamp pilot lamp)     | 11   | A2   |
| Fuel gauge                                | 34   | B1   | Side lamp LH or (headlamp pilot lamp)     | 12   | A2   |
| Fuel gauge tank unit                      | 35   | B1   | Service interval counter switch           | 277  | B2   |
| Gearbox relay                             | 362  |      | Service interval counter warning light*** | 278  | B2   |
| Gearbox solenoid                          | 361  |      | Speed control actuator                    | 347  | C2   |
| Handbrake switch                          | 165  | A3   | Speed control inhibit switch              | 344  | C2   |
| Handbrake warning lamp                    | 166  | B1   | Speed control master switch               | 346  | C2   |
| Hazard warning flasher unit (includes 25) | 154  | A3   | Speed control set switch                  | 345  | C2   |
| Hazard warning lamp                       | 152  | A3   | Speed control unit                        | 342  | C2   |
| Hazard warning switch                     | 153  | A3   | Speedometer                               | 360  | B1   |
| Headlamp dip switch                       | 7    | A2   | Starter motor                             | 5    | A1   |
| Headlamp dip beam                         | 209  | A2   | Starter solenoid                          | 4    | A1   |
| Headlamp inhibit relay                    | 164  | A2   | Starter solenoid                          | 194  | A1   |
| Headlamp inner RH 'NAS'                   | 113  | A2   | Stop lamps                                | 16   | A3   |
| Headlamp inner LH 'NAS'                   | 114  | A2   | Stop lamps failure sensor                 | 301  | A3   |
| Headlamp outer RH                         | 8    | A2   | Stop lamp switch                          | 18   | A3   |
| Headlamp outer LH                         | 9    | A2   | Tail lamp RH                              | 17   | A2   |
| Headlamp pilot lamp (see sidelamp)        | 11   | A2   | Tail lamp LH                              | 22   | A2   |
| Headlamp relay                            | 231  | A2   | Thermal circuit breaker door lock         | 259  | B3   |
| Horn                                      | 23   | B2   | Water temperature gauge                   | 46   | B1   |
| Horn push                                 | 24   | B2   | Water temperature transmitter for gauge   | 47   | B1   |
| Horn relay                                | 61   | B2   | Window lift motor                         | 220  | B3   |
| Ignition amplifier                        | 183  | A1   | Window lift safety relay                  | 221  | B3   |
| Ignition coil                             | 39   | A1   | Window lift switch RH front               | 216  | B3   |
| Ignition protection relay                 | 204  | A1   | Window lift switch LH front               | 218  | B3   |
| Ignition switch                           | 38   | A1   | Windscreen washer pump                    | 77   | B2   |
| Ignition warning lamp                     | 44   | A1   | Windscreen washer switch                  | 78   | B2   |
| Inertia switch                            | 250  | B1   | Windscreen wiper motor                    | 37   | B2   |
| Interior light                            | 280  | C1   | Windscreen wiper switch                   | 36   | B2   |
| Interior light rear passenger             | 111  | C1   |   |      |      |

\* See Air Conditioning Wiring Diagram

\*\* See Fuel Injection Wiring Diagram

\*\*\* The service interval counter operates the catalyst warning light




CABLE COLOUR CODE


|          |           |           |
|----------|-----------|-----------|
| N. Brown | P. Purple | W. White  |
| U. Blue  | G. Green  | Y. Yellow |
| R. Red   | L. Light  | B. Black  |
| K. Pink  | S. Slate  | O. Orange |

When a cable has two colour code letters, the first denotes the Main colour and the second the Tracer Colour.


SYMBOLS USED




Motor




Alternative Circuit




Line Splice




Earth Connection




Resistor




Potentiometer




Solenoid




Fuse




Reed Switch




Transistor




Cable Connector




Diode



Zener Diode



Lamp



Aerial



## CONTENTS

| Operation  | Operation No. | Page No. |
|--|---------------|----------|
| Battery condition gauge — Renew .....              | 88.10.07      | 88—3     |
| Clock (where fitted) — Renew .....                 | 88.15.07      | 88—5     |
| Coolant temperature gauge — Renew .....            | 88.25.14      | 88—3     |
| Coolant temperature transmitter — Renew .....      | 88.25.20      | 88—4     |
| Electronic speedometer — Description .....         | —             | 88—2     |
| Electronic speedometer — Renew .....               | 88.30.01      | 88—3     |
| Electronic speedometer — Test .....                | —             | 88—3     |
| Electronic speedometer transducer — Renew .....    | 88.30.14      | 88—4     |
| Fuel gauge — Renew .....                           | 88.25.26      | 88—3     |
| Fuel gauge tank unit — Renew .....                 | 88.25.32      | 88—4     |
| Instruments — Test .....                           | —             | 88—3     |
| Instrument panel lens assembly — Renew .....       | 88.20.17      | 88—3     |
| Instrument panel (module) — Remove and refit ..... | 88.20.01      | 88—3     |
| Oil pressure gauge — Renew .....                   | 88.25.01      | 88—3     |
| Oil pressure transmitter — Renew .....             | 88.25.20      | 88—4     |
| Oil pressure warning light switch — Renew .....    | 88.25.08      | 88—4     |
| Tachometer — Renew .....                           | 88.30.21      | 88—3     |
| Tachometer — Test .....                            | —             | 88—3     |
| Trip computer (where fitted) — Renew .....         | 88.30.13      | 88—5     |
| Trip computer — Test .....                         | —             | 88—5     |
| Trip computer interface unit — Renew .....         | 88.30.30      | 88—5     |

## ELECTRONIC SPEEDOMETER

## Description

The pulse signal required to operate both the speedometer (and where fitted, the service interval counter) is controlled by a speed transducer situated in the transmission unit in place of the angle drive. The service interval counter, NAS markets only, is situated in the boot compartment and is located by removing the rear detachable boot trim panel.

It is important to note that should the harness controlling the pulse input to the speedometer become disconnected at the speedometer, the service interval counter will also CEASE TO OPERATE. The control for resetting the speedometer is now situated in the speedometer fascia and is operated by depressing the control button.

## INSTRUMENTS

## Description

The fuel gauge, temperature gauge, oil gauge and battery gauge, are all air cored instruments. An air cored instrument can be considered as a magnet in a magnetic field. A bar magnet pivoted in its centre is mounted in the centre of three coils. To cause the magnet and therefore the pointer to move, the current flow in one of the three coils is changed, which in turn alters the magnetic strength in that coil.

The transmitter or sensors are all variable resistors, and are connected across or in parallel with one of the coils. As the resistance varies in the transmitter the current flow through the coil will also vary. This will alter the magnetic field strength causing the pointer to move.

## TACHOMETER

The engine speed signal received by the tachometer is derived from the ignition coil negative terminal. The voltage wave-form at this point can reach as much as 400 volts when a spark is generated, and it is desirable to suppress this voltage before allowing it into the wiring harness. If this is not done interference may occur with other signals. A resistor connected into the lead from the negative terminal of HT coil serves this purpose, and it is located inside the ignition amplifier. The battery voltage required to operate the instruments is derived from fuse No. 4.





Fig. 1

## KEY TO DIAGRAM

- |                                     |   |
|-------------------------------------|---|
| 1. Speedometer                      | 12. Fuel tank unit  |
| 2. Temperature gauge                | 13. Oxygen sensor warning lamp (NAS)                                  |
| 3. Oil pressure gauge               | 14. Low fuel warning lamp   |
| 4. Fuel gauge                       | 15. To ignition switch  |
| 5. Battery condition gauge          | 16. To fuse No. 4   |
| 6. Tachometer                       | 17. To ignition amplifier   |
| 7. Speed transducer                 | 18. Earth point on steering column bracket behind instrument panel    |
| 8. Bulb failure unit                | 19. Earth point between battery and wheel arch in luggage compartment |
| 9. Service interval counter (NAS)   | 20. Earth through body of unit  |
| 10. Coolant temperature transmitter |   |
| 11. Oil pressure transmitter        |   |

## Testing

Instrument tester 'Fast Check' SMD4045 (Fig. 2) has been developed to enable the operator to diagnose faults on the vehicle instrumentation with the minimal disruption to the wiring or the fascia panel. The tester will enable a functional check of the fuel, oil pressure and temperature gauges on the vehicle. The tachometer and the speedometer can also be checked. A signal from the output terminal of the tester will produce a preset reading on the gauge to which it is connected thus starting the test procedure at the transmitter of the respective gauge which will determine whether the fault lies in the gauge, the transmitter or the interconnecting harness. To test the tachometer check the fuse and all the connections. Insert the power take off plug into the cigar lighter socket.



J88 018

Fig. 2

Disconnect the white and slate lead to the tachometer from the ignition amplifier. Connect the black lead from the tester to a good earth, the other lead to the tachometer harness lead. Select tachometer on the tester and switch on the vehicle ignition. If the tachometer is operating correctly and the related circuit is satisfactory, the tachometer should register 4000 rpm. Should the tachometer not operate correctly, move the tester lead from the amplifier end of the harness to the tachometer terminal. This will establish whether the fault is in the tachometer or the harness.


The same procedure can be used when checking the electronic speedometer. Connect the tester to the disconnected lead from the speed transducer. Select speedometer on the tester, switch the ignition on and the speedometer should register 60 mph. If the fault still exists, then the fault is in the related harness or the speedometer. This can be checked using the same method as with the tachometer. When checking the other gauges the system is just the same, the tester simulates the top and bottom gauge readings by switching the tester to high or low.

## INSTRUMENT PANEL (MODULE)

### Remove and refit

#### Removing

Disconnect the battery earth cable. Remove the drivers side dash casing. Remove the centre securing strip and screw from instrument module surround (1, Fig. 3). Remove the screws securing the side pieces of the surround and remove the surround (2, Fig. 3). Prise off the covers from the securing screw apertures (3, Fig. 3) and remove the screws securing the instrument panel to the fascia (4, Fig. 3). Ease the module forward and disconnect the cable harness at the block connectors. Slacken the steering wheel adjustment ring and extend the steering column to its maximum travel. Manoeuvre the instrument panel clear of the fascia.



J88 017

Fig. 3

## PRINTED CIRCUIT AND INSTRUMENTS

### Renew

After removing the instrument panel module.

Remove the four instrument illumination bulb holders from the rear of the instrument panel (1, Fig. 4).

Note the position of all the fixing screws, connectors etc.

Remove the warning lamp retaining bar/earth (2, Fig. 4).

Remove the three nuts connecting the printed circuit to the tachometer (3, Fig. 4).

Remove the three nuts connecting the printed circuit to the speedometer (4, Fig. 4).


Remove the seven screws retaining the lens assembly and with the lens assembly removed it is now possible to withdraw the tachometer and/or the speedometer from the instrument panel.

Remove the screws connecting the printed circuit to the centre gauges (5, Fig. 4) it is now possible to remove a gauge by prising off the retaining clips and withdrawing the appropriate gauge.

Remove the seventeen warning lamp holders (6, Fig. 4).

Ease the printed circuit clear of the locating spigots.

**NOTE:** On refitting care should be taken to ensure the printed circuits are not torn or deformed, and all the connecting tags are correctly positioned under the terminals of components.



J88 016

Fig. 4

## OIL AND TEMPERATURE GAUGE TRANSMITTERS

## Renew

Disconnect the battery earth lead.  
Depressurise the cooling system for the renewal of the temperature transmitter.  
Disconnect the lead from the appropriate transmitter and withdraw the transmitter.

Fig. 5 Temperature gauge transmitter.

Fig. 6 Oil pressure gauge transmitter.

Fig. 7 Oil pressure warning light switch.




Fig. 5




Fig. 6




Fig. 7

## FUEL GAUGE TANK UNIT

## Renew

Service tool 18G 1001

Disconnect the battery earth lead.  
Remove the spare wheel for access. Drain the fuel tank.  
Turn the locking ring anti-clockwise using service tool 18G1001.  
Remove the locking ring.  
Turn the tank unit 180° and manoeuvre the unit from the tank.  
Ensure new seal and locking ring is fitted when replacing the tank unit.

## SPEED TRANSDUCER

## Renew

Disconnect the battery earth lead.  
Place an oil drip tray beneath the gear box.  
Operate the left-hand seat release lever and push the seat to its full rear position.  
Remove the left-hand side console pad.  
Peel down the carpet from the centre console to expose the plate for access to the speed transducer (Fig. 8).  
Remove the four screws retaining the plate and remove the plate.  
Remove the bolt securing the speed transducer and withdraw the transducer from the gearbox housing.  
Disconnect the cable harness block connector and remove the transducer (Fig. 8).




Fig. 8

On refitting smear sealant on the access plate to ensure a water tight seal.  
Check the gearbox oil level.

## TRIP COMPUTER (where fitted)

## Description

The trip computer records fuel usage, time and distance. By storing the three sets of information and relating one to another it computes fuel consumption, both average consumption for the journey or a current consumption figure updated every three seconds. The information may be displayed either in miles and gallons or litres and kilometres.

## Computer Controls

There are nine controls on the computer face, the use of each is described followed by examples of their use.

- mls/km — Use this switch to display metric or imperial / US units.
- RESET — Press for 5 seconds to switch all function displays to zero.
- DISP — Press to switch display off (function updating continues).
- TIME — Press to display time of day — press again to display elapsed time since reset — after 6 seconds, display will revert to time of day.
- AV. SPD — Press to display average speed since reset.
- DIST — Press to display distance travelled since reset.
- AVE — Press to display average fuel consumption since reset.
- INST — Press to display the fuel consumption at that time.
- FUEL — Press to display fuel consumed since reset.

To show which function is on display the relevant button will be illuminated. When the vehicle lights are switched on the computer illumination is dimmed but the legend plate is illuminated.




Fig. 9

## KEY TO DIAGRAM

- 1. Trip Computer
- 2. Interface Unit
- 3. Speed Transducer
- 4. Connector Blocks
- 5. Inline Fuse (2 amps)
- 6. Terminal Post
- 7. To Sidelamps
- 8. To Fuse No. 4 (10 amps)
- 9. To ECU
- 10. To Speedometer
- 11. Earth point between battery and wheel arch in the luggage compartment
- 12. Earth point on steering column bracket behind the instrument panel

The signals required to operate the trip computer are picked up from the ECU via the interface unit (2, Fig. 9) and the pulse generator (3, Fig. 9). A 12 volt supply is via the fuse (5, Fig. 9). This supply voltage enables the clock to function and for the computer to retain information it has received when the ignition is switched off. A second 12 volt supply is via fuse (8, Fig. 9) this supply enables the computer to display information when the ignition is switched on. The third 12 volt supply is via the red and blue lead (4, Fig. 9). This supply voltage enables the display and the buttons to dim when the sidelamps are switched on. The legend strip is also illuminated.

### Fault Diagnosis

Check the fuses and all connections. Ensure the earth connections are clean and tight. With the ignition switched off 12 volts should be obtained on the purple lead to the trip computer.

The voltmeter should give the following readings with the ignition switched on:

12 Volts at the green lead to the trip computer, the green lead to the pulse

generator, the green lead and the yellow/green lead to the interface unit.

With the engine running a voltage should be obtained at the orange lead to the computer. A zero reading indicates a faulty interface unit or lack of continuity in the wiring between the computer and the interface unit. Re-check at the interface unit located in the luggage compartment.

With the rear of the vehicle jacked up, and on stands. Start the engine and put the vehicle into drive. A voltage should then be obtained at the yellow lead to the computer. A zero reading indicates a faulty pulse generator or lack of continuity in the wiring between the pulse generator and the computer.

### TRIP COMPUTER

#### Renew

Disconnect the battery earth lead.

Prise the computer from the switch panel.

Disconnect the cable block connectors and remove the trip computer.

### INTERFACE UNIT

#### Renew

Disconnect the battery earth lead.

Remove the right-hand luggage compartment trim panel.

Lift the interface unit from its bracket (1, Fig. 10) and disconnect the cable harness block connector

Remove the interface unit.




Fig. 10

| FAULT  | ACTION  |
|--|---|
| Computer inoperative<br>Screen blank<br>All voltages correct   | Replace Computer                                  |
| Time of day displayed<br>Average speed and distance displayed<br>Fuel characteristics zero<br>Speedometer operating<br>All battery voltages correct<br>Zero voltage on orange lead with the engine running               | Replace interface unit                            |
| Time of day displayed<br>All other functions zero<br>Speedometer not operating<br>All battery voltages correct<br>Zero voltage on yellow lead with the vehicle on stands and the engine running and the vehicle in drive | Replace the pulse generator<br>(Speed transducer) |
| Trip computer does not dim with the sidelamps switched on<br>Battery voltage at the red/blue cable connection  | Trip computer faulty                              |
| More than one light emitting diode illuminated at the same time<br>All battery voltages correct  | Trip computer faulty                              |

### CLOCK (where fitted)

#### Renew

Disconnect the battery earth lead.

Prise the clock from the switch panel.

Remove the illumination bulb holder and disconnect the supply leads.

Remove the clock.